
ADVANTEST[®]
ADVANTEST CORPORATION

**INSTRUCTION
MANUAL**

R4611E

NETWORK ANALYZER

MANUAL NUMBER OEG01 9002

Before reselling to other corporations or re-exporting to other countries, you are required to obtain permission from both the Japanese Government under its Export Control Act and the U.S. Government under its Export Control Law.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

Table of Contents

TABLE OF CONTENTS

1. INTRODUCTION	1 - 1
1.1 Using the Manual	1 - 1
1.2 General Description of R4611E	1 - 3
1.3 Requirements before Using the R4611E	1 - 5
1.3.1 Checking External View and Accessories	1 - 5
1.3.2 Ambient Environment for Use and Precautions	1 - 5
1.3.3 Connecting Power Supply	1 - 6
2. DESCRIPTION FOR BEGINNERS	2 - 1
2.1 Power Supply and Initial Setting	2 - 2
2.1.1 Self-Diagnostic Test	2 - 2
2.1.2 Pre-setting	2 - 3
2.2 Reading CRT Display	2 - 4
2.3 Basic Operations	2 - 5
2.3.1 Basic Operational Keys	2 - 5
2.3.2 Basic Key Operations with Sample Measurements	2 - 9
2.4 Measurement Examples	2 - 12
3. OPERATING BASIC FUNCTIONS	3 - 1
3.1 Explanation	3 - 1
3.1.1 Front panel	3 - 2
3.1.2 Rear panel	3 - 3
3.2 Panel Keys and software Keys	3 - 4
3.3 Basic Functions	3 - 5
3.3.1 SOURCE MENU	3 - 5
3.3.2 SWEEP	3 - 6
3.3.3 IMP/ATT (Impedance/Attenuator)	3 - 12
3.3.4 RESOLN BW (Resolution Band Width)	3 - 13
3.3.5 INPUT MEAS (Measurement)	3 - 14
3.3.6 FORMAT	3 - 16
3.3.7 DISP (DISPLAY)	3 - 18
3.3.8 SCALE & REF (Reference)	3 - 21
3.3.9 MKR MKR (Marker Delta Marker)	3 - 22
3.3.10 MKR SRCH (Marker Search)	3 - 36
3.3.11 MKR (Marker)	3 - 41
3.3.12 AVG (Average)	3 - 44
3.3.13 CAL (Calibration)	3 - 45
4. OTHER FUNCTIONS	4 - 1
4.1 SAVE/RECALL	4 - 1
4.1.1 SAVE	4 - 2
4.1.2 RECALL	4 - 9
4.2 GPIB LOCAL	4 - 10
4.3 COPY	4 - 11
4.3.1 PLOTTER TYPE	4 - 12
4.3.2 SIZE & LOCATION	4 - 17
4.3.3 DEFINE PLOT	4 - 20
4.3.4 CONFIG PLOT	4 - 21

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

Table of Contents

4.4 Parallel I/O Functions	4 - 22
4.4.1 8-bit Input	4 - 22
4.4.2 8-bit Output	4 - 22
4.5 RS-232C	4 - 24
4.5.1 Connector and Signal List	4 - 24
4.5.2 Printer Output	4 - 24
4.6 Functions Keys	4 - 26
4.7 Video Plotter Output	4 - 28
4.8 Special Functions (f)	4 - 30
5. INSPECTION AND MAINTENANCE	5 - 1
5.1 Inspection and Brief Diagnosis	5 - 1
5.2 R4611E Storage and Transportation	5 - 2
5.2.1 Storing the R4611E	5 - 2
5.2.2 Cleaning CRT Display Filter	5 - 2
5.2.3 Cleaning CRT Display	5 - 2
5.2.4 Transporting R4611E	5 - 3
6. PERFORMANCE	6 - 1
7. EXPLANATION OF OPERATION	7 - 1
APPENDIX	A - 1
A.1 Software key menu	A - 1
A.1.1 MEASUREMENT	A - 1
A.1.2 SOURCE	A - 5
A.1.3 RECEIVER	A - 7
A.1.4 MARKER	A - 8
A.1.5 CAL and AVG	A - 17
A.1.6 GPIB	A - 18
A.1.7 INSTRUMENT STATE	A - 19
LIST OF FIGURES	F - 1
LIST OF TABLES	T - 1

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1. INTRODUCTION

This manual describes how to operate the R4611E network analyzer.

This chapter explains how to use this manual and contains the general description of the R4611E network analyzer functions, the procedure from the setup operation to the power supply operation, and general requirements. Before taking measurements with the R4611E network analyzer, read this manual very carefully.

1.1 Using the Manual

This manual explains the R4611E network analyzer according to the flow shown in Figure 1-1 for the users having moderate knowledge and experience with electronic measuring meters. Beginners must read through this manual from the beginning. If necessary, refer to the glossary attached to the end of this manual.

Experienced users may read only Chapter 3 of this manual. Before operating the analyzer, however, check the general requirements in this chapter. Chapter 4 contains the supplementary description of the functions.

The GPIB remote control operation is explained in the programming manual. Using GPIB requires a basic knowledge of programming. Refer to the proper basic programming manuals if necessary.

If the analyzer operation appears to be abnormal, see Chapter 5.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.1 Using the Manual




Figure 1-1 Structure of This Manual

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.2 General Description of R4611E

1.2 General Description of R4611E

R4611E is a network analyzer for measuring phase, group delay and impedance, accurately and speedily within the wide range of frequency, 10 to 300 MHz.

You can perform measurements by using not only 50 Ω but also 1 M Ω as the input impedance.

The main feature of the R4611E is the provision of a considerable increase in measurement precision and throughput by use of the unique analog and digital signal processing technology. For example, the partial variable sweep functions and the analysis function for the user-specified block of the R4611E functions are useful on the production line, and also increase the measurement throughput remarkably.

The integrated BASIC controller function allows you to create programs for measurements, analysis and data processing by using the external key board (TR45103), and permits high-speed processing. This greatly benefits the automatic production line operation.

You can display the measurement and analysis data on the integrated, CRT in various modes, such as the overwrite display mode or split display mode.

Features

(1) R4611E permits high-precision and high-resolution measurement.

- Integrates the synthesizer with 0.01 Hz resolution.
- Provides outstanding dynamic precision and resolution.
Amplitude measurement precision: 0.05 dB
Resolution: 0.001 dB
Phase measurement precision: 0.5 \circ
Resolution: 0.01 \circ
- Provided with an error correcting function.
- Allows high-impedance measurement.

(2) The R4611E provides high-throughput measurement.

- Permits high-speed measurement of 1 ms/point and allows selection of the measurement point.
- Increases the measurement speed greatly by using the partial variable sweep function.
- Enables high-speed data processing through sequential program creation by using the BASIC controller function.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.2 General Description of R4611E

(3) R4611E supports many marker functions and variable display modes.

- Allows you to perform the marker search operation, inflection point analysis (ripple and spurious), band width measurement and Q computation on the desired portion with one-touch operation.
- Provided with a compensate marker function for high-precision data reading between measurement points.
- Provided with a marker track function to track the maximum or minimum value every sweep operation.
- Provided with a split display function to display the 2-ch measurement data in each format.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.3 Requirements before Using the R4611E

1.3 Requirements before Using the R4611E

1.3.1 Checking External View and Accessories

On receiving the R4611E, inspect the external view and check whether any cracks or damage has occurred during transportation.

Then, check the standard accessories according to Table 1-1 and verify each quantity and specification.

If any cracks or damage is found or if some accessories are missing, contact the sales division or agency nearest your place of business.

Address and telephone numbers are listed at the end of this manual.

Table 1-1 R4611E Standard Accessory List

Item	Model name	Parts code	Quantity	Remarks
Power cable	A01402	DCB-DD2428X01	1	
BNC-BNC cable	M1-78	DCB-FF0981X01	2	30 cm
BNC through connector	BNC-A-JJ	JCF-AB001EX05-1	1	
Fuse	MDA-4A	DFT-AF4A	2	For standard model and option
	MDA-2A	DFT-AF2A		For options 42 and 44.
Instruction manual		J4611E	1	Japanese manual
		E4611E		English manual

1.3.2 Ambient Environment for Use and Precautions

- (1) Do not use this device in locations exposed to dust, direct sunshine or corrosive gases.
Also do not use this device in an ambient temperature lower than 0°C to +40°C (+5°C to +40°C for FDD) or humidity lower than 85% (no dewing).

(2) Cooling System

In the cooling system of the R4611E, air is taken in from the larger fan on the rear panel and discharged from the smaller one. Install the R4611E so that this cooling system works well. Do not put anything on the R4611E.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.3 Requirements before Using the R4611E

- (3) Though the R4611E has been designed with much consideration of the noise caused by the AC power line, it is better used with a minimum noise. To use the R4611E in a very noisy, environment attach a proper device such as a noise filter.
- (4) Do not use the R4611E in a location with much vibration.

1.3.3 Connecting Power Supply

(1) Connecting R4611E to Power Cable

Verify that the POWER switch on the R4611E front panel is set OFF and then connect the power cable of an accessory to the AC LINE connector on the rear panel.

The power voltage for use was set at shipping, according to the specification when the order was received.

In any case, the power frequency must be set to 48 to 66 Hz.

Table 1-2 Power Voltage

Option No.	Standard	32	42	44
Power voltage (V)	90 to 110	103 to 132	198 to 242	207 to 250

(2) Power Cable and Adapter

The power cable plug has three pins. The round pin at the center of the plug is the grounding pin.

To connect the plug to the outlet using the adapter, connect either of the grounding cords (shown in Figure 1-2 (a)) of the adapter) or the grounding terminal on the R4611E rear panel to ground via an external grounding cord.

Accessory adapter A09034 conforms to the Law for Electric Products. The width (A) of one electrode of the A09034 is different from (B) of the other one as shown in Figure 1-2 (b). When inserting this adapter into the outlet, check the direction of both the plug and outlet. When A09034 is unsuitable for the outlet to be used, purchase adapter KPR-13.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

1.3 Requirements before Using the R4611E




Figure 1-2 Power Cable Plug and Adapter

(3) Replacing Fuse

To replace a fuse, set the PS POWER switch to OFF and remove the power cable from the AC LINE connector.

Then, slide the plastic cover of the fuse box on the right side of the AC LINE connector to the left. Next, pull the lever, FUSE PULL, toward you to remove the fuse.

When replacing the fuse, use the following types: (See Figure 1-3.)

- Standard and option 32: MDA-4A (4A)
- Options 42 and 44 : MDA-2A (2A)




Figure 1-3 Replacing Fuse

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.1 Power Supply and Initial Setting

2. DESCRIPTION FOR BEGINNERS

This chapter describes the self-diagnostic test at power supply and the initial setting by using the PRESET key in the former part, and how to read the data displayed on the CRT screen in the latter part.

At the end of this chapter, the R4611E basic key operation is explained along with concrete measurement examples for beginners.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.1 Power Supply and Initial Setting

2.1 Power Supply and Initial Setting

Connect the R4611E to the AC power using the power cable and turn the power switch at the lower portion of the R4611E front panel ON.

Caution

Before supplying power, verify that the voltage of the AC power to be used is the same as the specified voltage.
Before using the R4611E, warm it up for about one hour to obtain the specified performance.

2.1.1 Self-Diagnostic Test

When power is supplied, all LEDs on the R4611E panel come on and the self-diagnostic test is executed automatically.

During execution of the self-diagnostic test, the following data is displayed on the CRT screen:

```
*****      **      *****      **      **
*      *      * *      *      * *      * *
*      *      * *      *      *      *
*****      * *      *****      *      *
*      *      *****      *      *      *      *
*      *      *      *      *      *      *
*      *      *      *****      *****      *****

                self Test in progress.

Main Ram          --> OK
I/O Ram           --> OK
I/O Communication --> OK
Coprocessor      --> OK
Display Rom       --> OK
Display Ram       --> OK
Display Communication --> OK
*** self Test All Pass!! ***

Copyright ADVANTEST Corporation
```

When the self-diagnostic test terminates, the system is set to the initial mode described in Section 2.1.2.
When NG is displayed by the self diagnostic test above, or when the display stops on the way, contact the sales division or agency nearest your place of business.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.1 Power Supply and Initial Setting

2.1.2 Pre-setting

R4611E is set to the initial mode forcedly when the power is set ON or when key **INST** is pressed.



ACTIVE CHANNEL : CH1

MEASUREMENT

INPUT MEAS : A/R
 CONVERSION : OFF
 ZO : 50
 FORMAT : LOG MAG
 SCALE REF.
 /DIV : 10 dB/DIV
 REF. VALUE : 0.000 dB
 REF. POSITION : Top of the screen (100.0%)
 REF. LINE : OFF
 DISPLAY
 DUAL CH ON/OFF : OFF
 SPLIT ON/OFF : OFF
 GRATICULE ON/OFF : ON
 INTENSITY : INTENSITY 8

SOURCE

MENU
 OUTPUT : 2
 OUTPUT LEVEL : 0dBm
 CENTER : 150 000 000.00 Hz
 SPAN : 300 000 000.00 Hz
 SWEEP
 TIME : 0.300 sec
 TYPE
 COUPLE CH ON/OFF: ON
 VAR.SWEEP ON/OFF: OFF
 POINT : 301
 TRIGGER : INTERNAL
 MODE : CONTINUE

RECEIVER

IMP/ATT : A 50 Ω/20 dB (ATT)
 RESOLN/BW : 1kHz

MARKER : ALL OFF

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.2 Reading CRT Display

2.2 Reading CRT Display

The following figure shows how to read the data displayed on the CRT screen:




Figure 2-1 Reading CRT Display

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.3 Basic Operations


2.3 Basic Operations

This section describes the basic key operations of R4611E along with concrete measurement examples for beginners first using the network analyzer.

It is assumed that experienced users can satisfactorily operate the R4611E after referring only to Chapters 3 and 4.

2.3.1 Basic Operational Keys

(1) Channel Selecting Keys



Select the key to set the MEASUREMENT key and MARKER key described in (2) and (5) to the active mode. This lights the LED corresponding to the current active channel. Usually, either of the two channels (CH1 or CH2), can be selected.

Both the receiver setting key and the MARKER key can be operated independently for both CH1 and CH2.

(2) MEASUREMENT keys



... Selects the input.



... Sets the measurement format (amplitude, phase, group delay, Smith diagram, etc.).



... Sets data such as the waveform trace to be displayed on the screen.

This key also sets the DUAL trace display mode, SPLIT display mode and LABEL.




... Sets the position and value of the scale on the screen (AUTOSCALE,/DIV) and the reference line.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.3 Basic Operations

(3) Signal Block Setting Keys



These keys are used to set the frequency, output level, sweep speed, sweep point count, sweep trigger and sweep mode of SOURCE (signal source).


The keys are also used to connect CH1 and CH2 and to set the partial sweep operation according to the sweep TYPE.

The SOURCE output is divided into two types, OUTPUT1 and OUTPUT2. Select either by using key ^{MENU} and the software keys. The selected output type is indicated by the LED at the upper portion of the connector. In the default mode, OUTPUT2 is selected.

NOTE

When a marker is displayed, if the setting of SPAN OHZ or the setting where SPAN becomes OHZ is performed, the message "Warning. Can't convert MKR X" is output. This message means ripple of MARKER and value of X during Nest search cannot be converted at SPAN OHZ. (If ripple and Next search is not needed, this message is invalid.)

(4) Receiver Setting Keys



These keys are used to set the input impedance and input attenuator of the RECEIVER.

The keys can also set the resolution band width according to the required measurement dynamic range.

(5) MARKER Keys

MKR Δ MKR
 ... Issues the normal marker, multi-marker or the other delta markers. This key can also set the marker correcting function, marker couple function and partial analysis function related to the all MARKER functions.

MKR SRCH
 ... Performs the marker search operation such as the MAX. search, X-dB down search and X-degree search (phase measurement).

MKR -
 ... Changes the setting condition by using the marker. For example, this key is used to change the marker frequency to the center frequency, marker frequency to the reference level, the frequency between the delta markers to the span frequency, etc.

(6) Software Keys

Seven key assigned in a line vertically at the right end of the CRT screen. The system displays selection items from 1 to 7 at the right end of the CRT screen according to the item set with the MEASUREMENT key. Select the desired item by using the software keys. In the following description, the software keys are indicated by adding the label on the left side of each key like PHASE .

(7) ENTRY Keys

These keys are used to enter numeric values for the setting items after the system is set to the ready mode for data entry by using the SOURCE keys.

Ten keys












<input type="checkbox"/> 7	<input type="checkbox"/> 8	<input type="checkbox"/> 9	dBm	<input type="checkbox"/> MHz	DIV S V	} ... Consists of numeric keys, unit keys and polarity keys. These keys are used to enter numeric values directly.
<input type="checkbox"/> 4	<input type="checkbox"/> 5	<input type="checkbox"/> 6	-dBm	<input type="checkbox"/> kHz	nS mV	
<input type="checkbox"/> 1	<input type="checkbox"/> 2	<input type="checkbox"/> 3	dB	<input type="checkbox"/> Hz	μS μV	
<input type="checkbox"/> 0	<input type="checkbox"/> .	<input type="checkbox"/> -	UNIT	<input type="checkbox"/> deg	nS nV	

Back space key BK SP ... Pressing the BKSP key deletes the last entered numeral and allows correction of the entry.





Entry-off key ENTRY OFF ... Clears the active function.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL






2.3 Basic Operations

- Exponent key  ... Used to enter exponents. To enter 1.23 MHz for example, press , , , ,  ,  and .
- Step key 
 ... Changes the set data every value (step unit) previously defined for each function.
- Data nob  ... Used for minor rearrangement of the set data.

(8) Unit Keys

- Frequency unit key ... MHz, kHz and Hz
 SCALE and REF keys for LOG MAG ... dB
 SCALE and REF keys for PHASE ... deg.
 SCALE and REF keys for DELAY ... S, ms, s and ns
 SCALE and REF keys for
 SMITH (R+jX), SMITH (G+jB), 1 U: Use 1  V .
 POLAR, LIN MAG, REAL and IMAG 1 mU: Use 1  V .
 1 U: Use 1  V .
 1 nU: Use 1  V .
- DELAY APERTURE unit key ... %
 REF POSITION unit key ... %
 INTENSITY unit key ... UNIT
 SWEEP TIME unit key ... S, ms, s and ns
 OUTPUT LEVEL unit key ... dBm and -dBm
 E.LENGTH VALUE unit key ... m and cm

(9) INSTRUMENT STATE Keys

- INSTR**  ... Pre-sets the device.
- SAVE**  ... Used to save the setting conditions.
- RECALL**  ... Used to recall the setting conditions.
- COPY**  ... Used to plot out the measurement waveform or to print out the measurement data.
- PROGRAM**  ... Used to create programs by using the BASIC controller function. This LED comes on when the created program is executed. To reset the screen to be measurement mode, press this key again.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.3 Basic Operations

(10) GPIB


LOCAL ... Sets the system controller or TALKER/LISTENER by using the BASIC controller function, and sets the address of the GPIB bus.

2.3.2 Basic Key Operations with Sample Measurements

This section describes the R4611E basic key operations showing a sample measurement of the filter characteristics. In this measurement, the impedance of the filter is assumed to be 50 Ω .

(1) Setup Operation

Connect the filter between the OUTPUT1 connector and the A connector.



(2) Pre-setting

Press ^{INSTR}_{PRESET}. See Section 2.1.2 for the initial mode.

(3) Setting Frequency of Signal Source

Perform the following key operation:

SPAN 5 0 dBm MHz ^{DIV} V
 CENTER 2 3 2 dBm MHz ^{DIV} V

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.3 Basic Operations

This key operation displays the waveform trace shown in Figure 2-2 on the screen.




Figure 2-2 Filter Characteristics Waveform Trace

(4) Measuring Insertion Loss

The output level of the signal source is the same as the reference level. Thus, the following key operation allows you to obtain the insertion loss directly by using the marker: (See Figure 2-3.)

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.3 Basic Operations

MKR Δ MKR
 Δ MODE MENU Δ REF-REF. POSN




Figure 2-3 Sample Measurement of Insertion Loss

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.4 Measurement Examples

2.4 Measurement Examples

This section introduces various measurement examples using the band-pass filter (BPF) and the X'tal resonator.

Try to measure your DUT according to the introduced examples.

The measurement examples are as follows:

- (1) Filter measurement
- (2) Phase measurement
- (3) Group delay time measurement
- (4) Narrow band/wide band sweep measurement
- (5) Amplitude/phase measurement
- (6) Amplitude/group delay measurement
- (7) Reflection measurement
- (8) X'tal resonator measurement
- (9) Measurement using multi-marker
- (10) Measurement using delta marker
- (11) Measurement using marker
- (12) Partial sweep measurement
- (13) Measurement in user defined sweep
- (14) Measurement of resonant and antiresonant points of ceramic resonator
(f=16.075MHz)

NOTE

In all of the above measurement examples, 153-MHz BPF is used as DUT.

- The key indicated by the solid line () is a panel key.
- The key indicated by the dot line () is a software key.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(1) Measuring Filter (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CEN TER , **[1]** , **[5]** , **[3]** , **MHz** ,
SPAN , **[1]** , **MHz** ,

Normalize





Press **CAL** and **NORMALIZE ON/OFF** .

Set the through state and normalize the frequency characteristics.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


Connect DUT to the R4611E as follows:



Ripple measurement 1


MKR Δ MKR , MKR CMP/UNCMP , Δ MODE MENU , Δ REF- Δ MKR , ↑ , ↓

Specify the ripple analysis block by using the above keys or the rotary encoder.



Ripple measurement 2

Press Δ RIPPLE and .




Press .

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Measure 3-dB
 band width




MKR Δ MKR MKR SRCH

MKR ALL OFF


TARGET SEARCH FLTR ANAL OFF

Press the above keys.



Press Δ REF=MAX and -3dB

Measure 6-dB
 band width




Press -6dB

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples

Measure the spurious level



RETURN , RETURN , SEARCH OFF


Press the above keys.



MKR Δ MKR , Δ MODE MENU , MKR SRCH

MORE 1/2

Press the above keys.



NEXT MAX SEARCH , NEXT MAX SEARCH ,
 NEXT MAX SEARCH , NEXT MAX SEARCH

Press the above keys.

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(2) Measuring Phase (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CENTER, [1], [5], [3], MHz,
 SPAN, [1], MHz.

Normalize






Press CAL and NORMALIZE.

Set the through state and normalize the frequency characteristics.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


Connect DUT to the R4611E as follows:





START
 [] . [1] . [5] . [3] . [MHz] ,
 STOP
 [] . [1] . [5] . [3] [.] ,
 [3] . [MHz]

Press the above keys to enlarge the filter band:


Phase measurement





Pressing  and  sets the screen to the normal mode.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.4 Measurement Examples



Pressing  and  sets the phase extension display.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(3) Measuring Group Delay Time (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E then press the keys below in this sequence:



CENTER, [1], [5], [3], [MHz],
 SPAN, [1], [MHz],

Normalize




Press CAL and NORMALIZE ON/OFF.



Set the through state and normalize the frequency characteristics.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples




Connect DUT to the R4611E as follows:





START [] , [1] , [5] , [3] , [MHz] ,
 STOP [] , [1] , [5] , [3] , [.] ,
 [3] , [MHz]

Press the above keys to enlarge the filter band:


Group delay measurement



Pressing  and  sets the screen to the group delay mode.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples



Pressing **SCALE REF** and **AUTO SCALE** sets the auto-scale mode for your eyes.

Change aperture



FORMAT , **DELAY** , **[2]** , **[0]**
 %
 kHz

This key entry sets the aperture to 20%.

End

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL


2.4 Measurement Examples

(4) Measuring Narrow Band/Wide Band Sweep (Using 153-MHz BPF as DUT)

Start

Set up the measurement device

Perform the following setup and power the R4611E, then press the keys below in this sequence:



, , , , ,


, , ,

Normalize

Press and .

Set the through state and normalize the frequency characteristics.
(Note) Also set CH2 to the frequency level to be used and normalize it.


Connect DUT to the R4611E as follows:



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


Set CH2 to the narrow band mode



START
 [CH 2] , [] , [1] , [5] , [3] ,
 STOP
 [MHz] , [] , [1] , [5] , [3] ,
 [] , [3] , [MHz]


Press the above keys:

Two screen simultaneous display mode



Press [DISPLAY] and [DUAL CH ON/OFF] .

Two screen split display mode



Press [MORE 1/3] and [SPLIT ON/OFF] .

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(5) Measuring Amplitude/Phase (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CENTER , [1] , [5] , [3] , MHz ,
 SPAN , [1] , MHz ,

Normalizing




Press CAL and NORMALIZE ON/OFF .

Set the through state and normalize the frequency characteristics.


(Note) Also set CH2 to the same frequency level and normalize it.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples



Connect DUT to the R4611E as follows:




Set CH2 to the phase mode



CH2 , CENTER , 1 , 5 , 3 ,
 MHz , SPAN , 1 , MHz , FORMAT
 PHASE

This key entry sets the frequency to that of CH1 and enables the phase mode.


Two-screen simultaneous display mode



Pressing DISPLAY and DUAL CH ON/OFF sets the 2-CH simultaneously display mode.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples



MKR Δ MKR
 , MKR Δ / UNCPL , CH1 ,
 MIN SEARCH
 MKR Δ MKR MKR SEARCH , MAX SEARCH

This key entry couples the markers for CH1 and CH2.

Two-screen split display mode



DISPL RM , MODE 1/3 , SPLIT Δ / OFF

This key entry sets the 2-CH split display mode.

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(6) Measuring Amplitude/Group Delay (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CENTER , **[1]** , **[5]** , **[3]** , **[MHz]** ,
SPAN , **[1]** , **[MHz]** ,

Normalize




Press **CAL** and **NORMALIZE OFF**.

Set the through state and normalize the frequency characteristics.



(Note) Also set CH2 to the same frequency level and normalize it.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples




Connect DUT to R4611 as follows:



START
 , 1 , 5 , 3 , MHz ,
 STOP
 , 1 , 5 , 3 , ,
 3 , MHz

This key entry enlarges the display.

Set CH2 to the group delay mode





START
 CH2 , , 1 , 5 , 3 ,
 STOP
 MHz , , 1 , 5 , 3 ,
 , 3 , MHz

This key entry sets the frequency level to that of CH1.

Pressing **FORMAT** and **DELAY** sets CH2 to the group delay mode.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples





This key entry sets the auto-scale for your eyes.

Two-screen simultaneous display mode



This key entry couples the markers of CH1 and CH2.

Two-screen split display mode



Press the above keys.

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(7) Measuring Reflection (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



Bridge

, , , , ,
 , , , , ,
 ,

Calibration




Connect OPEN to the test port of the bridge.

Pressing fetches the calibration data from three terms.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples




Connect SHORT to the test port of the bridge.

Pressing fetches the calibration data from three terms.



Connect the edge of 50 Ω to the test port of the bridge.


Pressing fetches the calibration data from three terms.



Pressing terminates calibration.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples




Pressing and corrects the error caused by 1 PORT FULL Calibration.

Measurement

(LOG MAG)



Remove the edge of 50 Ω and connect DUT as follows:




, , ,

Press the left keys.

This key entry sets the LOG MAG display mode.

(Smith chart)





, ,

Press the above keys.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples

(Admittance chart)





Press the above keys.

Polar display



Press the above keys.


Change scale



Press the above keys.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.4 Measurement Examples



F. SCALE VALUE, [5], [MHz]

Press the above keys.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(8) Measuring X'tal Resonator (Using 153-MHz BPF as DUT)

Start

Set up the measurement device (CH1)




Perform the following setup and power the R4611E, then press the keys below in this sequence:



, , , , , , , ,
 , , , , , ,

Normalize




Press and .



This sets the through mode and normalizes the frequency characteristics.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples




Connect X'tal to be measured to the test port. This operation narrows the resolution band width.



Setup operation (CH2)



Connect the through to the circuit jig again.




[CH2], [SWEEP], [POINTS], [100 Hz], [CENTER], [1], [0], [MHz], [SPAN],
 [2], [0], [0], [kHz], [MENU], [OUTPUT LEVEL], [5], [dBm], [MHz]

Press the above keys.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


Normalize



Press CAL and NORMALIZE ON/OFF. This normalizes CH2 in the same way as CH1.



Connect X'tal to be measured to the test port.





Press RESOLN BW and 100Hz.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples



Measure amplitude with CH1 and phase with CH2



Press the above keys.



Press the above keys.



Press the above keys.

This entry displays 2 CHs in both the simultaneous format and the split format.


Correction marker mode

These operations couple the markers for CH1 and CH2.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples

Narrow band measurement



SPAN , [1] , [0] , kHz , MKR SRCH
 MAX SEARCH , MKR - , MARKER CENTER F -
 SCALE REF , AUTO SCALE


Press the above keys.



CH2 , MKR - , MARKER CENTER F - , SPAN ,
 [1] , [0] , kHz , SCALE REF , AUTO SCALE

Press the above keys.

Zero-phase search




Press MKR SRCH and ZERO PH SEARCH

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


$\pm X^\circ$ search




TARGET SEARCH, REF ZERO PH, $\pm X^\circ$, [4], [5], deg

Press the above keys.

Tracking



RETURN, RETURN, SEARCH OFF, TRACKING ON/OFF, ZERO PH SEARCH



Remove the X'tal from the jig. The system displays the message meaning that the zero-phase point cannot be found since zero-phase search is performed every sweep operation. This condition is caused by the removal of X'tal. The left screen shows how the tracking operation has been performed.

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(9) Measurement by Using Multi-marker (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E then press the keys below in this sequence:



CENTER , [1] , [5] , [3] , MHz ,
 SPAN , [1] , MHz

Display 10 markers




MKR Δ MKR
 [] , MARKER NUMBER ,
 MARKER 2 , []



(Continued on the next page.)

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples



Measure frequency
 between markers



This key entry measures the frequency and level between marker 1 and marker 2.

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(10) Delta Marker (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power R4611E then press the keys below in this sequence:



CENTER , [1] , [5] , [3] , [MHz] ,
 SPAN , [1] , [MHz]

Set the delta block



MKR Δ MKR
 , Δ MODE MENU , ~~diff. data~~
 ,



Specify the ripple analysis block by using the above keys or the rotary encoder.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL



2.4 Measurement Examples

* The succeeding operations are enabled as if you do not follow the index.


Ripple 1




Ripple 2



Δ MAX-MIN




The above key is used to obtain the maximum and minimum values within the delta band.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples

Fixed marker



RETURN , Δ MODE OFF , MKR SRCH


MAX SEARCH ,



MKR Δ MKR , Δ MODE MENU , MORE 1/2

FIXED MARKER POSITION , FIXED M - ACTM POSN

This key entry sets the fixed marker to the current marker position.




RETURN , Δ REF FIXED MKR

This key entry displays the error between the fixed marker and the active marker.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples



Arrange DUT. In this case, lower the peak value. The system displays the error between the lowered active marker and the fixed marker.


Normal marker



RETURN , MARKER ALL OFF , MARKER NUMBER
 [1] , [5] , [3] , [.] , [0] ,
 [2] , [5] , [MHz]

Since the uncompensated marker mode is set, the system displays 153.02566667 Hz (153.02566667) despite of setting 153.025 MHz.

Correction marker




RETURN , MKR COMP/UNCMP , MARKER NUMBER
 [1] , [5] , [3] , [.] , [0] ,
 [0] , [2] , [5] , [MHz]

The system displays the specified marker value because the compensated marker mode is set.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Marker ripple




SWEPT , TYPE , COUPLE CH ON/OFF
 DISPLAY , DUAL CH ON/OFF , MORE 1/3
 SPLIT ON/OFF



CH2 , FOR MAT , PHASE , MKR Δ MKR
 MKR UNCLP , MKR UNCLP

When you move the CH2 marker, the CH1 marker follows.

Partial analysis (in delta block)








CH1 , DISPLAY , DUAL CH ON/OFF
 MORE 1/3 , SPLIT ON/OFF , MKR Δ MKR



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples





This key is used to perform the MIN search in the delta block.


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Marker track



A few seconds later, this key entry changes the MIN value and detects the value for every sweep operation.



End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(11) Measurement by Using Marker (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CENTER , [1] , [5] , [3] , MHz ,
 SPAN , [1] , MHz

Marker → Reference Level




MKR SRCH [] , MAX SEARCH [] , MKR → [] ,

MARKER REF. VALUE → [] ,

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


2.4 Measurement Examples

Marker → center frequency



MARKER -
 CENTER F. →

Marker → span frequency




MKR Δ MKR [] , [] , [] , [] MODE MENU

[] , [] , []

[]

△ 区間を設定します。




MKR - [] , [] MARKER SPAN F. →

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Marker → center scale



MKR SRCH




MAX SEARCH



MAX SEARCH
 MIN SEARCH
 TARGET SEARCH
 SEARCH OFF
 TRACKING ON / OFF
 PART ANGL ON / OFF
 MORE 1/2

Search the peak value to move the waveform peak to the center.



MKR -



MARKER CENT SCAL



MARKER - REF. VALUE
 MARKER - CENTER F.
 MARKER - START F.
 MARKER - STOP F.
 MARKER - SPAN F.
 MARKER - CENT SCAL

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(12) Measurement with Partial Sweep (Using 153-MHz BPF as DUT)

Start

Set up the measurement device




Perform the following setup and power the R4611E, then press the keys below in this sequence:



CENTER , [1] , [5] , [3] , [MHz] ,
 SPAN , [1] , [MHz]

Partial sweep menu





[SWEEP] , [TYPE] , [EDIT VAR. SWEEP] ,

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Set the partial sweep block



In this case, the system sweeps three blocks of 152.55 to 152.75 MHz, 153.05 to 153.20 MHz and 153.40 to 153.50 MHz.

```

SEG NO. , SEG START , [ 1 ] , [ 5 ] , [ 2 ] , [ . ] , [ 5 ] , [ 5 ] , [ MHz ]
          , SEG STOP  , [ 1 ] , [ 5 ] , [ 2 ] , [ . ] , [ 7 ] , [ 5 ] , [ MHz ]

SEG NO. , [ ↑ ] , SEG START , [ 1 ] , [ 5 ] , [ 3 ] , [ . ] , [ 0 ] , [ 5 ] , [ MHz ]
          , SEG STOP  , [ 1 ] , [ 5 ] , [ 3 ] , [ . ] , [ 2 ] , [ 0 ] , [ MHz ]

SEG NO. , [ ↑ ] , SEG START , [ 1 ] , [ 5 ] , [ 3 ] , [ . ] , [ 4 ] , [ 0 ] , [ MHz ]
          , SEG STOP  , [ 1 ] , [ 5 ] , [ 3 ] , [ . ] , [ 5 ] , [ 0 ] , [ MHz ]

RETURN  , VAR. SWEEP ON/OFF
    
```

End


R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples


(13) Measurement in user defined sweep (Example using the tandem filter to DUT)

Start



Set up



Perform the following set up and turn the power supply on.




User defined sweep menu



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Setting of user
 definition sweep



In this case, the system sweeps three blocks of 50 points between 3.083 and 3.095 MHz, 100 points between 3.5705 and 3.5885 MHz, 50 points between 4.0588 and 4.0925 MHz.

CLEAR ALL SEG

SEG NO. , [0] , [UNIT]

SEG START , [3] , [.] , [0] , [8] , [3] , [MHz]

SEG STOP , [3] , [.] , [0] , [9] , [0] , [5] , [MHz]

SEG POINT , [5] , [0] , [UNIT]


SEG NO. , [HOME] , SEG START , [3] , [.] , [5] , [7] , [0] , [5] , [MHz]

SEG STOP , [3] , [.] , [5] , [8] , [8] , [5] , [MHz]

SEG POINT , [1] , [0] , [0] , [UNIT]

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

2.4 Measurement Examples



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL



2.4 Measurement Examples

(14) Measurement of resonant and antiresonant points of ceramic resonator
($f=16.075\text{MHz}$)


Start

Set up the measurement device

Connect directional bridge with R4611E as follows.



- Dual CH




- Sweep time of 1 sec



CENTER 16.075MHz
SPAN 500kHz


CAL




1 PORT Full CAL is made for both CH1 and CH2.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples



Measurement of impedance and phase at antiresonant point in the linear mode



CH1 , INPUT MEAS , CVRSN , Z (REFL)
 CH2 , Z (REFL)
 CH1 , SCALE REF , AUTO SCALE
 CH2 , AUTO SCALE , FORMAT , PHASE

- Z mode (impedance) can be set and AUTO scaling can be made.



CH1 , MORE 1/2 , LIN MAG ,
 MKR Δ MKR , MKR / UNCMP ,
 MKR / UNCPL , MORE 1/2 ,
 LIN MKR , MKR SRCH , MAX SRCH ,
 CH2 , MKR Δ MKR , MKR / UNCMP

- Antiresonant point can be measured by coupling the markers of CH1 and CH2, and setting the marker indication to LINEAR MAG.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL



2.4 Measurement Examples

Measurement of impedance and phase at resonant point in the LOG mode



- Set CH1 to LOG mode and measure the resonant point.

Measurement of admittance and phase at resonant point in the linear mode





- Set the system to Y (admittance) mode and measure admittance and phase of the resonant point.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

2.4 Measurement Examples

Measurement of admittance and phase at antiresonant point in the LOG mode



- Set CH1 to LOG mode and measure admittance and phase of the antiresonant point.

End

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3. OPERATING BASIC FUNCTIONS

3. OPERATING BASIC FUNCTIONS

This chapter describes the outline of the R4611E panels in the former portion and explains the software key functions of the R4611E panel setting features in the latter.

3.1 Explanation

3.1 Description of Panel

3.1.1 Front panel




Figure 3-1 Front panel

3. OPERATING BASIC FUNCTIONS

3.1.2 Rear panel




Figure 3-2 Rear panel

3.2 Panel Keys and software Keys

On the R4611E, each function is set by using the panel keys and software keys. Pressing each panel keys displays up to seven set items (software key menu) on the right of the CRT.

Another screen (second page) is provided for each panel keys having eight set items or more. Some set items branch into further related items (secondary screen).

The key operation to select and set the desired item is divided into six types as follows:

- ① Operation requiring the numeric data entry: Display the current parameters and their data on the upper left (active function area) of the CRT display.
- ② Operation selecting the displayed set item
- ③ Operation changing the set item every pressing a software key: Indicates the current set item in the reverse display format.
- ④ Operation branching to further items: Exchanges all the data in the software key menu.
- ⑤ Operation moving to the next page (or back to the previous page)
- ⑥ Operation returning to the initial software key menu mode directly

The following figure shows the structure of the above operations:




Figure 3-3 Structure of Software Key Menu


3.3 Basic Functions

This section explains the basic functions of a part of the source, the RECEIVER section and MEASUREMENT section in the following sequence:

- A part of SOURCE ... [See Section 3.3.1 and 3.3.2.]
- RECEIVER section ... [See Section 3.3.3 and 3.3.4.]
- MEASUREMENT section ... [See Section 3.3.5 and 3.3.13.]


3.3.1 SOURCE MENU

This menu is used to select the signal source output for measurement and to set the output level.




3.3.2 SWEEP

This function sets the sweep time, measurement point count, sweep mode and so on.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions


(Partial sweep)



(See Section 2.4-(12) for the measurement example.)

SEG NO	Specifies the segment number (0 to 14). The terminate key is the deg key.
SEG START	Inputs the start frequency of the segment specified by SEG NO. (Use the ten keys.)
SEG STOP	Inputs the stop frequency of the segment specified by SEG NO. (Use the ten keys.)
CLEAR ALL SEG	Clears the input frequency data of all segments.
RETURN	Returns to the initial menu.

A "segment" represents each of the following blocks:



The segment of one point only can also be defined. To do so, Input SEG START and SEG STOP as the same value. SEG START and SEG STOP of each segment cannot be set in the out of range of measuring frequency range (START FREQ. STOP FREQ) which is set at that time.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(User defined sweep)

EDIT
USR. SWEEP

(For the example measured, refer to [Item 2.4-(3)])

SEG NO Specifies the segment No. (0 to 14). The terminate key is <input type="text" value="deg"/> key.
SEG START Input the start frequency of the segment specified by SEG No. (Ten-key is used)
SEG STOP Input the stop frequency of the segment specified by SEG No. (Ten-key is used)
SEG FREQ Input the frequency of the segment specified by SEG No. (Ten-key is used. When this value is input, SEG START becomes equal to SEG STOP, and next SEG POINT becomes 1)
SEG POINT Inputs the number of measuring points of the segment specified by SEG No. (This value defines the number of measuring points in the interval between SEG START and SEG STOP of the specified segment)
CLEAR ALL SEG Clears the information where all segments were input.
RETURN Returns to the first menu.

Though the "SEGMENT" is the same concept as that of the partial sweep, to define the segment of one point, either input SEG POINT as 1 or the value of SEG FREQ.


If SEG START and SEG STOP are the same value and SEG POINT is not 1, repeat the measurement of same frequency for the number of times specified by SEG POINT.

When SEG START is not equal to SEG STOP and SEG POINT is 1, execute the measurement only in the frequency specified by SEG START.

Total of POINTs of each segment cannot be set exceeding 1201.

Differs from the partial sweep, the user defined sweep can set the optional frequency regardless of the measuring frequency range set at that time.

All displays are performed with left justified.




Similar to the ordinary sweep, the number of measuring points can be set. If the total number of measuring points is 97 for each segment of user-defined sweep mode, the frequency waveforms is displayed on the entire screen when the number of measuring points of 101 is set. If the selected number of measuring points is much greater than that of each segment of user-defined sweep mode, the number of measuring points is changed automatically.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

The number of measuring points cannot be changed during user-defined sweep. It can be changed only when the other sweep mode is selected.

(3) POINTS



(4) TRIGGER


INTERNAL Free run
LINE Line trigger
EXTERNAL External trigger. This function starts the sweep operation according to the trigger input by EXT TRIG. on the rear panel. (Trigger ... TTL level and LOW enable)
RETURN Returns to the initial menu.

(5) MODE

CONTINUE Repeats the sweep operation continuously.
SINGLE Single sweep mode
HOLD Holds the sweep operation.
RETURN Returns to the initial menu.


3.3.3 IMP/ATT (Impedance/Attenuator)

This function sets the input impedance and input attenuator of INPUT, A, B and R.




3.3.4 RESOLN BW (Resolution Band Width)

This function sets the receiver resolution band width. Narrow the resolution band width according to the required dynamic range to lower the noise level. When you narrow the resolution band width, however, the response time of the filter integrated in the R4611E is prolonged. Thus, slow the sweep time so that the waveform trace does not change.



3.3.5 INPUT MEAS (Measurement)

(a) For standard R4611E



Since conversion to the complex impedance or the complex admittance is executed by the operation shown below,

$$Z(\text{REFL}) = \frac{1+\Gamma}{1-\Gamma} Z_0 = R+jX \quad Y(\text{REFL}) = \frac{1-\Gamma}{1+\Gamma} \times \frac{1}{Z_0} = G+jB$$


based on the complex reflection coefficient obtained by the set inputs (A/R, B/R, A/B, R, A, B ...), it is necessary to set the reflection coefficient measurement of the DUT for input.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(b) R4611E with an S-parameter test set

Select the entry to be used by CH1 or CH2.




Since conversion to the complex impedance or the complex admittance is executed by the operation shown below,

$$Z(\text{REFL}) = \frac{1+\Gamma}{1-\Gamma} Z_0 = R+jX \quad Y(\text{REFL}) = \frac{1-\Gamma}{1+\Gamma} \times \frac{1}{Z_0} = G+jB$$

based on the complex reflection coefficient obtained by the set inputs (A/R, B/R, A/B, R, A, B ...), it is necessary to set the reflection coefficient measurement of DUT for input.

3.3.6 FORMAT

Selects the measurement format for amplitude, phase and group delay.




R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

When conversion (Z or Y) of INPUT MEAS is set, the formats SMITH (R + jX), SMITH (G + jB), PHASE ($-\infty, +\infty$), and DELAY have no meaning.

Other formats have the following meaning respectively.
 (Here, the result of the conversion is written as follows,
 $Z = R + jX$, $Y = G + jB$)

FORMAT	The meaning of format
LOGMAG	$20 \log_{10} Z $ or $20 \log_{10} Y $
PHASE	$\tan^{-1} X/R$ or $\tan^{-1} B/G$
LIN MAG	$ Z $ or $ Y $
REAL	R or G
IMAG	X or B
POLAR	

To obtain the value of L or C from the imaginary part of Z or Y, refer to the MKR menu.

3.3.7 DISP (DISPLAY)

Sets the mode related to the CRT display (waveform trace display, list display and scale form display).

DISP

- DUAL CH
ON/OFF
- DISPLAY:
DATA
- DATA AND
MEMORY
- DATA/MEMO
ON/OFF
- DATA ⇌
MEMORY
- MORE 1/3

- Two-channel simultaneous display.
See Section 2.4-(4) for the measurement example.
- Displays the waveform data to be rewritten for every sweep operation on the CRT.
- Displays the above data and memory on the CRT at one time.

This key selects whether the DATA should be divided or not in the MEMORY. The division is executed by the complex form.
- Stores the waveform data to the internal memory.
- Returns to the second page of the menu.

- SPLIT
ON/OFF
- GRATICULE
ON/OFF
- LABEL
- MORE 2/3

- Split display. (CH1 and CH2 are displayed separately into two columns, up and down on half scale. See Section 2.4-(4) for the measurement example.
- Setting this OFF displays only the frame of the scale.
- Continued on Section 3.3.7-(1).
- Returns to the third page of the menu (continued on Section 3.3.7-(2)).

(1) LABEL

Displays the label character at the bottom of the screen.

LABEL

SELECT LETTER	Selects a letter. (Use the rotary encoder.) When a letter is selected, the cursor moves one character right.
SPACE	Space. This function deletes the character specified by the cursor and moves the cursor one character right.
BACK SPACE	Back space. This function moves the cursor one character left and deletes the character at the position.
CURSOL →	Moves the cursor one character right.
CURSOL ←	Moves the cursor one character left.
CLEAR LABEL	Deletes all label characters.
RETURN	Returns to the second page of the menu.


(2) MORE 3/3

MORE 2/3

INTENSITY	Arranges the CRT intensity. (Use the up-down keys and ten keys.) The intensity can be changed in 9 levels of 0 to 8. If level 0 is selected, the screen is changed to dark. When the intensity key is pressed again, level 8 is set automatically.
REAL TIME CLOCK	Sets the realtime clock. See Section 3.3.7-(3).
MORE 3/3	Returns to the first page of the menu.

(3) REAL TIME CLOCK


Sets the real-time clock.




3.3.8 SCALE & REF (Reference)

Sets the position and value of the reference line or screen scale.
 The unit of the entry key and menu varies with the selected format.

(a) When the format is LOG MAG, PHASE or DELAY:



(b) When the format is SMITH or POLAR:



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

3.3.9 MKR MKR (Marker Delta Marker)

The R4611E is provided with various marker functions to read data according to the displayed waveform. The system displays the marker data in the active function area or on the upper portion of the screen. The form and function of each marker are as follows:

Marker \ Channel	CH1	CH2
	Non-active marker	∇^N
Active marker	\blacktriangledown^N	\blacktriangle^N

The menu in the Smith or polar chart format (b) is different from that in the other formats (b).

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(a) When the format is not the Smith or polar chart mode:



MARKER NUMBER	Issues up to 10 multi-markers to read data. (Continued on Section 3.3.9-(a-1).) See Section 2.3-(9) for the measurement example.
MARKER ALL OFF	Sets all markers OFF.
Δ MODE MENU	Reads data by using the delta marker. (Continued on Section 3.3.9-(a-2).) See Section 2.3-(10) for the measurement example.
MKR CMP/UNCMP	MKR COMPENSATE system to display the response value with the frequency other than those at the sweep point by using the linear approximation. See Section 2.4-(10) for the measurement example.
MKR CPL/UNCPL	Even if the sweep frequency is uncoupled with the marker coupled in the 2-CH display mode, the system is set to the marker mode to search a frequency value with the displayed sweep frequency range by using each channel. See Section 2.4-(10) for the measurement example.
PART ANAL ON/OFF	Performs analysis (MAX search, MIN search, RIPPLE measurement, etc.) by using the marker in the specified block. See Section 2.4-(10) for the measurement example.


* See the figure on the next page.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

- MKR (CMP/UNCMP)
 <Reading the response value of fx>


The marker value in the UNCMP mode corresponds to response value L_3 at the measurement point nearest f_x . The marker value in the CMP mode corresponds to L_x obtained through linear approximation between response values L_3 and L_4 at measurement points f_3 and f_4 .



- MKR (CPL/UNCPL)


<UNCPL mode>

Only the active marker moves independently.



<CPL mode>

Non-active channel marker f_n moves in conjunction with the active channel marker f_n .



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions


● PART ANAL (ON/OFF)

< Measurement example in the MAX search mode >

At OFF: The system searches the maximum value of the response values within the measurement frequency range.

At ON : The system searches the maximum value in the block specified by the non-active marker (Δ MKR) (between * and \blacktriangle).

PART ANAL
ON/OFF




Block specified by non-
active marker (Δ MKR)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions


(a-1) Multi-marker



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(a-2) ΔMODE MENU

Δ MODE MENU 	
Δ REF=Δ MKR Sets the normal delta mode (using the entry keys). Pressing this key issues the child marker (*) at the position of the active marker (▼) to measure the delta value in the portion specified by moving the marker. See Section 2.4-(10) for the measurement example.
Δ REF= ACT MKR Sets the delta marker mode for the multi-marker function using the active marker. See Section 3.3.9-(a-2-3) for specifying the active marker number. For the measurement example, see Section 2.4-(9).
Δ REF= REF. POSN Sets the delta marker mode in the portion specified by the active marker based on the reference position.
(Δ RIPPLE) Used with ΔREF = ΔMKR or ΔREF = ACT MKR to set the ripple measurement mode. (Continued on Section 3.3.9-(a-2-3)).
Δ MODE OFF (This key is enabled only in the LOG MAG or DELAY display mode.)
RETURN Sets the delta mode OFF.
 Returns to the initial menu.
MORE 1/2 Goes to the second page of the MODE MENU. (Continued on Section 3.3.9-(a-2-4).)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

● Δ MODE Δ MENU

Δ REF = Δ MKR


The system measures the delta value between the active marker (\blacktriangledown) and child marker (*).

Δ REF = ACT MKR

The system measures the delta value between the active marker (\blacktriangledown) and the specified compare marker (∇ to ∇).

Δ REF = REF.POSN


The system measures the delta value between the active marker (\blacktriangledown) and the reference position.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions


(a-2-1) ΔREF = ACT MKR



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(a-2-2) ACT MKR NUMBER



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions


(a-2-3) Δ RIPPLE

For the measurement example, see Section 2.4-(10).

To specify the target block of the delta ripple function, use the delta marker.

Δ RIPPLE <input type="checkbox"/>	↓	
Δ RIPPLE1	Obtains the convex wave of the highest level and the concave wave of the lowest level in the specified block.
Δ RIPPLE2	Obtains the largest difference between a convex wave and the next concave wave.
Δ X	}	Used to change the detection sensitivity in the Δ RIPPLE mode. See the next section for details.
Δ Y		
Δ MAX-MIN	Obtains the maximum and minimum values in the specified block.
Δ RIPPLE OFF	Sets the Δ RIPPLE mode OFF.
RETURN	Returns to the second page of the menu.

● Δ MAX-MIN




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

● ΔX and ΔY

To obtain a ripple, first obtain the point a where the waveform gradient becomes more than $\Delta Y/\Delta X$, next, obtain the point d where the waveform gradient becomes less than $\Delta Y/\Delta X$, then obtain the maximum value between the two points.



This is why you can change the sensitivity of the peak detection by changing ΔX and ΔY . In the RIPPLE mode, ΔX and ΔY can be changed as follows:

For example:

Press ΔX , \square , $\boxed{3}$ and $\boxed{\text{MHz}}$. This sets ΔX to 3 MHz.
Press ΔY , \square , $\boxed{2}$, dB and $\boxed{\text{Hz}}$. This sets ΔY to 2 dB.
The initial value of ΔX is 1000000.00 Hz (0.33% of SPAN) and that of ΔY is 0.010 dB.

The range of ΔX is

$$\frac{\text{SPAN}}{1200} \leq \Delta X \leq \text{SPAN}$$


The system computes using the above conditions even when the source frequencies (CENTER, SPAN, START, STOP) have been changed.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

(a-2-4) FIXED MKR (Available only in the LOG MAG mode)


See Section 2.4-(10) for the measurement example. Though the normal marker can be specified only on the measurement wave, the fixed marker can be specified not only within the measurement frequency range but also outside of the screen.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

(b) When Smith chart or polar chart is used for format, SMITH MKR MENU or POLAR MKR MENU is added.

MKR Δ MKR


- MARKER NUMBER
- MARKER ALL OFF
- Δ MORE MEMU
- MKR CMP/UNCMP
- MKR CPL/UNCPL
- PART ANAL ON/OFF
- SMITH MKR MENU

..... Same as the operations in the formats other than the Smith chart format.

..... (Does not function at log sweep.)

..... (Sets the POLAR MKR menu in the polar chart mode.)

(In either of the following operations, the system converts the value of the active marker to the normal coordinate system and displays the converted value.)

- LIN MKR
- LOG MKR
- Re/Im MKR
- R+jX MKR
- G+jX MKR
- Z0 VALUE
- RETURN

..... Displays the linear amplitude and phase of the active marker.

..... Displays the LOG amplitude and phase of the active marker.

..... Displays the value of the active marker in terms of the multi-element data, real and imaginary parts.

..... Displays the value of the active marker in terms of impedance. (The system does not display the menu in the polar format.)


..... Displays the value of the active marker in terms of admittance. (The system does not display the menu in the polar format.)

..... Input characteristic impedance for system of measurement.

..... Returns to the initial menu.

(c) When parameter conversion is ON

MORE 1/2 is added




3.3.10 MKR SRCH (Marker Search)

This function is used to search the maximum value of the waveform trace, X-dB down band width, etc..

(a) LOG MAG Format

MKR SRCH



MAX SEARCH	Searches the maximum value of the waveform trace.
MIN SEARCH	Searches the minimum value of the waveform trace.
TARGET SEARCH	Starts the search operation at a reference value (reference position, etc.). (Continued on Section 3.3.10-(a-1)). (Does not function at log sweep.)
SEARCH OFF	Sets the search function OFF.
TRACKING ON/OFF	Performs the marker search operation specified for every sweep operation.
PART ANAL ON/OFF	Performs marker search in the specified range. This key is available only when a block is specified by the delta marker. See Section 2.4-(10) for the measurement example.
MORE 1/2	



NEXT MAX SEARCH	Each time this key is pressed the next maximum value is searched sequentially. (Does not function at log sweep)
NEXT MIN SEARCH	Each time this key is pressed the next minimum value is searched sequentially. (Does not function at log sweep)
Δ X	}	Used to change the data detection sensitivity in the NEXT MAN SEARCH or NEXT MIN SEARCH mode. The operations are the same as those in the MKR ΔMKR mode. [See Section 3.3.9-(a-2-2).]
Δ Y		
MORE 2/2	Returns to the first page of the menu.


R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(a-1) TARGET SEARCH


See Section 2.4-(1) for the measurement example.

$\Delta \text{ REF}=\text{MAX}$




c. f

$\Delta \text{ REF}=\text{REF. POSN}$




c. f

$\Delta \text{ REF}=\text{MKR}$



c. f

$\Delta \text{ REF}=\text{C. F}$



c. f

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

Δ REF=MAX Automatically specifies the maximum value of the waveform trace as the reference.
Δ REF= REF. POSN Automatically specifies the reference position as the reference.
Δ REF=MKR Specifies the selected marker as the reference.
Δ REF=C. F Automatically specifies the value of the center frequency as the reference.
XdB DOWN IN/OUT In X-dB down search: IN : The system searches the right and left portions of the marker point when REF is MAX or MKR. When Δ REF is REF. POS. or C.F, the system searches the right and left portions of the center frequency position.
FLTR ANAL ON/OFF OUT: The system starts the search operation at both ends of the screen. When the delta marker is set, the system starts the search operation toward the inside of the marker point.
RETURN Selects whether to compute the LEFT frequency, RIGHT frequency, center frequency, band width, Q and shape factor. When Δ REF is REF.POSN, Q and the shape factor disabled.
RETURN Returns to the initial menu.

-3dB 3-dB down band width
-6dB 6-dB down band width
-60dB 60-dB down band width
-XdB X-dB down band width (Use the entry keys.)
LEFT SEARCH Displays the left frequency of the X-dB down band width.
RIGHT SEARCH Displays the right frequency of the X-dB down band width.
RETURN Returns to the initial menu.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions

(b) When FORMAT is PHASE or PHASE ($-\infty$, $+\infty$).

See Section 2.4-(8) for the measurement example.

MKR SRCH




ZERO PH SEARCH
TARGET SEARCH
SEARCH OFF
TRACKING ON/OFF
PART ANAL ON/OFF

- Searches the point of 0°-waveform trace phase. The system, however, does not search phase 0° accurately with a certain number of measurement points. (Does not function at log sweep.) To search phase 0° accurately, set of $\text{MKR} \Delta \text{MKR}$ of $\text{CMP} \rightarrow \text{UNCMP}$ to CMP.
- Specifies the search function for a certain reference (zero phase, etc.). (Continued on Section 3.3.10-(b-1).) (Does not function at log sweep.)
- Sets the search function OFF.
- Performs the marker search operation specified for every sweep operation.
- Performs marker search in the specified block. This key is available only when a block is specified by the delta marker.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(b-1) TARGET SEARCH




3.3.11 MKR → (Marker →)

See Section 2.4-(11) for the measurement example.

This function is used to substitute the marker value for the value of another function. The menu for when only the data of the waveform trace is displayed (a) is different from that for when the data and memory are displayed (b).


(a) When only the data of the waveform trace is displayed:



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

3.3 Basic Functions


(b) When the data and memory of the waveform trace are displayed:



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

3.3 Basic Functions

(c) For level sweep



3.3.12 AVG (Average)

Pressing the AVERAGE key enables the settings related to averaging the measurement data.

In the averaging mode, the data fetched serially is averaged in terms of time.

The system adds the averaging data in terms of time sequentially according to the set count (number of times).

The R4611E uses the vector averaging system to reduce the noise level.

That is, the R4611E realizes the same effects as those brought about by narrowing the resolution band width (RBW) and allows you to perform a widely dynamic range or measurement by using RBW.

The following shows the averaging expression at each point on the frequency axes:


$$\bar{Y}_n = \frac{n-1}{n} \cdot \bar{Y}(n-1) + \frac{1}{n} Y_n \quad (n \leq N)$$

Y_n corresponds to "n"th data. \bar{Y}_n and $Y(n-1)$ correspond to the "n"th and "n-1"th averaging data.

When the averaging count reaches the specified value (N), $n-1/n$ is set to $N-1/N$ and $1/n$ is set to $1/N$.


Hereafter, averaging with $n > N$ is performed as follows:

$$\bar{Y}_n = \frac{N-1}{N} \cdot \bar{Y}(n-1) + \frac{1}{N} Y_n$$



3.3.13 CAL (Calibration)

See Section 2.4-(1) and 2.4-(7) for the measurement examples.



MEMO



A large, empty rectangular area with rounded corners, enclosed by a dashed border. A solid horizontal line extends from the left side of the top-left corner of this area towards the word 'MEMO'.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.1 SAVE/RECALL

4. OTHER FUNCTIONS

This chapter explains the supplementary function to support the basic functions described in Chapter 3.

4.1 SAVE/RECALL

SAVE : Saves the conditions specified on the R4611E to the internal register or your floppy disk. The system makes the backup copy of the internal register. However, if you leave the R4611E with the power code removed for a long period, this function will not work. In this case, the data of the SAVE register is deleted and the initial setting is invalidated. At this time, execute CLEAR or SAVE.


When the R4611E power code is connected to the AC power, you can leave the R4611E for a long period.

RECALL: Recalls the data saved with the SAVE function.

NOTE

Data saved into the floppy disk have upward compatibility for the firmware on the R4611E main unit. However, the data have no compatibility for the old version firmware. File saved by any version firmware can always be loaded on the updated firmware. Normal loading cannot be guaranteed when file is loaded on the old version firmware than that the file have been generated. (It has no probability that the file is destroyed.) In this case, update the firmware version of the R4611E main unit.

4.1.1 SAVE





R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.1 SAVE/RECALL

(1) SAVE REG

SAVE REG ↘



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.1 SAVE/RECALL

Pressing the NAME REG N key changes the software key menu as shown in the next page and prompts you to enter the "register name" by using the entry keys. On register name must be within nine characters.

NAME REG N ↘

SELECT LETTER
BACK SPACE
CURSOL →
CURSOL ←
CLEAR NAME
RETURN

.....Same as the operations of LABEL (see Section 3.3.7).

.....Returns to the third page of the menu.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

(2) CLEAR REG.

CLEAR
REG ↘

- CLEAR
REG 1
- CLEAR
REG 2
- CLEAR
REG 3
- CLEAR
REG 4

- RETURN

..... Specifies the register to be cleared.

..... Returns to the first page of the menu.


R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.1 SAVE/RECALL

(3) STORE


Cautions on STORE FILE

- If you set the R4611E OFF or execute the instrument preset operation during floppy access, the files may be destroyed.
- RAW ARRAY is prior to DATA ARRAY. When you specify loading the files saved with DATA ARRAY ON and RAW ARRAY ON, the system processes the values of the RAW ARRAY and ignores those of the DATA ARRAY.
- You cannot save DATA, RAW and MEM on CHs which have been not measured by the R4611E.



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.1 SAVE/RECALL



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

(4) PURGE

PURGE ↘

PURGE
FILE 1

PURGE
FILE 2

PURGE
FILE 3

PURGE
FILE 4

MORE
FILE

RETURN

..... Specifies the file to be cleared.

..... Displays the file names saved in files other than those displayed on the above four software key menus onto these four software key menus.

..... Returns to the first page of the menu.

4.1.2 RECALL

RECALL



- RECALL
REG 1
- RECALL
REG 2
- RECALL
REG 3
- RECALL
REG 4
- RECALL
POWER OFF
- LOAD FILE

..... Recalls the R4611E setting conditions saved with SAVE REG.

NOTE

MEM or CORRECTION COEFFICIENTS cannot be saved with SAVE REG. The following modes set before saving are reset to OFF when recalled.

{ Data/Memo ON/OFF
 Correct ON/OFF

..... Recalls the waveform data stored with STORE FILE.

- LOAD
FILE 1
- LOAD
FILE 2
- LOAD
FILE 3
- LOAD
FILE 4
- MORE
FILE
- RETURN

..... Specifies the file to be recalled.

NOTE



When you recall the file saved with RAW ARRAY ON or DATA ARRAY ON, the sweep mode is set to the HOLD mode automatically.

..... Displays the file names saved in the files other than those displayed on the above four software key menus onto these four software key menus.



..... Returns to the first page of the menu.

4.2 GPIB LOCAL

LOCAL





4.3 COPY



..... Draws the waveforms and setting conditions on the screen on to the plotter.

NOTE

When using the direct plotter, press the LOCAL key to change the TALKER LISTENER mode to the SYSTEM CONTROL mode and to set the plotter GPIB address.



..... Selects whether to use the ADVANTEST-supplied plotter or HP-supplied one. (Continued on Section 4.3.1.)

..... Specifies the size and location of the drawing on the plotter. (Continued on Section 4.3.2.)

..... Selects the data of the plot. (Continued on Section 4.3.3.)

..... Specifies PEN for the plot. (Continued on Section 4.3.4.)

..... Executes the direct plotter.

NOTE

After the EXECUTE key is pressed, all keys other than the ABORT key are disabled until the end of the plot operation. The measurement sweep operation is also stopped.

..... Aborts the execution.

..... Returns to the original menu.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.3 COPY


● TALKER/LISTENER mode

Using this mode requires an external controller.

First, press the plotter EXECUTE key manually or execute the EXECUTE operation via the external controller.

Second, set the plotter to the listener mode and the R4611E to the talker mode via the external controller, then set the GPIB ATN (attention) line to "H". This operation outputs the data to the plotter.

When the plotter output terminates, the system issues SRQ.



Sample program (TALKER/LISTENER mode)

PLOTTER HP series

```
10 OUTPUT 711;"PLTEXC"  
20 WAIT .1  
30 SEND 7;UNL UNT LISTEN 1  
40 SEND 7;TALK 11 DATA  
  
50 END
```

... Specifies the plotter output.
... Wait (Specify Wait for one second or more.)
... Sets the plotter to the listener mode.
... Sets the R4611E to the talker mode and sets the ATN line to "H".

4.3.1 PLOTTER TYPE

PLOTTER TYPE ↴

AT PLOTTER
HP PLOTTER
RETURN


.....Selected to use the ADVANTEST-supplied plotter.

.....Selected to use the HP-supplied plotter.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

- (1) To use the R9833 as a direct plotter by connecting it to R4611E, set as follows:

< Setting R4611E >



< Setting R9833 >

Set each DIP switch to the following standard values.

Setting DIP switches

The DIP switches are used to set the initial state at power supply and the interface conditions. Figure 4-1 shows the external view of the DIP switches.




Figure 4-1 External View of DIP Switches

① DSW1

When the SW number is 8 to 1, the HP mode is specified.
When the SW number is 8 to 0, the GP-GL mode is specified. (In the AT mode, set the SW number of 8 to 0 and 4 to 1.)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.3 COPY

② DSW2

Set the plotter address to 31 to 5.

- Table 4-1 lists the DSW1 functions and Table 4-2 lists the DSW2 functions.

Table 4-1 DSW1 Functions

SW number	Functions (ON = 1)				Standard value																				
1 to 3	<div style="display: flex; justify-content: space-between;"> Form size setting (S3 = 0) (S3 = 1) </div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">S1</th> <th style="width: 5%;">S2</th> <th style="width: 45%;">ISO or JIS system</th> <th style="width: 45%;">ANSI system</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td>A3 width and maximum depth</td> <td>B width and maximum depth</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> <td>Supplements the vertical length of A3 toward your side.</td> <td>Supplements the vertical length of B toward your side.</td> </tr> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> <td>Supplements the horizontal length of A4 toward your side.</td> <td>Supplements the horizontal length of A toward your side.</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> <td>Supplements the vertical length of A4 toward your side.</td> <td>Supplements the vertical length of A toward your side.</td> </tr> </tbody> </table>				S1	S2	ISO or JIS system	ANSI system	0	0	A3 width and maximum depth	B width and maximum depth	1	0	Supplements the vertical length of A3 toward your side.	Supplements the vertical length of B toward your side.	0	1	Supplements the horizontal length of A4 toward your side.	Supplements the horizontal length of A toward your side.	1	1	Supplements the vertical length of A4 toward your side.	Supplements the vertical length of A toward your side.	S1 = 0 S2 = 1 S3 = 0 A4 horizontal
S1	S2	ISO or JIS system	ANSI system																						
0	0	A3 width and maximum depth	B width and maximum depth																						
1	0	Supplements the vertical length of A3 toward your side.	Supplements the vertical length of B toward your side.																						
0	1	Supplements the horizontal length of A4 toward your side.	Supplements the horizontal length of A toward your side.																						
1	1	Supplements the vertical length of A4 toward your side.	Supplements the vertical length of A toward your side.																						
4	Rotation coordinate setting 1; Rotation coordinates is set "ON".				0																				
5	Unit length selection of step count 0; Standard 1; Switch				0																				
6	Paper-end function disable 0; Paper-end function is provided. 1; Paper-end function is not provided.				0																				
7	Input buffer size switch 1; Maximum value (12 KB) 0; 1 KB				0																				
8	Selection of FP-GL-I/FP-GL-II 1; FP-GL-I 0; FP-GL-II				1																				

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.3 COPY

Table 4-2 DSW2 Functions


SW number	Functions (ON = 1)	Standard value						
1 to 5	Plotter address setting. These switches are used to define the device address by using all bits as follows: Bit configuration <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="border: 1px solid black; padding: 2px 5px;">S5</td> <td style="border: 1px solid black; padding: 2px 5px;">S4</td> <td style="border: 1px solid black; padding: 2px 5px;">S3</td> <td style="border: 1px solid black; padding: 2px 5px;">S2</td> <td style="border: 1px solid black; padding: 2px 5px;">S1</td> <td style="padding-left: 10px;">Address 31 specifies the listen-only mode.</td> </tr> </table>	S5	S4	S3	S2	S1	Address 31 specifies the listen-only mode.	S1 = 1 S2 = 1 S3 = 1 S4 = 1 S5 = 1
S5	S4	S3	S2	S1	Address 31 specifies the listen-only mode.			
6	EOI signal control selection 0; EOI disable 1; EOI enable This switch is available only when FP-GL-II is used. The switch is not defined when FP-GL-I is used.	0						
7	Undefined.	0						
8	Shrinking plot mode selection (available only for FP-GL-II) 1; Selects the shrinking plot mode (0.9 times).	0						

When the EOI signal is set to 1 (enable) and "L" is received at the EOI terminal in the FP-GL-II mode, plotter operates in the same way as for a terminator reception. When sending data from the plotter, the system outputs the "LF" code at the end of the sending data and sets the EOI terminal to "L" at the same time. When the shrinking plot mode is selected with FP-GL-II used, the system plots the output figure of 0.9 times as large as the original one referring to the Global origin. At that time, the actual size of the effective plot range is not changed and the specifiable range has been enlarged only on the program.

(2) Connecting R4611E to TR9832(G)

To use the TR9832(G) as a direct plotter by connecting it to R4611E, set as follows:

< Setting R4611E >



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.3 COPY

<Setting TR9832(G)>

Set the switch to 8, A, C or E.

- Setting bottom digital rotary switch

To set the following functions to the initial state, use the digital rotary switch (see the following figure) in the acrylic cover on the bottom of TR9832:

Setting for R4611E to TR9832 Connection

Switch setting	5	7	8	A	C	E
Function						
Character form fine		o		o		o
Plot area shrinking	o	o			-	-
HP-GL specification			o	o	o	o
Command system	GP-GL		HP-GL			


o: Valid function

-: Invalid function

NOTE

If you do not set this switch as specified, you cannot get the correct plot. Before using the TR9832, check the following table. Refer to the TR9832 instruction manual (page 15) for details.

Your side




Inside of Bottom Acrylic Case

4.3.2 SIZE & LOCATION

SIZE LOCATION ↘

1 PICTUREDraws one plot on the A4-size form. (Continued on Section 4.3.2-(1).)
2 PICTUREDraws two plots on the A4-size form. (Continued on Section 4.3.2-(2).)
4 PICTUREDraws one plot on the A4-size form. (Continued on Section 4.3.2-(3).)
EXECUTEExecutes the direct plotter.
ABORTResets the execution.
RETURNReturns to the initial menu.

(1) 1 PICTURE





(A4-size form)



(2) 2 PICTURE

2 PICTURE  

LEFT
RIGHT
EXECUTE
ABORT
RETURN

LEFT	RIGHT
	

(A4-size form)
with HP-GL command
specified

LEFT	RIGHT
	

(A4-size form)
with GP-GL command
specified

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.3 COPY

(3) 4 PICTURE

4 PICTURE ↘



LEFT UPPER
LEFT LOWER
RIGHT UPPER
RIGHT LOWER
EXECUTE
ABORT
RETURN

LEFT UPPER	RIGHT UPPER
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
LEFT LOWER	RIGHT LOWER

(A4-size form)

4.3.3 DEFINE PLOT

DEFINE Key to select the data of the plot. The default values of the following items are all ON.

DATA ON/OFF Sets the plot of the measurement DATA waveform data ON/OFF.		
MEMORY ON/OFF Sets the plot of the memory waveform data ON/OFF.		
MARKER ON/OFF Sets the marker symbol ON/OFF.		
SCALE ON/OFF Sets the scale display mode ON/OFF.		
GRATICULE ON/OFF Sets the check display mode ON/OFF.		
RETURN Returns to the initial menu.		
MORE1/2			

REFLINE ON/OFF Sets the reference line ON/OFF.
TEXT ALL ON/OFF Sets the characters of the setting conditions ON/OFF.
LABEL ON/OFF Sets the label ON/OFF.
RETURN Returns to the initial menu.
MORE2/2 Returns to the first page of the menu.

4.3.4 CONFIG PLOT

CONFIG ↘

CH1 DATA PEN No.Pen to specify the characters related to the CH1 DATA waveform, CH1 REF LINE and CH1 and the CH1 marker.
CH1 MEM PEN No.Pen to specify the CH1 memory waveform.
CH2 DATA PEN No.Pen to specify the characters related to the CH2 DATA waveform, CH2 REF LINE and CH2 and the CH2 marker.
CH2 MEM PEN No.Pen to specify the CH2 memory waveform.
SCALE PEN No.Pen to specify the scale.
LABEL PEN No.Pen to specify the label.
RETURNReturns to the initial menu.

You can specify the pen of the plotter. This pen value must be within 1 and 15. The following table lists the default value of each setting:

CH1 DATA PEN	CH1 MEM PEN	CH2 DATA PEN	CH2 MEM PEN	SCALE PEN	LABEL PEN
1	3	2	4	5	6

4.4 Parallel I/O Functions

The parallel I/O functions are executed by using the 8-bit I/O (input/output) ports to communicate with the handler and peripheral devices.

The communication is performed with the parallel I/O connector on the rear panel. [Figure 4-5] shows the internal pin assignment of the connector. To control these I/O ports, refer to the R4611E programming manual (Section 5.5).

4.4.1 8-bit Input

To read signals sent from the handler and peripheral devices, use the "ENTER" statement.

Operating ENTER statement

```
ENTER 32;3
```

This entry fetches the data when DI0 and DI1 of pins 14 and 15 are set to "1".

4.4.2 8-bit Output

To output signals to the handler and peripheral devices, use the "OUTPUT" statement.


Operating OUTPUT statement

```
OUTPUT 32;2
```

This entry sets DO1 of pin 3 to "1".

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.4 Parallel I/O Functions



DO 7 to DO 0 : Output (DO 7 is MSB and DO 0 is LSB.)
 DI 7 to DI 0: Input (DI 7 is MSB and DI 0 is LSB.)

Figure 4-2 Connector Internal Pin Assignment and Signals

NOTE

DO 7 to DO 0 correspond to the output equivalent to the TTL 74LS series (including 100 Ω protection resistance).
 DI 7 to DI 0 correspond to the input equivalent to the TTL 74LS series (including 10 k Ω pull-up resistance).

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.5 RS-232C

4.5 RS-232C

Besides the GPIB interface, the R4611E is provided with the RS-232C interface as standard. Thus, the R4611E permits outputting the data communication with host CPUs and pattern programs to the RS-232C printer.

The RS-232C interface features the mechanical and electrical characteristics of the interface between the data terminals and data communication units standardized by the Electric Industry Association in the United States (EIA). For details, refer to the specifications of EIA.

4.5.1 Connector and Signal List

(1) Connector: 25-pin D-subconnector (male type)

Signal list

Pin No.	Signal	Meaning
1	FG	Safety ground
2	TxD	Sending data
3	RxD	Receiving data
4	RTS	Sending request
5	CTS	Sending enable
6	DSR	Data set ready
7	SG	Signal ground
20	DTR	Data terminal ready

TxD, RTS and DTR are sent at SN75188N (power supply +12 V), and RxD, CTS and DSR are received at SN75189AN.

4.5.2 Printer Output

This section describes the data output to the RS-232C printer. You can print data by using the R4611E in both the LPRINT format and the LLIST format.

LLIST : Outputs the basic program to the printer.

LPRINT: Outputs the data of the characteristics, numerals and variables.

Recommended device type

Device supplied by EPSON Co., Ltd.

- Printer

FP-80 series or equivalent one

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.5 RS-232C

- Interface
8148 (intelligent serial interface)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.6 Functions Keys

4.6 Functions Keys

The function keys on the left side of the R4611E display are used to execute the previously created programs.

These keys are allocated as follows. The function caused by pressing each key varies with the specified mode:

In the editor mode, the keys are all invalidated.

	[Measurement screen]	[Command line]	[Program execution]
1 <input type="checkbox"/> RUN	RUN	RUN	ON KEY1 (Note 1)
2 <input type="checkbox"/> CAT	Not function.	CAT	ON KEY2
3 <input type="checkbox"/> LIST	Not function.	LIST	ON KEY3
4 <input type="checkbox"/> CONT	CONT	CONT	ON KEY4
5 <input type="checkbox"/> LOAD	Not function.	LOAD (Note 2)	ON KEY5
6 <input type="checkbox"/> CLS	Not function.	CLS	ON KEY6
<input checked="" type="checkbox"/> STOP	STOP	STOP	STOP

NOTE

- ① An interruption occurs when this key is pressed during program execution. You can number each interruption from 1 to 6 and the specified interruption number corresponds to the key number and the number of the BASIC command "ON KEY". (Refer to the R4611E programming manual (Section 4.4).)
During program execution, function keys "F1" to "F6" have the same functions as software keys "1" to "6".
- ② Executing LOAD requires selecting a filename. To do this, use the rotary encoder, shift (↑↓), UNIT deg keys.
(The next page shows the LOAD examples.)
CAT can list up the menu of all files saved in a floppy disk. LOAD can function only for the BASIC type file.
To recall the setting data, depress RECALL key.
(LOAD examples are shown as follows.)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.6 Functions Keys

LOAD examples

- (1) Pressing keys 2 and CAT displays all files in the disk.

```
[COMMAD] < ..... > ( ? ) Done
```

<<	Entry File	Secto	Byte Group	>>
1.	ABC2_30	4	1820 BASIC	
2.	TRIANGL	5	2086 BASIC	
3.	RUNNING_TEST	1	294 BASIC	
4.	PAGING	1	126 BASIC	
5.	ASCII	1	232 BASIC	
6.	FILE_1	22	10952 SYSTEM	

▶

- (2) Pressing keys 5 and LOAD changes the screen as follows:

```
[COMMAD] < ..... > ( ? ) Done
```

Entry ⇔ 1

▶ LOAD "ABC2_30"

The number on the upper left corresponds to the number displayed on the left of the screen by using the "CAT" command. Use it to select a file. Display the file to be loaded by using the rotary encoder and press the UNIT deg key. This starts the LOAD operation.

Rotary encoder and shift keys (↑ ↓) ... Used to select files.
UNIT deg key ... Used to start the LOAD operation.


R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.7 Video Plotter Output

4.7 Video Plotter Output

You can output the waveforms on the screen to the video plotter by using the video output on the R4611 rear panel.


To connect R4611 to the video plotter, use the cable exclusively. The video plotter output uses separate signals. The pin numbers and signals of the connector (8-pin DIN connector) are as follows:



Pin No.	Signal
1	V SYNC (Positive)
2	
3	EXT CLOCK (IGM)
4	SEPARATE VIDEO (Positive)
5	
6	GND
7	HSYNC (Positive)
8	

The recommended video plotter is VP-45 (supplied by SEIKO Co., Ltd.) The following shows how to set each switch and volume used with VP-45:


<Setting on lower portion of front panel>



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.7 Video Plotter Output

<Setting DIP Switches on Rear Panel >




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

4.8 Special Functions (f)

4.8 Special Functions (f)

The special functions are usually not used. The special function keys are used for switching of marker point count display and others.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL


5.1 Inspection and Brief Diagnosis

5. INSPECTION AND MAINTENANCE

5.1 Inspection and Brief Diagnosis

If any problem occurs on the R4611E, verify the following inspection items before requesting repairs: When problems cannot be solved despite the inspection, contact our dealer or sales division nearest your place of business. The addresses and telephone numbers of the sales divisions are listed at the end of this manual. We will charge for actions with respect to problems associated with the following inspection items:

Table 5-1 Inspection Items

Condition	Cause	Action taken
R4611E cannot be powered. (The LED on the panel does not come on or the fan motor does not rotate.)	The power cable has not been completely inserted into the connector.	Disconnect the power supply and re-insert the power cable.
	Disconnection of the power fuse	Exchange the power fuse.
Though the LED on the panel lights, the data such as the scale characters is not displayed on the screen.	The display intensity has been set too low.	 Adjust the intensity by pressing these keys.
The normal waveform does not appear.	The selected input is different from that used for the measurement.	Correct the input to the selected level and re-start the measurement.
All keys are disabled.	The GPIB remote control mode has been set.	Stop the program execution and press the LOCAL key.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

5.2 R4611E Storage and Transportation

5.2 R4611E Storage and Transportation

5.2.1 Storing the R4611E

The R4611E must be stored at temperatures between -20°C to $+60^{\circ}\text{C}$. When the R4611E will not be used for a long period, wrap it with a plastic cover or store it in the carbon box and keep it in a dry location not exposed to direct sunshine.

5.2.2 Cleaning CRT Display Filter

Regularly clean the filter protecting the CRT display with a soft cloth soaked in alcohol. Do not soak the cloth with a liquid other than alcohol.

5.2.3 Cleaning CRT Display

Clean the surface of the CRT display filter. If there is any soil inside the filter or on the surface of the CRT display, remove the bezel, using the following procedure, and clean with a soft cloth soaked in alcohol:

- ① Remove the belt cover with a standard-type screw driver.
- ② Remove two screws on the bezel.




Figure 5-1 Removing CRT Filter

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

5.2 R4611E Storage and Transportation

NOTE

To conserve and clean this unit, do not use a solvent that degenerate prastics (ex. organic solvent such as benzene, toluene, and acetone).

5.2.4 Transporting R4611E

To transport the R4611E, use the packing material which came with the unit or the equivalent. If you have lost the material, use a carbon box 5-mm or more in thickness. After wrapping the R4611E in cushioning material, store it in the box and fasten the box with the packing rope.

Insert the yellow floppy disk into the floppy disk drive.

Otherwise, the floppy disk drive may be damaged because of vibration.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

6. PERFORMANCE

- Measure functions

Phase : θ (deg)
Group delay time : τ
Amplitude : A (dB)

(Signal source)

- Frequency

Range : 10 Hz to 300 MHz
Resolution : 10 MHz
Accuracy : $\pm 5 \times 10^{-7}$ /week, $\pm 2 \times 10^{-6}/0^{\circ}\text{C}$ to 40°C

- Output level

Range : +20.0 dBm to -64.9 dBm
Resolution : 0.1 dB
Accuracy : ± 1.0 dB (at 0 dBm, 10 MHz)
Add whichever is higher, +0.02 dB/dB or 0.2 dB
Flatness: : 1.5 dBp-p (-40 dBm or more)
2.0 dBp-p (-40 dBm or less)
Output impedance : 50 Ω
Return loss; 20 dB or more (at +10 dBm or less)
13 dB or more (at +10.1 dBm or less)

- Signal purity

High-frequency strain : ≤ -30 dB or less (at +15 dBm or less)
Non-high frequency spurious : Whichever is higher, < -35 dBc or -70 dBm
(at < 150 MHz, $\leq +15$ dBm)
Whichever is higher, < -30 dBc or -70 dBm
(at ≥ 150 MHz, $\leq +15$ dBm)
Phase noise : < -75 dBc/Hz (10 kHz offset)

- Sweep functions

Sweep parameter : Frequency, Signal level
Maximum sweep range : Frequency; 10 Hz to 300 MHz
Signal level; -64.9 dBm to +20 dBm
(But, frequency of more than 10 kHz is fixed)
Range setting : Start/stop or center/span
Sweep type : Sweep of linear and variable parts (only amplitude sweep)
Sweep trigger : Repeat, single, manual, EXT
Sweep mode : Dual and alternate sweeps of 2 ch
Sweep rate : 1 ms/1 point
Number of measuring point: 3, 6, 11, 21, 51, 101, 201, 301, 601, 1201 points
(Up to 601 points for indication)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

- Output type
Output : Single
- Connector : 50 Ω , BNC

(Analyzer)

- Input characteristics
Input terminal : 1 channels (Ach)
- Input impedance : 50 Ω , 1 M Ω /20PF or less
Return loss; 25 dB or more
Connector; 50 Ω , BNC
- Maximum input level :

	Attenuator 0 dB	Attenuator 20 dB
50 Ω	-20 dBm	0 dBm
1 M Ω	22.4 mV	224 mV

- Input breakdown level : 50 Ω ; +23 dBm or 0 V d.c.
1 M Ω ; 3 V rms or 0 V d.c.
- Cross-talk : 95 dB or more (during input)
- Resolution bandwidth : 1 kHz to 10 Hz (Variable at 1 and 3 steps)
- Noise floor :

Resolution bandwidth	Minimum frequency	Attenuator 0 dB (Maximum input level: -20 dBm)		Attenuator 20 dB (Maximum input level: -20 dBm)	
		Minimum frequency	30 kHz to 300 MHz	Minimum frequency	30 kHz to 300 MHz
10 Hz	100 Hz	-115 dBm	-130 dBm	-95 dBm	-110 dBm
100 Hz	500 Hz	-110 dBm	-125 dBm	-90 dBm	-105 dBm
1 kHz	5 kHz	-100 dBm	-115 dBm	-80 dBm	-95 dBm

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

6. PERFORMANCE

Automatic offset correction:

Normalize function; Removal of frequency characteristic in measurement system
 Electrical length correction; Equivalent electric length or delay time can be added to measured phase and group delay time.
 Range; -3×10^8 m to $+3 \times 10^8$ m or +1 s to -1 s

- Amplitude characteristic

Measuring range : Absolute amplitude; ATT = 0 dB -20 dBm to -130 dBm
 ATT = 20 dB 0 dBm to -110 dBm

Amplitude resolution : Amplitude ratio; 0 \pm 130 dB
 Accuracy : 0.001 dB
 (At 10 MHz, 25°C \pm 5°C, and maximum input level)

Frequency response : Absolute value measurement (R, A, B); \pm 0.5 dB
 Specific measurement (A/R, B/R, A/B); \pm 0.5 dB
 : When 50 Ω impedance is input
 Absolute value measurement (R, A, B)
 50 Ω input; 1 dBpp (10 Hz to 100 MHz)
 2 dBpp (100 MHz to 300 MHz)
 1M Ω input; 1.5 dBpp (10 Hz to 100 MHz)

Dynamic accuracy :
 0 to -10 dB \pm 0.04 dB
 -10 to -50 dB \pm 0.02 dB
 -50 to -60 dB \pm 0.05 dB
 -60 to -70 dB \pm 0.15 dB
 -70 to -80 dB \pm 0.40 dB
 -80 to -90 dB \pm 0.80 dB

- Phase characteristic

Measuring range : \pm 180° (Long display function enables continuous display.)
 Phase resolution : 0.01°
 Accuracy : \pm 2° (At 1 MHz, 25°C \pm 5°C, and maximum input level) Not included in specifications

Frequency response : (When damping quantity is the same)
 50 Ω input; 5° pp
 (10 Hz to 100 MHz) Not included in specifications.
 15° pp (100 MHz to 300 MHz)
 1 M Ω input; 10° pp
 (10 Hz to 100 MHz)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

Dynamic accuracy	:	0 to -10 dB	$\pm 0.4^\circ$
		-10 to -50 dB	$\pm 0.2^\circ$
		-50 to -60 dB	$\pm 0.5^\circ$
		-60 to -70 dB	$\pm 1.5^\circ$
		-70 to -80 dB	$\pm 4.0^\circ$
		-80 to -90 dB	$\pm 8.0^\circ$

- Characteristic of group delay time (effective for linear frequency sweep, specific measurement, and 50 Ω input)

Range : Solved by the following expression

$$= \frac{\Delta \phi}{360 \times \Delta f}$$

$\Delta \phi$ Phase

Δf Aperture frequency (Hz)

Measuring range : 1 ps to 250 s

Group delay time resolution:

1 ps

Aperture frequency : Equivalent to Δf , and can be set up to 20% of frequency span

Accuracy : $\frac{\text{Phase accuracy}}{360 \times \text{aperture frequency (Hz)}}$

(Display)

- Display

CRT : 7-inch monochromatic raster scan system

Resolution : 800 x 512 dots

Display mode : Right-angle log, linear coordinate, polar coordinate, Smith chart (Z, Y)

- Display control

CRT format : Double display of single and 2 channels, enlarged scale display, 2 channel separate display

Measuring condition display:

Display of Start/stop, center/span, scale/DIV, standard level, marker value, soft key function, warning message, etc.

Label : Up to 45 characters can be input.

Brightness : CRT brightness can be adjusted

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

(Others)

- Marker function

- Correction marker : Two modes, displaying data at measured frequency points to read a marker point and displaying values solved with interpolation at proper frequency.
- Multiple marker : 10 markers independent of channels respectively.
- Marker track : Marker search operates track function each sweep.
- Marker couple : Channel markers can be set as both combined or independent types.

Designated block analysis:

- Enables marker search of blocks specified by a Δ marker.
- Target research : Enables searches of bandwidth at KdB DOWN point, solution of Q, phase zero degree, and \pm X degree.
- MKT \rightarrow : MKR \rightarrow reference value, MKR \rightarrow START, MKR \rightarrow STOP, MKR \rightarrow CENTER, MKR \rightarrow Δ SPAN
- MKR search : MAX search, MIN search, NEXT MAX search
- MKR/ Δ MKR : Solution of Δ marker mode, ripple value

- System function

- Error corrective function

- Normalize : Correction of frequency response (both amplitude and phase) for transmission measurement.
- 1 port calibration : Correction of bridge direction for measuring reflection, frequency response, and errors by source match. Correction of error requires short, open, and load.
- Data averaging : Data (vector value) is averaged every sweep. An averaging factor can be set, ranging from 1 to 428.

- Instrument state function

- Save/recall : Using a save key, the system settings can be stored in a floppy disk. Stored settings can be recalled using a recall key. Settings contain setting conditions, limit lines, and indication label. With the help of power-off saving function, the system is set to state directly before power-off when the power is on.
- Data save/data recall : Using a standard floppy disk, several kinds of data (RAM data and CAL data) can be stored.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

- Connection to external equipment
 - COPY : Using GPIB, a compatible digital plotter and printer, printouts such as graphic hard copy and a data list can be output from the main unit without an external controller.
 - Output signal for a video plotter:
 - Separate signal
 - GPIB data output remote control
 - 8 bit input/output : TTL level
 - RS232C : Serial output conforms to RS232C

- Programming function
 - Built-in BASIC controller function:
 - With built-in controller function, this main unit and other instrumentation equipped with the GPIB interface function can be controlled by the program prepared using the main unit.
 - Built-in FDD function : Disk capacity; 1M byte (for unformat)
 - ; 750K bytes (for format)
 - Type of media; 3.5 inch double-side double-density
 - Built-in function : Maximum value (response);
 - MAX (Starting point, end point, measuring channel)
 - Maximum value (frequency);
 - FMAX (Starting point, end point, measuring channel)
 - Minimum value (response);
 - MIN (Starting point, end point, measuring channel)
 - Minimum value (frequency);
 - FMIN (Starting point, end point, measuring channel)
 - Bandwidth; BND (Specified measured value, specified damping quantity)
 - Cut-off frequency (low limit value);
 - BNDL (Specified measured value, specified damping quantity)
 - Cut-off frequency (high limit value);
 - BNDH (Specified measured value, specified damping quantity)
 - Ripple 1; RPL 1 (Starting point, and point, differential coefficient X differential coefficient Y, measuring channel)
 - Ripple 2; RPL 2 (Starting point, and point, differential coefficient X differential coefficient Y, measuring channel)

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

6. PERFORMANCE

Ripple 3; RPL 3 (Starting point, and point, differential coefficient X differential coefficient Y, measuring channel)
Maximum value (N, response value);
VRPLHN (N maximum value specification, measuring channel)
Maximum value (N, frequency value);
FRPLHN (N maximum value specification, measuring channel)
Minimum value (N, response value);
VRPLLN (N maximum value specification, measuring channel)
Minimum value (N, frequency value);
FPPLLN (N maximum value specification, measuring channel)
Limit test 1; LMTUL 1 (Uninspected data, upper limit value, lower limit value)
Limit test 2; LMTUL 2 (Uninspected data, upper limit value, lower limit value)
Measuring point; POINT 1 (Specified measuring point, measuring channel)
Measuring response value; VALUE (Specified frequency, measuring channel)
Corrective measuring response value;
CVALUE (Specified measuring point, measuring channel)

- General specification

External trigger : BNC, TTL level, LOW enable
External reference frequency input:
Frequency; 1, 2, 5, 10 MHz
Connector; BNC
Input level range; 0 to 20 dBm
Reference frequency output:
Frequency; 10 MHz 0 dBm or more
Connector; BNC
Using range : FDD in use; +5°C to 40°C, 85% or less
FDD unused; 0°C to 40°C, 85% or less
Storing range : -20°C to 60°C
Power : 100, 120, 220, 240 V \pm 10%
48 Hz to 66 Hz
330 VA or less
Outside dimension : About 424 (W) x 220 (H) x 500 (D) mm
Weight : About 30 kg or less

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

7. EXPLANATION OF OPERATION

7. EXPLANATION OF OPERATION

Figure 7-1 shows the outline of R4611E block diagram.

<Source>

10 Hz to 300 MHz output signals synthesized, 400.25 MHz to 780.25 MHz synthesizer and 480.25 MHz fixed oscillator output signals are output from OUTPUT 1 or OUTPUT 2.

<Receiver>

Input signals at 10 Hz to 300 MHz are converted to 1st IF signal at 250 MHz with a 1st mixer, and are output to a 2nd mixer. The 1st IF signal is converted to a 2nd IF signal at 10 kHz with the 2nd mixer, and is output to S/H & A/D circuits. Data converted into A/D is processed under high speed in DSP, and is synthesized to a video signal in a display circuit, then is displayed on the CRT.





Figure 7-1 Outline of R4611E Block Diagram

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus

APPENDIX

A.1 Software key menu




A.1.1 MEASUREMENT

(1) INPUT MEAS

• For standard R4611E


• For R4611E with S parameter



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

A.1 Soft Key Menus

(2) FORMAT




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL


A.1 Soft Key Menus

(3) SCALE REF

- When FORMAT is LOG MAG, PHASE, DELAY




- When FORMAT is SMITH, ROLAR



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus


(4) DISP




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

A.1.2 SOURCE

(1) MENU




(2) SWEEP




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

A.1.3 RECEIVER

(1) IMP/ATT




(2) RESOLN BW



A.1.4 MARKER


(1) MKR ΔMKR

• When FORMAT is not indicated by SMITH and POLAR chart.



- *1: This software key menu is not displayed Cw Sweep.
- *2: This software key menu is not displayed for Level Sweep.
- *3: This software key menu is not displayed when an interval is not specified in ΔMODE or FORMAT is not LOG MAG or G. DELAY.
- *4: This software key menu is not displayed when FORMAT is not LOG MAG.


• When FORMAT is indicated by SMITH and POLAR chart.



*1: This software key menu is not displayed for Cw Sweep.


*2: This software key menu is not displayed for Level Sweep.

*3: When FORMAT is SMITH:
When FORMAT is POLAR:



*4: This software key menu is not displayed when FORMAT is POLAR.

● When parameter conversion is ON.



*1: This software key menu is not displayed for Cw Sweep.

*2: This software key menu is not displayed for Level Sweep.


*3: This software key menu is not displayed for DEFAULT.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus

(2) MKR SRCH


- When FORMAT is LOG MAG.



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus


- When FORMAT is LOGMAG, PHASE, or PHASE (-∞, +∞).



R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus

- When FORMAT is not LOGMAG, PHASE, and PHASE (-∞, +∞).




*1: For key, the menu is not displayed for Cw Sweep.

*2: This software key menu is not displayed when FORMAT is not G. DELAY.

(3) MKR

- When FORMAT is not LOG MAG, or LIN MAG



*1: This software key menu is not displayed for Cw Sweep.

*2: For Level Sweep, the menu becomes MARKER.


*3: This software key menu is not displayed when FORMAT is SMITH and POLAR.

*4: This software key menu is not displayed when the waveform is not DATA & Memory.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus

- When FORMAT is LOG MAG, and LIN MAG, and waveform display is DATA only.



*1: This software key menu is not displayed for Cw Sweep.


*2: For Level Sweep, the menu becomes MARKER →
XXXXXX L .

*3: This software key menu is not displayed when FORMAT is SMITH and POLAR.

R4611E
 NETWORK ANALYZER
 INSTRUCTION MANUAL

A.1 Soft Key Menus

- When FORMAT is LOG MAG, and LIN MAG, and waveform display is DATA only.



*1: This software key menu is not displayed for Cw Sweep.

*2: For Level Sweep, the menu becomes


MARKER →
XXXXXX L.

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL


A.1 Soft Key Menus

A.1.5 CAL and AVG

(1) CAL



(2) AVG




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

A.1 Soft Key Menus


A.1.6 GPIB

(1) LOCAL



A.1.7 INSTRUMENT STATE


(1) SAVE




R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

(2) RECALL


RECALL



(3) COPY



(4) f



R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

List of Figures

LIST OF FIGURES


No.	Title	Page
1-1	Structure of This Manual	1 - 2
1-2	Power Cable Plug and Adapter	1 - 7
1-3	Replacing Fuse	1 - 7
2-1	Reading CRT Display	2 - 4
2-2	Filter Characteristics Waveform Trace	2 - 10
2-3	Sample Measurement of Insertion Loss	2 - 11
3-1	Front Panel	3 - 2
3-2	Rear Panel	3 - 3
3-3	Structure of Software Key Menu	3 - 4
4-1	External View of DIP Switches	4 - 13
4-2	Connector Internal Pin Assignment and Signals	4 - 23
5-1	Removing CRT Filter	5 - 2
7-1	Outline of R4611E Block Diagram	7 - 1

R4611E
NETWORK ANALYZER
INSTRUCTION MANUAL

List of Tables

LIST OF TABLES


<u>No.</u>	<u>Title</u>	<u>Page</u>
1-1	R4611E Standard Accessory List	1 - 5
1-2	Power Voltage	1 - 6
4-1	DSW1 Functions	4 - 14
4-2	DSW2 Functions	4 - 15
5-1	Inspection Items	5 - 1




SIDE VIEW

Unit:mm


**R4611E
EXTERNAL VIEW**




FRONT VIEW



REAR VIEW



R4611E FRONT VIEW



R4611E REAR VIEW

ADVANTEST®
ADVANTEST CORPORATION

**INSTRUCTION
MANUAL**
R4611E
NETWORK ANALYZER
(Programming)

MANUAL NUMBER (OEG01 9002)

Before reselling to other corporations or re-exporting to other countries, you are required to obtain permission from both the Japanese Government under its Export Control Act and the U.S. Government under its Export Control Law.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

Table of Contents

TABLE OF CONTENTS

1. OUTLINE	1 - 1
1.1 How to Use This Manual	1 - 1
1.2 GPIB Modes	1 - 2
2. REMOTE CONTROL BY GPIB EXTERNAL CONTROLLER	2 - 1
2.1 Outline	2 - 1
2.2 GPIB Functions	2 - 2
2.3 GPIB Addressing	2 - 3
2.4 GPIB Input and Output Formats	2 - 4
2.4.1 Outline	2 - 4
2.4.2 Permissible Input Characters	2 - 4
2.4.3 Input Formats	2 - 5
2.4.4 Output Formats	2 - 6
2.4.5 GPIB Program Code Table	2 - 6
2.5 Service Request	2 - 23
2.6 Program Examples	2 - 24
2.6.1 Program for Determining Difference between Very Large and Very Small Points within Same Specified Frequencies, and Maximum Value of Difference Between Adjacent Inflection Points	2 - 24
2.6.2 Trace Data Input/Output	2 - 26
2.6.3 SRQ	2 - 28
2.6.4 Starting BASIC from External Controller	2 - 29
2.6.5 Program Example Using External Controller or Built-in BASIC	2 - 32
2.6.6 X'TAL FILTER Measuring Program Example	2 - 34
2.6.7 Example of Measuring Program Using Parallel I/O Ports	2 - 37
2.6.8 Example of Program Where Limited Test Function Is Used in Low-pass	2 - 41
3. CONTROL MODE	3 - 1
3.1 Outline	3 - 1
3.2 Setting Controller Mode	3 - 2
3.3 Handling Floppy Disks	3 - 3
3.4 File Management	3 - 7
3.4.1 Outline	3 - 7
3.4.2 Saving and Recalling Programs	3 - 7
3.4.3 Floppy Disk Management (Initialization)	3 - 7
3.4.4 File Management CAT and CHKDSK	3 - 8
3.4.5 File Storage SAVE "File Name"	3 - 8
3.4.6 File Recalling LOAD "File Name"	3 - 8
3.4.7 File Deletion PURGE "File Name"	3 - 8
3.4.8 File Name Change RENAME "Old File Name" "New File Name" ..	3 - 8
4. BASIC PROGRAMMING	4 - 1
4.1 Outline	4 - 1
4.2 Activation of Program Mode	4 - 2

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

Table of Contents

4.3 Editor Mode Activation	4 - 4
4.4 Program Editor Keys	4 - 5
4.5 Program Editing	4 - 9
4.6 Programming Rules	4 - 11
4.6.1 Program Architecture	4 - 11
4.6.2 Objects	4 - 13
4.6.3 Operational Expressions	4 - 20
5. COMMAND AND STATEMENT SYNTAX AND COMMENTARY	5 - 1
5.1 Outline	5 - 1
5.2 List of Commands and Statements	5 - 2
5.3 BASIC Command Syntax	5 - 4
5.4 R4611E BASIC Statement Syntax	5 - 27
5.5 R4611E BASIC GPIB Control Statement Syntax and Activity	5 - 69
5.6 Syntax of the R4611E Network Analyzer BASIC File Control Statement	5 - 85
6. LIST OF BUILT-IN FUNCTIONS	6 - 1
6.1 Outline	6 - 1
6.2 List of R4611E Built-in Functions	6 - 2
6.2.1 Stimulus Frequency No. of Measurement Points	6 - 5
6.2.2 Measurement Point No. → Stimulus Frequency	6 - 6
6.2.3 Measurement Point No. → Response Value	6 - 7
6.2.4 Stimulus Frequency Response Value	6 - 8
6.2.5 Functions Which Include Search Functions	6 - 9
LIST OF FIGURES	F - 1
LIST OF TABLES	T - 1

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

1.1 How to Use This Manual

1. OUTLINE

The purpose of this programming manual is to describe the procedures for controlling the R4611E Network Analyzer and external peripherals using the analyzer's GPIB remote control and built-in BASIC controller functions.

R4611E includes the IEEE standards 488-1978 metering bus GPIB (General Purpose Interface Bus) as a standard feature to enable remote control by external controller. And using the controller functions and functions included in the built-in BASIC language, device characteristics can be tested at high speed, and small-scale GPIB systems can be readily constructed.

1.1 How to Use This Manual

This programming manual describes the controller handling procedures, plus the GPIB remote control operating procedures and BASIC programming for users who already have a certain amount of knowledge and experience in programming with the BASIC language.

R4611E can be remote controlled by any of the following three methods.

- ① Remote control by external controller
- ② Activation of built-in BASIC programming functions, and exchange data with an external controller while controlling the analyzer.
- ③ Activation of built-in BASIC programming functions, and controlling external devices and the analyzer itself as the GPIB controller.

Method ① is described in chapter 2, and methods ② and ③ are covered in chapters 3, 4, and 5.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.1 Outline

2. REMOTE CONTROL BY GPIB EXTERNAL CONTROLLER

2.1 Outline

GPIB is an interface system designed to connect measuring equipment to the controller and peripheral devices by simple cable connections. In comparison to more conventional interface systems, GPIB features greater expandability, plus electrical, mechanical, and functional compatibility with other equipment and other brands.

The GPIB system includes three roles - controller, TALKER, and LISTENER, and when controlled by an external GPIB controller, R4611E retains the TALKER and LISTENER functions.

CAUTION

When a BASIC program is run in TALKER/LISTENER mode, settings cannot be made by GPIB command from the external controller (due to priority given to BASIC enter and output commands). To make settings by GPIB command from external controller, the BASIC program must first be stopped.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.2 GPIB Functions


2.2 GPIB Functions

SH1: Source handshake function
AH1: Accept handshake function
T6 : Basic TALKER function, serial polling function, and TALKER function
cancellation by LISTENER designation
TE0: No expanded TALKER function
L4 : Basic LISTENER function, and LISTENER function cancellation by
TALKER designation
LE0: No expanded LISTENER function
SR1: Service request function
RL1: Remote function, local function, local lockout function
PP0: No parallel polling function
DC1: Device clear function
DT1: Device trigger (when in hold mode)
C0 : No controller function (when in TALKER/LISTENER mode)
C1 : System controller function (when in controller mode)
E1 : Use open collector bus driver

2.3 GPIB Addressing

GPIB Handling Procedures

When the LOCAL key is pressed and the GPIB address is selected, the following soft key menu is displayed.



- GPIB address is set when the R4611E key is pressed. GPIB address can be set to any value from 0 to 30. Following input of a number by the relevant numeric key, the GPIB address is set by pressing the deg keys.
- The plotter GPIB address is set by pressing the PLOTTER key. Plotter address can be set to any value from 0 to 30. Following input of a number by the relevant numeric key, the plotter address is set by pressing the dey keys. (This address is only valid when in system controller mode.)

NOTE

- Do not specify the same address as the GPIB address for an external controller and other connected devices.
- The address specified here is the address for controlling R4611E by using an external controller. The address for controlling R4611E by built-in BASIC program is fixed at "31".

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

2.4 GPIB Input and Output Formats

2.4.1 Outline

An external GPIB controller can be used to read setting conditions. The method for reading these conditions involves input of "?" after the R4611E GPIB setting code. If R4611E is then specified as TALKER, output of the requested data or code is obtained.

The output data or code can be in either of two formats.

- ① If data setting of the function indicating the setting code is possible, the output format is as described later.
- ② Where data setting is not possible, an output format of 1/0 is used for data or code expressed as yes or no.

Examples: (1) OUTPUT 701; "STARTF?"
ENTER 701;F

Input of a code called "STARTF" (start frequency) followed by "?" results in output of the value of the start frequency from R4611E.

(2) OUTPUT 701; "AVERAGE?"
ENTER 701;A

In a case where "AVERAGE" ON/OFF is to be confirmed, the output is "1" if ON, and "0" if OFF.

2.4.2 Permissible Input Characters

Although ASCII characters are recognized by R4611E, all those apart from the characters listed below are disregarded in normal operations except label input mode.

- ① Upper case alphabetic characters
- ② Numeric characters
- ③ Decimal point
- ④ + or -
- ⑤ , (comma)
- ⑥ ; (semi colon)
- ⑦ CR (carriage return) Recognized only as GPIB delimiter

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

- ⑧ LF (line feed) Recognized only as GPIB delimiter

All leading zeros are disregarded. 000208640 → 208640

All lower case characters are disregarded.

STARTFrequency1MHz → STARTF1MHZ

Numeric character inputs may include decimal point and exponential expressions.

0 thru 9 Mantissa may include sign and up to 17 significant digits.

. + -

E Exponential part may include sign and one or two significant digits.

2.4.3 Input Formats

- (1) General Format

[Code][Additional code][Data][Unit][Terminator]

- ① [Code]

Basic R4611E mnemonics

- ② [Additional Code]

Designation used for switches qualifying basic mnemonic or to indicate one of several types.

- ON/OFF
- Integer value which selects one of several types

- ③ [Data]

Data set in function specified by code

- Numeric value (ASCII)
Integer : 278 etc.
Real number: 278.0, -256.8E+2 etc.
- Character string (ASCII)
String enclosed between double quotation marks: "278" etc.

- ④ [Unit]

All data must have a unit.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

⑤ [Terminator]

Any of the following four types can be specified.

(CR) (LF) + EOI

(LF)

Final byte + EOI

(CR) (LF) Initial status type

(2) Input Format Types

① TYPE1: [Code][Terminator]

② TYPE2: [Code][Additional code][Terminator]

③ TYPE3: [Code][Data][Unit][Terminator]

④ TYPE4: Enquiry type: [Code][?]

2.4.4 Output Formats

① Numeric Values (integers) in ASCII Code

② Floating Decimal Point Numeric Values in ASCII Code

+D. DDDDDDDDDDDDDDE+DD

Total number of characters 22

Mantissa sign - (minus) Blank (plus)

One digit (mantissa and number of digits to left of decimal point) +
decimal point + 15 digits (mantissa and number of digits to right of
decimal point)

E Exponent

Exponential part sign - (minus) Blank (plus)

Two digits exponential part

Example: 1.123456789012345E+08

NOTE

Although there is no unit code output, an internal basic unit is
used.

Hz, V, dB, m, Sec, Unit, div, %, °, etc.

2.4.5 GPIB Program Code Table

R4611E is controlled by built-in BASIC program or external GPIB
controller using the following codes.

When controlling R4611E using BASIC in TALKER/LISTENER mode, No.31 is
used as shown in the following examples.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

OUTPUT 31;
ENTER 31;

For input or output to/from an 8-bit parallel port, No.32 is used as shown below.

OUTPUT 32;
ENTER 32;

The method for reading the GPIB code table is outlined in Table 2-1. The method for reading the GPIG program code table is outlined in Table 2-2.

Table 2-1 How to Read the GPIB Code Table

Item	Function
Code	Program setting code
Contents	Code function
Description format	Input format [t] : [Code][Terminator] [s] [t] : [Code][Additional code][Terminator] [d] [u] [t]: [Code][Data][Unit][Terminator] Additional code ON or OFF (ASCII) Numeric value (ASCII) (ASCII) Data (ASCII) Terminator GPIB terminator (CR, LF)
Response format	Response to enquiry about setting condition 1, 0: ON/OFF or YES/NO D : Data D → Numeric value [] contents s Data on horizontal axis : FORMAT valid in all modes r Data on vertical axis : FORMAT valid in all modes i Data on vertical axis (AUX) : FORMAT valid only when Smith or Polar or when parameter conversion is ON lc ... L[H] or C[F] : FORMAT valid only when Smith C Operation data The i and lc values are not returned if FORMAT setting is not valid. When partitioned by a comma (,) such as D(s,r), the output is also partitioned by comma in the GPIB.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (1/14)

Item	Code	Contents	Descriptive format	Response format
- ACTIVE CHANNEL - See section 2.3.1 of main instruction manual for description of basic functions.				
CHANNEL	CH1 CH2	CH1 active CH2 active	[t] [t]	1, 0 1, 0
- INPUT MEASURE - See section 3.3.5 of main instruction manual for description of basic functions.				
INPUT PORTS	AIN	A	[t]	1, 0
PARAMETOR CONVERSION	CONVRZ	Z (Reflection)	[t]	1, 0
	CONVRY	Y (Reflection)	[t]	1, 0
	CONVOFF	OFF	[t]	1, 0
	SETZ0	Z0	[d][u][t]	D
- FORMAT - See section 3.3.6 of main instruction manual for description of basic functions.				
FORMAT	LOGMAG PHASE DELAY SRJX SGJB POLAR LINMAG REAL IMAG UNWRAP	Log Mag Phase Delay Smith (R+jX) Smith (G+jB) Polar Lin Mag Real Imag Phase ($-\infty$, $+\infty$)	[t] [t] [t] [t] [t] [t] [t] [t] [t] [t]	1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0
- GROUP DELAY APERTURE - See section 3.3.6 of main instruction manual for description of basic functions.				
APERTURE	APERTP	Data Entry	[d] [u] [t]	D(%)
- SCALE REF. - See section 3.3.8 of main instruction manual for description of basic functions.				
SCALE	AUTO SDIV	Auto Scale /Division	[t] [d] [u] [t] D(r)
REFERENCE	REFV	Ref. Value	[d] [u] [t]	D(r)
	REFP	Ref. Position	[d] [u] [t]	D(%)
	REFL	Ref. Line on/off	[s] [t]	1, 0
UP SCALE	UPSCAL	on/off	[s] [t]	1, 0

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (2/14)

Item	Code	Contents	Descriptive format	Response format
- DISPLAY -		See section 3.3.7 of main instruction manual for description of basic functions.		
CHANNEL	DUAL SPLIT	Dual on/off Split on/off	[s] [t] [s] [t]	1, 0 1, 0
GRATICULE	GRAT	Graticule on/off	[s] [t]	1, 0
CRT	INTENS	Intensity	[d] [u] [t]	D
DISPLAY	DISPDATA DISPDM DTOM	Data Data & Memory Data to Memory	[t] [t] [t]	1, 0 1, 0 1, 0 *2
DATA/MEM	DISPDDM	on/off	[s] [t]	1, 0 *6
LABEL	LABEL	LABEL	[strings] [t]	... *8
- SOURCE -		See section 3.3.1 of main instruction manual for description of basic functions.		
FREQUENCY	STARTF STOPF CENTERF SPANF	Start freq. Stop freq. Center freq. Span freq.	[d] [u] [t] [d] [u] [t] [d] [u] [t] [d] [u] [t]	D(s) D(s) D(s) D(s)
OUTPUT PORTS	PORT1	Output port1	[t]	1, 0
OUTPUT LEVEL	OUTLEV	Output level	[d] [u] [t]	D(r)
FREQ.STEP	FSTPA FSTPM	Freq. step auto Freq. step manual	[t] [t]	1, 0 1, 0
STEP SIZE	FRQSTP	Freq. step	[d] [u] [t]	D(s) *1
- SWEEP -		See section 3.3.2 of main instruction manual for description of basic functions.		
TIME	STIME	Sweep time	[d] [u] [t]	D(t)
TYPE	COUPLE LINFREQ LOGFREQ CW LEVEL	Couple on/off Lin freq. Log freq. CQ Level sweep	[s] [t] [t] [t] [t] [t]	1, 0 1, 0 1, 0 1, 0 1, 0

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (3/14)

Item	Code	Contents	Descriptive format	Response format
POINTS	PARTIAL (VARIABLE)	PARTIAL on/off	[s] [t]	1, 0
	USRSWP	User sweep	[d] [v] [t]	1, 0
	M1201P	1201 Points	[t]	1, 0
	M601P	601 Points	[t]	1, 0
	M301P	301 Points	[t]	1, 0
	M201P	201 Points	[t]	1, 0
	M101P	101 Points	[t]	1, 0
	M51P	51 Points	[t]	1, 0
	M21P	21 Points	[t]	1, 0
	M11P	11 Points	[t]	1, 0
TRIGGER	M6P	6 Points	[t]	1, 0
	M3P	3 Points	[t]	1, 0
	FREE	Internal	[t]	1, 0
MODE	LINE	Line	[t]	1, 0
	EXTERN	External	[t]	1, 0
	CONT	Continue	[t]	1, 0
RESTART	SINGLE	Single	[t]	1, 0
	SWPHLD	Sweep HOLD	[t]	1, 0
	MEAS	Restart	[t]	... *3
- PARTIAL SWEEP DATA ENTRY -		See section 3.3.2 of main instruction manual for description of basic functions. *4		
PARTIAL SWEEP DATA ENTRY	PSEGCL	Segment clear	[t]	1, 0
	PSEG	Segment No.	[d] [u] [t]	D *5
	PSTART	Start freq.	[d] [u] [t]	D(s)
	PSTOP	Stop freq.	[d] [u] [t]	D(s)
- USER SWEEP DATA ENTRY -		See section 3.3.2 of main instruction manual for description of basic functions. *4		
USER SWEEP DATA ENTRY	USEGCL	Segment clear	[t]	1, 0
	USEG	Segment No.	[d] [u] [t]	D *5
	USTART	Start freq.	[d] [u] [t]	D(s)
	USTOP	Stop freq.	[d] [u] [t]	D(s)
	UFREQ	Freq.	[d] [u] [t]	D(s)
	UPOINT	Point.	[d] [u] [t]	D
- LEVEL SWEEP DATA ENTRY -		See section 3.3.2 of main instruction manual for description of basic functions.		

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (4/14)

Item	Code	Contents	Descriptive format	Response format
LEVEL SWEEP DATA ENTRY	STLEVEL SPLEVEL	Start level Stop level	[d] [u] [t] [d] [u] [t]	D(r) D(r)
CW FREQUENCY	CWFREQ	CW Frequency	[d] [u] [t]	D(s)
- RECEIVER - See sections 3.3.3 and 3.3.4 of main instruction manual for description of basic functions.				
IMPEDANCE ATTENUATOR	AI50A20	A50 Ω , 20 dB	[t]	1, 0
	AI50A0	A50 Ω , 0 dB	[t]	1, 0
	AI1A20	A1 M Ω , 20 dB	[t]	1, 0
	AI1A0	A1 M Ω , 0 dB	[t]	1, 0
RBW	RBW1KHZ	1 KHz	[t]	1, 0
	RBW300HZ	300 Hz	[t]	1, 0
	RBW100HZ	100 Hz	[t]	1, 0
	RBW30HZ	30 Hz	[t]	1, 0
	RBW10HZ	10 Hz	[t]	1, 0
CLEAR TRIP	CLRTRIP	Clear trip	[t]	...
- CW SWEEP DATA ENTRY -				
CW freq.	CWF		[d] [u] [t]	D(s)
- AVERAGE - See section 3.3.12 of main instruction manual for description of basic functions.				
AVERAGING	AVERAGE	off	[s] [t]	1, 0
	AVR2	2	[t]	1, 0
	AVR4	4	[t]	1, 0
	AVR8	8	[t]	1, 0
	AVR16	16	[t]	1, 0
	AVR32	32	[t]	1, 0
	AVR64	64	[t]	1, 0
	AVR128	128	[t]	1, 0
- CALIBRATION - See section 3.3.13 of main instruction manual for description of basic functions.				
CALIBRATION 1PORT FULL CAL	CORRECT	Correction on/off	[s] [t]	1, 0 *7
	OPEN	Open	[t]	... *12
	SHORT	Short	[t]	... *12
	CLEAR	Clear	[t]

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (5/14)

Item	Code	Contents	Descriptive format	Response format
ELECTRICAL LENGTH	DONE	Done	[t] *12
	LOAD	Load	[t] *12
	NORM	Normalize on/off	[s] [t]	1, 0
	LENGTH	on/off	[s] [t]	1, 0
	LENGVAL	Value	[d] [u] [t]	D(1)
- MKR/D MKR -		See section 3.3.9 of main instruction manual for description of basic functions.		
MARKER NUMBER	MKR1A	Marker # 1	[d] [u] [t]	D(s,r,i,lc) *30
	MKR2A	Marker # 2	[d] [u] [t]	D(s,r,i,lc) *30
	MKR3A	Marker # 3	[d] [u] [t]	D(s,r,i,lc) *30
	MKR4A	Marker # 4	[d] [u] [t]	D(s,r,i,lc) *30
	MKR5A	Marker # 5	[d] [u] [t]	D(s,r,i,lc) *30
	MKR6A	Marker # 6	[d] [u] [t]	D(s,r,i,lc) *30
	MKR7A	Marker # 7	[d] [u] [t]	D(s,r,i,lc) *30
	MKR8A	Marker # 8	[d] [u] [t]	D(s,r,i,lc) *30
	MKR9A	Marker # 9	[d] [u] [t]	D(s,r,i,lc) *30
	MKR10A	Marker #10	[d] [u] [t]	D(s,r,i,lc) *30
	MARKER OFF	MKRAOF	Marker all off	[t]
MKROFF		Active marker off	[t]
MARKER TO MEM	MKR10F	Marker # 1 off	[t]	1, 0
	MKR20F	Marker # 2 off	[t]	1, 0
	MKR30F	Marker # 3 off	[t]	1, 0
	MKR40F	Marker # 4 off	[t]	1, 0
	MKR50F	Marker # 5 off	[t]	1, 0
	MKR60F	Marker # 6 off	[t]	1, 0
	MKR70F	Marker # 7 off	[t]	1, 0
	MKR80F	Marker # 8 off	[t]	1, 0
	MKR90F	Marker # 9 off	[t]	1, 0
	MKR100F	Marker #10 off	[t]	1, 0
MARKER TO MEM	MKRATOM	All to memory	[t] *13
	MKRTOM	Active marker to data	[t] *13
- MKR/D MKR -		See section 3.3.9 of main instruction manual for description of basic functions.		
MARKER TO DATA	MKRATOD MKRTOD	All to data Active marker to data	[t] [t]

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (6/14)

Item	Code	Contents	Descriptive format	Response format
COMPENSATE	MKRCMP	Compensate	[t]	1, 0
	MKRUCMP	Uncompensate	[t]	1, 0
COUPLE	MKRCOUP	Coupled	[t]	1, 0
	MKRUCOUP	Uncoupled	[t]	1, 0
SMITH MKR	SMKRLIN	Lin marker	[t]	1, 0
	SMKRLOG	Log marker	[t]	1, 0
	SMKRRI	Re/Im marker	[t]	1, 0
	SMKRRX	R+jX marker	[t]	1, 0
	SMKRGB	G+jB marker	[t]	1, 0
POLAR MKR	PMKRLIN	Lin marker	[t]	1, 0
	PMKRLOG	Log marker	[t]	1, 0
	PMKRRI	Re/Im marker	[t]	1, 0
IMPEDANCE MARKER	ZYMKDFLT	Default marker	[t]	1, 0
	ZYMKLIN	Lin marker	[t]	1, 0
	ZYMKRI	Re/Im marker	[t]	1, 0
	ZYMKLC	LC on/off	[S] [t]	1, 0
Smith Marker impedance ZO	MKRZ050	smith MKR ZO=50	[t]	1, 0
	MKRZ075	smith MKR ZO=75	[t]	1, 0
REFERENCE	DMKRC	REF = MKR	[t], [d] [u] [t]	1, 0
	DMKRR	REF = REF.POSN	[t], [d] [u] [t]	1, 0
	DMKRA	Active marker	[t], [d] [u] [t]	1, 0 *14
	DMKRF	REF = FIXED.MKR	[t], [d] [u] [t]	1, 0 *15
MODE OFF	DMKROF	mode off	[t]	1, 0
FIXED MKR	FMKRS	Stimulus value	[t]	1, 0 *16
	FMKRV	Value	[d] [u] [t]	D(r) *16
	MKRFIX	FIXED.MX ACT.M POSN.	[t] *16
RIPPLE	DRIPPL1	ripple 1	[t]	D(r) *17 18
	DRIPPL2	ripple 2	[t]	D(r) *17 18
	DLTX	x	[d] [u] [t]	D(s)
	DLTY	y	[d] [u] [t]	D(r)
	DMAXMIN	max-min	[t]	D(r) *17 18
	DRIPOFF	off	[t]	1, 0

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (7/14)

Item	Code	Contents	Descriptive format	Response format
- MKR/D MKR -		See section 3.3.9 of main instruction manual for description of basic functions.		
Δ'S OFFSET	DMKR10	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR20	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR30	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR40	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR50	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR60	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR70	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR80	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR90	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
	DMKR100	Multi MKR Δ	[t], [d] [u] [t]	1, 0 *19
- MARKER SEARCH -		See section 3.3.10 of main instruction manual for description of basic functions.		
SEARCH	MAXSRCH	Max search	[t]	D(s,r,i,lc)*24,31
	MINSRCH	Min search	[t]	D(s,r,i,lc)*24,31
	SRCHOFF	Search off	[t]
	LMAXSRC	Next max SRCH	[t]	D(s,r,i,lc)*24,31
	LMINSRC	Next min SRCH	[t]	D(s,r,i,lc)*24,31
TARGET	TREFMAX	ΔRef.=max	[t]	1, 0 *16
	TREFREF	ΔRef.=Ref	[t]	1, 0 *16
	TREFACT	ΔRef.=Act MKR	[t]	1, 0 *16
	TREFCNT	ΔRef.=C.F.	[t]	1, 0 *16
	T3DB	-3 dB	[t]	D(s,r,s,s) *29,16
	T6DB	-6 dB	[t]	D(s,r,s,s) *29,16
	T60DB	-60 dB	[t]	D(s,r,s,s) *29,16
	TXDB	-x dB	[d] [u] [t]	D(s,r,s,s) *29,16
	TLEFT	Left Search	[t]	D(s,r) *16
	TRIGHT	Right Search	[t]	D(s,r) *16
	TIN	x dB down IN	[t]	1, 0 *16
	TOUT	x dB down OUT	[t]	1, 0 *16
	FILTER ANALYSIS	FLTANA	on/off	[s] [t]
PHASE MKR	ZRPSRCH	Zero phase search	[t]	D(s,r) *21
	TREFZRP	ΔRef.=Zero search	[t]	1, 0 *21

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (8/14)

Item	Code	Contents	Descriptive format	Response format
	T3DEG T6DEG TXDEG	+3° +6° +X°	[t] [t] [d] [u] [t]	D(s,r) *21 D(s,r) *21 D(s,r) *21
- MARKER SEARCH -		See section 3.3.10 of main instruction manual for description of basic functions.		
PART ANALYSIS	MKRPART	Part analysis	[s] [t]	1, 0 *18
TRACKING	MKRTRAC	Tracking	[s] [t]	1, 0
- MKR → -		See section 3.3.11 of main instruction manual for description of basic functions.		
MKR →	MKRREF MKRCENT MKRSTAR MKRSTOP MKRSPAN MKRCACL	MKR → Ref. value MKR → Center F. MKR → Start F. MKR → Stop F. MKR → Span F. MKR → Center scale	[t] [t] [t] [t] [t] [t] *22 *22 *22 *22
MARKER to MEMORY	MKR1TM MKR2TM MKR3TM MKR4TM MKR5TM MKR6TM MKR7TM MKR8TM MKR9TM MKR10TM	MKR # 1 to mem MKR # 2 to mem MKR # 3 to mem MKR # 4 to mem MKR # 5 to mem MKR # 6 to mem MKR # 7 to mem MKR # 8 to mem MKR # 9 to mem MKR #10 to mem	[t] [t] [t] [t] [t] [t] [t] [t] [t] [t]	1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13 1, 0 *13
MARKER to DATA	MKR1TD MKR2TD MKR3TD MKR4TD MKR5TD MKR6TD MKR7TD MKR8TD MKR9TD MKR10TD	MKR # 1 to data MKR # 2 to data MKR # 3 to data MKR # 4 to data MKR # 5 to data MKR # 6 to data MKR # 7 to data MKR # 8 to data MKR # 9 to data MKR #10 to data	[t] [t] [t] [t] [t] [t] [t] [t] [t] [t]	1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0 1, 0

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (9/14)

Item	Code	Contents	Descriptive format	Response format
- AUTO ZOOM -				
AUTO ZOOM	AUTOZOOM ATZMSPAN	AUTO ZOOM AUTO ZOOM SPAN	[t] [d] [u] [t]	... *27 *23 D(s)
- Entry -				
NUMERAL	0 1 2 3 4 6 7 9 . - + EXP	0 1 2 3 4 6 7 9 . - + EXP on ENT		
STEP	STPUP STPDN FU CU FD CD	↑ ↓ ⊙ ⊙ ⊙ ⊙		
BACKSPACE	BS			
ENTRY OFF	EOFF			
UNITS	MHZ KHZ HZ DEG DP DM DB METER CM SEC MSEC	MHz KHz Hz ° dBm dBm dB m cm sec msec		

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (10/14)

Item	Code	Contents	Descriptive format	Response format
	USEC	usec		
	NSEC	nsec		
	VOLT	V		
	MV	mV		
	UV	uV		
	NV	nV		
	UNIT	Unit		
	DIV	Div		
	PER,%	%		
DELIMITER	DL0		[t]
	DL1		[t]
	DL2		[t]
	DL3		[t]
IDENTIFICATION	IDNT	Identification	[t]	Strings *1
INSTRUMENT PRESET	IP	Instrument Preset	[t] *28
- PLOTTER -		See section 4.3 of main instruction manual for description of basic functions.		
GPIB address	ADDRPLOT	Plotter GPIB address	[d] [u] [t]	D
Plotter entry	PLT1PICT	Full size	[t]	1, 0
	PLT2PICT	Half size	[t]	1, 0
	PLT4PICT	Quarter size	[t]	1, 0
	PLTEXEC	Execute	[t]
	PLTABORT	Abort	[t]
	PLT2LEFT	Half (LEFT)	[t]	1, 0
	PLT2RIGHT	Half (RIGHT)	[t]	1, 0
	PLT4LUP	Quarter (L,Up)	[t]	1, 0
	PLT4LLOW	Quarter (L,Lo)	[t]	1, 0
	PLT4RUP	Quarter (R,Up)	[t]	1, 0
	PLT4RLOW	Quarter (R,Lo)	[t]	1, 0
	PLTDATA	Data on/off	[s] [t]	1, 0
	PLTMEM	Memory on/off	[s] [t]	1, 0
	PLTMKR	Marker on/off	[s] [t]	1, 0
	PLTSCALE	Scale on/off	[s] [t]	1, 0
	PLTGRAT	Scaletype on/off	[s] [t]	1, 0
	PLTREFLN	Ref.line on/off	[s] [t]	1, 0

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (11/14)

Item	Code	Contents	Descriptive format	Response format
	PLTTEXT	Text all on/off	[s] [t]	1, 0
	PLTLABEL	Label on/off	[s] [t]	1, 0
	PLTD1PEN	PEN select CH1 data	[d] [u] [t]	D
	PLTM1PEN	PEN select CH1 mem	[d] [u] [t]	D
	PLTD2PEN	PEN select CH2 data	[d] [u] [t]	D
	PLTM2PEN	PEN select CH2 mem	[d] [u] [t]	D
	PLTSCLPEN	PEN select scale	[d] [u] [t]	D
	PLTLBLPEN	PEN select label	[d] [u] [t]	D
	PLTAT	PLOTTER type (AT)	[t]	1, 0
	PLTHP	PLOTTER type (HP)	[t]	1, 0
- SAVE/RECALL -		See section 4.1 of main instruction manual for description of basic functions.		
SAVE/RECALL	SAVEREG1	Data save to reg1	[t]
	SAVEREG2	Data save to reg2	[t]
	SAVEREG3	Data save to reg3	[t]
	SAVEREG4	Data save to reg4	[t]
	RECLREG1	Data recall to reg1	[t]	1, 0
	RECLREG2	Data recall to reg2	[t]	1, 0
	RECLREG3	Data recall to reg3	[t]	1, 0
	RECLREG4	Data recall to reg4	[t]	1, 0
	RECLPOFF	Power off recall	[t]	1, 0
	CLRREG1	Clear reg1	[t]
	CLRREG2	Clear reg2	[t]
	CLRREG3	Clear reg3	[t]
	CLRREG4	Clear reg4	[t]
- SAVE/RECALL(FILE) -		See section 4.1 of main instruction manual for description of basic functions.		
LOAD FILE	LDFILE	LOAD FILE	[strings] [t] *8 *26
STORE FILE	STFILE1	STORE FILE	[strings] [t] *8 *26
PURGE INITIALIZE	PURGE INITIAL	Purge Initialize	[strings] [t] [t] *8 *26
- SRQ -				
	SRQE	SRQ enable	[t]	1, 0
	SRQD	SRQ disable	[t]	1, 0

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (12/14)

Item	Code	Contents	Descriptive format	Response format
- REAL TIME CLOCK -		See section 3.3.7 of main instruction manual for description of basic functions.		
REAL TIME CLOCK	RTC30ADJ	30sec ADJUST	[t]
	YEAR	YEAR	[d] [u] [t]	D *25
	MONTH	MONTH	[d] [u] [t]	D *25
	DAY	DAY	[d] [u] [t]	D *25
	WEEK	WEEK	[d] [u] [t]	D *25
	HOUR	HOUR	[d] [u] [t]	D *25
	MINUTE	MINUTE	[d] [u] [t]	D *25
DEFINE STORE	RAWARY	RAW DATA on/off	[s] [t]	1, 0
	CORARY	CORR DATA on/off	[s] [t]	1, 0
	DATAARY	DATA on/off	[s] [t]	1, 0
	MEMARY	MEM on/off	[s] [t]	1, 0
- SCREEN -				
EDIT	EDIT	EDIT mode (on/off)	[s] [t]	1, 0 *10
- Marker Point Display -				
MKRPOINT	MKRPOINT	MKR Point on/off	[s] [t]	1, 0

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (13/14)

GPIB code	Contents
- TRACE DATA (OUTPUT) -	
OT1DRAT	CH1 input meas and raw data following AVG
OT1MRAT	CH1 mem raw data
OT2DRAT	CH2 input meas and raw data following AVG
OT2MRAT	CH2 mem raw data
OT1CORDI	CH1 directional error coefficient
OT1CORSO	CH1 source match error coefficient
OT1CORTR	CH1 tracking error coefficient
OT1CORN	CH1 normalized averaging data
OT2CORDI	CH2 directional error coefficient
OT2CORSO	CH2 source match error coefficient
OT2CORTR	CH2 tracking error coefficient
OT2CORN	CH2 normalized averaging data
OT1CORED	CH1 data after error correction
OT2CORED	CH2 data after error correction
OT1NORED	CH1 data after data/mem operation
OT2NORED	CH2 data after data/mem operation
OT1DFOR	CH1 data after formatting
OT1MFOR	CH1 mem after formatting
OT2DROR	CH2 data after formatting
OT2MFOR	CH2 mem after formatting
- TRACE DATA (INPUT) -	
IN1DRAT	CH1 input meas and raw data following AVG
IN1MRAT	CH1 mem raw data
IN2DRAT	CH2 input meas and raw data following AVG
IN2MRAT	CH2 mem raw data
IN1CORDI	CH1 directional error coefficient
IN1CORSO	CH1 source match error coefficient
IN1CORTR	CH1 tracking error coefficient
IN2CORDI	CH2 directional error coefficient
IN2CORSO	CH2 source match error coefficient
IN2CORTR	CH2 tracking error coefficient
IN1CORDNR	CH1 normalized averaging data
IN2CORDNR	CH2 normalized averaging data

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

Table 2-2 GPIB Program Code (14/14)

GPIB code	Contents
IN1CORED IN2CORED	CH1 data after error correction CH2 data after error correction
IN1NORED IN2NORED	CH1 data after data/mem operation CH2 data after data/mem operation
IN1DFOR IN1MFOR	CH1 data after formatting CH1 mem after formatting
IN2DROR IN2MFOR	CH2 data after formatting CH2 mem after formatting
	☆
	☆

- *1 : Response given as character string.
- *2 : Response of 1 if MEM already stored, but 0 if not.
- *3 : Sweep from beginning.
- *4 : Partial sweep on/off is selected in type column.
- *5 : Response of latest setting
- *6 : ON not possible if MEM not stored.
- *7 : ON not possible if OPEN, SHORT, LOAD, or DONE not run.
- *8 : Append character string after GPIB code.
- *10: Measuring menu set by EDITOFF, and EDITOR menu set by EDITON.
- *11: When setting FSTPA, a value 1/10th of SPAN is automatically set instead.
- *12: If already executed, there is no operation until CLEAR is run.
- *13: No execution unless in DISPDM mode
- *14: Because of delta between multimarkers, there is no execution unless several markers are ON.
- *15: No execution unless fixed marker is ON
- *16: No execution unless format is in LOGMAG mode
- *17: No execution unless format is in LOGMAG or GDELAY mode
- *18: ON not possible unless in DMKRC or DMKRA mode
- *19: Command for setting marker number which will serve as active marker in inter-multimarker delta mode
- *20: Cannot be executed when format is in phase mode.
- *21: Cannot be executed when format is in phase or unwrap mode.
- *22: MRK → Freq. when sweep type is LINFRQ
- *23: MRK → level when sweep type is level sweep
- *24: No valid data is returned if search command is not executed.
- *25: Always insert a wait of at least 1 second after executing this command.
- *26: Always insert a sufficient wait period to ensure end of floppy disk access after executing this command.
- *27: Not executed in SINGLE SWEEP, SWEEP HOLD, or EXTERNAL TRIGGER mode.
 After execution of this command, wait the next processing until SRQ of SWEEP END appears.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.4 GPIB Input and Output Formats

- *28: Insert a wait of 5-second after executing IP.
- *29: When FLTANA is OFF, $D(s,r,s,s)$... (BW, Loss, Δf_L , Δf_R) is returned.
 When FLTANA is ON, $D(s,r,s,s,s,c,c)$... (BW, Loss, cf, Lf, Rf, Q, sf,) is returned.
- *30: For MKR1A? to MKR10A?, the number of data items which returned depending on the measuring condition at that time is different.

Parameter conversion		FORMAT	SMITH		POLAR	When other than SMITH and POLAR
		SMITH MKR	LIN MKR LOG MKR Re/Im MKR	R+jX G+jB		
OFF			$D(s,r,i)$	$D(s,r,i,lc)$	$D(s,r,i)$	$D(s,r)$
ON	DEFAULT MRT		$D(s,r,i)$		$D(s,r,i)$	$D(s,r)$
	LIN MKR	L or C OFF	$D(s,r,i)$		$D(s,r,i)$	$D(s,r,i)$
	Re/Im MKR	L or C ON	$D(s,r,i,lc)$		$D(s,r,i,lc)$	$D(s,r,i,lc)$

However, when the marker of specified No. is the active marker and also in MODE, the data for lc is not returned.

- *31: FOR MAXSRCH? } The number of data items which is returned
 MINSRCH? } depending on the measuring condition at that
 LMAXSRC? } this is different.
 LMINSRC? }

The same as the table of *30.

* However, for Δ MODE, the data for lc is not returned.

- ☆ : No input or output permitted if mem is not ON.
- △ : No input or output permitted if correction is not ON.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.5 Service Request

2.5 Service Request

The status register is outlined in Figure 2-1 below.




Figure 2-1 Status Register

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

2.6 Program Examples

2.6.1 Program for Determining Difference between Very Large and Very Small Points within Same Specified Frequencies, and Maximum Value of Difference Between Adjacent Inflection Points

To run this program, set the GPIB address to 11 with R4611E in TALKER/LISTENER mode.

<HP200 Series>


```
100 !
110 !          SAMPLE PROGRAM
120 !
130 OUTPUT 711; "CH1 ARIN LOGMAG"
140 OUTPUT 711; "SPANF      12 MHZ"
150 OUTPUT 711; "CENTERF    57 MHZ"
160 OUTPUT 711; "SDIV       10 DB"          ! SET PER DIVISION
170 OUTPUT 711; "REFV       0 DB"          ! SET REF LEVEL
180 OUTPUT 711; "REFP      100 PER"       ! SET REF POSITION
190 OUTPUT 711; "OUTLEV     0 DB"          ! SET OUTPUT LEVEL
200 OUTPUT 711; "AI50A0  RBW1KHZ"        ! ATT/IMP & BAND WIDTH
210 OUTPUT 711; "M301P"                  ! RESOLUTION 301 POINT
220 OUTPUT 711; "MKRCMPON"              ! MARKER COMPENSATE MODE ON
230 OUTPUT 711; "LINFREQ"               ! LINEAR SWEEP
240 OUTPUT 711; "MKR1A     53 MHZ"       ! MARKER 1 ON
250 OUTPUT 711; "DMKRC"                 ! CHILD MARKER ON
260 OUTPUT 711; "MKR1A     9 MHZ"       ! DELTA OFFSET
270 OUTPUT 711; "DLTX     40 MHZ"       ! DELTA X
280 OUTPUT 711; "DLTY     0.01 DB"      ! DELTA Y
290 OUTPUT 711; "DRIPPL1"              ! RIPPLE 1 RUN
300 OUTPUT 711; "DRIPPL1?"
310 ENTER 711;Ripl1                     ! READ RIPPLE 1
320 OUTPUT 711; "DRIPPL2"              ! RIPPLE 2 RUN
330 OUTPUT 711; "DRIPPL2?"
340 ENTER 711;Ripl2                     ! READ RIPPLE 2
350 PRINT Ripl1,Ripl2
360 END
```

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

<Commentary>

Address	Contents
130	Channel 1 INPUT A/R LOGMAG
140	SPAN 12MHZ
150	CENTER 57MHZ
160	/DIV Set to 10 dB
170	REF LEVEL Set to 0 dB
180	REF Position Set to 100%
190	OUTPUT LEVEL Set to 0 dB
200	Impedance 50 ohms Attenuator 0 dB RESOLUTION band width 1 kHz
210	Set to measuring point 301
220	MARKER COMPENSATE mode ON
230	Linear sweep
240) Set point A
250	
260	Set (plus B point) OFFSET 9 MHz at point A
270	Differential coefficient (ΔX)
300) Read RIPPLE1 from R4611E
310	
320	Compute RIPPLE2 (R_2)
330) Read RIPPLE2 from R4611E
340	
350	Display
360	End



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

2.6.2 Trace Data Input/Output

● TRACE DATA (INPUT)

To run this program, set the GPIB address to 11 with R4611E in TALKER/LISTENER mode.

<HP200 Series>


```

100 DIM R(600)
110 Add=711
120 OUTPUT Add; "M601P"
130 OUTPUT Add; "IN1DFOR"
140 FOR I=0 TO 600
150 OUTPUT Add;R(I)
160 OUTPUT Add;Imag
170 NEXT I
180 OUTPUT Add; "TREND"
190 END
  
```

<Commentary>

Address	Contents
100	Array declaration
110	GPIB address setting
120	Specify measuring points as 601 points
130	Request input of TRACE DATA
140	Loop for the number of points
150	Data output to R4611E (real number)
160	Data output to R4611E (imaginary number: dummy output when not required)
170	
180	End of data output to R4611E
190	End

Note: TRACE DATA input is inserted in real/imaginary number sequence at each point.



 Point 1 Point 2 Point count-1 Point count

Output sequence to R4611E

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

- Data in excess of the R4611E measurement points is disregarded. For example, if R4611E measurement points are set to 601 and data consisting of 602 or more points is sent to R4611E, the excess points are disregarded.
- The "TREND" in line 180 must always be inserted when the transfer is completed.
- TRACE DATA (OUTPUT)

To run this program, set the GPIB address to 11 with R4611E in TALKER/LISTENER mode.

<HP200 Series>

```
100 DIM R(1200)
110 Add=711
120 OUTPUT Add; "OT1DFOR"
130 ENTER Add;Po
140 FOR I=0 TO Po-1
150 ENTER Add;R(I)
160 ENTER Add;Imag
170 NEXT I
180 PRINT R(*)
190 END
```


<Commentary>

Address	Contents
100	Array declaration
110	GPIB address setting
120	Request output of TRACE DATA
130	Enter the number of points
140	Loop for the number of points
150	Data input (real number)
160	Data input (imaginary number: dummy output when not required)
170	
180	Output
190	End

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

Note: TRACE DATA output consists of output of the initial point, then output in real/imaginary number sequence at each point.



Output sequence to R4611E

2.6.3 SRQ

When the GPIB code "SRQE" is executed, the sweep end SRQ output is passed to the external controller.

To run this program, set the GPIB address to 11 with R4611E in TALKER/LISTENER mode.

<HP200 Series>

10	OUTPUT 711; "SRQE"	! R4611E SRQ ENABLE
20	ON INTR 7 GOTO 100	!
30	ENABLE INTR 7;2	
40	! LOOP	! LOOP
50	GOTO 40	! LOOP
100	! SWEEP END	! SWEEP END
110	S=SPOLL(711)	! SERIAL POLL
120	IF S <> 65 THEN GOTO 199	! SWEEP END ?
130	OUTPUT 711; "MAXSRCH?"	! YES MAX SEARCH
140	ENTER 711;S,R,I,LC	! GET DATA
150	PRINT R	! PRINT LABEL
199	GOTO 30	
200	END	

<Commentary>

Address	Contents
10	R4611E sweep end SRQ output designation
20	Branch to line number 100 when SRQ arrives
30	Interrupt enable
40	} Loop
50	
100	

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

Address	Contents
110	Serial poll
120	Go to 199 if not sweep end
130	MAX SEARCH
140	Input of measurement data from R4611E
150	Print label
199	GOTO 30
200	END

2.6.4 Starting BASIC from External Controller

While R4611E is in TALKER/LISTENER mode, BASIC commands can be executed from the external controller.

"@BASIC command"

Appending @ to the beginning enables BASIC commands inside R4611E to be activated from the external controller.

Description of Program Example

Certain BASIC programs are generated in advance in remote control BASIC, and saved to R4611E floppy disk under file names "FILE_1", "FILE_2", "FILE_3", and "FILE_4". Then when program example 1 is generated and executed by external controller, programs in R4611E are loaded and run one after another.

- Note:
- To run these programs, set the GPIB address to 11 with R4611E in TALKER/LISTENER mode.
 - The R4611E built-in BASIC REQUEST command has been included to inform the external controller when execution is completed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

Program example 1

<HP200 Series>

```
100 DIM A$(3) [6] , L$[20]
110 F=4
115 E=0
120 ON INTR 7 GOSUB 1000
130 A$(0)="FILE_1"
140 A$(1)="FILE_2"
150 A$(2)="FILE_3"
160 A$(3)="FILE_4"
200 FOR I=0 TO F-1
210 L$="@LOAD "&CHR$(34)&A$(I)&CHR$(34)
220 OUTPUT 711;L$
230 WAIT 5
240 OUTPUT 711; "@RUN"
250 ENABLE INTR 7;2
260 IF E=0 THEN 260
270 WAIT 5
280 E=0
290 NEXT I
1000 ! SRQ
1010 S=SPOLL(711)
1020 IF S=65 THEN
1030     BEEP
1040     E=1
1050     END IF
1060 RETURN
1070 END
```

● R4611E BASIC

<FILE_1>

```
100 FOR I=1 TO 24
110 PRINT I
120 NEXT I
130 REQUEST 64+1
```

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

<Commentary>

Address	Contents
100	Loop 24 times
110	Display I
120	
130	REQUEST to HOST

<FILE_2>

```

100 FOR I=1 TO 24
110 PRINT I*2
120 NEXT I
130 REQUEST 64+1
  
```

<Commentary>

Address	Contents
100	Loop 24 times
110	Display I*2
120	
130	REQUEST to HOST

<FILE_3>

```

100 FOR I=24 TO 1 STEP -1
110 PRINT I
120 NEXT I
130 REQUEST 64+1
  
```

<Commentary>

Address	Contents
100	Loop 24 times (minus steps)
110	Display I
120	
130	REQUEST to HOST

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

<FILE_4>

```
100 FOR I=24 TO 1 STEP -1
110 PRINT "ADVANTEST R4611E NETWORK ANALYZER"
120 NEXT I
130 REQUEST 64+1
```

<Commentary>

Address	Contents
100	Loop 24 times (minus steps)
110	Display ADVANTEST R4611E NETWORK ANALYZER
120	
130	REQUEST to HOST

2.6.5 Program Example Using External Controller or Built-in BASIC

When using an external controller

To run this program, set the GPIB address to 11 with R4611E in TALKER/LESTENER mode.

<HP200 Series>

```
100 OUTPUT 711; "EDITOFF "
110 OUTPUT 711; "LOGMAG"
120 OUTPUT 711; "CENTERF100MHZ "
130 OUTPUT 711; "SPANF10MHZ "
140 OUTPUT 711; "AUTO"
150 OUTPUT 711; "CENTERF ?"
160 ENTER 711;Cf
170 OUTPUT 711; "SPANF ?"
180 ENTER 711;Sf
190 OUTPUT 711; "MAXSRCH "
200 OUTPUT 711; "MAXSRCH ?"
210 ENTER 711;F,L,D1,D2
220 PRINT "Center freq.= " ,Cf
230 PRINT "Span   freq.= " ,Sf
240 PRINT "MAX   Level = " ,L
250 END
```

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

< Commentary >

Address	Contents
100	Switch to measurement menu
110	LOGMAG mode
120	Set central frequency to 100 MHz
130	Set frequency width to 10 MHz
140	Execute auto scale
150	Request center frequency response
160	Substitute center frequency response in variable Cf
170	Request frequency width response
180	Substitute frequency width response in variable Sf
190	Search for maximum level
200	Request maximum level response
210	Substitute maximum level response in each variable
220	Display center frequency
230	Display frequency width
240	Display maximum level
250	

When using R4611E built-in BASIC

(When the built-in BASIC is used, R4611E itself can be controlled specifying OUTPUT and ENTER address as 31.)

100	OUTPUT 31; "EDITOFF "
110	OUTPUT 31; "LOGMAG"
120	OUTPUT 31; "CENTERF100MHZ "
130	OUTPUT 31; "SPANF10MHZ "
140	OUTPUT 31; "AUTO"
150	OUTPUT 31; "CENTERF ?"
160	ENTER 31;Cf
170	OUTPUT 31; "SPANF ?"
180	ENTER 31;Sf
190	OUTPUT 31; "MAXSRCH "
200	OUTPUT 31; "MAXSRCH ?"
210	ENTER 31;F,L,D1,D2
220	PRINT "Center freq.= " ,Cf
230	PRINT "Span freq.= " ,Sf
240	PRINT "MAX Level = " ,L
250	STOP

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

< Commentary >

Address	Contents
100	Switch to measurement menu
110	LOGMAG mode
120	Set central frequency to 100 MHz
130	Set frequency width to 10 MHz
140	Execute auto scale
150	Request center frequency response
160	Substitute center frequency response in variable Cf
170	Request frequency width response
180	Substitute frequency width response in variable Sf
190	Search for maximum level
200	Request maximum level response
210	Substitute maximum level response in each variable
220	Display center frequency
230	Display frequency width
240	Display maximum level
250	

2.6.6 X'TAL FILTER Measuring Program Example

```
1000 REM .....
1100 REM SAMPLE PROGRAM FOR
1200 REM XTAL FILTER
1300 REM
1400 REM .....
1500 REM FILTER IS . . .
1600 REM 21.4MHz BPF
1700 REM .....
1800 REM
1900 REM
2000 REM *** INITIALIZE R4611E ***
2100 REM
2200 OUTPUT 31; "CH1 AIN LOGMAG "
2300 OUTPUT 31; "SDIV 10 DB"
2400 OUTPUT 31; "REFV 0 DB "
2500 OUTPUT 31; "REFP 100 PER"
2600 OUTPUT 31; "REFLON PORT1"
2700 OUTPUT 31; "OUTLEV 0 DB "
2800 OUTPUT 31; "AI50A20 "
2900 OUTPUT 31; "RBW1KHZ "
```

Continued to next page

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
3000 OUTPUT 31; "FREE CONT M301P "  
3100 OUTPUT 31; "MKRCMP"  
3200 REM  
3300 REM *** LOOP TOP ***  
3400 REM  
3500 OUTPUT 31; "SPANF 25 KHZ"  
3600 OUTPUT 31; "CENTERF 21.4 MHZ"  
3700 REM  
3800 REM *** 1 SWEEP ***  
3900 REM  
4000 OUTPUT 31; "SINGLE"  
4100 BUZZER 0 1500  
4200 REM  
4300 REM *** SCREEN INITIALIZE ***  
4400 REM  
4500 CLS  
4600 FOR I=1 TO 10  
4700 PRINT  
4800 NEXT I  
4900 REM  
5000 REM *** GET INS LOSS ***  
5100 REM  
5200 LOSS=MAX (0,1200,0)  
5300 MAXP=PMAX (0,1200,0)  
5400 PRINT "LOSS" ,LOSS, "dB"  
5500 REM  
5600 REM *** GET RIPPLE ***  
5700 REM  
5800 RIPPLE=RPL1 (400,800,4,0.01,0)  
5900 PRINT "RIPPLE ",RIPPLE, "dB"  
6000 REM  
6100 REM *** GET BW (3dB) ***  
6200 REM  
6300 BW3DB=BND (600,3,0)  
6400 PRINT "BW (3dB)" ,BW3DB, "Hz"  
6500 REM  
6600 REM *** GET BW (400dB) ***  
6700 REM  
6800 BW40DB=BND (600,40,0)  
6900 PRINT "BW (40dB)" ,BW40DB, "Hz"  
7000 REM  
7100 REM *** 1MHZ DEVIATION LEVEL ***  
7200 REM  
7300 OUTPUT 31; "SPANF 2 MHZ"  
7400 OUTPUT 31; "SINGLE"  
7500 BUZZER 0 1500
```

Continued to next page

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

```

7600 LLEVEL=VALUE (0,0)
7700 RLEVEL=VALUE (1200,0)
7800 PRINT "1MHz DEV. LEVEL(dB) "
7900 PRINT LLEVEL,RLEVEL
8000 GOTO 3200
8100 REM
8200 REM *** END JOB ***
8300 REM
8400 OUTPUT 31; "CONT"
8500 END
  
```

<Commentary>

Address	Contents
2000	Initialization
2	
4200	Measure insertion loss
5000	
5500	Ripple measurement
5600	
6000	Measure 3 dB band width
6100	
6500	Measure 40 dB band width
6600	
7000	Measure levels at ± 1 MHz away from tuned frequency
7100	
7700	Return to loop top and repeat measurement
8000	

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

2.6.7 Example of Measuring Program Using Parallel I/O Ports

```
[EDITOR] <.....> [MOD] Done
1000 REM *****
1010 REM *** ***
1020 REM *** R4611E NETWORK ANALYZER ***
1030 REM ***
1040 REM *** SEMI AUTO PROGRAM BY PIO ***
1050 REM *** ***
1060 REM *****
1070 REM
1080 CURSOR 0 18
1090 PRINT "*** R4611E DEMO PROGRAM ***"
1100 PRINT ""
1110 PRINT " * USE PIO DEMO SET"
1120 PRINT
1130 PRINT " [1] NARROW BAND TEST"
1140 PRINT " [2] WIDE BAND TEST"
1150 PRINT " [3] PHASE MEASUREMENT"
1160 PRINT " [4] G.D. MEASUREMENT"
1170 PRINT " "
1180 OUTPUT 31; "CH1 AIN LOGMAG"
1190 OUTPUT 31; "SDIV 10 DB"
1200 OUTPUT 31; "REFV 0 DB"
1210 OUTPUT 31; "REFP 100 PER"
1220 OUTPUT 31; "REFLON PORT1"
1230 OUTPUT 31; "OUTLEV 0 DB"
1240 OUTPUT 31; "BI1A20"
1250 OUTPUT 31; "AI1A20"
1260 OUTPUT 31; "RI50A20"
1270 OUTPUT 31; "RBW1KHZ"
1280 OUTPUT 31; "FREE CONT M301P"
1290 OUTPUT 31; "MKRCMP"
1300 OUTPUT 31; "SPLITON"
1310 OUTPUT 31; "DUALOFF"
1320 OUTPUT 31; "CENTERF 455 KHZ"
1330 BUZZER 0 1000
1340 CURSOR 2, 28
1350 *LOOPTOP
1360 CURSOR 2, 28
1370 PRINT "SELECT PIO NUMBER ?"
1380 *LOOPTOP1
1390 ENTER 32;PIO
1400 IF PIO=1 THEN GOTO *MEAS1
```

Continued to next page

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
1410 IF PIO=2 THEN GOTO *MEAS2
1420 IF PIO=4 THEN GOTO *MEAS3
1430 IF PIO=8 THEN GOTO *MEAS4
1440 GOTO *LOOPTOP1
1450 REM
1460 REM
1470 REM
1480 REM --- NARROW BAND MEASURE ---
1490 *MEAS1
1500 CLS
1510 OUTPUT 31; "SPANF 100 KHZ"
1520 OUTPUT 31; "LOGMAG"
1530 REM
1540 REM *** 1 SWEEP ***
1550 REM
1560 CURSOR 0,19
1570 BUZZER 0 1000
1580 CLS
1590 REM
1600 REM *** SCREEN INITIALIZE ***
1610 REM
1620 CURSOR 0,19
1630 REM
1640 REM *** GET INS LOSS ***
1650 REM
1660 LOSS=MAX (0,1200,0)
1670 MAXP=PMAX (0,1200,0)
1680 PRINT "LOSS" ,LOSS, "dB"
1690 REM
1700 REM *** GET RIPPLE ***
1710 REM
1720 RIPPLE=RPL1 (400,800,4,0.01,0)
1730 PRINT "RIPPLE" ,RIPPLE, "dB"
1740 REM
1750 REM *** GET BW (83dB) ***
1760 REM
1770 BW3DB=BND (600,3,0)
1780 PRINT "BW (3dB)" ,BW3DB, "Hz"
1790 REM
1800 REM *** GET BW (40dB) ***
1810 REM
1820 BW40DB=BND (600,40,0)
1830 PRINT "BW (40dB)" ,BW40DB, "Hz"
1840 GOTO *LOOPTOP
1850 REM
```

Continued to next page

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
1860 REM --- WIDE BAND MEASUREMENT ---
1870 REM
1880 *MEAS2
1890 CLS
1900 OUTPUT 31; "SPANF 2 MHZ "
1910 OUTPUT 31; "LOGMAG"
1920 BUZZER 0 1000
1930 CURSOR 0,19
1940 CLS
1950 LLEVEL=VALUE (0,0)
1960 RLEVEL=VALUE (1200,0)
1970 CLS : CURSOR 0 20
1980 PRINT "1MHZ DEV. LEVEL (dB)  "
1990 PRINT LLEVEL,RLEVEL
2000 GOTO *LOOPTOP
2010 REM
2020 REM
2030 REM
2040 END
2050 REM --- PHASE MEASUREMENT ---
2060 REM
2070 *MEAS3
2080 CLS
2090 OUTPUT 31; "SPANF 100 KHZ "
2100 OUTPUT 31; "PHASE"
2110 REM
2120 REM *** 1SWEEP ***
2130 REM
2140 CURSOR 0 19
2150 CLS
2160 REM
2170 REM *** SCREEN INITIALIZE ***
2180 REM
2190 CURSOR 0 19
2200 GOTO *LOOPTOP
2210 REM
2220 REM --- DELAY MEASUREMENT ---
2230 REM
2240 *MEAS4
2250 CLS
2260 OUTPUT 31; "SPANF 100 KHZ "
2270 OUTPUT 31; "DELAY"
2280 BUZZER 0 3000
2290 OUTPUT 31; "AUTO"
2300 REM
2310 REM *** 1 SWEEP ***
2320 REM
2330 CURSOR 0 19
2340 BUZZER 0 2000
2350 GOTO *LOOPTOP
```

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

Commentary

Address	Contents
1180	
?	Initialization
1330	
1370	
?	Set measuring function by parallel I/O input signal
1430	
1480	Return to loop top and repeat measurement
?	MEAS1 measurement
1840	On basis of narrow band frequency span
?	(Insertion loss, ripple, 3 dB band width, 40 dB band width)
1860	MEAS2 measurement
?	Measure levels of start and stop points on basis of wide
2000	band frequency span
2050	MEAS3 measurement
?	Phase measurement
2200	Return to loop top and repeat measurement
2240	MEAS4 measurement
?	Group delay measurements
2350	Return to loop top and repeat measurement

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

2.6.8 Example of Program Where Limited Test Function Is Used in Low-pass
Filter Measurements

```
1000 :  
1010 :  
1020 ! INITIALIZE  
1030 :  
1040 OUTPUT 31; "CH1 LOGMAG"  
1050 OUTPUT 31; "MKRCMP"  
1060 OUTPUT 31; "SINGLE"  
1070 OUTPUT 31; "STARTF 1.5MHZ"  
1080 OUTPUT 31; "STOPF 6 MHZ"  
1090 OUTPUT 31; "DUAL ON"  
1100 OUTPUT 31; "SPLIT ON"  
1110 OUTPUT 31; "COUPLE ON"  
1120 OUTPUT 31; "CH2 DELAY"  
1130 BUZZER 0 500  
1140 OUTPUT 31; "SRQE"  
1150 :  
1160 ! MEASUREMENT  
1170 :  
1180 BUZZER 4 100  
1190 OUTPUT 31; "MEAS"  
1200 ON ISRQ GOTO 1240  
1210 ENABLE INTR  
1220 :  
1230 GOTO 1220  
1240 :  
1250 Fr=FMIN (0,1200,0)  
1260 F1=MIN (0,1200,0)  
1270 F2=POINT1 (2e+06,0)  
1280 L2=VALUE (F2,0)  
1290 F3=POINT1 (3e+06,0)  
1300 L2=VALUE (F3,0)  
1310 F4=POINT1 (4e+06,0)  
1320 L4=VALUE (F4,0)  
1330 Fi=POINT1 (3.58e+06,0)  
1340 Li=VALUE (Fi,0)  
1350 :  
1360 ! DELAY  
1370 :  
1380 BUZZER 0 500  
1390 F3=POINT1 (3.58e+06,1)  
1400 D3=VALUE (F3,1)  
1410 F3=POINT1 (4.08e+06,1)  
1420 D4=VALUE (F4,1)
```

Continued to next page

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

```

1430 !
1440 ! GO/NOTO CHECK !!
1450 !
1460 CURSOR 0,3
1470 N1=LMTUL1 [Fr,5.3025e+06,4.7975e+06]
1480 N2=LMTUL1 [F1,-30,-200]
1490 N3=LMTUL1 [L2,-5,-11]
1500 N4=LMTUL1 [L3,5,-1.2]
1510 N5=LMTUL1 [L4,5,-1.2]
1520 N6=LMTUL1 [Li,5,-1]
1530 N7=LMTUL1 [D3,230,170]
1540 N8=LMTUL1 [D4,330,0]
1550 N=N1+N2+N3+N4+N5+N6+N7+N8
1560 IF N=0 THEN GOTO 1590
1570 PRINT "NG !!"
1580 GOTO 1180
1590 PRINT "OK !!"
1600 GOTO 1180
1610 STOP
  
```

<Commentary >

Address	Contents
1020	
?	Initialization
1120	
1130	500 msec wait
1140	Enable SRQ
1200	Set internal SRQ interrupt and branch
1210	Accept interrupt
1250	Measured value interrupt at frequency measurement point
?	specified by CH1
1340	
1380	Measured value interrupt at frequency measurement point
?	specified by CH2
1420	
1470	
?	Designation of limit values for each measured value
1540	
1550	Set branching according to result of comparison value
1570	Print NG if even a single item was NG
1590	Print OK if all items are OK, and continue to measure repeatedly

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
10  REM -----
20  REM
30  REM      XTAL EQUIVALENT CIRCUITM
40  REM
50  REM
60  REM      PI-CIRCUIT-METHOD
70  REM
80  REM -----
90  REM
100 REM
110 REM
120 REM
130 REM
140 REM
150 REM
160 REM
170 REM
180 SPAN1$ = "SPANF 1KHZ"
190 CENTER1$ = "CENTER 11.97596430MHZ"
200 CLS : CURSOR 0 14
210 REM
220 REM -----
230 REM
240 REM      START
250 REM
260 REM -----
270 NA=31
280 CFLAG=0
290 OUTPUT NA; "COUPLE?"
300 ENTER NA;X
310 PRINT " [ ";X;" ] "
320 IF X=0 THEN OUTPUT NA; "COUPLEON"
330 PRINT
340 PRINT
350 PRINT "Do you need CAL?  YES;1 NO;0 "
360 INPUT QQ
370 PRINT " [ "QQ" ] "
380 IF QQ=1 THEN CFLAG=1
390 GOTO *MEAS
400 *CALUC
410 REM
420 REM *** CALCULATE ***
430 REM
440 XDEG=3
450 RR=25*(10 ^ (-LOSS/20)-1)
460 AA=1+0.50878*(RR/12.5)
```

Continued to next page

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
470 BB=2*0.50878*(RR/12.5)
480 CC=FR*PI*2* XDEG
490 DD=180*DF3
500 Q=(AA/BB)*(CC/DD)
510 C1=1/(2*PI*FS*RP*Q)
520 L=1/((2*PI*FS) 2*C1)
530 PRINT "***** R4611E DEMO (XTAL) *****"
540 PRINT "LOSS (dB) " , -LOSS
550 PRINT "Fs (Hz) " , FS
560 PRINT "Fr (Hz) " , FR
570 PRINT "dF (Hz) " , DF3
580 PRINT
590 PRINT "Q " , Q
600 PRINT "Rr (ohm) " , RR
610 PRINT "C1 (pF) " , C1*1e+12
620 PRINT "L (mH) " , L*1000
630 PRINT "-----"
640 GOTO *MEAS2
650 REM
660 REM *** MEASUREMENT ***
670 REM
680 *MEAS
690 OUTPUT NA; "DUALON"
700 OUTPUT NA; "SPLITOFF"
710 FOR CH=1 TO 2
720 IF CH=1 THEN GOTO 750
730 OUTPUT NA; "CH2"
740 GOTO *EX1
750 OUTPUT NA; "CH1"
760 *EX1
770 OUTPUT NA;SPAN1$
780 OUTPUT NA;CENTER1$
790 OUTPUT NA; "AIN"
800 OUTPUT NA; "PORT1"
810 OUTPUT NA; "A150A0"
840 OUTPUT NA; "RBW30HZ"
850 OUTPUT NA; "MKRCMP"
860 OUTPUT NA; "STIME 0.1 SEC"
870 OUTPUT NA; "M101P"
880 OUTPUT NA; "FREE CONT"
890 NEXT CH
900 OUTPUT NA; "CH1 LOGMAG"
910 OUTPUT NA; "REFV 0 DB"
920 OUTPUT NA; "REFP 90 PER"
```

Continued to next page

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

2.6 Program Examples

```
930  OUTPUT NA; "CH2 PHASE"
940  OUTPUT NA; "REFV 0 DEG"
950  OUTPUT NA; "REFP 50 PER"
960  OUTPUT NA; "SINGLE"
970  REM
980  REM *** CALIBRATION ***
990  REM
1000 *CAL
1010 IF CFLAG=0 THEN GOTO *MEAS2
1020 OUTPUT NA; "CH1 NORMOFF"
1030 OUTPUT NA; "CH2 NORMOFF"
1040 CLS
1050 BEEP
1060 PRINT ">> CONNECT [THRU] "
1070 INPUT "& PRESS [RETURN] KEY" ,Q$
1080 PRINT "Calibration....."
1090 BUZZER 0 3000
1100 OUTPUT NA; "CH1 NORMON"
1110 OUTPUT NA; "CH2 NORMON"
1120 PRINT "CAL done."
1130 BEEP
1140 PRINT ">> CONNECT [DUT]"
1150 INPUT "& PRESS [RETURN] KEY" ,Q$
1160 PRINT "MEASURING START "
1170 REM
1180 REM *** MEASURE START ***
1190 REM
1200 *MEAS2
1210 OUTPUT NA; "SRQE"
1220 OUTPUT NA; "MEAS"
1230 ON ISRQ GOTO 1260
1240 ENABLE INTR
1250 GOTO 1240
1260 REM
1270 REM *** GET MAG DATA ***
1280 REM
1290 OUTPUT NA; "CH1 "
1300 LOSS=MAX (0,1200,0)
1310 FS=FMAX (0,1200,0)
1320 REM
1330 REM *** GET PHASE DATA ***
1340 REM
1350 OUTPUT NA; "CH2"
1360 OUTPUT NA; "ZRPSRCH"
1370 OUTPUT NA; "MKR1A?"
1380 ENTER NA;FR
```

Continued to next page

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

```

1390 OUTPUT NA; "TREFZRP"
1400 OUTPUT NA; "T3DEG"
1410 OUTPUT NA; "T3DEG?"
1420 ENTER NA;DF3
1430 REM
1440 REM
1450 CLS
1460 GOTO *CALUC
1470 REM
1480 REM
1490 END
  
```

< Commentary >

Address	Contents
180	Set center frequency to 11.97596430 MHz, and span width to
?	1 kHz
190	
200	Clear screen, and decide on cursor position
290	
?	Switch marker couple ON
320	
350	
?	Select whether CAL is required or not (0 or 1)
370	
390	Jump to initialization routine
420	X'TAL element constants calculation and display of result
440	
?	Calculate X'TAL element constants
520	
530	
?	Display result of X'TAL element calculation
630	
650	
?	R4611E initialization
660	
680	
?	Switch dual-channel display on, and split display off
700	
710	
?	Form loop required to set two channels CH1 and CH2
750	
770	
?	Various setting conditions
960	

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

2.6 Program Examples

Address	Contents
970	
?	Calibration routine
980	
1000	Determine whether calibration is necessary, then proceed to initialization
?	
1030	
1040	Clear screen display
1060	
?	Display short bar connection message
1080	
1100	
?	Proceed with normalization
1120	
1130	
?	Display [DUT] ... X'TAL connection message
1160	
1180	Routine for repeating sweep, and output/detection of service request at end of sweep
?	
1240	
1270	Built-in function for return of maximum amplitude level and corresponding frequency in screen display during amplitude measurement mode
?	
1310	
1340	Return of value of frequency 3 dB band width for phase value of 0° in phase measurement mode
?	
1420	
1460	Jump to calculation routine

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

3.1 Outline

3. CONTROL MODE

3.1 Outline

R4611E is equipped with a GPIB controller function capable of controlling external equipment. By using the BASIC programming function, both the R4611E Network Analyzer itself and external equipment connected to R4611E can be controlled.

NOTE

If the GPIB is locked when in controller mode, press the R4611E STOP key three times to initialize the GPIB port.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

3.2 Setting Controller Mode

3.2 Setting Controller Mode

Select the system controller function by pressing the front panel LOCAL switch and selecting SYSTEM CONTROL from the menu. Then select GPIB ADDRESS and key in R4611E's GPIB address (0 thru 30) by pressing the corresponding numeric keys. Addressing is also necessary when setting controller mode.

NOTE

- The GPIB address of external equipment connected to R4611E must not be the same as the R4611E address.
- The address specified at this stage is used for internal processing purposes. The address used for controlling R4611E by built-in BASIC program is fixed to "31".

3.3 Handling Floppy Disks

(1) Floppy Disk Dimensions and Component Parts




Figure 3-1 Floppy Disk Dimensions and Component Parts

- Label : The label is affixed by the user when a floppy disk is used.
- Head window : Head window apertures are located on both sides of the disk at the same position as the read/write heads. The heads move vertically across these apertures. When a floppy disk is removed from the drive slot, the automatic shutter closes to protect the disk surface.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

3.3 Handling Floppy Disks

- catching hub (drive and center holes)
 - : When a floppy disk is inserted into the drive slot, it is secured and rotated by a spindle using a catching magnet.
- Write protection hole: This hole prevents important data from being erased accidentally by operational error.

(2) Floppy Disk Loading and Other Handling Precautions

The correct way to insert a floppy disk into the disk drive is shown in Figure 3-2. Note that the label side faces the left hand side. Push the disk fully into the drive by hand, and check that it has been secured. To remove the disk, press the EJECT button.

Note: Do not press the EJECT button if the red disk drive button is flashing on and off.




Figure 3-2 Floppy Disk Insertion Method

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

3.3 Handling Floppy Disks

Take note of the following precautions when storing disks after removal from the drive.

- ① Keep disks away from magnetic fields and other strong magnetic materials.
Data stored on disks can be distorted by strong magnetic fields.
- ② Protect disks from heat sources and direct sunlight.
- ③ Heat, cigarette ash, and other foreign matter can also lead to disk damage.
- ④ Do not touch the magnetically coated surface by hand, and do not try to clean the surface by hand. Data can be lost by scratches incurred in this way.
- ⑤ Do not place heavy articles on top of floppy disks.

In floppy disks which are physically damaged (by wetting, creasing, warping, etc.) the head will "float" away from the coated surface, resulting in track jumping, continuous level dropping, and other errors. A disk which has been damaged or spoiled should always be replaced. And disks soiled by sticky fluids (such as soft drinks, coffee, and oil) or iron filings etc. must not be used in other drives. If the heads of other drives are become dirty, not only will the head be damaged and put out of action, but other floppy disks may also be spoiled.

NOTE

The floppy disk contents may not be read correctly if the power is switched on with a disk already mounted in the drive. In this case, switch the power off, and remove the disk before switching the power back on.

(3) Write Protect

To prevent valuable data from being erased accidentally by operational error etc., writing additional data to that disk can be inhibited by the write protect feature.

This feature is selected by moving the write protect sliding knob shown in Figure 3-3. Normally, this knob is left in the position nearest the center hole to permit writing, but is moved to the corner position to prevent writing.




Figure 3-3 Floppy Disk Write Protect and Write Enable

3.4 File Management

3.4.1 Outline

BASIC programs, saved data, and other information stored on floppy disk are called "files". Files can be displayed, erased, and copied. The main factors involved in storage of information on floppy disks are briefly described below.

DISKNAME : To identify individual floppy disks, DISKNAME is written when the disk is initialized. (See section on initialization.)

FILE : BASIC programs, save data, and other information are stored in individual files which may take up any number of sectors.

SECTOR : The smallest unit in which data can be stored on disk. 1 sector corresponds to 512 bytes.

File type : File groups are separated into BASIC and SYSTEM.

Disk capacity: The maximum data storage capacity per disk is:-
Maximum number of files: 200
Total number of sectors: 1400
Data can be stored as long as neither of these limits is exceeded.

3.4.2 Saving and Recalling Programs

Generated programs will be lost when the power is switched off if they are not stored on floppy disk.

The SAVE command is used to store programs. And the LOAD command is used to recall programs from floppy disk.

By using the various R4611E save/recall functions, saved data can also be recorded as files on floppy disk.

3.4.3 Floppy Disk Management (Initialization)

Before a floppy disk can be used in R4611E, it must first be initialized by writing data of predetermined format to that disk. Note, however, that when a used disk is initialized, all previous data stored on that disk is lost. Therefore, before initializing a disk, always check its contents. Disk director information can be checked by using CAT or CHKDSK. Floppy disks are initialized by using the INITIALIZE command.

Example: INITIALIZE) ... ADVANTEST:R4611E and disk name
are determined automatically.
INITIALIZE "DEMO.DISK" ... The name enclosed between double
quotation marks becomes the disk
name.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

3.4 File Management

NOTE

The disk name can consist of up to 16 characters, the available characters being the same as those used in file names.

3.4.4 File Management CAT and CHKDSK

The CAT command is used to display the directory of the currently inserted disk. Directory details include (reading from left to right) registration number, file name, number of sectors used, number of characters, and file attributes.

The CHKDSK command is used to display disk information such as the disk name registered when the disk was initialized, number of files, and number of disk sectors used.

3.4.5 File Storage SAVE "File Name"

The SAVE command is used to store programs on floppy disk after appending a file name to the program. If a file name which already exists on that disk is specified, the contents of that file are updated.

3.4.6 File Recalling LOAD "File Name"

The LOAD command is used to retrieve files from floppy disk to memory.

3.4.7 File Deletion PURGE "File Name"

The PURGE command is used to remove unwanted files.

3.4.8 File Name Change RENAME "Old File Name" "New File Name"

The RENAME command is used to change the name of current files without changing their contents.

NOTE

File names can consist of up to 16 characters including alphanumeric characters and any special characters apart from those listed below.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.1 Outline

4. BASIC PROGRAMMING

4.1 Outline

In addition to general purpose BASIC commands, the BASIC language incorporated in R4611E is also equipped with GPIB control commands and R4611E dedicated built-in functions. Small-scale GPIB systems can be readily constructed.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

4.2 Activation of Program Mode

4.2 Activation of Program Mode

(1) Program Mode

Program mode can be activated by pressing the PROGRAM key on the R4611E front panel, or by pressing CHG MODE on the keyboard. As a result, the display shown below appears on the CRT screen. Since this is a toggle key, program mode is switched back to measuring mode if the key is pressed again.




Figure 4-1 CRT Display During Program Mode

① Display current input mode

[COMMAND] When cursor is on input line
 [EDITOR] When cursor is in scroll area

② Display file name which can currently be edited

<.....> ... Currently generating new data, or no file loaded
 <file-name> ... Name of file currently loaded

③ Display editor mode status

{ OK } File correctly loaded
 { NG } File not correctly loaded
 { NEW } New file being generated
 { MOD } Editing existing file
 { APN } Adding to existing file
 { ? } Command mode

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.2 Activation of Program Mode

- ④ When a function key is pressed, that function is displayed.

Input mode may be either command or editor. The initial mode set is command mode where all input data (maximum of 45 characters) is typed in on the input line. Direct input to the scroll area is not possible at this stage.

(2) Commands and Programs

When a statement following a line number is keyed in, that line becomes a program line. If a statement is typed in and executed without specifying a line number, the line is called a command.

Example: ▶10 PRINT "R4611E BASIC" Program
 ▶LIST 10 100 Command

(3) Input and Execution

To input a program line, type in a line number followed by a valid statement, and then press the RETURN or ENTER key. That line is then stored in memory as part of a program. That line is not executed until the program itself is executed.

When executing a new program, always remove the old program by typing in SCRATCH from the keyboard.

Example: ▶SCRATCH

The SCRATCH statement is used to initialize previous input programs and variables.

SCRATCH Initialization of programs and variables
SCRATCH 1 Initialization of variables
SCRATCH 2 Initialization of programs

4.3 Editor Mode Activation

Program input in command mode requires input of line numbers. And since program lines are cleared once the end is reached, it is very difficult to know the current position within a program, or to collate a program which has already been entered. The editor mode is used to overcome this problem.

• Editor Mode

Editor mode is activated by typing in EDIT and pressing the RETURN key. As a result, the display shown below appears on the CRT screen.




Figure 4-2 CRT Display During Editor Mode

Line numbers are displayed automatically in editor mode. Two parameters can be specified in the EDIT command. These are the initial line number, and the line increment. For example, the command

```
EDIT 100
```

specifies that line 100 of the file current in the editor area be displayed in the center of the CRT screen, and that the cursor be set at the end of that line.

If no parameters are specified, the following default values are used.

```
Initial line number: 10  
Line increment      : 10
```

But where a previous program is currently being edited, the line increment parameter value is disregarded.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.4 Program Editor Keys

4.4 Program Editor Keys

An optional keyboard (TR45103) is used to input programs. This keyboard is connected to R4611E which is then set to program mode. Note that apart from some panel keys and software keys, none of the R4611E functions can be used when in program mode.

NOTE

Since disconnecting the external keyboard connector during operation results in generation of an error, always switch the power off before connecting or disconnecting this connector.

The keyboard conforms with the JIS layout. Together with shift positions (with the SHIFT key depressed), standard ASCII characters including alphanumeric characters and special signs can be typed in.

① Special Keys

SHIFT

Used to key in characters in the shift position of each key. And when keying in alphabetic characters, the SHIFT key is used to key in upper case characters. If the CAPS LOCK key is locked, lower case characters are keyed in.

CTRL












Used in combination with other keys for input of special codes.

Table 4-1 CTRL Key Operation

Key input	Operation
CTRL + C	Suspend program or command execution
CTRL + D	Reset if editor fails
CTRL + G	Activate buzzer
CTRL + H	Delete character to left of cursor (same action as BACK SP key)
CTRL + I	Same as pressing TAB key
CTRL + J	LINE FEED Move cursor to beginning of line
CTRL + M	Terminate program input (same as RETURN key)
CTRL + Q	Same as pressing NO SCROLL key once
CTRL + S	Same as pressing NO SCROLL key twice

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.4 Program Editor Keys

	Press to terminate input of one line. In editor mode, the cursor moves to the beginning of the next line. In command mode, the input line is cleared, and the cursor moves to the beginning of the line.
	No function
	Move cursor one character to the right.
	Move cursor one character to the left.
	Move cursor one line upwards. If the cursor is already at the top line, the entire program is scrolled down by half a page, and the cursor moves to the center of the screen.
	Move cursor one line downwards. If the cursor is already at the bottom line, the entire program is scrolled up by half a page. There is no action when in command mode.
	Delete the character at the cursor position.
	When this key is locked by pressing, all subsequent input characters are keyed in as upper case characters. The key is unlocked by pressing a second time.
	Used to cancel editor mode, and to switch to command mode.
	Input of two spaces
	Delete character to the left of the cursor.

② Function Keys

First check that the function key name plate is 09. This name plate is divided into two upper rows with the function name printed on each key. Normally, only the lower row of functions is used. To use the upper row functions, the keys have to be pressed together with the SHIFT key.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

4.4 Program Editor Keys

Table 4-2 Function Key Operations

Function name	Command	Editor	Measuring mode
↓	x	o	x
⇓	x	o	x
↑	x	o	x
⇑	x	o	x
LIST	o	o	x
DEL LN	o	o	x
INS LN	x	o	x
CLR LN	x	o	x
F1 (LOAD ")	o	●	●
F2 (SAVE ")	o	●	●
F3 (SCRATCH)	o	●	●
F4	x	●	●
F5	x	●	●
F6	x	●	●
CAT	o	x	x
EDIT	o	x	x
CHKDSK	o	x	x
CHG MODE	o	x	o
NEXT	o	o	x
PREV	o	o	x
CLS	o	x	x
PAUSE	o	x	x
CONT	o	x	x
STOP	o	x	o
STEP	o	x	x
RUN	o	x	o

●: Partial functioning
 o: Function activated
 x: No function.

● Description of Functions

- ↓ Scroll up program by one line without changing cursor position.
- ⇓ Scroll up by half a page and move cursor to center line.
- ↑ Scroll down program by one line without changing cursor position.
- ⇑ Scroll down by half a page and move cursor to center line.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.4 Program Editor Keys

LIST	Commence display of program from beginning when in command mode, or redisplay current screen when in editor mode.
DELIN	Delete cursor line and line number.
INSLN	Open space equivalent to one character on the line where the cursor is located, and display a suitable minimum line number in that space. If insertion between lines is not possible, a message is displayed to recommend that no insertion be attempted.
CLRLN	Clear current cursor line without erasing line number.
F1 - F6	See main instruction manual (4.6 "Function Keys"). (Note that F1 thru F3 contain commands.)
CAT	Display CAT on command line.
EDIT	Display EDIT on command line.
ACHKDSK	Display floppy disk information.
CHG MODE	Switch menu screens for command and measuring modes.
PREV	Restore previous command executed in command mode.
NEXT	Reverse the result of executing PREV in command mode.
CLS	Clear editor screen, and set display start line at beginning.
PAUSE, CONT, STOP, STEP, and RUN	correspond to BASIC commands.

NOTE

- ① Use of the INS LN and DEL IN function keys may on odd occasions result in cursor or line number malfunction. If this happens, press LIST (redisplay screen) once or twice to correct the display and resume editing.
- ② The editor screen may deteriorate when using the CURSOR command in editor mode. In this case, press CTRL-D (reset editor) to return to normal editor display.
- ③ When the last line of a program is specified at the EDIT line number, the same line may appear twice on the screen. In this case, press LIST to return to normal.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.5 Program Editing

4.5 Program Editing

① Input of Program Lines

To insert a program line, type the program line after the line number, and then press the RETURN key.
In editor mode, line numbers are given automatically, but input or changing of line numbers is not possible.

② Insertion of Characters

To insert a character in a line which has already been programmed or which is about to be programmed, a single character can be inserted at the position of the cursor.
When a character is keyed in to be inserted at the cursor position, all characters from that position up to the end of the line after shifted to the right by one character.
After completing character insertion, always press the RETURN key. Although the screen display is changed, the actual program will remain unchanged if the RETURN key is not pressed.

③ Deletion of Characters

Characters can be deleted during programming by pressing the DEL or BS key. The character at the cursor position is deleted when the DEL key is pressed, and all characters to the right of that position are shifted to the left by one character.
When the BS key is pressed, the character to the left of the cursor is deleted, followed by left justification.

④ Insertion of Lines

Use INS_LN to insert a new line. For example, to insert a line between lines 130 and 140 in the following program, first move the cursor to the beginning of line 140. When INS_LN is pressed, line 131 is displayed waiting for the input data. If more than one line is inserted at this stage and RETURN is pressed, "Illegal insert line" is displayed. Therefore, first exist from editor mode, execute the REN command, and repeat the above procedure.

```
130 PRINT "KEY NUMBER ?"  
140 OUTPUT 31; "CH1"  
  
130 PRINT "KEY NUMBER ?"  
131 _  
140 OUTPUT 31; "CH1"
```


⑤ Clearing and Deletion of Lines

Lines may be removed by clearing (CLR_LN) or deleting (DEL_LN). Whereas "clearing" refers to removal of a program line without removing the line number, "deletion" refers to removal of the program line plus the line number.

```
(CLR_LN)  
130 PRINT "KEY NUMBER ?"
```

(Removed data)

```
(DEL_LN)  
140 PRINT "KEY NUMBER ?"
```

(Removed data)

And when in COMMAND mode, the DEL command is used to remove data. Two specifiers can be specified in the DEL command. The first number specifies the line number at the beginning of the block to be removed, and the second number specifies the line number at the end of the block.

```
DEL 100          Delete line 100.  
DEL 100, 200    Delete 200 lines from line 100.
```

⑥ Rearranging Program Numbers

If editing involves the deletion and insertion of many lines, the line numbers can be rearranged to make the program easier to read. This feature is also useful where many additional lines are inserted. Line numbers are rearranged by using the REN command. The first line number and the line increment can be specified.

For example, specifying
REN 50 100 5

results in the lines of the entire program (where the first line number is 50) currently stored in memory being renumbered from line 100 in line increments of 5. The default line increment value is 10.

⑦ Generation of Program List

Execute the LIST statement to display the entire program (or part of it) on the CRT screen. The range of lines to be shown can be specified in the LIST statement.

```
LIST 100          Display line 100 only.  
LIST 100, 200    Display from line 100 to line 200.  
LIST             Display entire program.  
LISTN 100, 10    Display 10 lines from line 100.
```

4.6 Programming Rules

4.6.1 Program Architecture

BASIC programs are collections of various types of statements. Statements are divided into two main types - control statements and executive statements (commands).




Figure 4-3 Statement Configuration

Each statement consists of a key word and expression, and this configuration is determined by grammatical syntax rules.

BASIC words whose meaning and applications have been decided in advance are called key words. Therefore, the same names as key word names cannot be used for any other purposes.

A list of key words is given in the following table.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

4.6 Programming Rules

Table 4-3 List of Key Words

AND,	APPEND,	AS,	ASCII,	BAND,	BASIC,
BINARY,	BNOT,	BOR,	BREAK,	BUZZER,	BXOR,
CASE,	CAT,	CHKDSK,	CLEAR,	CLOSE,	CLS,
CMD,	CONT,	CONTINUE,	CONTROL,	COPY,	COPYFILES,
COUNT,	CSR,	CURSOR,	DATA,	DEL,	DELIMITER,
DIM,	DISABLE,	DSTAT,	DUMP,	ELSE,	ENABLE,
END,	ENT,	ENTER,	ENTERF,	ERROR,	FOR,
FORMAT,	GLIST,	GLISTN,	GOSUB,	GOTO,	GPRINT,
IF,	INIT,	INITIALIZE,	INP,	INPUT,	INTEGER,
INTERFACE,	INTR,	ISRQ,	KEY,	LABEL,	LIST,
LISTEN,	LISTN,	LLIST,	LLISTN,	LOCAL,	LOCKOUT,
LPRINT,	LOAD,	MERGE,	NEXT,	NEWVERSION,	NOT,
OFF,	ON,	OPEN,	OR,	OUTPUT,	OUT,
OUTPUTF,	PAUSE,	PRINT,	PRINTER,	PRF,	PRINTF,
READ,	RESTORE,	PURGE,	RENAME,	REM,	REMOTE,
REN,	REQUEST,	RETURN,	RUN,	SAVE,	SCRATCH,
SELECT,	SEND,	SPRINTF,	SRQ,	STEP,	STOP,
SYSTEM,	TALK,	TEXT,	THEN,	TIME,	TO,
TRIGGER,	UNL,	UNT,	UNTIL,	USE,	USING,
XOR,					

Shorten name is used for entering a key word. Shorten names are provided for the frequently used and long key words. Shorten name can be used as a key word. On the display, shorten name is used when control register of 3 is set to 1 by CONTROL command. To display in full name, set the control register of 3 to 0.

(Correspondence of full name and shorten name)

Full name	Shorten name
CURSOR	CSR
ENTER	ET
INITIALIZE	INIT
INPUT	INP
OUTPUT	OUT
PRINTF	PRF
USING	USE

● Expressions

Expressions consist of objects and operators, and can be placed anywhere within the syntax where an expression can be specified. (To maintain compatibility with conventional BASIC, however, substitute expressions cannot be written in IF statement conditional expression since "=" is interpreted as a code.) Expressions include,

arithmetic expressions,
character string expressions,
logical expressions, and
label expressions

which differ according to the data format in which the final calculated value is obtained. Arithmetic expressions consist of integer and real numbers. Logical expressions are determined by syntax, irrespective of whether the expression contains logical operators, the final value being evaluated as a logical value. That is, 0 is false, and anything else is true. Likewise, label expressions are also determined by syntax, the final value representing a line number. Unlike other expressions, however, label expressions contain a label constant.

4.6.2 Objects

Elements subject to BASIC processing are called objects. These include constants, variables, and functions in each data format (integer numbers, real numbers, and character strings).

Arrays can be used in integer formats. Variables which have no array structure are called scalar variables and real number variables.




Figure 4-4 Object Configuration

(1) Constants

• Real Constants

Numerical values with no decimal point are regarded as integer numbers in programs. Since these can be expressed internally in 4 bytes, numbers can be expressed from -2,147,483,648 to 2,147,483,647.

• Real Numbers

Numerical values containing a decimal point, or expressed as an exponential number like 1E+20 are regarded as real numbers. And since these can be expressed internally by using 8 bytes (IEEE), numbers from about -1E+308 to 1E+308 can be represented with an accuracy of 15 digits.

• Character String Constants

Character strings are expressed by being enclosed between double quotation marks ("). Character strings can be specified as a null character string (" "), or as strings containing up to 255 characters. The component character unit is 8 bits which allows a maximum of 256 different character units to be expressed. The ASCII character code is used, characters 128 thru 255 being special symbols.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

Reference:

To express (by program) codes not assigned to the keyboard, and to input data by INPUT statement, (\) is used in a method called \014 (form field). Likewise, to include double quotation marks inside a character string, this may be written as \".

The following escape sequence is provided to express ASCII control characters.

	Octal	Decimal	
x b	010	8	Back space
x t	011	9	Vertical tabulation
x n	012	10	Line feed (New line)
x v	013	11	Vertical tabulation
x f	014	12	Form feed (Clearing screen)
x r	015	13	Carriage return

● Label Constants

Label constants are used instead of statement numbers, and are declared by appending an asterisk (*) at the start of a program. Although the characters which can be used are the same as those for variables, substitution is not possible because they are not variables. And places where labels can be written are restricted by syntax. Labels are described further in a later section.

(2) Variables

Variable names consist of up to 20 alphanumeric characters starting with an alphabetic character.

Table 4-4 Alphanumeric Characters

1, 2, 3, 4, 5, 6, 7, 8, 9, 0
a, b, c, d, e, f, g, h, i, j, k, l, m, n, o, p, q, r, s, t
u, v, w, x, y, z
A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T
U, V, W, X, Y, Z
—

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

Variable names become character string variables if \$ appended to the end. And if ... is appended to the end of a variable name instead of a \$, that variable becomes an array type variable. If a variable is not specifically declared by INTEGER statement, it becomes a real number type of variable.

Examples of variable types:

value, v123	Real variables
string\$, s123\$	Character string variables
array(3)	Array type real variable
INTEGER code	Integer variable
INTEGER week(7)	Array type integer variable

① Scalar Variables

- Integer variables
- Real variables
- Character string variables

Numerical variables are allocated the value 0 unless specifically initialized. Therefore, variables to initialized to a specific value must have a specific value substituted in them in the program. The size of values which can be stored in each data type are the same as for constants.

There are no array character string variables. Like character string constants, character strings include a length attribute. The DIM statement is used to declare length.

```
DIM string$[100]
```

If collating without a declaration, the default character string length is 18 characters.

By using a sub string operator ([]), certain parts of the character string can be handled (see sub string operator).

```
string$ = "ADVANTEST CORPORATION"  
PRINT string$[1,14]; "."
```

Result:

```
ADVANTEST CORP.
```

② System Variables

● Current Line Variable @

Storage of the program line number currently be executed. Values cannot be substituted.

LIST @-10 @+10 : Display of 10 lines before and after the line currently being executed.

● Built-in Variables

Built-in variables are registered automatically when BASIC is started up. These are initialized by fixed values, and can be substituted by specific values. To return to the original value, either explicitly substitute that value, or initialize by using NEW 2, NEW.

PI : 3.14152
EXP: 2.71828

③ Array

Use the DIM or INTEGER statement to declare an array.

● Numerical Array

If collating without a declaration, the default size (that is, number of elements) is 10. The result is the same as when declaring as shown below.

DIM array(10)
INTEGER array(10)

Real number array DIM real(20)
Integer number array INTEGER int(30)(40)

(3) Functions

All functions are built-in functions, and are divided into integer, real number, and character string types in terms of the return value. And since function calls can be described in operational expressions, functions can be handled in the same way as variables.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

```
string$ = "ADVANTEST"  
PRINT string$  
A = NUM("A")  
a = NUM("a")  
FOR idx = 0 TO LEN(string$)  
    b = NUM(string$[idx:1]) - A + a  
    string$[idx:1] = CHR$(b)  
NEXT idx  
PRINT string$
```

Result:

```
ADVANTEST  
advantest
```

Built-in functions

- NUM(character string expression)
The ASCII code of the leading character of the character string expression is returned.
NUM("A") → 65
- CHR\$(arithmetic expression)
The character string expression of the single ASCII character corresponding to the arithmetic expression value is returned.
CHR\$(65) → "A"
- LEN(character string expression)
Length of character string expression is returned.
LEN("ADVANTEST") → 9
- POS(character string expression 1, character string expression 2)
The start position of a certain position in character string expression 2 is returned from character string expression 1.
POS("ADVANTEST", "AN") → 4
- SIN(arithmetic expression)
- COS(arithmetic expression)
- TAN(arithmetic expression)
- ATN(arithmetic expression)
- LOG(arithmetic expression)
- SQR(arithmetic expression)

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

In addition to those listed below, a wide range of R4611E built-in functions capable of handling measured values is available. See the list of built-in functions in section 5.1 "Built-in Functions".

--- built-in function ---

Stimulus freq. → Point No.

POINT1 (F,M)
POINT2 (F,M)
DPOINT (F0,F1,M)

Point No. → Stimulus freq.

FREQ (P,M)
DFREQ (P0,P1,M)

Point No. → Response Value

VALUE (P,M)
DVALUE (P0,P1,M)

Stimulus freq. → Response Value

CVALUE (F,M)
DCVALUE (F0,F1,M)

Searching Maximum

MAX (P0,P1,M)
FMAX (P0,P1,M)
PMAX (P0,P1,M)

Searching Minimum

MIN (P0,P1,M)
FMIN (P0,P1,M)
PMIN (P0,P1,M)

Calculate Band width

BND (X,Ls,M)
BNDL (X,Ls,M)
BNDH (X,Ls,M)

Differential coefficient

DIFFX (deltaX,deltaY)
DIFFY (deltaX,deltaY)

Finding Ripple out (I)

RPL1 (P0,P1,deltaX,deltaY,M)
RPL2 (P0,P1,deltaX,deltaY,M)
RPL3 (P0,P1,deltaX,deltaY,M)

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

Finding

RPLH(P0,P1,deltaX,deltaY,M)
FRPLH(P0,P1,deltaX,deltaY,M)
PRPLH(P0,P1,deltaX,deltaY,M)
RPLL(P0,P1,deltaX,deltaY,M)
FRPLL(P0,P1,deltaX,deltaY,M)
PRPLL(P0,P1,deltaX,deltaY,M)
NRPLH(P0,P1,deltaX,deltaY,M)
NRPLL(P0,P1,deltaX,deltaY,M)
PRPLHN(N,M)
PRPLLN(N,M)
FRPLHN(N,M)
FRPLLN(N,M)
VRPLHN(N,M)
VRPLLN(N,M)

Testing limit

LMTUL1(X,Up,Lo,M)
LMTUL2(P,Up,Lo,M)
LMTMD1(X,Up,Lo,M)
LMTMD2(P,Up,Lo,M)

4.6.3 Operational Expressions

Objects are manipulated by operators, and objects and operators are combined in expressions.

Operators ——— (1) Substitution operator
 |
 | (2) Unary arithmetic operator
 | (3) Binary arithmetic operator
 | (4) Logical operator
 | (5) Comparative operator
 | (6) Sub string operator

(1) Substitution Operators

The conventional BASIC keyword "LET" has not been included. The substitution operator contains its own value to become a single expression.

PRINT a=1 → 1
PRINT a\$="ADVANTEST" → "ADVANTEST"
PRINT (a=1)+a → 2

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

4.6 Programming Rules

The substitution operator contains the following elements.

= Normal substitution

In character string substitutions, the valid characters on the right hand side are transferred.

Example: INTEGER string\$[20]
PRINT LEN(string\$ = "121345")

Result: 5

Substitution after conversion to data format on left hand side of =.

Example: string\$ = 123.456 → "123.456"
numeric = "123" → 123
integer = 123.456 → 123

+= a += 10 <==> a = a + 10
-= a -= 10 <==> a = a - 10
*= a *= 10 <==> a = a * 10
/= a /= 10 <==> a = a / 10
%= a %= 10 <==> a = a % 10

=< Substitute after left justification of character string.
=> Substitute after right justification of character string.

(2) Unary Arithmetic Operators

- Minus sign
+ Plus sign
++ Pre-/post-increment
Pre- a = 1 : b = ++a
Substitute in b after adding 1 to a.
Post- a = 1 : b = a++
Add 1 to a after substituting in b.
-- Pre-/post-decrement
Pre- a = 1 : b = --a
Substitute in b after subtracting 1 from a.
Post- a = 1 : b = a--
Substitute 1 from a after substituting in b.

Example:

a = 10 : PRINT a++ : PRINT a : PRINT --a : PRINT --a : PRINT a

Result: 10.
11.
10.
9.
9.

(3) Binary Arithmetic Operators

- + Addition
- Subtraction
- * Multiplication
- / Division
- % Modulo (remainder)
To maintain BASIC compatibility, same as MOD. MOD, however, is converted internally to %.
- ^ Involution
- & Character string concatenation

(4) Logical Operators

NOT
AND
OR
XOR

(5) Bit Operators

They execute the 16-bit calculation. Only the integer type equations can be set. If a real type equation is set, an error occurs.

BNOT
BAND
BOR
BXOR

(6) Comparative Operators

The following comparative operators are used. 1 is taken if result is true, and 0 if false. When a comparative operation is executed in BASIC syntax, and the final result is 0, this is taken as false. All other results are taken as true.

= Equal (or ==)
<> Not equal
<
>
<=
>=

Since this comparative operator must always execute a logical operation in IF statement conditions, the "=" operator is regarded as a unconditional comparative operator. Therefore, substitution expressions cannot be included in IF statement condition expression.

To execute comparison operations apart from using an IF condition expression, "==" is used for equal operation purposes to make a distinction from "=" used in substitution operators.

```
a = (b$ == "COMPUTER")
```

If the character variable b\$ is "COMPUTER", variable a is 1.

(7) Sub String Operator

Character string expression parts can be specified as a character string.

```
Character string expression[arithmetic expression 1  
                             ,arithmetic expression 2]
```

The section of a character string expression where arithmetic expression 1 has advanced from the beginning of the string expression by the indicated value up to the value where arithmetic expression 2 is indicated is the sub string.

```
"ADVANTEST" [1,5] → "ADVAN"
```

```
Character string expression[arithmetic expression 1  
                             ;arithmetic expression 2]
```

The number of characters in a character string expression where arithmetic expression 1 has advanced from the beginning of the string expression by the indicated value up to the value where arithmetic expression is indicated is the sub string.

```
"ADVANTEST" [6,4] → "TEST"
```


R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.1 Outline

5. COMMAND AND STATEMENT SYNTAX AND COMMENTARY

5.1 Outline

The command and statement syntax used in R4611E is described here in combined diagrammatical/textual format to make it easier to understand.

<Syntax representation>

(1) Diagrammatical Representation

The syntax is divided into component elements linked up by straight lines.

Statements always proceed in the direction indicated by arrows. If branching occurs, the statement proceeds along one of those branches. And where a loop is formed, that loop may be passed any number of times.

(2) Textual Representation

The following symbols are used in textual representation.

- []: Sections enclosed by this symbol may be omitted.
- { }: Sections enclosed by this symbol may be used any number of times.
- | : This symbol denotes "or".
(Example: <A>| ... Use either <A> or .)

Terminology used in these diagrammatical and textual representations is described below.

- Numerical value representation
... Numerical constant, numerical variable, or numerical expression
- Character string representation
... Character string constant, character string variable, character string function, or expression consisting of substrings.
- Device address
... Address of device connected to GPIB

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.2 List of Commands and Statements

5.2 List of Commands and Statements

* Commands

EDIT : Start editor mode
COPY : Copy file
DEL : Delete specified line number
CHKDSK : Display disk status
CAT : Output file name on CRT screen
INITIALIZE: Initialize floppy disk
LIST : Display program list on CRT screen
LISTN : Display program list on CRT screen
LOAD : Load BASIC program from floppy disk
MERGE : Load and merge program with another program
SCRATCH : Delete previously loaded program
GLIST : Output program list to GPIB
GLISTN : Output program list to GPIB
LLIST : Output program list to serial port
LLISTN : Output program list to serial port
PRINTER : Set printer GPIB address
PURGE : Delete file from disk
RENAME : Change file name
REN : Renumber line numbers
RUN : Execute a program
CONT : Resume program execution
STEP : Execute one line of program
SAVE : Save BASIC program to floppy disk
CONTROL : Set the various BASIC control variables
DUMP : Indication in the memory and file
FRE : Indication of the basic program buffer remain

* Statements

BUZZER : Buzzer
CURSOR : Cursor position control
DIM : Declare array variables
INTEGER : Define variable as integer number
DISABLE INTR: Disable interrupt branching
ENABLE INTR : Enable interrupt branching
FOR-TO-STEP : Execute loop processing
NEXT : Execute loop processing
GOSUB : Branch to subroutine
RETURN : Return from subroutine
GOTO : Branch to specific line
IF THEN : Conditional branching
INPUT : Input from keyboard
OFF SRQ : Release interrupt branching generated by SRQ
OFF ISRQ : Release interrupt branching generated by ISRQ
OFF KEY : Release interrupt branching generated by KEY input
ON SRQ : Define interrupt branching by GPIB external SRQ signal

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.2 List of Commands and Statements

(List of commands and statements - cont.)

ON ISRQ : Define interrupt branching by R4611E internal source
ON KEY : Define interrupt branching by KEY input
ON ERROR : Define branching to be executed if BASIC error is detected
PAUSE : Halts program execution temporarily
PRINT[USING]: Display (output) of numerical values and character strings
PRINTF : Display (output) of numerical values and character strings
SPRINTF : Replaces character strings with results of PRINTF format
GPRINT : Output numerical values and character strings to GPIB
LPRINT : Output numerical values and character strings to serial
port
PRINTER : Set GPIB address for printer
REM : Comment
CLS : Clear screen
DATA : Replaces constants in the DATA statements with variables
READ : Defines numerical values and character strings to be read
in the READ statement
RESTORE : Defines DATA lines to be read in the next DATA statement
SELECT : Branches as conditioned by values of the equation
CASE : Defines conditions
ERRN : Returns error code
ERRM\$: Returns error message
BREAK : Exit FOR-NEXT block
CONTINUE : Branch to loop of next step value from FOR-NEXT loop

GPIB control statements

CLEAR : Clear device
DELIMITER : Specify block delimiter
ENTER : Input from GPIB
INTERFACE CLEAR: Clear GPIB interface
LOCAL : Release remote control
LOCAL LOCKOUT : Local lockout
OUTPUT : Output to GPIB
REMOTE : Remote control
REQUEST : Set status byte
SEND-DATA-CMD-TALK-LISTEN-UNT-UNL
: Output of commands and data to GPIB
TRIGGER : Output of group execute trigger

File control statements

ENTER [USING] : Reads data in files
OFF END : Releases processing specified by the ON END statement
ON END : Defines end-of-file processing
CLOSE : Closes files for file descriptor
OPEN : Opens files for file descriptor
OUTPUT [USING]: Writes (output) data into the file
COPYFILES : Copies files to another floppy disk

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.3 BASIC Command Syntax

5.3 BASIC Command Syntax

- | | | | |
|-------------------|----------------|----------------|----------------|
| 1. EDIT | See page 5-5. | 25. DUMP | See page 5-25. |
| 2. COPY | See page 5-6. | 26. FRE | See page 5-26. |
| 3. DEL | See page 5-6. | | |
| 4. CHKDSK | See page 5-7. | | |
| 5. CAT | See page 5-8. | | |
| 6. INITIALIZE ... | See page 5-8. | | |
| 7. LIST | See page 5-9. | | |
| 8. LISTN | See page 5-11. | | |
| 9. LOAD | See page 5-13. | | |
| 10. MERGE | See page 5-14. | | |
| 11. SCRATCH | See page 5-14. | | |
| 12. GLIST | See page 5-15. | | |
| 13. GLISTN | See page 5-16. | | |
| 14. LLIST | See page 5-17. | | |
| 15. LLISTN | See page 5-18. | | |
| 16. PRINTER | See page 5-19. | | |
| 17. PURGE | See page 5-19. | | |
| 18. RENAME | See page 5-19. | | |
| 19. REN | See page 5-20. | | |
| 20. RUN | See page 5-21. | | |
| 21. CONT | See page 5-21. | | |
| 22. STEP | See page 5-22. | | |
| 23. SAVE | See page 5-22. | | |
| 24. CONTROL | See page 5-23. | | |

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.3 BASIC Command Syntax

1. EDIT

Outline

Start program editor mode. During input of program, line numbers appear automatically on the CRT screen.

Syntax



EDIT [Integer][Integer]

Specify any integer from 1 to 65535.

Commentary

- Display several lines before and after the current line when program editor mode is started.
- The first integer specifies the start line number, and the second integer specifies the line increment. Both values are valid only when editor mode is started with no program in the BASIC buffer (such as immediately after SCRATCH).

EDIT Start line number Increment

These integer numbers can be omitted, defaults values of 10 being set automatically for each integer.

Example


```
EDIT  
EDIT 100  
EDIT 30 5
```

2. COPY

Outline

Copy registered file to floppy disk.

Syntax



Commentary


- Copy old file name to new file name. No action taken if file name with same name as "new file name" already exists, or if the new file name is the same as the old file name. Both file names can be specified using character string representation.

3. DEL

Outline

Delete line from program.

Syntax



Commentary

- Delete line from input program.
- Specify any line number from 1 to 65535.
- Error message is displayed if no number is specified.

Example

```

DEL 10          Delete line #10
DEL 10, 100    Delete lines #10 to 100
DEL , 100      Delete first line to line #10
DEL 10,        Delete lines #10 to last line
    
```

4. CHKDSK

Outline

Display status of disk in disk drive.

Syntax



Commentary

- Display status of disk in disk drive. This information includes:

DISKNAME ... Disk name applied during initialization
FILES Number of files
SECTOR Number of sectors used
DATE Date and time of initialization

Where:

FILES are up to 200.

SECTORS are up to 1400.

SECTOR is a unit of information stored on a disk.

1 SECTOR is equal to 512 bytes.

Example

The following display appears when CHKDSK is executed immediately after initialization.

<DISK-ID>


```
[DATE      : 1988.01.15 (Fri) 13:05]
[FILE      :    0 /   200          ]
[SECTOR    :    0 /  1400          ]
[DISKNAME  : ADVANTEST_R4611E     ]
```

5. CAT

Outline

Display of file stored on floppy disk.

Syntax



CAT

Commentary


- Display of contents of file stored on disk. When CAT is used, the registration number, file name, number of sectors used, number of characters, and file attributes are displayed in that order. And by using CAT "DATE", the registration number and file name are followed by the time the file was generated.

6. INITIALIZE

Outline

Initialize a new disk, or a disk which is no longer required.

Syntax



Commentary

- Floppy disks used in R4611E must first be initialized by an initialization process specific for R4611E. A disk name used to identify the disk is input at this stage. If no disk name is set, the disk name automatically becomes 'ADVANTEST : R4611E'. This disk name can be specified as a character string expression.

Caution


Disk names may contain up to 16 characters, and the character which may be used are the same as those which may be used in file names. (See SAVE 'Caution' note.)

7. LIST

Outline

Display program list on CRT screen.

Syntax



LIST [Start line] [,] [Stop line]

* When the numerical value for the start line or that of the stop line is specified, the system assumes the start line.
Specify any integer from 1 to 65535.

Commentary

The portion of BASIC program list specified by the parameter is displayed on the CRT screen. Displaying of list can be interrupted by the stop key. Unlike program execution, resumption of display from the point of interruption is impossible.
Line numbers are specified by equations. Line number zero and number 65536 or higher are given special meanings, the first line and the last line of the program. A line number that is lower or higher than the actual program line number in the buffer is also considered the first line and the last line of the program.

To state the portion to be displayed, use one of the methods listed above.

- (1) Displays the portion specified by the start line and the stop line.
- (2) Displays the portion specified by the start line and comma, where the comma represents the last line of the program. Display continues up to the last line, though not specified.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.3 BASIC Command Syntax


- (3) Displays only the start line.
- (4) Displays the first line of the program to the specified stop line. Comma cannot be omitted.
- (5) When both the start line and the stop line are omitted, all the lines are displayed.

8. LISTN

Outline

Display program list on CRT screen.

Syntax



LISTN [First line] [,] [Number of lines]

Specify any integer from 1 to 65535.

Commentary

The portion of the BASIC program list specified by the parameter is displayed on the CRT screen. In this function, which is basically the same as the LIST command, the second parameter is the number of lines to be displayed.

- (1) Displays the specified number of lines counting from the first line. When the specified number of lines has a negative value, the count is reversed.
- (2) The number of lines is omitted. Displays the portion specified by the first line and the last line. The system assumes method (3) if the required comma is omitted.
- (3) Displays only the first line.
- (4) The first line is not specified. If the specified number of lines has a positive value, display starts from the first line, and if the specified number of lines has a negative value, the display is reversed from the last line.
- (5) When the specification is the comma only, without parameters, all the lines are displayed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.3 BASIC Command Syntax

Example

```
LISTN  
LISTN 100 20  
LISTN 200,-10
```

Caution

In BASIC command patterns apart from EDIT, either character string variables or numerical value representation can be specified. That is, numerical variables used in BASIC can also be used here. For easier reading purposes, however, integer and character string expressions are used in the following pages. The decimal places of real numbers are rounded off to the nearest whole number.

As a rule, commas (,) are not required if the boundary between successive expressions in a BASIC command can be detected in terms of command syntax.


For example, no comma is required in line 2 of the above example since the numeric values 100 and 20 can be read. But in line 3, omission of the comma results in the numeric values being read as $200 - 10 = 190$. That is, line 190 would be displayed instead of the ten lines counting back from line 200.

9. LOAD

Outline

Call file from floppy disk.

Syntax



Commentary

Call the file specified by file name to enable editing of that file. Non-BASIC files which cannot be edited (such as system files) cannot be called.


R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.3 BASIC Command Syntax

10. MERGE

Outline Call file from floppy disk.

Syntax




Commentary Unlike LOAD, the BASIC buffer is not initialized prior to loading. The program already present in the BASIC buffer is not cleared unless line numbers coincide.

11. SCRATCH

Outline Erase BASIC program from memory.

Syntax



SCRATCH [1 2]

Commentary

- Run this program if the previously loaded BASIC program is no longer required.
- If only the data of the program present in the BASIC buffer is to be initialize, specify 1.
- If only the procedure of the program present in the BASIC buffer is to be initialized, specify 2.

Example


```
SCRATCH  
SCRATCH 1  
SCRATCH 2
```

12. GLIST

Outline

Output of program list to printer etc. via GPIB.

Syntax



GLIST [Integer][,Integer]

Specify any integer from 1 to 65535.

Commentary

- Output of BASIC program to printer etc. connected to GPIB.
- The printer GPIB address is set by PRINTER statement.
- The output program list starts from the specified line number.

Example


GLIST
GLIST 100,200

13. GLISTN

Outline

Output of program list to printer etc. via GPIB.

Syntax



GLISTN [Integer 1][,Integer 2]

Commentary

- Output of BASIC program to printer etc. connected to GPIB.
- The printer GPIB address is set by PRINTER statement.
- Output program list of the number of lines specified by integer 2 starting from the line number specified by integer 1.
- If integer 1 has a negative value, the number of lines counting in reverse are listed.

Example


```
GLISTN
GLISTN 100,20
GLISTN 200,-10
```

14. LLIST

Outline

Output of program list to printer etc. via serial port.

Syntax



LLIST [Integer][,Integer]

Specify any integer from 1 to 65535.

Commentary

- Output of BASIC program to printer etc. connected to the serial port.
- Output of program list starting from specified line number.

Example


LLIST
LLIST 100,200

15. LLISTN

Outline

Output of program list to printer etc. via serial port.

Syntax



LLISTN [Integer 1][,Integer 2]

Commentary

- Output of BASIC program to printer etc. connected to the serial port.
- Output program list of the number of lines specified by integer 2 starting from the line number specified by integer 1.
- If integer 1 has a negative value, the number of lines counting in reverse are listed.

Example

```
LLISTN  
LLISTN 100,20  
LLISTN 200,-10
```

16. PRINTER


See PRINTER statement for details.

17. PURGE

Outline

Erase file from floppy disk.

Syntax



Commentary


- Erase existing files which are no longer required.
- File names stored by SAVE/RECALL but no longer required can be erased by this command.

18. RENAME

Outline

Change the name of file stored on floppy disk.

Syntax



Commentary


- Change old file to new file name. The new file name must not be the same as any existing file name nor the old file name. And since only the name is changed, the contents of the new file are identical to the contents of the old file.

19. REN

Outline.

Renumber the line numbers of each program line.

Syntax



REN [[Old line number]][,[New line number][,[Increment]]]

- * Old and new line numbers, and increment, are all integers (1 thru 65535).
- * The default value for the new line number and increment is 10.
- * If the old line number is omitted, a comma must be inserted before the new line number to identify that number.

Commentary

- The "old line number" is the current program line number where line renumbering is to commence.
- The "new line number" is the new start line number.
- The "increment" is the new line number increment.
- The REN command also changes line numbers used by GOTO, GOSUB etc.
- The REN command cannot generate line numbers greater than 65535. Nor is it possible to change the order of line numbers.

Example

REN
Program starts from line 10, and is incremented throughout in steps of 10.


REN 30,50,3
Line number 30 is changed to 50, and subsequent lines are incremented in steps of 3.

20. RUN

Outline

Run a BASIC program.

Syntax



RUN [Line number]

Commentary

- Run BASIC program from specified line.
- Run program from first line if no line is specified.
- When the RUN command is executed, all variables are cleared prior to commencement, and array declarations etc. are reset.

Example


RUN
RUN 200

21. CONT

Outline

Resume execution of BASIC program.

Syntax



CONT [Line number]

Commentary

- Execution of BASIC program is resumed from specified line.
- Variables are not initialized by CONT command.


Example

CONT 200

22. STEP

- Outline
- Syntax

Run a single line of a BASIC program.



STEP [Line number]

Commentary

- Run the single specified line of a BASIC program. Note that STEP cannot be run in a FOR statement.
- Execute the next line after the last executed line if no line is specified.


Example

```
STEP  
STEP 100
```

23. SAVE

- Outline
- Syntax

Save file to floppy disk.



Commentary

- An edited program (from the first statement with a line number up to the last) is registered as a file under the specified file name. If the specified file name already exists, the old file contents are updated by the new file.

Caution


File names may consist of up to 16 characters. All characters apart from " (double quotation mark) may be used.

24. CONTROL

Outline

Set various values related to BASIC control.

Syntax



CONTROL <Registration number>;<Value>

Commentary

Specify control elements to be set by registration number. Values following the semicolon are actual settings.

Registration number

(Registor 1)

Serial I/O port initialization

Specifies by the summation of the following values.

Value: Baud rate

0: 1200 baud
1: 2400 baud
2: 4800 baud o
3: 9600 baud

Character length

0; 5 bits
4; 6 bits
8; 7 bits
12; 8 bits o

Parity

0; No parity o
16; Odd parity
48; Even parity

Number of stop bits

0; None
64; 1 bit
128; 1 1/2 bit
192; 2 bits o

(o denotes default setting
when power is switched on.)

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.3 BASIC Command Syntax

(Register 2)

The printing position from the left hand margin is specified by the number of spaces with LLIST/GLIST.

(Register 3)

Selects whether the BASIC program is indicated in shorten name or conventional full name. When 1 is set, BASIC program is indicated in shorten name. When 0 is set, full name indication is selected.

(Register 5)

Register 5 is used to change the environment to that for maintenance. When register 5 is set to 1, POKE command is effective. If register 5 is set to 0, POKE command is invalid.

Example

Registration number 1

Set baud rate to 9600, character length to 8 bits, even parity, and 2 stop bits.

[CONTROL 1;3+12+48+192] or [CONTROL 1;255]

This completes the setting.

Registration number 2

Right justify LIST output
Execute the following command.

[CONTROL 2;5]

When the LLIST or GLIST command is run, 5 spaces are inserted in front of each line number before output of the list.


```
----- 10 PRINT "ADVANTEST"  
----- 20 PRINT "    R4611 NETWORK"  
----- 30 PRINT "        ANALYZER"  
----- 40 END
```

25. DUMP

Outline

Displays memory and files.

Syntax



DUMP "AFILE"

Commentary

This debugger command displays the entire memory or file as is.

When two equations are specified, the system assumes them to be the first address and the last address of the memory, and displays the portion between them in hexadecimal and associated ASCII codes.

When the character string is specified, the system assumes it is the file name and displays the entire file.


If the PAUSE key is pressed to stop displaying, resumption is impossible.

26. FRE

Outline

Indicates the remaining memory capacity for the BASIC program.

Syntax



Commentary

PRINT FRE (Φ)

This system function indicates in alphanumerics the approximate remaining memory capacity for the BASIC program.

The system only makes a rough judgment without reconstructing the memory, thus once saved, the indicated capacity may be larger than the real capacity.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

5.4 R4611E BASIC Statement Syntax


- | | | | |
|---------------------|----------------|-------------------|-----------------|
| 1. BUZZER | See page 5-28. | 23. PRINTER | See page 5-61. |
| 2. CURSOR | See page 5-29. | 24. REM | See page 5-62. |
| 3. DIM | See page 5-30. | 25. CLS | See page 5-62. |
| 4. INTEGER | See page 5-32. | 26. DATA | See page 5-63. |
| 5. DISABLE INTR ... | See page 5-33. | 27. READ | See page 5-64. |
| 6. ENABLE INTR | See page 5-34. | 28. RESTORE | See page 5-65. |
| 7. FOR-TO-STEP | See page 5-35. | 29. SELECT | See page 5-66. |
| NEXT | | CASE | |
| 8. GOSUB | See page 5-37. | 30. ERRN | See page 5-67. |
| RETURN | | 31. ERRM\$ | See page 5-68. |
| 9. GOTO | See page 5-39. | 32. PEEK | See page 5-68a. |
| 10. IF THEN | See page 5-40. | 33. POKE | See page 5-68b. |
| 11. INPUT | See page 5-43. | | |
| 12. (LET) | See page 5-45. | | |
| 13. OFF SRQ | See page 5-47. | | |
| OFF ISRQ | | | |
| 14. OFF KEY | See page 5-48. | | |
| 15. ON SRQ | See page 5-49. | | |
| ON ISRQ | | | |
| 16. ON KEY | See page 5-51. | | |
| 17. ON ERROR | See page 5-52. | | |
| 18. PAUSE | See page 5-53. | | |
| 19. PRINT | See page 5-54. | | |
| 20. PRINTF | See page 5-57. | | |
| 21. SPRINTF | See page 5-59. | | |
| 22. GPRINT | See page 5-60. | | |
| LPRINT | | | |

1. BUZZER

Outline

Activate buzzer.

Syntax



BUZZER Integer 1 Integer 2

Commentary

- When BUZZER statement is executed, the R4611E's built-in buzzer is activated in accordance with the designation.
- The buzzer tone is specified by integer 1. Specify any value from 0 (high tone) to 255 (low tone).

Example:

```
10 FOR I = 1 TO 255  
20 BUZZER I, 10  
30 NEXT I  
40 STOP
```

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.4 R4611E BASIC Statement Syntax

2. CURSOR

Outline

Move cursor to specified coordinate position.

Syntax



CURSOR Numerical value representation
[X axis designation]
Column direction

, Numerical value representation
[Y designation]
Row direction

Commentary

- Move cursor to specified position on the CRT screen.
- The first value enclosed in parentheses indicates the X axis coordinate, and the second value indicates the Y axis coordinate.

CURSOR X axis coordinate, Y axis coordinate

These two values must lie within the following ranges.

$0 \leq X \text{ axis coordinate} \leq 45$

$0 \leq Y \text{ axis coordinate} \leq 24$

Example


```
10 PRINT CHR$(12)
20 X=0:Y=4:X1=1:Y1=1
30 CURSOR X,Y:PRINT "*"
40 X=X+X1:Y=Y+Y1
50 IF X<=0 OR 46<=X THEN X1 *= -1
60 IF Y<=0 OR 26<=Y THEN Y1 *= -1
70 CURSOR X,Y:PRINT ""
80 GOTO 30
90 STOP
```

3. DIM

Outline

Array variable or character string variable definition declaration.

Syntax



DIM A (Numerical value representation)
 { ,<A>(Numerical value representation)}

A ::= Numerical variable

Commentary

- When an array variable or character string variable is used, the array variable name and array size must be defined by DIM statement. If name and size are not defined, the array becomes 10 elements in 1-dimension, and the character string takes a length of 18 characters.
- When an array is declared using the DIM statement, the array variable of the specified size is stored in memory. Therefore, if the declared variable is too big, there will be insufficient space left for the BASIC program. (An error is generated and program execution is stopped if the array size is greater than the memory space.)
 (Out of memory)
- If the result of operation on a numerical value representation for array variable size is a real number expression, the decimal places are rounded off to an integer number expression.
- When using a character string variable, the length of the character string is declared by numerical value representation.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example

```
10 DIM n(5)
20 FOR i = 1 TO 5
30   n(i) = i*i/2
40 NEXT i
50 FOR i = 1 TO 5
60   PRINT n(i)
70 NEXT i
```

<Execution result>


```
0.5
2.0
4.5
8.0
12.5
```

4. INTEGER

Outline

Declaration that the variable or array variable is an integer.

Syntax.



INTEGER <A>(Numerical value representation)
 { ,<A>(Numerical value representation) }

<A> ::= Numerical variable

Example

```

10 INTEGER array(2,3)
20 PRINT "j\i" ;
30 PRINT USING "X,3D,3D,3D" ;1,2,3
40 PRINT " " ;
50 FOR i = 1 TO 2
60   FOR j = 1 TO 3
70     array(i,j) = i*10 + j
80   NEXT j
90 NEXT i
100 FOR i = 1 TO 2
110 PRINT USING "- ,2D,2X,#" ;i
120   FOR j = 1 TO 3
130     PRINT USING "3D,#" ,array(i,j)
140   NEXT j
150 NEXT i
    
```

<Execution result>

```

j\i  1  2  3
1  11 12 13
2  21 22 23
    
```

5. DISABLE INTR

Outline

Disable acceptance of interrupts.

Syntax

DISABLE INTR

DISABLE INTR

Commentary

- Disable interrupts enabled by ENABLE INTR.
- To enable interrupts again after executing this statement, execute the ENABLE INTR statement. Branch conditions set by ON XXX statement are maintained unchanged in this case. If the interrupt branch conditions are to be changed, use the ON XXX or OFF XXX statement before executing the ENABLE INTR statement.
- Interrupts are disabled from immediately after execution of this program until the ENABLE INTR statement is executed.

Example

```
10 OUTPUT 31; "EDITOFF SRQE"  
20 ON ISRQ GOTO 60  
30 ENABLE INTR  
40 ! LOOP  
50 GOTO 40  
60 DISABLE INTR  
70 PRINT "INTERRUPT"  
80 GOTO
```


6. ENABLE INTR

Outline

Cancel interrupt disable status generated by ON XXX statement or DISABLE INTR.

Syntax:

ENABLE INTR

ENABLE INTR

Commentary

- If branching is generated by interrupt enabled by ON XXX statement, all interrupt generated branching is disabled temporarily. This is to prevent nesting of interrupt processing in cases where another interrupt is generated while a previous interrupt is being processed.
- If this statement is executed when interrupts are enabled again after branching generated by an interrupt has been processed, the interrupt disabled status is cancelled to enable branching by interrupt again.
- If interrupt processing is placed in a subroutine, execution of the processing can be made smoother by inserting this statement immediately before the RETURN statement.
- Also execute this statement if interrupts are to be enabled again after the DISABLE INTR statement is executed.
- Interrupts are disabled from immediately after program execution up to execution of this statement.

Example


```
10 OUTPUT 31; "EDITOFF SRQE"  
20 ON ISRQ GOTO 60  
30 ENABLE INTR  
40 ! LOOP  
50 GOTO 40  
60 DISABLE INTR           ! INTERRUPT  
70 PRINT "INTERRUPT"     !  
80 END
```

7. FOR-TO-STEP
 NEXT


Outline

Program loops are formed by using the FOR and NEXT pair of statements.

Syntax



FOR Numerical variable = Numerical value representation
 TO Numerical value representation
 [STEP Numerical value representation]



NEXT [Numerical variable]

Commentary

- The specified numerical variable is used as a loop counter with changes made one step (increment) at a time from initial to final value. The loop is stopped when the counter value is equal to or greater than the final value. Counter increase/decrease is made by the NEXT statement. Therefore, the section of program between the FOR and NEXT statements is processed repeatedly.
- The initial and final values and the increment are specified in the following way.

FOR A = (Initial value) TO (Final value)
 STEP (Increment)

- If STEP (increment) is omitted, the increment automatically becomes +1.

- The FOR statement to NEXT statement section can be nested.
- The variable name of the loop counter used with a pair of FOR and NEXT statements must be the same in both statements. An error is generated if the name is different.
(NEXT without FOR)
- And if the value of the numerical variable used in the loop counter while processing the program between the FOR and NEXT statements is changed, the repetition processing will not proceed in the normal way.
- If the numerical variable after the NEXT statement is omitted, the value for the previous FOR statement is adopted automatically.

Example


```
10 FOR R = 11 TO 0 STEP -5
20   FOR I = 0 TO PI STEP PI/180
30     X=SIN(I)*R+23
40     Y=COS(I)*R+15
50     CURSOR X,Y:PRINT "*"
60   NEXT I
70 NEXT R
80 STOP
```

8. GOSUB
RETURN

Outline

Branch to and return from the specified subroutine.

Syntax



GOSUB Numerical value representation Label expression



RETURN

Commentary

- Transfer process control to subroutine starting from the line number specified by integer or label expression.
Return to next statement after the GOSUB statement by using the RETURN statement.
- Always include the RETURN statement at the end of the subroutine to ensure return to the main program.
- An error is generated if a RETURN statement is executed without subroutine branching.
- Since the GOSUB statement to RETURN statement section can be nested, branching to another subroutine from the first subroutine is possible. Too much nesting, however, can use up memory space and result in error. If a label expression is used in GOTO or GOSUB, and the corresponding line number does not exist, the
<<< Undefined line: Enter CORRECT line. >>>
message appears on that line. No further processing is possible since the branch destination does not exist. Insert the correct line number. If this error message line is deleted accidentally, the value of the GOTO or GOSUB label expression is cleared to 0, and any further attempt to execute the program results in the
Undefined line
error message appearing. To enable processing to proceed insert the correct label expression value in the GOTO or GOSUB statement.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example


```
10 FOR I = 1 TO 9
20     GOSUB 60
30     GOSUB *PRT
40 NEXT I
50 STOP
60 ! SUB ROUTINE
70 X = I * I
80 RETURN
90 *PRT ! SUB ROUTINE
100 PRINT I; " * " ;I; " = " ;X
110 RETURN
```

9. GOTO

Outline

Branch to the specified line number.

Syntax



GOTO Integer Label expression

Commentary

- Branch unconditionally to the specified line number.
- If LIST is executed when the specified line number is found not to exist in the program, a REM statement is automatically inserted in the position corresponding to the missing line number.
- If a loop is formed by branching back to the current line number as in the following example, a never-ending loop is formed.

Therefore, always
split the line.

```
10 GOTO 10
   |
10 REM
20 GOTO 10
```

Example


```
10 FOR I = 1 TO 9
20   GOTO 60
30   GOTO *PRT
40 NEXT I
50 STOP
60 !
70 X = I * I
80 GOTO 30
90 *PRT
100 PRINT I; "*" ;I; "=" ;X
110 GOTO 40
```

10. IF THEN


Outline

Branch to and execute the specified statement depending on conditions.


Syntax



IF <Conditional expression> THEN <Statement>




IF <Conditional expression> THEN
Compound expression
END IF



IF <Conditional expression> THEN
Compound expression
ELSE
Compound expression
END IF

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax



```
IF <Conditional expression> THEN  
Compound expression  
ELSE  
Compound expression  
END IF
```

Commentary

- Although the conditional expression is a logical expression, a numerical value representation can also be written here apart from logical expressions using comparison operators. In this case, the operation result is false only if the value is 0, but true if any other value.
- The program is branched and processed according to the logical expression conditions.
- The THEN statement is executed once the logical expression relationship is established. The THEN statement can include successive statements, followed by execution of the next statement.
- If the logical expression relationship is not established, the next line is processed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

- The following six types of logical operators can be used.

A=B (A==B)	Established if A and B are equal
A>B	Established if A is greater than B
A<B	Established if A is smaller than B
A>=B	Established if A is equal to or greater than B
A<=B	Established if A is equal to or smaller than B
A<>B (A!=B)	Established if A and B are not equal

Expressions in parentheses can also be used.

In the above logical expressions, both A and B may be numerical value representations. And numerical value representations can be compared with character string expressions.

Example


```
10 FLG = 0
20 FOR I = 0 TO
30   PRINT I;
40   IF (I % 2) = 0 THEN FLG = 1
50   IF FLG = 1 THEN
60       PRINT "  EVEN" ;
70       FLG = 0
80   END IF
90   PRINT
100 NEXT I
110 STOP
```

11. INPUT

Outline

Substitute keyboard input data in numerical variable.

Syntax



```
INPUT ["<Character string>,"]{ Numerical variable  
                               | Character string }
```

Commentary

- When the INPUT statement is executed, the program is stopped temporarily to wait for input of data from the keyboard. This input wait status is maintained until the ENTER key is pressed, resulting in the key input data being substituted in a variable.
- The INPUT statement can handle both numerical and character string variables. However, if the input contains non-numerical characters (such as alphabetic characters and symbols), all non-numerical characters are disregarded. And if there are no numerical characters at all, a value of 0 is substituted in the variable. No substitution takes place if only the ENTER key is pressed. That is, the value prior to input remains unchanged.
- Character constant inputs do not have to be enclosed between quotation marks.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example


```
10 OUTPUT 31; "SINGLE EDITON"  
20 INPUT "CENTER FREQUENCY(MHz) ?" ,CF  
30 INPUT "SPAN FREQUENCY(KHz) ?" ,SF  
40 OUTPUT 31; "EDITOFF"  
50 OUTPUT 31; "CENTERF" ,CF, "MHZ"  
60 OUTPUT 31; "SPANF" ,SF, "KHZ"  
70 OUTPUT 31; "SINGLE"  
80 OUTPUT 31; "MAXSRCH"  
90 OUTPUT 31; "MAXSRCH ?"  
100 ENTER 31; F,L,D1,D2  
110 OUTPUT 31; "EDITON"  
120 PRINT "MAX = " ,L  
130 STOP
```

12. LET

LET is not used in programs. Direct substitution statements are written.

- Outline
- Syntax

Substitute in variables.



<A> { , <A> }

<A>, ::= Numerical variable = Numerical value representation

Commentary

- The "=" sign used here denotes substitution. It is not the mathematical equal sign. If the left hand side of this sign is a numerical value, character strings too can convert and substitute the numerical value section. Especially when substituting a character string, the most that can be substituted is the length of the right hand side when "=" is used. With "=>", however, where the character string on the right hand side may be shorter than the character string on the left hand side, the length is substituted in the left hand side with spaces filling the lead. With "=<", on the other hand, spaces are filled in behind. That is, "=>" and "=<" are valid substitution operators only for character strings.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example

```
10 DIM STR$
20 PRINT "123456789012345678"
30 STR$ = "ABC" :PRINT STR$
40 STR$ =< "OPQ" :PRINT STR$
50 STR$ => "XYZ" :PRINT STR$
```

<Execution result>

123456789012345678

ABC

OPQ

XYZ

13. OFF SRQ [Only in controller mode]
 OFF ISRQ

Outline

Cancel branch function and definition by SRQ or ISRQ interrupt.

Syntax



OFF SRQ
 OFF ISRQ

Commentary

- Cancellation of branching generated by an interrupt enabled by ON SRQ statement.

Example

```
100 OUTPUT 31; "EDITOFF SRQE"
110 ON ISRQ GOTO *MAX
120 OUTPUT 31; "SINGLE"
130 ENABLE INTR
140 ! LOOP
150 GOTO 140
160 *MAX
170 DISABLE INTR
180 OUTPUT 31; "MAXSRCH"
190 OUTPUT 31; "MAXSRCH?"
200 ENTER 31;F,L,D1,DL2
210 PRINT L
220 GOTO 130
```

< Commentary >


Address	Details	Address	Details
100	Set measuring screen, and enable SRQ	170	Disable interrupt
110	Set internal SRQ interrupt branching	180	Search for maximum level
120	Single sweep	190	Request return of maximum level
130	Accept interrupt	200	Substitute returned data in respective variables
		210	Display level

14. OFF KEY

Outline

Cancel branch function and definition by KEY input interrupt.

Syntax



OFF KEY Key code

Commentary

- Cancellation of branching generated by R4611E key input interrupt enabled by ON KEY statement.

Example

```
10 ON KEY 2 GOTO 100
20 ENABLE INTR
30 ! LOOP
40 GOTO 30
100 OFF KEY
110 PRINT "OFF KEY"
120 STOP
```


15. ON SRQ
ON ISRQ

[ON SRQ only in controller mode]

Outline

Enable interrupt branching by external SRQ signal via GPIB. (ON SRQ)
Or, enable interrupt branching by when an internal interrupt source is generated. (ON ISRQ)

Syntax



ON SRQ GOTO|GOSUB Integer|Label expression

Commentary

- Execute branching by interrupt during execution of program.
- Branching is executed after the statement being executed at the time of the interrupt has been completed.
- And the return destination required after branching to a subroutine becomes the next statement to be executed after the statement being executed at the time the interrupt was generated.
- ON SRQ is capable of interrupt branching by SRQ signal from external GPIB only when executing in controller mode.

Note* ON SRQ is valid in controller mode.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example

Search for MAX during each single sweep.

```

100 OUTPUT 31; "EDITOFF SRQE"
110 ON ISRQ GOTO *MAX
120 OUTPUT 31; "SINGLE"
130 ENABLE INTR
140 ! LOOP
150 GOTO 140
160 *MAX
170 DISABLE INTR
180 OUTPUT 31; "MAXSRCH"
190 OUTPUT 31; "MAXSRCH?"
200 ENTER 31;F,L,D1,D2
210 PRINT L
220 GOTO 130
  
```

<Commentary>


Address	Details	Address	Details
100	Set measuring screen, and enable SRQ	170	Disable interrupt
110	Set internal SRQ interrupt branching	180	Search for maximum level
120	Single sweep	190	Request return of maximum level
130	Accept interrupt	200	Substitute returned data in respective variables
		210	Display level

16. ON KEY

Outline

Enable branching by KEY input interrupt.

Syntax



ON KEY "key code" GOTO|GOSUB Integer|Label expression

Commentary

- Branch by KEY input interrupt during program execution.
- Branching is executed after the statement being executed when the interrupt was generated has been completed.
- And the return destination required after branching to a subroutine becomes the next statement to be executed after the statement being executed at the time the interrupt was generated.
- Key codes are numerical values from 1 to 6, and correspond to the soft key and function keys F1 thru F6 on the left hand side of the CRT screen.

Example

```


1   CLS
10  ENABLE INTR
20  ON KEY 1 GOTO 1000
30  ON KEY 2 GOTO 1100
40  ON KEY 3 GOTO 1200
50  ON KEY 4 GOTO 1300
60  ON KEY 5 GOTO 1400
70  ON KEY 6 GOTO 1500
75  COUNT = 10
80  *HERE:
85  I = 0: PRINT ""
90  IF I=COUNT THEN GOTO *HERE
100 ++I: PRINT ">" ;
101 GOTO 90
1000 PRINT "FIRST KEY"
1001 COUNT = 1
1010 GOTO *HERE
1100 PRINT "SECOND KEY"
1101 COUNT = 10
1110 GOTO *HERE
1200 PRINT "THIRD KEY"
1201 COUNT = 20
1210 GOTO *HERE
1300 PRINT "FOURTH KEY"
1301 COUNT = 30
1310 GOTO *HERE
1400 PRINT "FIFTH KEY"
1401 COUNT = 40
1410 GOTO *HERE
1500 PRINT "SIXTH KEY"
1501 COUNT = 50
1510 GOTO *HERE
  
```

17. ON ERROR

Outline

Specifies branch destination on error.

Syntax



ON ERROR GOTO 1000

Commentary

When an error is generated during BASIC program execution, the system displays the line number and error message and stops execution. In case of built-in function (requests for measuring equipment services) errors, program execution resumes immediately after display of the error message. To troubleshoot such errors, use the ON ERROR statement. Specify branch destination with a numeric constant, numeric variable, or label. ERRN system variables that keep record of error codes classifies the errors. If unable to recover from the error immediately after generation, use the OFF ERROR statement to avoid resulting in an endless loop.

18. PAUSE

Outline

Temporarily halts program execution.

Syntax



Commentary

This BASIC command temporarily halts the BASIC program execution, thus resumption from the interrupted line by the CONT command is possible.

To halt execution from outside the program, press the nearest key in the leftmost column.


Example

```
10 FOR I = 1 TO 9
20   GOTO 60
30   GOTO *PRT
40 NEXT I
50 PAUSE
60 !
70 X = I * I
80 GOTO 30
90 *PRT
100 PRINT I; "*" ;I; "=" ;X
110 GOTO 40
```

19. PRINTF

- Outline
- Syntax

Display numerical or character string data.



```
PRINT [Numerical value representation
      Character string representation
      { , ; Numerical value representation
        Character string representation ]
```

Commentary

- Display specified numerical data or character string.
- If numerical values and character strings are partitioned by commas (,) successive values and strings can be output without executing a carriage return.
- And if a semicolon (;) is placed at the end of a PRINT statement, there is no carriage return at the end of the printer output. Therefore, printing is continued on the same line as the last printing when the next PRINT statement is executed.

Example

```
10 PRINT 123*456
20 PRINT "ABC"
30 PRINT "Freq.=" , A, "Hz"
40 PRINT I,
```

- PRINT USING Format designation expression;[Expression[...]]

The format designation expression is a character string representation where the format is specified with image specifications partitioned by commas.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

<Image specifications >

D --- Display space in the remaining part of specified field.
Z --- Specify 0 in the remaining part of specified field.
K --- Display expression value without change.
S --- Always append + or - sign flag.
M --- Append - sign flag, or take a space when positive.
. --- Display decimal point.
E --- Display e, sign, and exponential part.
H --- Display expression value without change, but with decimal point displayed in European format.
R --- Display European format decimal point.
* --- Specify * in the remaining part of specified field.
A --- Display single character.
k --- Display character string without change.
X --- Display space.
 --- Use \ " to enclose sections to be written literally in literal format designation expressions.
B --- Display expression value as ASCII code.
@ --- New page
+ --- Shift display position to start of same line.
- --- Shift display position to start of next line.
--- No final carriage return
n --- Output in n-digit precision. When specified for character string, this value becomes the length of the actual character string.

Example

```
10 PRINT USING "4Z,2X,5D,2X,5*" ;123,-444,567
```

<Results of execution>
0123 -444 **567

Example

```
10 PRINT USING "S3D,X,S3D" ; -4.5,465  
20 PRINT USING "M3Z,Z,S,M3ZR3Z" ;1.26,-5.452
```

<Results of execution>
-4 +465
001.3 -005,452

Example

```
10 PRINT USING "K,X,H" ;5.03884e+22,4.5563
```

<Results of execution>
5.03884e+22 4,5563

Example

```
10 PRINT USING "k,#" ; "character:"  
20 PRINT USING "B" ;69
```

<Results of execution>
character:E

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

Example

```
10 PRINT USING "\" ..... \" ,+,A" ; "*"
20 PRINT USING "k,-, \" .END. " \" ; string"
```

<Results of execution>

```
*.....
string
.END.
```

Example

```
100 PRINT USING "DDD.DD" ;1.2
110 PRINT USING "ZZZ.ZZ" ;1.2
120 PRINT USING "K" ;1.2
130 PRINT USING "SDDD.DD" ;1.2
140 PRINT USING "MDDD.DD" ;1.2
150 PRINT USING "MDDD.DD" ;-1.2
160 PRINT USING "H" ; 1.2
170 PRINT USING "DDDRDD" ; 1.2
180 PRINT USING "****.**" ; 1.2
190 PRINT USING "A" ; "A" ; "a"
200 PRINT USING "k" ; "string"
210 PRINT USING "B" , 42
220 PRINT USING "3D.2D" ;1.2
```

<Results of execution>


```
1.20
001.20
1.2
+1.20
1.20
-1.20
1,2
1,20
**1.20
a
string
*
1.20
Program ended normally.
```

20. PRINTF

Outline

Display numerical or character string data.

Syntax



Commentary

- Display specified numerical data or character string.
- If numerical values and character strings are partitioned by commas (,) successive values and strings can be output without executing a carriage return.
- And if a comma (,) or semicolon (;) is placed at the end of a PRINTF statement, there is no carriage return at the end of the printer output. Therefore, printing is continued on the same line as the last printing when the next PRINTF statement is executed.
- The character string representation in the first parameter is used to specify the format of subsequent parameters.

The format designation method is outlined below.

- PRINTF Format designation expression;[Expression[Expression[...]]]

The format designation method resembles the Printf function in C language.

The format designation expression is a character string type expression, and the output format is specified by the following parameters following %. Other character strings apart from this format are simply straight forward outputs.

If output of % is required, use %%.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

% [-], [0], and [.n] characters
- Left justify within specified field, but right justify if no designation.
0 Select 0 instead of spaces as the character used to fill up the remainder of the specified field.
+ Always append + or - sign flag.
Space Append - sign flag, or take a space when positive.
m Take m characters of field.
.n Output in n-digit precision. When specified for character string, this value becomes the length of the actual character string.
Characters d: Decimal number with sign
u: Decimal number without sign
o: Octal number
x: Hexadecimal number
s: Character string
e: Floating decimal point display with sign

Example

```
10 N = 500000
20 U = LOG(1+1/N)
30 V = U - 1 / N)
40 PRINTF "%7d t%16.5e t%16.5e\n" ,N,U,V
50 PRINTF "%s\n" , "end "
```

```
<Results of execution>
 50000          2.00000e-06          -1.99994e-12
end
```

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.4 R4611E BASIC Statement Syntax

21. SPRINTF

Outline

Convert the format in accordance with the format conversion specification for PRINTF command, and assign the result to the character string variable.

Syntax



Commentary

Convert the value of expression using a method of PRINTF format specification, and assign the result to the character string variable of the first parameter. Refer to the 'PRINTF' for a method of the format specification. Special attention should be taken to the method of format specification, the number of expression, and character string variable field. If the character string variable field is not enough to assign the result, a basic buffer will be broken.


22. GPRINT
LPRINT

GPIB output
 Serial output

Outline

Output numerical or character string data.

Syntax



```
GPRINT [Numerical value representation  
LPRINT  Character string representation  
        { , ; Numerical value representation  
          Character string representation ]
```

Commentary

- Display specified numerical data or character string.
- If numerical values and character strings are partitioned by commas (,) successive values and strings can be output without executing a carriage return.
- And if a comma (,) or semicolon (;) is placed at the end of a PRINT statement, there is no carriage return at the end of the printer output. Therefore, printing is continued on the same line as the last printing when the next PRINT statement is executed.

Example


```
100 PRINTER 1  
110 FOR I = 0 TO 20  
120   GPRINT I  
130   LPRINT I  
140 NEXT I  
150 STOP
```

23. PRINTER

Outline

Specify device address to be sent to the printer.

Syntax



PRINTER Numerical value representation

Commentary

- The device address of the printer connected to the GPIB is passed to R4611E by this PRINTER command. Before executing a PRINT statement, always specify (in R4611E) the printer address by this PRINTER statement.
- The device address is an integer from 0 to 30.

Example


10 PRINTER,1

24. REM

Outline

Program remarks.

Syntax



REM <Character string>

Commentary

- Use the REM statement to insert remarks in the program.
- Since the REM statement is not executed, any character string may be inserted after REM. Any alphanumeric character or symbol may be included.
- The REM statement can also be represented by an exclamation mark !.
- Colons cannot be used for multiple statement purposes after a REM statement. Everything including the colon is regarded as remarks.

Example


```
10 REM "PROGRAM 1"  
20 ! 1983-JUN-02  
30 A=A+1:! INCREMENT A
```

25. CLS

Outline

Clear the CRT screen.

Syntax



CLS

Commentary

- Clear all characters displayed on the CRT screen.
- At the same time that the screen is cleared, the cursor is returned to the home position.

Example


```
10 CLS
```

26. DATA

Outline

Defines numeric values and character strings to be read by the READ statement.

Syntax



Commentary

DATA statements are not executed but read by the READ statement.

Therefore though the DATA statements can be at any line number, they must be arranged in the order of reference. To rearrange them, use the RESTORE statement.

More than one constant, separated by commas, can be specified in a single DATA statement. Put character strings in double quotations (" ") as a character string constant.

Caution


Parameters in the DATA statement cannot contain equations with variables.

27. READ

Outline

Replaces constants in the DATA statement with variables.

Syntax



READ Entries { Entries }

Commentary

This statement replaces numerics and character strings defined by the DATA statement with variables specified by the argument.

When the system encounters a READ statement, it searches for the DATA statements.

With the first READ statement, the system starts searching each line number from the head of the program in descending order (if not rearranged by the RESTORE statement) and replaces the first argument found with the variable.

Then the system keeps on searching for DATA statement constants and replaces them one by one.

If the number of constants specified by the DATA statements is less than the number of variables in the READ statements, it results in an error.

In this case, the line numbers of the READ and DATA statements are ignored.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.4 R4611E BASIC Statement Syntax

28. RESTORE

Outline

Specifies DATA lines to be read by the next READ statement.

Syntax



Commentary


Specify the line number with an expression or label. If not specified, the DATA statement constants are read from the head of the program to be specified by the next READ statement. Any line number after the argument line number that is considered the starting position of the search can be specified.

29. SELECT, CASE


Outline

Syntax


Branch several times using a value in the expression.



Compound statement



Compound statement



Compound statement



Commentary

This statement executes all the compound statements following the CASE statement that has the equivalent value as specified by the SELECT statement. Execution continues until another CASE, CASE ELSE, or END SELECT statement is encountered.

Nesting of the SELECT statement is possible. Internal SELECT contains the entire external SELECT.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

30. ERRN

Outline

This statement is a system variable for retaining an error number.

Syntax



Commentary

This is a system variable for retaining an error number generated when the BASIC program is executed. The system variable is initialized to 0 at the start of the BASIC program and the value is substituted when an error occurs.

The value is initialized to 0 when 0 is substituted explicitly or the BASIC program is reexecuted.

Actual error number structure is as follows:

Error class * 256 + Error message number

Error class


- | | |
|---|--|
| 1 | Associated with the data I/O. |
| 2 | Associated with the data operation. |
| 3 | Associated with the build-in function. |
| 4 | Associated with the BASIC statement. |

31. ERRM\$

Outline

This statement is a system function for returning an error message of the specified number.

Syntax



Commentary

The system function returns an error message specified in a parameter.

When specifying 0 as a parameter, it returns the last displayed error message.

The error number structure is as follows:

Error class * 256 + Error message number

Only the error message number is referred to internally although an error number including an error class is specified. Therefore, ERRN can be specified for an error number.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

32. PEEK

Outline

The PEEK system function is used for maintenance of the tester. This function reads the contents of built-in tester memory.

Syntax

PEEK (side, address, type)
side 0: I/O CPU board
 1: main CPU board
address The address from which data is read
type 0: Single-byte unit (char)
 1: Two-byte unit (short)
 Others: Four-byte unit (long)

Commentary

This function is used for maintenance only. It is not used for ordinary measurement. The PEEK function reads data from the specified address of the specified board and returns it as the return value.

Example

```
10 side     = 0           ! I/O CPU board
20 address = 0x5ff80
30 type     = 0
40 FOR i = address TO 0x5ffff
50     PRINTF "%c", PEEK(side, i, type)
60 NEXT i
```

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.4 R4611E BASIC Statement Syntax

33. POKE

Outline

The POKE command is used for maintenance of the tester. This command writes data in the tester built-in memory.

Syntax

POKE side address data type
side 0: I/O CPU board
 1: main CPU board
address The address where the data is written
data The data to be written in the specified address
type 0: Single-byte unit (char)
 1: Two-byte unit (short)
 Others: Four-byte unit (long)

Commentary

This function is used for maintenance only. It is not used for ordinary measurement. The POKE function writes data in the unit specified by "type". It writes data in the specified memory address of the specified board. The user should know the memory contents before using this command. To protect the important system data, this function is enabled only when control register 5 is set to 1. (See the CONTROL command section.)

Example

POKE 0 0x100000 0xFF 0
A single byte of X'FF' is written in address X'100000.

5.5 R4611E BASIC GPIB Control Statement Syntax and Activity


1. CLEAR See page 5-70.
2. DELIMITER See page 5-71.
3. ENTER See page 5-72.
4. INTERFACE CLEAR ... See page 5-74.
5. LOCAL See page 5-75.
6. LOCAL LOCKOUT See page 5-76.
7. OUTPUT See page 5-77.
8. REMOTE See page 5-79.
9. REQUEST See page 5-80.
10. SEND See page 5-81.
11. TRIGGER See page 5-83.
12. SPOLL See page 5-84.

1. CLEAR

Outline

Initialization of all devices, or a specifically selected device connected to the GPIB.

Syntax



CLEAR [Device address{,Device address}]

Commentary

- If only CLEAR is executed without specifying any device address, the universal command "device clear" (DCL) is sent to the GPIB. All devices connected to the GPIB are thus initialized.
- If a device address is specified after CLEAR, only the device specified by the device address is addressed, and the address command "select device clear" (SLC) is sent.

Hence, only the specified device is initialized. And more than one specific device address can be specified at the same time.

Example

```
10 CLEAR  
20 CLEAR 2  
30 CLEAR 1 3 5 7
```

Caution


CLEAR does not function when in talker/listener mode.

2. DELIMITER

Outline

Statement for selecting and setting one of four delimiters.

Syntax



DELIMITER Numerical value representation

Commentary

- The delimiter corresponding to the number indicated in the numerical value representation is set. The delimiter selection numbers and types are listed below.

Selection number	Type of delimiter
0	Output of "CR" and "LF" 2-byte code. Or "LF" output together with "EOI" single wire output.
1	Output of "LF" 1-byte code.
2	Output of "EOI" single wire output together with last byte of data.
3	Output of "CR" and "LF" 2-byte code.

- An error is generated if the Numerical value representation result does lie in the 0 to 3 range. And the value is regarded as an integer with decimal places disregarded.
- "DELIMITER=0" is set automatically when the power is switched on.

Example


```
10 DELIMITER 0  
20 DELIMITER 1  
30 DELIMITER A*10
```


3. ENTER

Outline

Entry of data from GPIB.

Syntax



ENTER Device address: Numerical variable
| Character string variable

Device address

- 0 thru 30: Address of external device connected to the GPIB
- 31 : Data input from R4611E measuring section
- 32 : Data input from parallel port

Commentary

- Input of data via GPIB from device specified by device address, and storage as numerical value or character string within BASIC variable. Note, however, that if the device specified by device address does not have a TALKER function, the program is stopped without the controller being able to complete the handshake. And if a character string variable is used, that character string must be declared in advance by DIM statement.
- When input is by character string, the length of the character string variable used in the destination must be sufficient to prevent overflow of the input data and disregarding of data which cannot fit in.

Example

```
10 ENTER 1;A
20 DIM A$(100), B$(20)
30 ENTER 2;A$ EOI
40 ENTER 3;B$
```

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.5 R4611E BASIC GPIB Control
Statement Syntax and Activity

Caution

- Function when in controller mode
Specify the designated address function as TALKER, and accept data.
- Function when in TALKER/LISTENER mode
Time out error is generated if R4611E is not specified as TALKER within one minute by external controller.

4. INTERFACE CLEAR

Outline

Initialization of entire GPIB interface connected to R4611E.

Syntax



INTERFACE CLEAR

Commentary

- Execution of this statement results in output of GPIB single wire signal IFC for about 100 microseconds. When the GPIB interface of all devices connected to the R4611E GPIB receives the IFC signal, the TALKER or LISTENER status is cancelled.

Example

10 INTERFACE CLEAR

Caution


Does not function when in TALKER/LISTENER mode.

5. LOCAL

Outline

Release of specified device from remote control status, or making the remote enable (REN) line to false.

Syntax



LOCAL [Device address ,Device address]

Commentary

- If LOCAL is executed without specifying a device address, the GPIB remote control (REN) line becomes false (high level), and all devices connected to the GPIB are switched to local mode. While REN is false, note that GPIB devices cannot be set by OUTPUT command (since GPIB control is no longer effective). To make REN true (low level) again, execute the REMOTE statement.
- If a device address is specified after LOCAL, remote mode can be canceled by addressing only the device specified by that device address.

Example

```
10 LOCAL
20 LOCAL 1
30 LOCAL 1, 2, 3
40 LOCAL A*10+J
```

Caution

Does not function when in TALKER/LISTENER mode.

6. LOCAL LOCKOUT

Outline

Cancellation of the function which enables devices connected to the GPIB to be switched to local mode by front panel operation.

Syntax

LOCAL LOCKOUT

LOCAL LOCKOUT

Commentary

- When each device connected to the GPIB is in remote mode (that is, when controlled by remote control via the GPIB) the panel keys on each device are locked to prevent local setting of data. The LOCAL key, remains effective, however, and if pressed, the respective devices are returned to local mode where local setting of data is possible. Consequently, various interruptions during remote control operations are possible, and accurate control may not be possible. By executing the LOCAL LOCKOUT statement, however, the LOCAL key on all devices connected to GPIB can be locked to prevent all local control operations at each device.
- When the LOCAL LOCKOUT statement is executed, the universal command "local lockout" (LLO) is sent to the GPIB.

Example

10 LOCAL LOCKOUT

Caution


Does not function when in TALKER/LISTENER mode.

7. OUTPUT

Outline

Output of data to GPIB.

Syntax



OUTPUT Device address{,Device address } A

<A> ::= Numerical value representation
|Character string representation
{,Numerical value representation
|Character string representation }

Device address

- 0 thru 30: Address of external device connected to the GPIB
- 31 : Output to R4611E measuring section
- 32 : Output to parallel port

Commentary

- Numerical and character string data is sent as ASCII data to the device specified by device address. More than one device can be specified at once by partitioning device addresses with commas, and numerical value representation and character string representation can even be mixed by also partitioning with commas.
- If the OUTPUT statement is executed when the REN line is true (low level), devices specified by device address are automatically set to remote mode. Remote mode can be cancelled by executing the LOCAL statement.

Example

```
10 OUTPUT 3:123
20 A=5
30 B=6
40 OUTPUT A; "STARTF" , B, "MHz"
```

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.5 R4611E BASIC GPIB Control
Statement Syntax and Activity

Caution


- When in controller mode
Specify the designated address function as LISTENER,
and output data.
- When in TALKER/LISTENER mode
Time out error is generated if R4611E is not specified
as LISTENER within one minute by external controller.

8. REMOTE

Outline

Set specified device to remote mode, or make the GPIB remote enable (REN) line true.

Syntax



REMOTE [Device address{,Device address}]

Commentary

- If only REMOTE is executed without specifying a device address, the GPIB remote enable (REN) line becomes true (low level) and remote control of the devices connected to GPIB becomes possible. The REN line can be made false (high level) by executing the LOCAL statement.
- If a device address is specified after REMOTE, the corresponding device is put into remote mode (as long as the REN line is true (low level)). More than one device address can be specified together. And remote mode can be canceled by executing the LOCAL statement.
- Although the purpose of the REMOTE statement is to put selected devices into remote mode, specified devices are automatically set to remote mode (without executing the REMOTE statement) when any of the following statements is executed (but only as long as the REN line is true (low level)).

```
CLEAR [Device address{,Device address}]  
OUTPUT Device address{,Device address}:  
    <output data>{,<output data>}  
REMOTE [Device address{,Device address}]  
SEND LISTEN Device address{,Device address}  
TRIGGER Device address{,Device address}
```

Example

```
10 REMOTE 1  
20 REMOTE 5  
30 REMOTE 1, 2, 3, 4  
40 REMOTE A*100+I
```

Caution


Does not function when in talker/listener mode.

9. REQUEST

Outline

Set status byte to be sent to external GPIB when in talker/listener mode.

Syntax



REQUEST Integer

Integer value: 0 thru 255

Commentary

- Set status byte to be sent to external GPIB when in talker/listener mode.
- Set a value greater than 64 when generating SRQ.

Example

10 REQUEST 65


Caution

Does not function when in controller mode.

10. SEND

- Outline
- Syntax

Output of command and data to GPIB.



SEND <A>|{,<A>}

<A> ::= CMD DATA|LISTEN TALK[<C>{,<C>}]

 ::= UNT UNL

<C> ::= Numerical value representation

Commentary

- Statement for sending universal commands, address commands, and data independently to the GPIB.
 - CMD : Make the attention (ATN) line true (low level), and send the given numerical values to the GPIB. Since the numerical values are converted to 8-bit binary data and output to the GPIB, the numbers handled must not exceed the 0 thru 255 range. And numerical values expressed as decimal numbers are automatically converted to integer numbers.
 - DATA : Make the ANT line false (high level) and sent the given numerical values to the GPIB. The numerical values handled here are subject to the same restrictions as those handled by "CMD".

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.5 R4611E BASIC GPIB Control
Statement Syntax and Activity

- LISTEN: Send the given numerical values to the GPIB as LISTENER address group (LAG). Multiple numbers can also be specified.
- TALK : Send the given numerical values to the GPIB as TALKER address group (TAG). Multiple numbers can also be specified.
- UNT : Send the untalk (UNT) command to the GPIB. TALKER mode of the device specified as TALKER before this command was executed is canceled.
- UNL : Send the unlisten (UNL) command to the GPIB. LISTENER mode of the device specified as LISTENER before this command was executed is canceled.

Example

```
10 SEND UNT UNL LISTEN 1, 2, 3 TALK 4  
20 SEND UNT CMD 10, 200 DATA 30, 54
```

Caution


Does not function when in TALKER/LISTENER mode.

11. TRIGGER

Outline

Send the address command group (ACG) group execute trigger (GET) to all devices, or specifically selected devices connected to the GPIB.

Syntax



TRIGGER [Device address ,Device address]

Commentary

- If TRIGGER alone is executed without specifying a device address, only the address command "group execute trigger" (GET) is sent to the GPIB. In this case, devices where a trigger is to be applied must be set to listener in advance.
- If a device address is specified after TRIGGER, the GET command is only sent to the specified device.

Example

```
10 TRIGGER 1
20 TRIGGER
30 TRIGGER 2, A*100-J, 30
```

Caution


Does not function when in talker/listener mode.

12. SPOLL

Outline

This statement executes serial polling of the specified GPIB equipment to read a status byte.

Syntax



SPOLL (equipment address)

Commentary

- The statement executes serial polling of the other GPIB equipment when the R4611E network analyzer is in the controller mode.
- The statement executes serial polling of equipment corresponding to each address when the equipment address is 0 to 30.
- The statement takes out a status byte for the R4611E network analyzer regardless of the mode, such as controller mode and TALKER/LISTENER mode, when the equipment address is 31.

Example

```
10 ON ISRQ GOSUB 100
20 ON SRQ GOSUB 200
30 ENABLE INTR
40 !
50 GOTO 40
100 S=SPOLL (31)
110 PRONT S
120 RETURN
200 S=SPOLL (1)
210 PRONT S
220 RETURN
```

Caution

'φ' is returned when the equipment address 0 to 30 is specified in the TALKER/LISTENER mode and SPOLL is executed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

5.6 Syntax of the R4611E Network Analyzer BASIC File Control Statement

1. ENTER See page 5-83.
2. ENTER USING See page 5-85.
3. OFF END See page 5-87.
4. ON END See page 5-88.
5. CLOSE See page 5-89.
6. OPEN See page 5-90.
7. OUTPUT See page 5-91.
8. OUTPUT USING ... See page 5-93.
9. COPYFILES See page 5-95.
10. DSTAT See page 5-96.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

1. ENTER

Outline

This statement reads data from the file and substitutes it for the entry item.

Syntax



ENTER #File descriptor ; Entry item

Commentary

The statement reads data in the data type format of the corresponding entry item from the file assigned to the file descriptor, and substitutes it for the entry item.

Example

①

BINARY file

The BINARY file expresses the internal data without change.

The BINARY file reads four bytes of header when an entry item is an integer or character string, or eight bytes of header when an entry file is a real number. Then, it reads the data for the length specified by the header. Since the number of bytes to be read depends on the entry item type, correct data cannot be obtained unless the same entry type as for output is entered.

```
10 INTEGER I
20 DIM R
30 OPEN "FILE" FOR INPUT AS #FD
40 ENTER #FD;I,R,S$
```

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


5.6 Syntax of the R4611E Network
 Analyzer BASIC File Control Statement

Number of bytes to be read depends on the entered variable type.



When a variable is a real number, eight bytes of data are read and substituted in the variable without change.

When a variable is an integer, four bytes of data are read and substituted in the variable without change.




When a variable is a character string, four bytes of header and the data for the length specified by the header are read, and substituted in the character string.

② TEXT file

The TEXT file reads up to line feed regardless of the number of entry items. Data up to comma (,) is assumed to be one item of data, converted to the corresponding entry item type, and substituted.

When the number of entry items are larger than the actual data, the last stored data item remains in the excessive variables. Inversely, when the number of variables is smaller than the actual data, the excess data is discarded.

```
10 INTEGER I
20 DIM R
30 OPEN "FILE" FOR INPUT AS #FD;TEXT
40 ENTER #FD;I,R,S$
```



Line feed is provided at the end of the item.

Each item is divided by a comma.


R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

③ ASCII file

The ASCII file reads two bytes of header and the data for the length specified by the header. It converts the data according to the variable type, and substitutes it for the variable.

```
10 INTEGER I
20 DIM R
30 OPEN "FILE" FOR INPUT AS #FD;ASCII
40 ENTER #FD;I,R,S$
```



R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

2. ENTER (ENT) USING (USE)

Outline

This statement enters data from the file to an entry item in the image specifications format.

Syntax



ENTER #File descriptor [USING image specifications];
Entry item

Commentary

The statement enters data from the file assigned to the file descriptor to an entry item in the image specifications format.

Image specifications

- D : A value is read assuming that the number of Ds is the number of digits of that value, and substituted for a variable of an entry item.
- Z : The same as D.
- K : One line is read, converted to numerical data, and substituted for a variable for an entry item.
- S : The same as D.
- M : The same as D.
- . : The same as D.
- E : The same as D.
- H : The same as K, but the value is converted to the European numerical format (a comma is used as decimal point).
- * : The same as D.
- A : Characters are read for the number of As and substituted for the character string variable.
- k : One line is read and substituted for a character string variable.
- X : One character data is skipped.
- Literal: A character string closed by \" is skipped.
- B : A character is read and substituted for an entry item as an ASCII code.
- @ : One byte data is skipped.


R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
 Analyzer BASIC File Control Statement

- + : The same as the @.
- : The same as the @.
- # : It is ignored by the ENTER statement.
- n : The later image specifications is repeated n times.

Example

```
10 INTEGER INT
20 DIM REL
30 ENTER #FD USING "ZZZ,DD.D,3A";INT,REL,S$
```




INT: Three bytes of data are read, converted to the integer type of the INT data type and substituted for the INT. The INT value is set to 10 after execution.

REL: 'DD.D' of the image specifications corresponds to the REL of an entry item. Four bytes data are read, converted to the real number type, and substituted for the REL. The REL is set to 4.5 after execution.

S\$: Three bytes of data are read and substituted for S\$. The S\$ is set to abc after execution.

```
10 DIM A,B
20 ENTER #FD USING "SDDD,X,MZZZ";A,B
```



A,B: Four bytes of data are read, converted to the real number type, and substitutes for A and B. A and B are set to 5.0 and 13.0 after execution. One byte for X of the image specifications is read, but no data is substituted for a variable. Data entered in the SDDD format is read and substituted for A. X does not need a variable, and one character is skipped. Four bytes are entered, converted to the real number type, and substituted for B assuming that 'MZZZZ' corresponds to B.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

```
10 DIM A
20 ENTER #FD USING "K";A
```

S	T	R	I	N	G	1	2	3	.	5	#	#	n	.	.
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

A is set to 123.5 after execution.
'STRING123.5##' is read and converted to the real number type of the entry variable A.

When an entry item is the real number type, characters other than preceding values, codes (+, -), and indexes E and e are ignored, and only numerals are accepted. Conversion to numerals stops at the position where a character other than numerical is encountered. Since line feed is used as a terminator for K, E, k, and H of the image specifications, the data is substituted to a variable assuming that the data from the current file pointer to line feed is one item.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

3. OFF END

Outline

This statement clears the processing for the end of file specified in the ON END statement.

Syntax



OFF END #File descriptor

Commentary

When the end of file occurs after the destination of the branch defined in the file descriptor is cleared, the error message below is displayed and the system control ends.


end of "DATAFILE" file

4. OFF END

Outline

This statement defines the processing (destination of branch) for the end of file.

Syntax



ON END #File descriptor

Commentary

End of file occurs when data is read from the file by the ENTER statement until the end of file is reached and no data to be entered is found. The error message is displayed and the system control ends after the file is closed unless the processing is declared by the ON END statement.


Destination of the branch is specified in a numerical variable, numerical constant, or label.

5. CLOSE

Outline

This statement closes the file assigned to the file descriptor.

Syntax



CLOSE #File descriptor

Commentary

File opened by the OPEN command must be closed before a floppy disk is removed or the power to the equipment is turned off. Otherwise, data in a file opened for writing is destroyed.

A file is not closed automatically when the BASIC program is stopped by the PAUSE or STOP key. All files are closed when the program ends when it is stopped by a key other than the above. A file is closed when the program ends in error. If the ON ERROR is set, a file is not closed for the erroneous end.

Execute the following close operation explicitly when the program ends in error:

CLOSE *

The above is a specification method to close all files by executing a command.

A file is closed automatically when the SCRATCH or LOAD is executed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

6. OPEN

Outline

This statement assigns the file descriptor to the file and opens it in the specified processing mode.

Syntax



OPEN "file name" FOR Processing mode AS #File descriptor;
Type

Commentary

The statement assigns the file descriptor to the file to make the program recognize the file and opens it in the specified processing mode.

Processing mode

Processing mode has two types: OUTPUT and INPUT.
OUTPUT is used to write data to the file and INPUT used to read data from the file.

#File descriptor

ENTER/OUTPUT is used to write/read an actual file. The file descriptor is used to make these commands recognize the file to be processed.
The file descriptor name is described by alphanumeric after #.

File type

File type consists of BINARY, TEXT, and ASCII.
If no file type is specified, BINARY is assumed.

BINARY is used to record data with internal expression. Four bytes or eight bytes are recorded if the data is an integer or real number. Four bytes of header are followed by ASCII data if the data is a character string. Space for one byte is provided after the data if the number of data characters is an odd number.

TEXT is used to convert data to ASCII code and output. "-" or a space is provided before a value. USING can be specified in the TEXT file.

ASCII is used to express entry and output items with ASCII codes after two bytes header. "-" or a space is provided before a value. One byte of space is provided after the data if the number of data characters is an odd number.


- When the file descriptor assigned to the other file is opened, the last assigned file is closed and the newly specified file is opened.
- The same file cannot be opened at the same point by multiple file descriptors.
- If an existing file is opened in the OUTPUT mode, an error message is displayed and the program stops. This operation avoids deleting a necessary file erroneously. To create a new file whose name is the same as that of an existing one, delete an existing file by the PURGE command.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL



5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

Example

```
10 OPEN "DATA.BAS" FOR OUTPUT AS #FD ; TEXT
20 OUTPUT #FD;10,4.5,"abc"
```



```
10 OPEN "DATA.BAS" FOR OUTPUT AS #FD ; ASCII
20 OUTPUT #FD;10,4.5,"abc"
```



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


5.6 Syntax of the R4611E Network
 Analyzer BASIC File Control Statement

7. OUTPUT (OUT)

Outline

This statement outputs (or writes) the data assigned to the #file descriptor.

Syntax



OUTPUT #File descriptor ; [Output item]

Commentary

The statement converts output items to the BASIC standard format to be output.



The file descriptor specified when the file is opened is used. The file descriptor is assigned to the file to be processed when the file is opened. The subsequent processing for the file is always performed via this file descriptor.

Example

① BINARY file

The data is output in the same type as the internal expression. The character string is output with a four-byte header indicating the length of the character string. When the number of characters of the character string is an odd number, a space for one character is provided at the end of the characters.

```
10 OPEN "FILE" FOR OUTPUT AS #FD
20 OUTPUT #FD; 10,4.5,"abc"
```



The length of the header is the same as the data.


R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
 Analyzer BASIC File Control Statement

② TEXT file

Data is converted to ASCII code and output. "-" or a space is followed by numerical data.

```
10 OPEN "FILE" FOR OUTPUT AS #FD ;TEXT
20 OUTPUT #FD; 10,4.5,"abc"
```




Line feed is output at the
end of items.

└─ Each items is divided by a comma.

③ ASCII file

Data is converted to ASCII code and output. "-" or a space is followed by numerical data. A space is provided at the end of the data when the number of bytes of data is an odd number.

```
10 OPEN "FILE" FOR OUTPUT AS #FD ;ASCII
20 OUTPUT #FD; 10,4.5,"abc"
```




The length of the header is the same as that of the data.

8. OUTPUT (OUT) USING

Outline

This statement outputs (writes) data to the file assigned to the #file descriptor in the specified format.

Syntax



OUTPUT #File descriptor USING image specifications;
 [Output item]

Commentary

The statement converts the format freely to output data by specifying the USING and the image specifications. The image specifications are specified in the character string format.
 The file descriptor specified when the file is opened is used. The file descriptor is assigned to the file to be processed when the file is opened. The subsequent processing for the file is always performed via this file descriptor.

Image specifications

- D : The number of digits to output a value is specified by the number of Ds. A blank in the specified field is provided by a space.
- Z : The number of digits to output a value is specified by the number of Zs. A blank in the specified field is provided by a 0.
- K : The expression value is output in the BASIC standard format (the same as the PRINT).
- S : Plus (+) or minus (-) is output to the S position.
- M : Minus (-) for a negative value or a space for a positive value is output to the M position.
- . : Alignment is done so that a decimal point is on the position ".".
- E : Outputs the format e code exponent.
- H : The same as K, but a comma is used as a decimal point.
- R : The same as ".", but a comma is used as a decimal point.


R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
 Analyzer BASIC File Control Statement

- * : The number of digits to output a value is specified by the number of asterisks (*). * is output to a blank in the specified field.
- A : One character is output to the position A.
- k : The value of a character string is output without change.
- Literal: A character string closed by \" is output without change regardless of the output item.
- X : A space is provided for the X position.
- B : An expression value is accepted as an ASCII code.
- @ : Form feed is output.
- + : Carriage return is output.
- : Line feed is output.
- # : Line feed is provided at the end of items automatically. Line feed is not provided if this image is specified.
- n : The number of repetitions of each image specification is specified by a numeral. For example, 3D.2D means DDD.DD and 4A means AAAA.

Example

OUTPUT #FD USING "ZZZ,DD.D,3A";10;4.5;"abc"



↑ "abc" is converted to the format of image specification "3A" and is output.

↑ 4.5 is output in the format of "DD.D".

↑ 10 is output in the format of "ZZZ".

OUTPUT #FD USING "SDDD, X,MZZZ";+5,-13.57



↑ The first decimal place of 13,57 is rounded off. Three digits of integers are entered.

↑ A space for one byte is provided.

↑ A four-byte area is provided and is output with a code.

9. COPYFILES

Outline

This statement copies all files in the floppy disk to the other floppy disk by one command.

Syntax

→ COPYFILES →

Commentary

The statement copies all files in a floppy disk to the other floppy disk. Since the system is provided with only one floppy disk, the actual operation needs the following operation in addition to execution of the above command.

Operation to change media is needed. Operation instructions are displayed on the CRT in sequence when the COPYFILES command is specified. Follow these instructions, and the processing will be completed.

The processing is as follows:

- ① Obtain a file name to be copied and size from the directory by executing the command.
- ② Check that the BASIC buffer is provided with an empty area for the above file size.
- ③ If the BASIC buffer is provided with an empty area, read a file to the buffer. Continue this operation until no empty area is found in the buffer or no file to be copied is found in the floppy disk to be copied (source). If the buffer is provided with no empty area, a request to insert a floppy disk to copy (target) is made.
- ④ Set a target floppy disk and press the Y and RETURN keys.
- ⑤ Output all files copied to the BASIC buffer to the target floppy disk.
- ⑥ If any file is left in the source file, inserting the source floppy disk is requested and the processing is repeated from item 1.

If the capacity of all files to be copied does not exceed the BASIC buffer size, copying can be completed only by inserting a source floppy disk, then a target floppy disk once. When a large number of files is copied, the above cycle must be repeated several times until copying of all the files is completed.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

Caution

Care must be taken not to insert the source and target floppy disks inversely during copying. Avoid removing the floppy disk during read/write. The temporary storage area uses a different buffer than that used for executing the BASIC program. Executing SCRATCH for the programs in the buffer is recommended to reduce the number of new floppy disks inserted. The reason is that the COPYFILES cannot use the buffer used for these programs. This command has a limitation. The data in one floppy disk must be completely stored in the BASIC buffer. Data stored in the BASIC buffer cannot be copied. Such data is ignored by this command. Note that the STOP key is not effective during the COPYFILES operation.


10. DSTAT

Outline

This statement inserts data from the directory to the BASIC variable.

Syntax

- ① DSTAT <index><numeric variable>
 <index>: 0
- ② DSTAT <index><filename><filetype><size><sectors><year>
 <month><day><week><hour><minute><start-sector>
 <index>: 1..200
- ③



DSTAT [;SELECT File name { [File type], File type, COUNT variable]

Commentary

Syntax ① is for a command to check the number of files catalogued in the file system directory. The <index> specifies an expression resulting in 0. The second parameter specified is a numerical variable. The execution result is substituted for a numerical variable.

Syntax ② is for a command to enter the file system directory information to the BASIC variable. The first <index> specifies an index in the directory by an expression. Values which can be obtained by Syntax 0 to Syntax 1 are available.

The file name specifies a character string variable. Since a file name uses no more than sixteen characters, the length need not be declared.

The third and later parameters specify numerical variables. The following data is substituted:

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

5.6 Syntax of the R4611E Network
Analyzer BASIC File Control Statement

filetype	File type
	1 BASIC
	2 SYSTEM
	3 ASCII
	4 TEXT
	5 BINARY
	6 DATA
size	File size (the number of bytes)
sectors	Number of sectors
year,month,day	File creation year and date
week	1988 is assumed to be 1.
hour,minute	Sunday is assumed to be 0.

Variable specification can be omitted for an unnecessary value. File name and creation year and date can be obtained as follows:

```
DSTAT 1 FNAME$,,,,year,month,day
```

The above syntax is substituted in a variable to specify the number of the following files after the COUNT: files of character strings specified by the SELECT and files whose file types are specified in numerical expressions.

Example

```
DSTAT ; SELECT "FILE", COUNT NUM
```

SELECT

This statement searches a character string after the SELECT from the disk as a file name. When a character string includes the following characters (metacharacters), that character string has a special meaning. The following characters used in a file name are also assumed to be metacharacters:

- ? : Matches one character.
- * : Matches one or more characters.
- []: Matches a character in a character string surrounded with brackets, []. Matches a character in a range from the first character to the second character by specification of [character - character].

```
DSTAT ; SELECT "PROG?.*",COUNT A
```

The file type specifies one of SYSTEM, BASIC, ASCII, TEXT, or BINARY. A file of the specified file type is searched from the floppy disk.

COUNT

This statement substitutes the number of the file searched by the SELECT for a variable.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

6.1 Outline

6. LIST OF BUILT-IN FUNCTIONS

6.1 Outline

Built-in functions are functions incorporated in R4611E for use in CPU high-speed calculations and evaluations of various different operations ranging from analysis of input data to GO and NG judgments.


Since the 64-bit high-speed operations executed in R4611E do not require the wasteful data transfers common in more conventional chips, processing efficiency has been greatly improved.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

6.2 List of R4611E Built-in Functions


(1) Stimulus Frequency → Measurement Point No.

	Input	Output
POINT1 (F,M)	(meas.point)	
POINT2 (F,M)	(1201 point)	
DPOINT (F ₀ ,F ₁ ,M)	(1201 point)	

(2) Measurement Point No. → Stimulus Frequency

FREQ (P,M)	(1201 point)	
DFREQ (P ₀ ,P ₁ ,M)	(1201 point)	

(3) Measurement Point No. → Response Value

VALUE (P,M)	(meas.point)	
DVALUE (P ₀ ,P ₁ ,M)	(meas.point)	

(4) Stimulus Frequency → Response Value

CVALUE (F,M)
 DCVALUE (F₀,F₁,M)

(5) Functions Which Include Search Functions

① Max Search Function

MAX (P ₀ ,P ₁ ,M)	(meas.point) → Max response value
FMAX (P ₀ ,P ₁ ,M)	(meas.point) → F of max response value
PMAX (P ₀ ,P ₁ ,M)	(meas.point) → P of max response value

② Min Search Function

MIN (P ₀ ,P ₁ ,M)	(meas.point) → Max response value
FMIN (P ₀ ,P ₁ ,M)	(meas.point) → F of max response value
PMIN (P ₀ ,P ₁ ,M)	(meas.point) → P of max response value

③ Band Width Calculation Function

BND (P,X,M)	(compensate) → Band width
BNDL (P,X,M)	(compensate) → Band width low frequency
BNDH (P,X,M)	(compensate) → Band width high frequency

④ Differential Coefficient

DEFERX (ΔX,ΔY,M)	(1201 point) → ΔX measurement point count
DEFERY (ΔX,ΔY,M)	(1201 point) → ΔY

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

	Input	Output
⑤ Ripple Detection Function (I)		
RPL1 (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Greatest maximum value - smallest minimum value
RPL2 (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Maximum difference between adjacent maximum and minimum values
RPL3 (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Maximum internal value to which difference between adjacent maximum and minimum values has been added
⑥ Ripple Detection Function (II)		
RPLF (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Frequency difference between maximum and minimum values
RPLR (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Response value difference between maximum and minimum values
⑦ Maximum point frequency		
RPLH (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Maximum value
FRPLH (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Maximum point frequency
PRPLH (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Point no. of maximum point
RPLL (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Minimum value
FRPLL (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Minimum point frequency
PRPLL (P ₀ , P ₁ , ΔX, ΔY, M)	(1201 point)	→ Point no. of minimum point
NRPLH (P ₀ , P ₁ , ΔX, ΔY, M)		Number of maximum values
NRPLL (P ₀ , P ₁ , ΔX, ΔY, M)		Number of minimum points
PRPLHN (N, M)	(meas. point)	→ Point no. of Nth maximum point
PRPLLN (N, M)	(meas. point)	→ Point no. of Nth minimum point
FRPLHN (N, M)	(meas. point)	→ Frequency of Nth maximum point
FRPLLN (N, M)	(meas. point)	→ Frequency of Nth minimum point
VRPLHN (N, M)	(meas. point)	→ Response value of Nth maximum point
VRPLLN (N, M)	(meas. point)	→ Response value of Nth minimum point
⑧ Limit Test		
LMTUL1 (X, Up, Lo)	(1201 point) (1201 point)	→ (Free)
LMTUL2 (P, Up, Lo, M)		
LMTMD1 (X, Md, D1)		
LMTMD2 (P, Md, D1, M)		

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

⑨ Zero Phase Detection Function



⑩ Direct Search Functions

- | | |
|-------------------------------|--|
| DIRECT (P_0, P_1, X, M) | (1201 point)→Measuring point of the response value |
| CDIRECT (F_0, F_1, X, M) | (Frequency) →Frequency of the response |
| DDIRECT (P_0, P_1, X, M) | (1201 point)→Difference of measuring point of the response |
| CDDIRECT (F_0, F_1, X, M) | (Frequency) →Frequency difference of the response |

NOTE

(a) The following functions cannot be used for Log Sweep.

POINT2, DPOINT, CVALUE, DCVALUE, BND, BNDL, BNDH, CBND, CBNDL, CBNDH, ZEROPHS, and functions referring to Ripple, CDIRECT and CDDIRECT

(b) The following functions cannot be used for Cw Sweep.

POINT2, DPOINT, DFREQ, DCVALUE, BND, BNDL, BNDH, CBND, CBNDL, CBNDH, ZEROPHS, and functions referring to Ripple, DIRECT, DDIRECT, CDIRECT and CDDIRECT

(c) The following functions cannot be used for Level Sweep.

BND, BNDL, BNDH, CBND, CBNDL, CBNDH, ZEROPHS, and functions referring to Ripple

(d) The following functions cannot be used during parameter conversion is ON.

BND, BNDL, BNDH, CBND, CBNDL, CBNDH, and functions referring to Ripple.

(e) The following functions cannot be used in the user sweep mode:

POINT2 and DPOINT

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

6.2.1 Stimulus Frequency → No. of Measurement Points

POINT function: If the frequency is specified, that frequency is taken as the measurement point inside the measuring device to calculate the point to which it corresponds.
 (This is required to operate system functions at high speed.)

<p>POINT1 (F,M)</p> <p>POINT2 (F,M)</p>	<p>Measurement channel designation</p> <p>Specified frequency</p> <p>Point</p>	<p>M=0 (1CH) Data</p> <p>M=1 (2CH) Data</p> <p>M=2 (1CH) Memory</p> <p>M=3 (2CH) Memory</p>
(MEAS POINT)	(1201 POINT)	

< POINT1 description >



The no. of the measurement point closest to the specified frequency is returned (see above diagram).

But if the channel is undefined due to the specified frequency lying outside the range between the start and stop points indicated above, an error message and -1 are returned.

< POINT2 description >


Unlike the POINT1 function, the 1201 point no. is returned regardless of the number of measurement points in the measuring device.

But again, if the channel is undefined due to the specified frequency lying outside the range between the start and stop points indicated above, an error message and -1 are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

DPOINT function: If the frequency width is specified, that frequency width is taken as the measurement point inside the measuring device to calculate the point to which it corresponds.




The value obtained by dividing the range (frequency span) by 1200 is the frequency width per measurement point.


- Note:
- When $freq_0 > freq_1$, process by interchanging $freq_0$ and $freq_1$.
 - 0 is returned when $freq_0 = freq_1$.
 - When the channel is undefined, and the specified frequency lies outside the range, an error message and -1 are returned.

6.2.2 Measurement Point No. → Stimulus Frequency

FREQ function: If the measurement point no. inside the measuring device is specified, the stimulus frequency corresponding to that measurement point is calculated and returned.



The start and stop frequencies indicate the upper and lower limits of the measuring device stimulus specified frequency. A maximum of 1201 points of data are taken in this range.



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Hence, conversion from measurement point no. to stimulus frequency complies with the following simple equation.

$$\text{Stimulus frequency} = \text{Start frequency} + \frac{\text{Stop frequency} - \text{Start frequency}}{1201} \times \text{Measurement point no.}$$

Note: If channel is undefined while the specified measurement point no. is in the 0 thru 1200 range, an error message and an unspecified value are returned.

DFREQ function: If the measurement point no. inside the measuring device is specified, the stimulus frequency corresponding to the measurement point width is calculated and returned.

DFREQ(P₀, P₁, M)

	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">M=0 (1CH)</td> <td rowspan="4" style="font-size: 2em; vertical-align: middle;">}</td> <td rowspan="4">Data</td> </tr> <tr> <td>M=1 (2CH)</td> </tr> <tr> <td>M=2 (1CH)</td> <td rowspan="2" style="font-size: 2em; vertical-align: middle;">}</td> <td rowspan="2">Memory</td> </tr> <tr> <td>M=3 (2CH)</td> </tr> </table>	M=0 (1CH)	}	Data	M=1 (2CH)	M=2 (1CH)	}	Memory	M=3 (2CH)
M=0 (1CH)	}	Data							
M=1 (2CH)									
M=2 (1CH)					}	Memory			
M=3 (2CH)									

(1201 POINT)

- Note:
- When point0 > point1, process by interchanging.
 - 0.0 is returned when point0 = point1.
 - When the channel is undefined, and the specified frequency lies inside the range, an error message and an unspecified value are returned.

6.2.3 Measurement Point No. → Response Value

VALUE function: If the number of measurement points is specified, the measurement response value at that measurement point is returned.

VALUE(P, M)

	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">M=0 (1CH)</td> <td rowspan="4" style="font-size: 2em; vertical-align: middle;">}</td> <td rowspan="4">Data</td> </tr> <tr> <td>M=1 (2CH)</td> </tr> <tr> <td>M=2 (1CH)</td> <td rowspan="2" style="font-size: 2em; vertical-align: middle;">}</td> <td rowspan="2">Memory</td> </tr> <tr> <td>M=3 (2CH)</td> </tr> </table>	M=0 (1CH)	}	Data	M=1 (2CH)	M=2 (1CH)	}	Memory	M=3 (2CH)
M=0 (1CH)	}	Data							
M=1 (2CH)									
M=2 (1CH)					}	Memory			
M=3 (2CH)									

(MEAS POINT)

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Note: When the channel is undefined, and P is not a value inside the 0 thru 1200 range but is a point where a measurement has not been made inside the measuring device, an error message and an unspecified value are returned.

DVALUE function: If two measurement points are specified, the difference in measurement response value at that measurement point is calculated and returned.

DVALUE(P₀,P₁,M)

M=0 (1CH)	Data
M=1 (2CH)	
M=2 (1CH)	Memory
M=3 (2CH)	

Response value difference

(MEAS POINT)

- Note:
- When the channel is undefined, and P₀ and P₁ are not values inside the 0 thru 1200 range but are points where measurements have not been made inside the measuring device, an error message and an unspecified value are returned.
 - When point₀ > point₁, process by interchanging.
 - 0.0 is returned when point₀ = point₁.

6.2.4 Stimulus Frequency → Response Value

CVALUE function: If frequency is specified, the measurement response value at that frequency is displayed.

CVALUE(F,M)

M=0 (1CH)	Data
M=1 (2CH)	
M=2 (1CH)	Memory
M=3 (2CH)	

Response value at specified frequency


Note: If arguments are unsuitable

- If specified frequency is outside range
 - When channel is undefined
- } Error message and unspecified value are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

DCVALUE function: If two frequencies are specified, the difference between the measurement response values at those frequencies is displayed.





Note: If arguments are unsuitable

- If specified frequency is outside range
 - When channel is undefined
 - If $F_0 > F_1$ Execute after interchanging F_0 and F_1
- } ... Error message and unspecified value are returned.

6.2.5 Functions Which Include Search Functions

(1) Max Search Function

MAX function: If the measurement point region is specified, the maximum response value in that region is returned.



(MEAS POINT)



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Note: If arguments are unsuitable

- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and unspecified value are returned.

FMAX function: If the measurement point region is specified, the stimulus frequency of the point with the maximum response value in that region is returned.



(MEAS POINT)

Note: If arguments are unsuitable

- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and unspecified value are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

PMAX function: If the measurement point region is specified, the point no. with the maximum response value in that region is returned.

$P_{MAX}(P_0, P_1, M)$

Measurement channel designation	M=0 (1CH)	Data
Specified region measurement point no.	M=1 (2CH)	
	M=2 (1CH)	
M=3 (2CH)		

(MEAS POINT)

Note: If arguments are unsuitable

- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and -1 are returned.

(2) Min Search Function

MIN function: If the measurement point region is specified, the minimum response value in that region is returned.

$P_{MIN}(P_0, P_1, M)$

Measurement channel designation	M=0 (1CH)	Data
Specified region measurement point no.	M=1 (2CH)	
	M=2 (1CH)	
M=3 (2CH)		

Min Response Value

(MEAS POINT)


R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Note: If arguments are unsuitable

- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and unspecified value are returned.


FMIN function: If the measurement point region is specified, the stimulus frequency of the point with the maximum response value in that region is returned.



Note: If arguments are unsuitable

- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and unspecified value are returned.

PMIN function: If the measurement point region is specified, the point no. with the maximum response value in that region is returned.



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Note: If arguments are unsuitable


- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$... Execute as is
 - When $P_0 > P_1$... Execute after interchanging P_0 and P_1
- } ... Error message and -1 are returned.

(3) Band Width Calculation Function

BND function: If the reference data measurement point no. and LOSS level are specified, the band width is calculated and returned.



BND(P,X,M)

Measurement channel designation	M=0 (1CH)	Data
Reference data measurement point no.	M=1 (2CH)	Memory
Specified loss level	M=2 (1CH)	
Band width	M=3 (2CH)	



(COMPENSATE)

Note: Argument (down) handles the following signs.



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL



6.2 List of R4611E Built-in Functions

If arguments are unsuitable

- When P is not in 0 thru 1200 range
 - When channel is undefined
- } Error message and unspecified value are returned.

BNDL function: If the reference data measurement point no. and LOSS level are specified, the low frequency of the band width is searched for and returned.

BNDL(P,X,M)



(COMPENSATE)

Note: If arguments are unsuitable


- When P is not in 0 thru 1200 range
 - When channel is undefined
- } Error message and unspecified value are returned.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

BNDH function: If the reference data measurement point no. and LOSS level are specified, the high frequency of the band width is searched for and returned.

BNDH(P,X,M)



M=0 (1CH)) Data
M=1 (2CH))
M=2 (1CH)) Memory
M=3 (2CH))



(COMPENSATE)

Note: If arguments are unsuitable


- When P is not in 0 thru 1200 range
 - When channel is undefined
- } Error message and unspecified value are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

CBND function: If time base-frequency and LOSS level are specified, the band width is calculated and returned.

CBND(F,X,M)





- M=0 (1CH)) Data
- M=1 (2CH))
- M=2 (1CH)) Memory
- M=3 (2CH))



(COMPENSATE)

Note: Argument (down) handles the following signs.



<If arguments are unsuitable>


- When channel is undefined } Error message and unspecified value are returned.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

CBNDL function: If time base-frequency and LOSS level are specified, the low frequency of the band width is searched for and returned.

CBNDL (F,X,M)



M=0 (1CH) Data
M=1 (2CH) Data
M=2 (1CH) Memory
M=3 (2CH) Memory



(COMPENSATE)

Note: < If arguments are unsuitable >


- When channel is undefined } Error message and unspecified value are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions


The explanations of BND, BNDL, BNDH, CBND, CBNDL, and CBNDH above are for the case when FORMAT is LOG MAG.

When FORMAT IS G. DELAY, the following curves are shown.



(Be careful of polarity. It is the inverse of LOG MAG)

When FORMAT is PHASE and PHASE (- , +), the following curve is shown. (It becomes $+X^0$ search).




R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

CBNDH function: If time base-frequency and LOSS level are specified, the high frequency of the band width is searched for and returned.

CBNDH(F,X,M)



M=0 (1CH) Data
 M=1 (2CH))
 M=2 (1CH) Memory
 M=3 (2CH))



(COMPENSATE)


Note: <If arguments are unsuitable >

- When channel is undefined } Error message and unspecified value are returned.


(4) Differential Coefficient

DIFF function: Differential coefficients are converted to match the internal format of the measuring device to enable their use as arguments in any system function.

DIFF X($\Delta X, \Delta Y, M$)



DEFER Y($\Delta X, \Delta Y, M$)



Note: Contract for use of same arguments in both functions

(1201 POINT)

Note: <If arguments are unsuitable>

DEFER X function

- When ΔX is negative ... Execute after inverting sign
- When ΔX is 0 Error message and -1 are returned
- When ΔY is 0 Error message and -1 are returned
- When ΔY is negative ... Execute after inverting sign
- When channel is undefined
 ... Error message and -1 are returned

DEFER Y function



- When ΔX is negative ... Execute after inverting sign
- When ΔX is 0 Error message and unspecified value are returned
- When ΔY is 0 Error message and unspecified value are returned
- When ΔY is negative ... Execute after inverting sign
- When channel is undefined
 ... Error message and unspecified value are returned

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

(5) Ripple Detection Function (I)

RPL1 function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The difference between the greatest maximum and the smallest minimum is calculated and returned.



(1201 POINT)

Note: <If arguments are unsuitable>



- When M is undefined data
 - When P_0 and P_1 are negative with a value larger than 1200
 - When $P_0 = P_1$
 - When $P_0 > P_1$
 - When ΔX is negative, when value is larger than 1200, when 0
 - When ΔY is negative ...
 - When ΔY is 0
- } ... Error message and unspecified value are returned.
- } ... Error message and unspecified value are returned.
- } ... Error message and unspecified value are returned.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

RPL2 function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The maximum difference between adjacent maximum and minimum values is calculated and returned.

RPL2(P₀,P₁,ΔX,ΔY,M)



ΔX: Number of points
 ΔY: Level (dB)
 (Value already converted internally by DEFER function)

(1201 POINT)


Note: Same as for RPL1.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

RPL3 function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The maximum value obtained by adding the difference between adjacent maximum and minimum values is calculated and returned.

RPL3(P₀, P₁, ΔX, ΔY, M)



$$|(P_2 - P_1) + (P_2 - P_3)|, |(P_4 - P_3) + (P_4 - P_5)|, |(P_6 - P_5) + (P_6 - P_7)|, \dots \text{Maximum of these values}$$

(1201 POINT)

Note: Same as for RPL1.



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

(6) Ripple Detection Function (II)

RPLF function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The frequency difference between the first maximum and minimum values found is calculated and returned.

RPLF($P_0, P_1, \Delta X, \Delta Y, M$)



ΔX : Number of points
 ΔY : Level (dB)
 (Value already converted internally by DEFER function)

(1201 POINT)



Note: Same as for RPL1 function.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

RPLR function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The response value difference between the first maximum and minimum values found is calculated and returned.

RPLR($P_0, P_1, \Delta X, \Delta Y, M$)



ΔX : Number of points
 ΔY : Level (dB)
 (Value already converted internally by DEFER function)

(1201 POINT)

Note: Same as for RPL1 function.



R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

(7) Maximum and Minimum Detection Function

RPLH function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum and minimum values in that region. The first maximum value found is calculated and returned.

RPLH($P_0, P_1, \Delta X, \Delta Y, M$)





Note: Same as for RPL1 function.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

FRPLH function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum value in that region. The frequency of the first maximum value found is returned.

FRPLH($P_0, P_1, \Delta X, \Delta Y, M$)



ΔX : Number of points
 ΔY : Level (dB)
 (Value already converted internally by DEFER function)

(1201 POINT)



Note: Same as for RPL1 function.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

PRPLH function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the maximum value in that region. The measurement point no. of the first maximum value found is returned.

PRPLH(P₀,P₁,ΔX,ΔY,M)



ΔX: Number of points
 ΔY: Level (dB)
 (Value already converted internally by DEFER function)

(1201 POINT)



Note: Same as for RPL1 function. (But error message and -1 are returned if error is generated.)

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

RPLL function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the minimum value in that region. The first minimum value found is returned.

RPLL($P_0, P_1, \Delta X, \Delta Y, M$)



(1201 POINT)



Note: Same as for RPL1 function.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

FRPLL function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the minimum value in that region. The frequency of the first minimum value found is returned.

FRPLL($P_0, P_1, \Delta X, \Delta Y, M$)



ΔX : Number of points
 ΔY : Level (dB)
(Value already converted internally by DEFER function)

(1201 POINT)



Note: Same as for RPL1 function.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

PRPLL function: If the region is specified by measurement point no. and if the differential coefficient is specified, a search is made for the minimum value in that region. The measurement point no. of the first minimum value found is returned.

PRPLL($P_0, P_1, \Delta X, \Delta Y, M$)




(1201 POINT)

Note: Same as for RPL1 function. (But error message and -1 are returned if error is generated.)

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions


NRPLH function: If the measurement point no. and the differential coefficient are specified, a search is made for the maximum value in the region. The number of maximum values is determined.



Δ X: Number of points (Value already converted internally)
 Δ Y: Level (dB) (by DEFER function)

Note: Same as for RPL1 function. (But error message and -1 are returned if error is generated.)

NRPLL function: If the measurement point no. and the differential coefficient are specified, a search is made for the minimum value in the region. The number of minimum values is determined.




Δ X: Number of points (Value already converted internally)
 Δ Y: Level (dB) (by DEFER function)

Note: Same as for RPL1 function. (But error message and -1 are returned if error is generated.)

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

PRPLHN function: If the maximum point no. (indicating the nth maximum point) is specified after executing the NRPLH function, that maximum point is displayed.




ΔX: Number of points (Value already converted internally)
 ΔY: Level (dB) (by DEFER function)

Note: <If arguments are unsuitable>

- When channel is undefined ... Error message and -1 are returned
- When N is not within the range from N to [Number of maximum values determined by NRPLH] Error message and -1 are returned

PRPLLN function: If the minimum point no. (indicating the nth minimum point) is specified after executing the NRPLL function, that minimum point is displayed.



ΔX: Number of points (Value already converted internally)
 ΔY: Level (dB) (by DEFER function)


Note: <If arguments are unsuitable>

- When channel is undefined ... Error message and -1 are returned
- When N is not within the range from N to [Number of minimum values determined by NRPLL] Error message and -1 are returned

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

FRPLHN function: If the maximum point no. is specified after executing the NRPLH function, the frequency of that maximum point is displayed.




ΔX : Number of points (Value already converted internally)
 ΔY : Level (dB) (by DEFER function)

Note: <If arguments are unsuitable>

- When channel is undefined data ... Error message and un-specified value are returned
- When N is not within the range from N to [Number of maximum values determined by NRPLH] Error message and un-specified value are returned

FRPLLN function: If the minimum point no. is specified after executing the NRPLL function, the frequency of that minimum point is displayed.



ΔX : Number of points (Value already converted internally)
 ΔY : Level (dB) (by DEFER function)


Note: <If arguments are unsuitable>

- When channel is undefined data ... Error message and un-specified value are returned
- When N is not within the range from N to [Number of minimum values determined by NRPLL] Error message and un-specified value are returned

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

VRPLHN function: If the maximum point no. is specified after executing the NRPLH function, the response value of that maximum point is displayed.



Note: Same as for FRPLHN function.

VRPLLN function: If the minimum point no. is specified after executing the NRPLL function, the response value of that minimum point is displayed.



Note: Same as for FRPLHN function.

CAUTION

- ① When the above functions are used together with the RPL1, RPL2, and RPL3 functions, P₀, P₁, X, and Y must be set together.
- ② The settings to be made when the RPL1, RPL2, and RPL3 functions are executed after executing the above functions can be made as desired.

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

(8) Limit Test


LMT function: If the upper and lower limits, and detected data are given, the fact whether the data lies between the limits or not is checked and the result returned.

M=0 (1CH)) Data
 M=1 (2CH))
 M=2 (1CH)) Memory
 M=3 (2CH))


LMTUL1 (X,Up,Lo)






LMTUL2 (P,Up,Lo,M)



LMTMD1 (X,Md,D1)



LMTMD2 (P,Md,D1,M)



(1201 POINT)

Results: When inside range : 0
 When above upper limit: 1
 When below lower limit: 2
 When specified point is not measured after specifying point : -1

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

Note: When arguments are unsuitable

- When $Lo > Up$ Execute after interchanging Lo and Up
- When channel is undefined data
 ... Error message and -1 are returned
- When P is not within 0 thru 1200 range
 ... Error message and -1 are returned
- When $D1$ is negative ... Execute after inverting sign

(9) Zero Phase Detection Function

ZEROPHS function: Zero Phase is searched in the specified region by P_0 and P_1 and the frequency is returned.

ZEROPHS(P_0, P_1, M)

	<p>Measurement channel designation</p> <p>Measurement point No. of specified region</p> <p>Frequency of Pero Phase</p>	<p>M=0 (1CH) Data</p> <p>M=1 (2CH) Data</p> <p>M=2 (1CH) Memory</p> <p>M=3 (2CH) Memory</p>
--	--	---

(10) Direct Search functions

DIRECT function: Calculates the measuring point of the specified response and returns it.

DIRECT (P_0, P_1, X, M)

	<p>Measurement channel designation</p> <p>Response</p> <p>Measuring point of the specified area</p>	<p>M=0 (1CH) Data</p> <p>M=1 (2CH) Data</p> <p>M=2 (1CH) Memory</p> <p>M=3 (2CH) Memory</p>	
--	---	---	--

R4611E
 NETWORK ANALYZER PROGRAMMING
 INSTRUCTION MANUAL

6.2 List of R4611E Built-in Functions

CDIRECT function: Calculates the frequency of the specified response and returns it.

CDIRECT (F_0, F_1, X, M)

Measurement channel designation

Response

Measuring frequency of the specified area

M=0 (1CH) } Data
 M=1 (2CH) }
 M=2 (1CH) } Memory
 M=3 (2CH) }

DDIRECT function: Calculates the measuring point difference of the specified response and returns it.

CDIRECT (P_0, P_1, X, M)

Measurement channel designation

Response

Measuring point of the specified area


M=0 (1CH) } Data
 M=1 (2CH) }
 M=2 (1CH) } Memory
 M=3 (2CH) }

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL


6.2 List of R4611E Built-in Functions

CDDIRECT function: Calculates the frequency difference of the specified response and returns it.

CDIRECT (F_0, F_1, X, M)



- M=0 (1CH) } Data
- M=1 (2CH) } Data
- M=2 (1CH) } Memory
- M=3 (2CH) } Memory



- Notes:
- $P_0=P_1$ (If $F_0=F_1$, and error occurs.)
 - If value X is omitted, an error occurs.

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

List of Figures

LIST OF FIGURES

No.	Title	Page
2-1	Status Register	2 - 20
3-1	Floppy Disk Dimensions and Component Parts	3 - 3
3-2	Floppy Disk Insertion Method	3 - 4
3-3	Floppy Disk Write Protect and Write Enable	3 - 6
4-1	CRT Display During Program Mode	4 - 2
4-2	CRT Display During Editor Mode	4 - 4
4-3	Statement Configuration	4 - 11
4-4	Object Configuration	4 - 14

R4611E
NETWORK ANALYZER PROGRAMMING
INSTRUCTION MANUAL

List of Tables

LIST OF TABLES

No.	Title	Page
2-1	How to Read the GPIB Code Table	2 - 7
2-2	GPIB Program Code (1/14)	2 - 8
2-2	GPIB Program Code (2/14)	2 - 9
2-2	GPIB Program Code (3/14)	2 - 10
2-2	GPIB Program Code (4/14)	2 - 11
2-2	GPIB Program Code (5/14)	2 - 12
2-2	GPIB Program Code (6/14)	2 - 13
2-2	GPIB Program Code (7/14)	2 - 14
2-2	GPIB Program Code (8/14)	2 - 15
2-2	GPIB Program Code (9/14)	2 - 16
2-2	GPIB Program Code (10/14)	2 - 17
2-2	GPIB Program Code (11/14)	2 - 18
2-2	GPIB Program Code (12/14)	2 - 19
2-2	GPIB Program Code (13/14)	2 - 20
2-2	GPIB Program Code (14/14)	2 - 21
4-1	CTRL Key Operation	4 - 5
4-2	Function Key Operations	4 - 7
4-3	List of Key Words	4 - 12
4-4	Alphanumeric Characters	4 - 15

IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

SOFTWARE License

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

Restrictions

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

Liability

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
 - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
 - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
 - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
 - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
 - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
 - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
 - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
 - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

CUSTOMER SERVICE DESCRIPTION

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea
Phone: +82-2-532-7071
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.
Phone: +86-21-6485-2725
Fax: +86-21-6485-2726

Shanghai Branch Office:
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,
Hai Dian District, Beijing,
China 100083
Phone: +86-10-8235-3377
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06
Alexandra Technopark Singapore 119967
Phone: +65-6274-3100
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A
Phone: +1-408-988-7700
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany
(P.O.B. 80 14 60 D-81614 München, Germany)
Phone: +49-89-4129-13711
Fax: +49-89-4129-13723

ADVANTEST®

<http://www.advantest.co.jp>