

---

**ADVANTEST®**  
ADVANTEST CORPORATION

---

*R3465 OPT51/56*

*GSM Measurement Option*

*Operation Manual*

MANUAL NUMBER FOE-8311289D01

---

*Applicable model*

*R3465*



---

## Safety Summary

To ensure thorough understanding of all functions and to ensure efficient use of this instrument, please read the manual carefully before using. Note that Advantest bears absolutely no responsibility for the result of operations caused due to incorrect or inappropriate use of this instrument.

If the equipment is used in a manner not specified by Advantest, the protection provided by the equipment may be impaired.

- **Warning Labels**

Warning labels are applied to Advantest products in locations where specific dangers exist. Pay careful attention to these labels during handling. Do not remove or tear these labels. If you have any questions regarding warning labels, please ask your nearest Advantest dealer. Our address and phone number are listed at the end of this manual.

Symbols of those warning labels are shown below together with their meaning.

**DANGER:** Indicates an imminently hazardous situation which will result in death or serious personal injury.

**WARNING:** Indicates a potentially hazardous situation which will result in death or serious personal injury.

**CAUTION:** Indicates a potentially hazardous situation which will result in personal injury or a damage to property including the product.

- **Basic Precautions**

Please observe the following precautions to prevent fire, burn, electric shock, and personal injury.

- Use a power cable rated for the voltage in question. Be sure however to use a power cable conforming to safety standards of your nation when using a product overseas.
- When inserting the plug into the electrical outlet, first turn the power switch OFF and then insert the plug as far as it will go.
- When removing the plug from the electrical outlet, first turn the power switch OFF and then pull it out by gripping the plug. Do not pull on the power cable itself. Make sure your hands are dry at this time.
- Before turning on the power, be sure to check that the supply voltage matches the voltage requirements of the instrument.
- Connect the power cable to a power outlet that is connected to a protected ground terminal. Grounding will be defeated if you use an extension cord which does not include a protected ground terminal.
- Be sure to use fuses rated for the voltage in question.
- Do not use this instrument with the case open.
- Do not place anything on the product and do not apply excessive pressure to the product. Also, do not place flower pots or other containers containing liquid such as chemicals near this

---

## Safety Summary

product.

- When the product has ventilation outlets, do not stick or drop metal or easily flammable objects into the ventilation outlets.
- When using the product on a cart, fix it with belts to avoid its drop.
- When connecting the product to peripheral equipment, turn the power off.

- **Caution Symbols Used Within this Manual**

Symbols indicating items requiring caution which are used in this manual are shown below together with their meaning.

**DANGER:** Indicates an item where there is a danger of serious personal injury (death or serious injury).

**WARNING:** Indicates an item relating to personal safety or health.

**CAUTION:** Indicates an item relating to possible damage to the product or instrument or relating to a restriction on operation.

- **Safety Marks on the Product**

The following safety marks can be found on Advantest products.



: ATTENTION - Refer to manual.



: Protective ground (earth) terminal.



: DANGER - High voltage.



: CAUTION - Risk of electric shock.

- **Replacing Parts with Limited Life**

The following parts used in the instrument are main parts with limited life.

Replace the parts listed below before their expected lifespan has expired to maintain the performance and function of the instrument.

Note that the estimated lifespan for the parts listed below may be shortened by factors such as the environment where the instrument is stored or used, and how often the instrument is used.

The parts inside are not user-replaceable. For a part replacement, please contact the Advantest sales office for servicing.

Each product may use parts with limited life.

For more information, refer to the section in this document where the parts with limited life are described.

## Main Parts with Limited Life

Part name	Life
Unit power supply	5 years
Fan motor	5 years
Electrolytic capacitor	5 years
LCD display	6 years
LCD backlight	2.5 years
Floppy disk drive	5 years
Memory backup battery	5 years

- **Hard Disk Mounted Products**

The operational warnings are listed below.

- Do not move, shock and vibrate the product while the power is turned on.  
Reading or writing data in the hard disk unit is performed with the memory disk turning at a high speed. It is a very delicate process.
- Store and operate the products under the following environmental conditions.  
An area with no sudden temperature changes.  
An area away from shock or vibrations.  
An area free from moisture, dirt, or dust.  
An area away from magnets or an instrument which generates a magnetic field.
- Make back-ups of important data.  
The data stored in the disk may become damaged if the product is mishandled. The hard disc has a limited life span which depends on the operational conditions. Note that there is no guarantee for any loss of data.

- **Precautions when Disposing of this Instrument**

When disposing of harmful substances, be sure dispose of them properly with abiding by the state-provided law.

Harmful substances: (1) PCB (polycarbon biphenyl)  
(2) Mercury  
(3) Ni-Cd (nickel cadmium)  
(4) Other  
Items possessing cyan, organic phosphorous and hexadic chromium and items which may leak cadmium or arsenic (excluding lead in solder).

Example: fluorescent tubes, batteries

# Environmental Conditions

This instrument should only be used in an area which satisfies the following conditions:

- An area free from corrosive gas
- An area away from direct sunlight
- A dust-free area
- An area free from vibrations
- Altitude of up to 2000 m



**Figure-1 Environmental Conditions**

- Operating position



**Figure-2 Operating Position**

- Storage position



**Figure-3 Storage Position**

- The classification of the transient over-voltage, which exists typically in the main power supply, and the pollution degree is defined by IEC61010-1 and described below.

Impulse withstand voltage (over-voltage) category II defined by IEC60364-4-443

Pollution Degree 2

## Types of Power Cable

Replace any references to the power cable type, according to the following table, with the appropriate power cable type for your country.

Plug configuration	Standards	Rating, color and length	Model number (Option number)
	PSE: Japan  Electrical Appliance and Material Safety Law	125 V at 7 A Black 2 m (6 ft)	Straight: A01402  Angled: A01412
	UL: United States of America  CSA: Canada	125 V at 7 A Black 2 m (6 ft)	Straight: A01403 (Option 95)  Angled: A01413
	CEE: Europe DEMKO: Denmark NEMKO: Norway VDE: Germany KEMA: The Netherlands CEBEC: Belgium OVE: Austria FIMKO: Finland SEMKO: Sweden	250 V at 6 A Gray 2 m (6 ft)	Straight: A01404 (Option 96)  Angled: A01414
	SEV: Switzerland	250 V at 6 A Gray 2 m (6 ft)	Straight: A01405 (Option 97)  Angled: A01415
	SAA: Australia, New Zealand	250 V at 6 A Gray 2 m (6 ft)	Straight: A01406 (Option 98)  Angled: -----
	BS: United Kingdom	250 V at 6 A Black 2 m (6 ft)	Straight: A01407 (Option 99)  Angled: A01417
	CCC: China	250 V at 10 A Black 2 m (6 ft)	Straight: A114009 (Option 94)  Angled: A114109











## Table of Power Cable Options

There are six power cable options (refer to following table).

Order power cable options by Model number.

	Plug configuration	Standards	Rating, color and length	Model number (Option number)
1		JIS: Japan Law on Electrical Appliances	125 V at 7 A Black 2 m (6 ft)	Straight: A01402 Angled: A01412
2		UL: United States of America CSA: Canada	125 V at 7 A Black 2 m (6 ft)	Straight: A01403 (Option 95) Angled: A01413
3		CEE: Europe DEMKO: Denmark NEMKO: Norway VDE: Germany KEMA: The Netherlands CEBEC: Belgium OVE: Austria FIMKO: Finland SEMKO: Sweden	250 V at 6 A Gray 2 m (6 ft)	Straight: A01404 (Option 96) Angled: A01414
4		SEV: Switzerland	250 V at 6 A Gray 2 m (6 ft)	Straight: A01405 (Option 97) Angled: A01415
5		SAA: Australia, New Zealand	250 V at 6 A Gray 2 m (6 ft)	Straight: A01406 (Option 98) Angled: -----
6		BS: United Kingdom	250 V at 6 A Black 2 m (6 ft)	Straight: A01407 (Option 99) Angled: A01417



## TABLE OF CONTENTS

### Chapter 1 MEASUREMENT FUNCTIONS

1.	Outline of GSM Measurement Option . . . . .	1-2
	OPT51 . . . . .	1-2
	OPT56 . . . . .	1-2
2.	Switching Standard Measurement Function (Only OPT51) . . . . .	1-3
3.	Function of CW Mode . . . . .	1-4
4.	Function of MEASUREMENT Section . . . . .	1-5
	Explanation of OBW (Occupied Bandwidth) Key . . . . .	1-5
	Explanation of ACP (Adjacent Channels Leakage Power) Key . . . . .	1-8
	HARMONICS (Higher Harmonics) Measuring Function . . . . .	1-10
	Function of TRANSIENT Key . . . . .	1-11
	TDMA waveform Analysis and Burst Envelope Waveform Display . . . . .	1-12
	Explanation of Menu on Transmission-Power . . . . .	1-40
	Power vs Time Measurement . . . . .	1-41
	Explanation of Menu on Frequency-Error Measurement . . . . .	1-44
	Description of Communication Protocol Setting Menu . . . . .	1-45
5.	Cautions on the RECALL Function . . . . .	1-48

### Chapter 2 GPIB REMOTE PROGRAMMING

1.	GPIB Code of TRANSIENT Mode . . . . .	2-2
2.	Program Example of TRANSIENT Mode . . . . .	2-8

### Chapter 3 SPECIFICATIONS

1.	GSM Measurement Option Specifications . . . . .	3-2
	Transient RF Analysis . . . . .	3-2
	Anti-modulation System . . . . .	3-2
	Analysis Input Range . . . . .	3-2
	Average Power Measurement . . . . .	3-2
	Frequency/Phase Error . . . . .	3-2


## APPENDIX

1. Glossary .....	A-2
2. Menu Lists .....	A-3
3. List of Messages .....	A-7

## LIST OF ILLUSTRATIONS

No.	Title	Page
1-1	Dialog Box .....	1-3
1-2	Panel Keys in MEASUREMENT Section .....	1-5
1-3	Power Template Measurement Screen .....	1-13
1-4	Trigger Setup Dialog Box .....	1-16
1-5	Waveform at Gate Sweep OFF .....	1-19
1-6	Waveform at Gate Sweep ON .....	1-19
1-7	Expansion of Display Using Window .....	1-21
1-8	Sample Power Spectrum Measurement .....	1-28
1-9	Output Power Spectrum in Modulation Period .....	1-31
1-10	Pass/Fail Judgment .....	1-34
1-11	Selection of Frequency Range .....	1-38
1-12	Display of Tx Power Measurement Result .....	1-40
1-13	Example of Power vs Time Measurement .....	1-42
1-14	Display of Template Entry .....	1-43
1-15	Display of Phase Error Measurement Results .....	1-44
1-16	Communication Protocol Setting Menu .....	1-45
1-17	Display Example at Center Frequency Channel Input ...	1-46
1-18	Recall Screen .....	1-48





# CHAPTER 1

## Measurement Function

This chapter explains the GSM measurement option.

---

### CONTENTS

---

1. Outline of GSM Measurement Option . . . . .	1-2
2. Switching Standard Measurement Function (Only OPT51) . . . . .	1-3
3. Function under CW Mode . . . . .	1-4
4. Functions of MEASUREMENT Section . . . . .	1-5
5. Cautions on the RECALL function . . . . .	1-48

---

## 1. Outline of GSM Measurement Option

Two kinds of GSM measurement options are provided. One is OPT51 which offers the GSM measurement function besides the PDC/PHS/NADC measurement function. The other is OPT56 which offers GSM measurement function only.

This manual covers explanations of these two kinds of options.

### ■ OPT 51

OPT51 allows the GSM standard (GSM900/DCS1800/DCS1900) measurement besides the PDC/PHS/NADC standard measurement. Installing this option to an instrument, the instrument can support all the above standard measurement. However, the PDC/PHS/NADC standard measurement function and the GSM standard measurement function each act exclusively. So, to use the equipment as a system applicable to each standard measurement, it is necessary to switch the standard according to the explanation on page 1-3.

### ■ OPT 56

OPT56 supports the GSM standard measurement only. This option does not offer the PDC/PHS/NADC standard measurement.




## 2. Switching Standard Measurement Function (Only OPT51)

In OPT51, it is necessary to switch the system between PDC/PHS/NADC standard measurement and GSM standard measurement.


The switching operation is made as a system function operation.

1

Press



then



keys to display the dialog box in Figure 1-1.




Figure 1-1 Dialog Box

2

Select a communication system (PDC/PHS/NADC or GSM) with the data knob.

3

Press the key or turn the data knob to determine the setting.

Then a box for a confirmation appears. If you want to make the setting effective, select "Confirm". If making it ineffective, select "Cancel" and press the key.

4

If the power is turned off once then turned on, the communication system to be measured and the menu for measurement are switched. Then either PDC/PHS/NADC standard measurement or GSM standard measurement becomes executable according to your selection.


### NOTE

After the system is switched by using Comm. System, always execute a calibration.

### 3. Function under CW Mode

When the GSM measurement function is set by OPT51 or OPT56, the specifications of the **FREQ** key of the basic key and the **OBW/ACP/HARM/STD** key in the **MEASUREMENT** section differ from the case that **PDC/PHS/NADC** measurement function is set.

● **Explanation of Center Frequency Menu**



**FREQ:** Frequency input method  
**CHANNEL No.:** Channel input method

The correspondence between input channel and center frequency depends on the setting of the communication type and link.

## 4. Functions of MEASUREMENT Section




Figure 1-2 Panel Keys in MEASUREMENT Section

### ■ Explanation of OBW (Occupied Bandwidth) Key

Pressing  key enters OBW measurement mode, halting sweep.


This is the condition waiting for OBW measurement related parameters being input or measurement start command being input.


When currently set parameters need not be changed, press  or  key to start measurement.

When measurement has been started with  key, measurement is continued after the end of a measurement.


When measurement has been started with  key, operation stops after the end of a measurement.

4. Functions of MEASUREMENT Section









### ■ Explanation of ACP (Adjacent Channels Leakage Power) Key


Pressing  key enters ACP measuring mode, halting sweep.


When

currently set parameters need not be changed, press  or  key to start measurement.

When measurement has been started with  key, measurement is continued after the end of a measurement.

When measurement has been started with  key, operation stops after the end of a measurement.





## ■ HARMONICS (higher harmonics) measuring function


Pressing  key enters higher harmonics measuring mode, halting sweep.

Entering higher harmonics measuring mode automatically sets start/stop frequency according to the parameters preset at selecting the mode.

When currently set parameters need not be changed, press  or  key to start measurement.

When measurement has been started with  key, measurement is continued after the end of a measurement.

When measurement has been started with  key, operation stops after the end of a measurement.





## ■ Function of TRANSIENT key

TRANSIENT	Select TRANSIENT mode to perform burst and modulation waveform analysis in the time domain and envelope analysis in the frequency domain of a burst signal. This is used exclusively from the conventional spectrum analysis mode (CW mode).
Burst Env Spectrum	This is used when performing waveform analysis of burst signals.
Power	This is used when performing average electric power measurements of the burst pulse in the time domain.
Spectrum	This is used when performing measurements in the frequency domain (spectrum due to modulation and due to transients) and when performing spurious measurements.
Tx Power	Demodulates the input signal then finds out the timing of a burst signal to calculate the power.
Phase Err	Calculates the peak phase error, the RMS phase error and the frequency error.
Setup STD	This is used when setting parameters such as specifications for the measurement signal and transmission direction.

### **CAUTION !**

*In general, operations in TRANSIENT mode are performed using soft keys. The following keys which can be used when performing conventional spectrum measurements (in CW mode) cannot be used in this mode.*

**SWEEP, INPUT, FORMAT, WINDOW, →CF, →RF**

*Also, only settings made using numeric values, knobs, and arrow keys can be made for the following keys (the corresponding soft key menu will not be displayed).*

**FREQ, LEVEL, SPAN(\*1), ATT(\*2)**

**(\*1): SPAN can only be used during frequency domain measurements.**


**(\*2): ATT can only be used when the setting is MNL.**

**All measurements are started and stopped using the SINGLE/ REPEAT keys. Be sure that the system is in stop mode when changing measurement parameters.**

**When using the external trigger, input a trigger signal with the TTL level into the external trigger input terminal on the rear panel.**

## ■ TDMA waveform analysis and burst envelope waveform display

- TDMA waveform analysis Function



A template (limit line) conforming to all ETSI specifications is automatically displayed, and the burst pulse is judged for Pass/Fail.

**NOTE: No template will be displayed if the limit line mode is OFF or if a limit line defined by the user is selected but no user definition table data exists. The rising edge position and wave level of the temporal waveform displayed does not necessarily match standard template (limit line) values.**

**In order to use this function efficiently, it is necessary to adjust the horizontal (time axis) positions and vertical (level) positions of the burst pulse and template.**

**This is used to adjust Shift X of the Trigger Position and limit line in the horizontal direction and Shift Y of the limit line in the vertical direction. Once these settings have been made, subsequent measurements can be made without having to make the adjustments again. If specifications (GSM, DCS1800, DCS1900) have changed, however, it will be necessary to make re-adjustments.**




Figure 1-3 Power Template Measurement Screen

Auto Level Set

This is used to set the internal reference level (REF LEVEL), which is used in the time waveform analysis and the frequency waveform analysis, to the optimum value according to the measurement signal.

Trigger Setup

A Dialog Box for trigger settings will appear. It can be used to set trigger source, trigger level, trigger position, and delay time settings. When making settings, select the parameter to be set using the step key and select the parameter value to be set using the data knob. After parameters have been selected, you can set them

by pressing the data knob or pressing the 

ENTER
Hz

 key. The Dialog Box will disappear either of these keys is pressed.

Trigger: Selects the trigger source (signal from which synchronization is taken) for controlling the measurement timing for the burst signal or other.

Free Run: Selects asynchronous measurement mode. (Measure using internal measurement timing.)

Video: Selects a measurement mode synchronized with the internal Video signal.

4. Functions of MEASUREMENT Section

IF Signal: Selects a measurement mode synchronized with the internal IF signal (21.4 MHz).

Ext: Selects a measurement mode synchronized with a signal input from an external source (EXT TRIG connector on the rear panel).

Slope: Select whether to match the sync position with the rising edge (+) of the signal (Video, IF Signal or EXT) or with the falling edge (-) of the signal.

Trigger Level: Specifies the level position of the trigger source signal (Video, IF Signal or EXT) at which to take synchronization. A trigger level position mark (▶) will be displayed at the left of the display scale. The data can be set by using the data knob or ten-key and pressing the

ENTER  
Hz key.

Source Monitor: Select whether or not to display the temporal waveform for the trigger source. This is automatically set to OFF whenever the trigger source is changed. (This selection is only available when the trigger source is the IF signal.)

Trigger Posi: Sets the X axis position (time) of the trigger source signal (Video, IF Signal or EXT) at which to synchronize. A trigger position mark (▼) will be displayed above the display scale. The data can be set by using the data knob or ten-key and pressing the

ENTER  
Hz key.

TDMA Structure:

This is the parameter to decide the delay time from the trigger. Select the type of slot width inside the frame. One is the 156.25-bit fixed-width type and the other is 156/157-bit variable-width type. The delay time from the trigger is calculated depending on the slot wide type. The obtained delay time is automatically set to Delay Time shown below. (This parameter is effective only when the trigger source is Ext.)

The delay time from the trigger point is calculated according to this parameter and the value of the following Slot Number. The calculation is made as follows.

- If 156.25-bit is selected:

$$\text{Delay Time} = \text{Slot Number} \times 0.577 \text{ msec}$$

- If 156/157-bit is selected:

- If Slot Number = 0,

$$\text{Delay Time} = 0$$

- If  $0 < \text{Slot Number} < 5$ ,

$$\text{Delay Time}$$

$$= \left(\frac{120}{26}\right) \times \left(\frac{157}{156.25 \times 8}\right) + (\text{Slot Number}-1)$$

$$\times \left(\frac{120}{26}\right) \times \left(\frac{156}{156.25 \times 8}\right) \text{ msec}$$

- If  $4 < \text{Slot Number} < 8$ ,

$$\text{Delay Time} =$$

$$2 \times \left(\frac{120}{26}\right) \times \left(\frac{157}{156.25 \times 8}\right) + (\text{Slot Number}-2)$$

$$\times \left(\frac{120}{26}\right) \times \left(\frac{156}{156.25 \times 8}\right) \text{ msec}$$

Slot Number:

This is the parameter to decide the delay time from the trigger. Specify the slot number (position) inside the frame. The available values' range is from 0 to 7. (This parameter is effective only when the trigger source is Ext.)

The Delay Time value is automatically set according to the values of the above TDMA Structure and this parameter.

4. Functions of MEASUREMENT Section

Delay Time: Sets the delay time to be added to the trigger source signal.

**Note:** *If the trigger source is Ext, Delay Time is changed by changing values of TDMA Structure and Slot Number.*




Figure 1-4 Trigger Setup Dialog Box

Gated Spectrum


Parameter settings for gated sweep can be made while monitoring the waveform in the time domain or in the frequency domain. In this mode, a split screen display results with the frequency waveform in the upper screen and the temporal waveform in the lower screen.

Save Parameter

This records all gated sweep parameters. Parameters recorded here are used as the gated sweep parameters for the Spectrum Due To Modulation measurement. The following parameters are inherited by the Due To Modulation measurement: Gate Position/Gate Width, Gate Source, Slope; Gate Threshold.

Gate Setup

This is used to set the gate position/width to be used for gated sweep.



**Note:** *The default value of the gate position/width is set as follows depending on Burst Length (148-bit/88-bit).*

●Gate position =

$$0.6 \times \left( \frac{B}{156.25} \right) \times \left( \frac{15}{26} \right) + 0.014 \text{ msec}$$

●Gate width =


$$0.3 \times \left( \frac{B}{156.25} \right) \times \left( \frac{15}{26} \right) \text{ msec}$$

**Assign 148 to B, if Burst Length is 148-bit.**

**Assign 88 to B, if Burst Length is 88-bit.**

**The gate position is the value from the trigger position.**

4. Functions of MEASUREMENT Section



**Note:** *When gated sweep is selected, sweep for both the frequency waveform and the temporal waveform will appear as if stopped if the parameters set for gated sweep are inappropriate, but sweep can be started when changing to appropriate settings.*






Figure 1-5 Waveform at Gate Sweep OFF





Figure 1-6 Waveform at Gate Sweep ON

Quit

This escapes from gated sweep mode and returns to the menu of the previous level. The split screen display will automatically return to a single screen display once Quit is selected.

4. Functions of MEASUREMENT Section



Frame: Makes the following settings according to frame burst waveform monitoring, and cancels Zoom mode.  
 Trigger delay time: 0 sec  
 Sweep time: 5 msec  
 Trigger position: 0%






Figure 1-7 Expansion of Display Using Window


4. Functions of MEASUREMENT Section






4. Functions of MEASUREMENT Section

---



• Average Power Measurement in the Time Domain



4. Functions of MEASUREMENT Section

Trigger Level: Specifies the level position of the trigger source signal (Video, IF Signal or EXT) at which to synchronize. A trigger level position mark (▶) will be displayed to the left of the display scale.  
The data can be set by using the data knob or ten-key and pressing the

ENTER  
Hz key.

Source Monitor: Select whether or not to display the waveform for the trigger source. This is automatically set to OFF whenever the trigger source is changed. (This selection is only available when the trigger source is the IF signal.)

Trigger Posi: Sets the X axis position (time) of the trigger source signal (Video, IF Signal or EXT) at which to synchronize. A trigger position mark ([▼]) will be displayed above the display scale.  
The data can be set by using the data knob or ten-key and pressing the

ENTER  
Hz key.

TDMA Structure:

This is the parameter to decide the delay time from the trigger. Select the type of slot width inside the frame. One is the 156.25-bit fixed-width type and the other is 156/157-bit variable-width type. The delay time from the trigger is calculated depending on the slot wide type. The obtained delay time is automatically set to Delay Time shown below. (This parameter is effective only when the trigger source is Ext.)

The delay time from the trigger point is calculated according to this parameter and the value of the following Slot Number.

The calculation is made as follows.

- If 156.25-bit is selected:  
Delay Time = Slot Number × 0.577 msec
- If 156/157-bit is selected:
  - If Slot Number = 0,  
Delay Time = 0



●If Slot Number = 1 to 4,  
 Delay Time

$$= \left(\frac{120}{26}\right) \times \left(\frac{157}{156.25 \times 8}\right) + (\text{Slot Number}-1)$$

$$\times \left(\frac{120}{26}\right) \times \left(\frac{156}{156.25 \times 8}\right) \text{msec}$$


●If Slot Number = 5 to 7,  
 Delay Time

$$2 \times \left(\frac{120}{26}\right) \times \left(\frac{157}{156.25 \times 8}\right) + (\text{Slot Number}-2)$$


$$\times \left(\frac{120}{26}\right) \times \left(\frac{156}{156.25 \times 8}\right) \text{msec}$$

Delay Time: Sets the delay time to be added to the trigger source signal.


**Note:** *If the trigger source is Ext, Delay Time is changed by changing values of TDMA Structure and Slot Number.*



Changes the vertical axis display scale. 10dB/div, 5dB/div, or 2dB/div can be selected.



This sets the position/width of the window displayed.



This displays a window which limits the measurement range. When the window is displayed, all points within the window are used to calculate electric power. When the window is not displayed, all points within the screen are used.

4. Functions of MEASUREMENT Section







Figure 1-8 Sample Power Spectrum Measurement



4. Functions of MEASUREMENT Section



• Frequency Domain Analysis









Figure 1-9 Output Power Spectrum in Modulation Period



4. Functions of MEASUREMENT Section





4. Functions of MEASUREMENT Section






Figure 1-10 Pass/Fail Judgment





4. Functions of MEASUREMENT Section



±6 MHz to 12.5 MHz/ to 37.5MHz/ to 29.8MHz:

The start frequency and the stop frequency of the standardized transmission band are set and the spurious search of IN-Band is measured. Measurement conditions at this time are set as follows.

Sweep time: 2.4 sec

RBW: 100 kHz

VBW: 300 kHz

DETECTOR: POSI

	Start f	Stop f
GSM900(MS)	880MHz	915MHz
GSM900(BS)	925MHz	960MHz
DCS1800(MS)	1710MHz	1785MHz
DCS1800(BS)	1805MHz	1880MHz
DCS1900(MS)	1850.2MHz	1909.8MHz
DCS1900(BS)	1930.2MHz	1989.8MHz

Span: AUTO: Sets the span or the start and stop frequency to the parameter shown above.

FULL: Sets to full span mode.

**Notes:**

*The various measurement conditions selected using this key only apply when STD is selected on the Parameter Setup menu.*

*Only signals having an amplitude difference of 5 dB or more are recognized as spurious. (This corresponds to a 0.5 div ΔY for the MARKER peak search.)*






Figure 1-11 Selection of Frequency Range





## ■ Explanation of Menu on Transmission-Power






Figure 1-12 Display of Tx Power Measurement Result

## ■ Power vs Time Measurement

The input signal is demodulated and then is triggered with training sequence code to suit with the template.







Figure 1-13 Example of Power vs Time Measurement

**NOTE:** Burst Power calculates the power of the burst-ON period.






Figure 1-14 Display of Template Entry

**NOTE:** *The default template is as shown in Figure 1-14 due to shortage of the dynamic range. Because the specified dynamic range is not satisfied, use the template in combination with "Burst Env" measurement.*

Pressing  MARKER  ON to display the marker, the data at each symbol point can be read out.  
To set the marker to OFF, press  MARKER  ON again.

## ■ Explanation of Menu on Frequency-Error Measurement





Figure 1-15 Display of Phase Error Measurement Results

## ■ Description of Communication Protocol Setting Menu

Pressing **TRANSIENT** and **Setup STD** in this order or pressing **STD** displays the communication protocol setting menu. With this menu, the communication type, link, power control level and so on of the object signal can be set. In this menu, the step keys can be used to go to each item, the data knob can be used to select/determine the parameter in each item, and the ten keys can be used to enter data.




Figure 1-16 Communication Protocol Setting Menu

Type: Sets the communication type.

GSM900  
 DCS1800  
 DCS1900

Link: Sets the base station and the mobile station.

MS: Mobile station  
 BTS: Base station

Power Control Level (on MS selection):

Power Class (on BTS selection):

Sets the output power level or class of the station to be measured.

Depending on this setting, the template value used in Due To Modulation/Switching is decided.

4. Functions of MEASUREMENT Section

Offset Level:

The offset of the reference level can be set within the range of 0 to ±100 dB.

To set the value, the ten keys and the data knob can be used.

Freq Input:

Sets the input method of the center frequency using the FREQ key.

FREQUENCY: Frequency input mode

CHANNEL NO.: Channel input mode

Correspondence between input channel and center frequency depends on the settings of the communication type and the link.




Figure 1-17 Display Example at Center Frequency Channel Input

Channel Offset:

Becomes active when CHANNEL NO in Frequency Input is selected.

This gives,

$$\text{Offset Frequency} = (\text{channel offset } N \times \text{channel spacing})$$

Ex. channel spacing 200kHz in GSM

allows to define own channel assignment.

Signal Type:

Sets the burst length to be measured. Depending on this parameter, the template value used in time waveform analysis is decided.

148 bit Burst: Effective for the Normal Burst/Synchronization Burst/Dummy Burst measurement.

88 bit Burst: Effective for the Access Burst measurement.

Sync Trigger:

Searches for the training sequence and sets up whether the burst is judged or not.

TSC: Searches for the training sequence code and judges the burst section.

NO: Judges the burst section from the magnitude.

Training Seq. Code (TSC):

Selects the training sequence code when the training sequence code was selected at the above Sync Trigger.

Data Capture Trigger:

Selects the trigger to take in the signal for measurement.

AUTO: When Signal Type is CONTINUOUS, the data is taken in by the internal timing.  
The data is taken in by the timing in the measuring apparatus.

SOFTWARE: When Signal Type is BURST, the burst is searched with the software.

EXT: The data is taken in by the external trigger signal.

Ext Trigger Slope:

Selects EXT trigger slope when EXT is selected at the above Data Capture Trigger.

+: The data is taken in at the rising signal of the external trigger.

-: The data is taken in at the falling signal of the external trigger.

Cont. Auto Level Set:

While setting up the reference level automatically, sets up whether the measurement is performed or not.

ON: Measures while setting up the reference level automatically.

OFF: The reference level is not set up.

## 5. Caution on the RECALL Function

When R3465 is turned on just after the communication system is changed with using "Comm. System", R3465 is started at the factory-shipped initial setting screen. The file or the register under the communication system (PDC/PHS/NADC versus GSM) cannot be recalled. (If recalled, an error message "Communication system unmatched." is displayed on the screen.)





Figure 1-18 Recall Screen



## **GPIB REMOTE PROGRAMMING**

This chapter describes GPIB code of TRANSIENT mode and Program example of TRANSIENT mode.

---

### **CONTENTS**

---

1. GPIB Code of TRANSIENT Mode . . . . . 2-2
  2. Program Example of TRANSIENT Mode . . . 2-8
-

# 1. GPIB Code of TRANSIENT Mode

Function	Listener code	Talker request		Remarks	
		Code	Output format		
Standard	Operation mode CW Transient	SETFUNC CW SETFUNC TRAN	SETFUNC?	0 : CW 1 : TRANSIENT	
	Communication system GSM900 DCS1800 DCS1900	MODTYP GSM MODTYP DCS1800 MODTYP DCS1900	MODTYP?	3 : GSM900 4 : DCS1800 5 : DCS1900	
	Communication direction MS BTS	LINK MS LINK BTS	LINK?	0 : MS 1 : BTS	
	Signal type Continuous wave Burst wave 148 bit 88 bit	MEASMD CONT MEASMD BURST MEASMD BURST1	MEASMD?	0 : 148 bit burst 1 : 88 bit burst 2 : Continuous wave	
	CH setting CF setting Offset	CH n (n: Channel number) CHOFS n (n: Offset CH)	CH? CHOFS?	Integer (Channel number) Integer (Offset channel)	
	Sync trigger TSC Sync Bit None	SYNC TSCn (n: 0 to 7) SYNC BIT SYNC NO	SYNC?	0 : TSC0 to 7 : TSC7	
	TSC: Training Sequence Code				
	Auto level Execution (Other than Burst Env) Execution (Burst Env) Auto Level ON Auto Level OFF	AUTOLVL AUTOWFL ALS ON ALS OFF	- - - -	- - - -	
	Power class GSM900 DCS1800/ DCS1900	PWCLS n (n: 1 to 8) PWCLS n (n: 1 to 4)	PWCLS? PWCLS?	1: 55dBm / 2: 52dBm 3: 49dBm / 4: 46dBm 5: 43dBm / 6: 40dBm 7: 37dBm / 8: 34dBm 1: 43dBm / 2: 40dBm 3: 37dBm / 4: 34dBm	



(cont'd)

	Function		Listener code	Talker request		Remarks
				Code	Output format	
Standard	Power control level		PWCTL n (n: 2 to 19)	PWCTL?	2: 39dBm / 3: 37dBm	
	GSM900				4: 35dBm / 5: 33dBm	
	DCS1800				6: 31dBm / 7: 29dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	8: 27dBm / 9: 25dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	10: 23dBm/ 11: 21dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	12: 19dBm/ 13: 17dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	14: 15dBm/ 15: 13dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	16: 11dBm/ 17: 9dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	18: 7dBm / 19: 5dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	0: 30dBm / 1: 28dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	2: 26dBm / 3: 24dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	4: 22dBm / 5: 20dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	6: 18dBm / 7: 16dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	8: 14dBm / 9: 12dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	10: 10dBm/ 11: 8dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	12: 6dBm / 13: 4dBm	
	DCS1800		PWCTL n (n: 0 to 15)	PWCTL?	14: 2dBm / 15: 0dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	0: 30dBm / 1: 28dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	2: 26dBm / 3: 24dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	4: 22dBm / 5: 20dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	6: 18dBm / 7: 16dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	8: 14dBm / 9: 12dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	10: 10dBm/ 11: 8dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	12: 6dBm / 13: 4dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	14: 2dBm / 15: 0dBm	
	DCS1900		PWCTL n (n: 0 to 15, 30, 31)	PWCTL?	30: 33dBm/ 31: 32dBm	
	Level offset		RO *	RO?	Level	
	Trigger					
	Mode	AUTO	TRGMODE AUTO	-	-	
		SOFTWARE	TRGMODE SOFT	-	-	
		EXT	TRGMODE EXT	-	-	
	EXT Slope	+	TRGMSLP RISE	-	-	
		-	TRGMSLP FALL	-	-	
Measurement conditions	Source	FREE	TRGSRC FREE	-	-	
		VIDEO	TRGSRC VIDEO	-	-	
		IF	TRGSRC IF	-	-	
		EXT	TRGSRC EXT	-	-	
	SLOPE	+	TRGSLP RISE	-	-	
		-	TRGSLP FALL	-	-	

1. GPIB Code of TRANSIENT Mode

(cont'd)

Function		Listener code	Talker request		Remarks	
			Code	Output format		
Measurement conditions	Level	TRGLVL *	-	Integer (Level : 0 to 100)		
	Position	TRGPOS *	-	Integer (Time : 0 to 100)		
	Source monitor	ON OFF	TRGMON ON TRGMON OFF	TRGMON?	0 : OFF 1 : ON	
	Delay time	TRGDT *	TRGDT?	Time		
	TDMA Structure					
	156.25 bit	TRGSTR TYP1	TRGSTR?	0 : 156.25 bit		
	156/157 bit	TRGSTR TYP2	-	1 : 156/157 bit		
	Slot number	TRGSLOT *	TRGSLOT?	Integer (Slot number : 0 to 7)		
	Gated spectrum					
	Gate	Position Width Default	TGTPOS * TGTWID * TGTDEF	TGTPOS? TGTWID? -	Time Time -	
	Source	IF signal EXT Trigger	TGTSRC IF TGTSRC EXT	TGTSRC?	0 : IF signal 2 : EXT Trigger	
	Slope	+ -	TGTSLP RISE TGTSLP FALL	- -	- -	
	Threshold		TGTTHD *	TGTTHD	Integer (0 to 100)	0: OFF
Save parameters		TGTSV	-	-		
Gated sweep	ON OFF	TGTSWP ON TGTSWP OFF	TGTSWP?	0 : OFF 1 : ON		

(cont'd)

Function	Listener code	Talker request		Remarks
		Code	Output format	
Display control				
Window position	DCPOS *	DCPOS?	Time	
Window width	DCWID *	DCWID?	Time	
T-Zoom ON	DCZOM	-	-	
Reset	DCRST	-	-	
Zoom on window	DCHZOM ON	-	-	
Return to last span	DCHZOM OFF	-	-	
Span to 1 burst	DCHZOM BURST	-	-	
Span to 1 frame	DCHZOM FRAME	-	-	
Vertical Zoom ON	DCVZOM ON	-	-	ON: 2dB/div
OFF	DCVZOM OFF	-	-	OFF: 10dB/div
Y Scale selection				
10dB/div	DCVDIV P10DB	DCVDIV?	0: 10dB/div	Valid only when measurement mode is going on.
5dB/div	DCVDIV P5DB		1: 5dB/div	
2dB/div	DCVDIV P2DB		2: 2dB/div	
Average				
Carrier Power	TPWTM *	TPWTM?	Integer (1 to 999)	1: OFF
Tx Power	TAVGTX *	TAVGTX?	Integer (1 to 32)	
Power vs Time	GPTAVG *	GPTAVG?	Integer (1 to 32)	
Phase Error	TAVGPH *	TAVGPH?	Integer (1 to 32)	
Burst Envelope	TAVGBST *	TAVGBST?	Integer (1 to 32)	
Due to Modulation	TAVGDTM *	TAVGDTM?	Integer (1 to 999)	
Spurious Emissions	TAVGSPR *	TAVGSPR?	Integer (1 to 999)	
Max Hold				
Due to Switching	TMAXDTS *	TMAXDTS?	Integer (1 to 999)	
Limit line				
Type selection *1				Table : TM1 = UP TM2 = LOW
Burst Envelope	TLMTYP TM1	-	-	
Carrier Power	TLMTYP TM2	-	-	
Due to Modulation	TLMTYP FR1	-	-	
Due to Switching	TLMTYP FR2	-	-	
STD	LMCPSL STD	-	-	
USER	LMCPSL USR	-	-	

\*1: Be sure to make a Type selection before setting STD/USER, Level Adjust, X/Y-axis shift and so on.

1. GPIB Code of TRANSIENT Mode

(cont'd)

Function	Listener code	Talker request		Remarks	
		Code	Output format		
Level Adjust	AUTO MANUAL	LMSFAT LMSFMNL	- -	- -	
X-axis shift		TLMSFT *	TLMSFT?	Frequency or time	
Y-axis shift		TLMASFT *	TLMASFT?	Level	
Limit line	ON OFF	TLMT ON TLMT OFF	TLMT?	0 : OFF 1 : ON	
Table data	*2				
Table insertion		TLMIN *		*= F, L	
Table deletion		TLMDEL			
Measurement conditions	PASS/FAIL				
	Judgment	ON OFF	PFC ON PFC OFF	PFC?	0: OFF 1: In continuous measurement
	Judgment results ?		-	PFJ?	0 : FAIL 1 : PASS
	Judgment results ? (details)		-	OPF?	0 : PASS 1 : UPPER 2 : LOWER 3 : UPPER and LOWER 4 : ERROR
	Fail point reading				
	Upper side		-	FPU?	Fail point number <CR+LF> + Frequency, Level <CR/LF> (Repeated for the number of point)
	Lower side		-	FPL?	Ditto to Upper
Carrier power					
Window	ON OFF	TWDO ON TWDO OFF	TWDO?	0 : OFF 1 : ON	Carrier power only
Position		TWLX *	TWLX?	Time	
Width		TWDX *	TWDX?	Time	
Default		TWDEF	-	-	

\*2: In the type selection for inserting or deleting the table data, TM1 corresponds to UP and TM2 corresponds to LOW in the template specification.

(cont'd)

	Function	Listener code	Talker request		Remarks	
			Code	Output format		
Measurement conditions	Y Scale selection 10dB/div 5dB/div 2dB/div	DCPDIV P10DB DCPDIV P5DB DCPDIV P2DB	DCPDIV?	0 : 10dB/div 1 : 5dB/div 2 : 2dB/div	Valid only when measurement mode is going on.	
	Due to Modulation Trace detection Posi-Nega Posi Nega Sample	TDET NRM TDET POS TDET NEG TDET SMP	TDET?	0 : Posi-Nega 1 : Posi 2 : Nega 3 : Sample		
	Reference power selection Sweep DSP	REFPWR SWP REFPWR DSP	REFPWR?	0 : SWP 1 : DSP		
	Limit line Margin ΔX	LIMMRG *	LIMMRG?	Frequency		0Hz : OFF
	Spurious Emissions Offset frequency from carrier	CRFO * *: 1.8MHz (1.8MHz ≥) 6.0MHz (6.0MHz ≥)	CRFO?	Frequency		
	Span mode Auto Full span	SPRSP AUTO SPRSP FULL	- -	- -		
	Power vs Time Y Scale selection 10dB/div 5dB/div 2dB/div	GPTDIV P10DB GPTDIV P5DB GPTDIV P2DB	GPTDIV?	0 : 10dB/div 1 : 5dB/div 2 : 2dB/div		Valid only when measurement mode is going on.
	Template selection	GPTTYP * *: 1/2/3/4	GPTTYP?	Integer (Template number: 1/2/3/4)		
	Template edit	GPTENT d1, d2, d3, d4, d5, d6 d1 to d6: Relative level (dB)	-	-		Level unit dB is required.
	Measurement start	Burst Envelope	PWRTIME	-		-
Carrier Power		TPWAVG	-	-		
Due to Modulation		DUEMOD	-	-		
Due to Switching		DUESWT	-	-		
Spurious Emissions		SPREMI	-	-		
Tx Power		TXPWR	-	-		
Power vs Time		GPWRTM	-	-		
Phase Error		PHACC	-	-		
Execute measurement of same item		SI	-	-		


1. GPIB Code of TRANSIENT Mode

(cont'd)

	Function	Listener code	Talker request		Remarks
			Code	Output format	
Measurement start	dB down				
	XdB down width	MKBW *	MKBW?	Level	
	XdB down	XDB	-	-	
	XdB down left	XDL	-	-	
	XdB down right	XDR	-	-	
	XdB relative	DC0	-	-	
	XdB abs. left	DC1	-	-	
	XdB abs. right	DC2	-	-	
	XdB executing status	-	DC?	0 : Relative 1 : Absolute (left side) 2 : Absolute (right side)	
Measured result	Burst Envelope	-	-	Judged as PASS/FAIL	
	Carrier Power	-	TPWAVG?	Level	
	Due to Modulation	-	-	Judged as PASS/FAIL	
	Level list data?		DUEMOD?	<l1, l2, ... l10 >	
	Due to Switching	-	-	Judged as PASS/FAIL	
	Level list data?		DUESWT?	<l1, l2, ... l8 >	
	Spurious Emissions	-	SPREMI?	<n, f1, l1, ... fn, ln >	
	Tx Power	-	TXPWR?	<Pw1, Pw2 >	
	Power vs Time				
	Power level	-	GPWRM?	Level (unit : W)	
	PASS/FAIL judgment	-	GPTJDG?	0 : FAIL 1 : PASS	
	Fail zone	-	GPTFAIL?	Real number (10/20/30/40/50/60/70/80/90)	See the following page for the correspondence of the returned values and the fail zone.
	Phase Accuracy	-	PHACC?	<Pk, Ph, Fr > Pk: Phase (degree) Ph: Phase (degree rms) Fr: Frequency (Hz)	Pk: Peak Phase Err Ph: Phase Err Fr: Frequency Err
	X dB down	-	MF? MT?	Frequency or time	

■REFERENCE■

Correspondence of Returned values and Fail Zone



## 2. Program Example of TRANSIENT Mode

Program example of PC9801 series (GPIB Address = 8)

Example 1 To measure the spurious near the carrier in the Transient mode. (When SRQ signal is not used.)

```

10 ISET IFC :ISET REN
20 SPA = 8
30 DIM DAT(20)
40 STAT = 0
50 GSMTYP = 0
60 LINKTYP = 0
70 AVG = 0
80 OFST = 0
90 AUTOSP = 0
100 '
110 PRINT @SPA;"SETFUNC TRAN"           ' Enters the Transient mode
120 PRINT @SPA;"CF 903MZ"               ' Sets the center frequency to 903MHz
130 '
140 '                                     ' Selects the communication system
150 INPUT "GSM TYPE? (0:GSM900/1:DCS1800/2:DCS1900) >>> ",GSMTYP
160 IF GSMTYP = 0 THEN PRINT @SPA;"MODTYP GSM"
170 IF GSMTYP = 1 THEN PRINT @SPA;"MODTYP DCS1800"
180 IF GSMTYP = 2 THEN PRINT @SPA;"MODTYP DCS1900"
190 '
200 PRINT @SPA;"S1"                     ' Sets the service request interruption to OFF
210 PRINT @SPA;"SPREMI"                 ' Displays the Spurious Emissions
                                         measurement display

220 *MEAS.START
230 '
240 '                                     ' Selects the communication direction
250 INPUT "LINK? (0:Mobil/1:Base Station) >>> ",LINKTYP
260 IF LINKTYP = 0 THEN PRINT @SPA;"LINK MS"
270 IF LINKTYP = 1 THEN PRINT @SPA;"LINK BTS"
280 '
290 '                                     ' Selects the span mode
300 INPUT "AUTO SPAN? (0:Full Span/1:Auto Span) >>> ",AUTOSP
310 IF AUTOSP = 0 THEN PRINT @SPA;"SPRSP FULL"
320 IF AUTOSP = 1 THEN GOSUB *SPAUTO.SET
330 '
340 '                                     ' Sets the number of averaging times
350 INPUT "AVG Times? (1:OFF/2<>999:AVG Times) >>> ",AVG
360 PRINT @SPA;"TAVGSPR",AVG
370 PRINT @SPA;"*CLS"
380 *RESTART
390 PRINT @SPA;"SI"
400 GOSUB *MEAS.END
410 GOTO *RESTART

```



(ctd. from example 1)

```
420 '
430 *SPAUTO.SET
440 PRINT @SPA;"SPRSP AUTO"
450 '                               ' Selects the offset frequency from the carrier
460 INPUT "FREQ. OFFSET? (0:1.8 < > 6MHz/1:6 < > 12MHz) > > > ",OFST
470 IF OFST = 0 THEN PRINT @SPA;"CRFO 1.8MZ"
480 IF OFST = 1 THEN PRINT @SPA;"CRFO 6MZ"
490 RETURN
500 '
510 *MEAS.END
520 PRINT @SPA;"*CLS"               ' Clears the status byte
530 *WLOOP
540 PRINT @SPA;"OPREVT?":INPUT @SPA;S ' Reads out the status byte
550 IF (S AND 272) = 0 THEN GOTO *WLOOP ' Waits until the measurement end or the
                                         averaging end
560 PRINT @SPA;"SPREMI?"
570 INPUT @SPA;DAT(0),DAT(1),DAT(2),DAT(3),DAT(4),DAT(5),DAT(6),DAT(7),DAT(8),DAT(9),
    DAT(10),DAT(11),DAT(12),DAT(13),DAT(14),DAT(15),DAT(16),DAT(17),DAT(18),DAT(19),
    DAT(20)
580 PRINT "Spurious List (";DAT(0);")"
590 FOR I = 1 TO DAT(0)
600   PRINT I;"": ";DAT(I*2-1);"Hz",DAT(I*2);"dBm"   ' Displays measurement results
610 NEXT I
620 PRINT @SPA;"ERRNO?":INPUT @SPA;ERR.NUM ' Reads the error number
630 IF ERR.NUM < > 0 THEN GOTO *MEAS.ERROR ' Outputs a measurement error if
                                         other than 0
640 RETURN
650 '
660 *MEAS.ERROR
670 PRINT "Measuring Error. Error Number:";ERR.NUM ' Displays the error number
680 STOP
690 '
700 END
```

2. Program Example of TRANSIENT Mode

Program examples of HP200, 300 series (GPIB Address = 8)

Example 2 To measure the spurious near the carrier in the Transient mode. (When SRQ signal is used.)

```

1000 !! Spurious Emissions Measurement
1010 !
1020 OPTION BASE 0
1030 DIM Result(20)
1040 INTEGER Spa,Stat,Gsmtyp,Linktyp,Avg,Ofst,Autosp
1050 ON INTR 7 GOSUB Measend__intr
1060 Spa = 708
1070 Stat = 0
1080 Gsmtyp = 0                !0:GSM900/1:DCS1800/2:DCS1900
1090 Linktyp = 0             !0:MS/1:BTS
1100 Avg = 0                 !1:OFF/2 < > 999:ON
1110 Ofst = 0                !0:1.8MHz/1:6MHz
1120 Autosp = 0              !0:FULL/1:AUTO
1130 !
1140 OUTPUT Spa;"SETFUNC TRAN"    ! Enters the Transient mode
1150 OUTPUT Spa;"CF903MZ"        ! Sets the center frequency to 903MHz
1155 !                            ! Selects the communication system
1160 INPUT "GSM TYPE? (0:GSM900/1:DCS1800/2:DCS1900) > > > ",Gsmtyp
1170 IF Gsmtyp = 0 THEN
1180     OUTPUT Spa;"MODTYP GSM"
1190 ELSE
1200     IF Gsmtyp = 1 THEN
1210         OUTPUT Spa;"MODTYP DCS1800"
1220     ELSE
1230         OUTPUT Spa;"MODTYP DCS1900"
1240     END IF
1250 END IF
1255 ! Sets the SRQ interruption to measurement end or average end
1260 OUTPUT Spa;"S0;OPR272;"SRE128" ! Sets the service request interruption to ON
1270 OUTPUT Spa;"SPREMI"          ! Displays the Spurious Emissions measurement
                                   display
1280 Meas__start:
1285 !                            ! Selects the communication direction
1290 INPUT "LINK? (0:Mobile/1:Base Station) > > > ",Linktyp
1300 IF Linktyp = 0 THEN
1310     OUTPUT Spa;"LINK MS"
1320 ELSE
1330     OUTPUT Spa;"LINK BTS"
1340 END IF
1345 !                            ! Sets the span mode
1350 INPUT "AUTO SPAN? (0:Full Span/1:Auto Span) > > > ",Autosp
1360 IF Autosp = 0 THEN

```

(ctd. from example 2)

```
1370  OUTPUT Spa;"SPRSP FULL"
1380  ELSE
1390  OUTPUT Spa;"SPRSP AUTO"
1395  !                               ! Selects the offset frequency from the carrier
1400  INPUT "FREQ. OFFSET? (0:1.8< >6MHz/1:6< >12MHz) >>> ",Ofst
1410  IF Ofst = 0 THEN
1420      OUTPUT Spa;"CRFO 1.8MZ"
1430  ELSE
1440      OUTPUT Spa;"CRFO 6MZ"
1450  END IF
1460 END IF
1465  !                               ! Sets the number of averaging times
1470 INPUT "AVG Times? (1:OFF/2< >999:AVG Times) >>> ",Avg
1480 OUTPUT Spa;"TAVGSPR";Avg
1490 OUTPUT Spa;"*CLS"                ! Clears the status byte
1500 ENABLE INTR 7;2
1510 Restart: !
1520 OUTPUT Spa;"SI"                  ! Executes measurement in the same mode
1530 Stat = 0
1540 Measend: !
1550 IF Stat = 0 THEN GOTO Measend
1560 OUTPUT Spa;"SPREMI?"            ! Reads out measurement results
1570 ENTER Spa;Result(*)
1580 PRINT "Spurious List (";Result(0);")"
1590 FOR I = 1 TO Result(0)
1600 PRINT I;" ";Result(I*2-1);"Hz",Result(I*2);"dBm"    ! Displays measurement results
1610 NEXT I
1620 ! GOTO Meas_start
1630 GOTO Restart
1640 STOP
1650 !
1660 Measend_intr: !
1670 OUTPUT Spa;"*CLS"
1680 BEEP
1690 Stat = 1
1700 ENABLE INTR 7;2
1710 RETURN
1720 END
```



# CHAPTER 3

## SPECIFICATIONS

This chapter contains specifications of the GSM measurement function.

---

### CONTENTS

---

1. GSM Measurement Option Specifications . 3-2
-

# 1. GSM Measurement Option Specifications

## ■ Transient RF Analysis

### ● Burst Envelope measurement

Amplitude resolution	12 bits
Sweep time/Resolution	50 $\mu$ s to 2s/100ns
Trigger	Free-run, Single, Video, IF detection, External Delay trigger/Time 200ns to 650 ms

### ● Burst spectrum measurement (With Gated Sweep)

Gate Position/Resolution	1 $\mu$ s to 65 ms/1 $\mu$ s
Gate Width/Resolution	2 $\mu$ s to 65 ms/1 $\mu$ s
Trigger	Internal IF detection, External

## ■ Anti-modulation System

GMSK (GSM, DCS1800, DCS1900)

## ■ Analysis Input Range

-30 dBm to +30 dBm

## ■ Average Power Measurement

(After an auto-calibration, in the band of GSM, DCS1800 and DCS1900)

### ● Measurement accuracy

$\pm 0.8$  dB (15°C to 35°C)  
 $\pm 1$  dB (0°C to 50°C)


## ■ Frequency/Phase Error

### ● Frequency error

Tolerance	$\pm 10$ kHz
Accuracy	Reference accuracy $\times$ Carrier frequency $\pm 5$ Hz

### ● Phase error

Tolerance	0° to 30° (Peak)
Accuracy	$\leq \pm 5^\circ$ (Peak) $\leq \pm 1^\circ$ (rms)



**A P P E N D I X**

In this appendix, you will find a glossary, a menu lists and list of messages.

---

**CONTENTS**

---

1. Glossary .....	A-2
2. Menu Lists .....	A-3
3. List of Messages .....	A-7


---

# 1. Glossary


## Tx Power

According to GSM 11.10 V4.80 page 121, "The transmitter out power is calculated as the average of the samples over the 147 useful bits."

In Tx Power, the input signal is demodulated and the setup training sequence is searched. Based on the position of the searched training sequence, decide the 147 useful bits and calculate the power.




When the trigger is not set in the training sequence, take a correlation between template shown in the down figure and the input burst to be 1 for the time of the 147 bits to find out the burst part.







## 2. Menu Lists




2. Menu Lists



\*1: This soft key is displayed in the Power measurement.



2. Menu Lists



※ This menu is displayed by operating when entering to the measurement state of Transient Mode.

### 3. List of Messages

Message	Explanation	Error No.
Sound demodulation is working. Please turn off the Sound mode. [CW 1/2]	Sound demodulation is working.	1
Span is set 0 Hz. Please change a span.	It is set in Zero span.	5
Power Measure is working. Please turn off each item. [CW- > Power Meas]	Power Measure is working.	9
Signal Track is working. Please turn off Signal Track. [Marker 1/3]	Signal Track is working.	10
Noise/Hz is working. Please quit the Noise/Hz. [CW 2/2]	Noise/Hz is working.	11
Only dBm and dBuV is useful while Noise/Hz is been working.	It is not possible to select because Noise/Hz is been working.	12
Counter is working. Please turn off the Counter. [CW 1/2]	Counter is working.	13
$\Delta$ MKR is not active. Please activate the $\Delta$ MKR. [Marker 1/3]	The delta marker is not active.	14
Not available in Multi Screen. Please reset Multi Screen mode. [Window 1/1]	It is not possible to execute in Multi Screen mode.	17
View or Blank trace is selected. Please select Write mode. [Format- > Trace A]	It is not possible to execute in View/Blank.	18
Trigger source is not Video. Please select Video trigger. [Sweep- > Trigger Source]	Trigger source is not Video.	19

## 3. List of Messages

Message	Explanation	Error No.
MKR is not on Trace A. Please execute Trace MKR Move. [Marker 3/3]	The marker is not on Trace A.	20
Calculated power is out of range.	The calculated power is out of range.	25
Edit table is opened. Please return to execute menu.	It is not possible to execute in the Edit mode.	26
Frequency table is empty. Please edit a table and execute.	There are no table data.	27
Calibration signal was not detected. Please check CAL OUT signal.	There is no CAL signal connected.	28
Trace Average is working. Please turn Average off. [Format-> Trace A]	Trace average is working.	39
Trace Point is set to 501. Please change mode to 1001. [SYS 1/1]	Trace 501 Point mode is set.	41
Not available while Zooming.	It is not possible to execute while Zooming.	42
No trace data. Please start a measure.	Trace data is not displayed. Start the measurement.	43
Attenuator is MANUAL mode. Please select AUTO mode.	Attenuator is set to the MANUAL mode. Change the mode to Auto, then execute the measurement.	44
No margin for filtering.	There's no margin for filtering in trigger position.	200
Trigger occurs in a slot.	Trigger is in a slot.	204
Multiple TSC was detected.	Plural Training sequence code were detected.	220
Printer is not ready. Please check a printer setting.	It is not possible to print. Please check the printer setting.	300*
Printer cable problem. Please check a cable or connection.	The printer cable is defective. Please check the cable or connection.	301*
Printer is not active.	The printer is not active.	302*

Message	Explanation	Error No.
Plotter cable problem or plotter is not active.	The plotter cable is defective or the plotter does not operate.	303*
INPUT ATT: Calibration failure.	It is a failure of the Calibration.	400
IF STEP AMP: Calibration failure.	It is a failure of the Calibration.	401
LOG LINEARITY: Calibration failure.	It is a failure of the Calibration.	402
TOTAL GAIN: Calibration failure.	It is a failure of the Calibration.	403
RBW SWITCHING: Calibration failure.	It is a failure of the Calibration.	404
AMPTD MAG: Calibration failure.	It is a failure of the Calibration.	405
Calibration data is not enough. Please execute CAL ALL.	It is not possible to execute because source calibration data is missing.	406
HS ADC: Calibration failure.	It is a failure of the Calibration.	407
MOD DSP: Calibration failure.	It is a failure of the Calibration.	408
NORMAL ADC: Calibration failure.	It is a failure of the Calibration.	409
Illegal parameters.	The specified parameters are illegal.	600
Illegal file or device name.	The file or device name is illegal.	601
Software version unmatched.	Software version is unmatched.	602
Cannot format a device.	The memory card cannot be initialized.	603
Cannot rename a file in RAM disk.	The file name in RAM disk cannot be changed.	604
Broken saved block data.	The saved data is lost.	605
Device already exists.	The device already has been selected.	606
Device not found.	There are no devices.	607

## 3. List of Messages

Message	Explanation	Error No.
Device not ready.	The device cannot be referred.	608
Directory not found.	There are no directories.	609
File already exists.	The file already exists.	610
File not found.	There are no files.	611
Invalid BPB. Please format a card.	BPB is invalid. The card needs to be initialized.	612
Cannot delete a file. (read-only file)	It is not possible to delete because it is a read-only file.	613
No disk space.	Card/Disk capacity is full.	614
Read-only file.	It is the read-only file.	615
Read-only media.	It is the read-only media.	616
Read-only volume.	The card is in the write protection.	617
Invalid boot sector signature.	The boot sector signature cannot be recognized.	618
CRC error.	CRC error occurred.	619
Any trouble in DSP or AD module.	DSP or AD module has some trouble.	620
Broken Freq-Correction data. Please report to qualified service person.	An error of the frequency characteristic correction data occurred.	621*
Handshake error occurred to TBC. Please report to qualified service person.	A handshake error occurred.	622*
Handshake error occurred to DSP. Please report to qualified service person.	A handshake error occurred.	623*
Cannot detect Mod. DSP board. Please report to qualified service person.	Connection error has occurred.	624*
File or register empty.	It is impossible to recall a file or a register that is empty.	634
Communication system unmatched.	The communication system is improper.	635



Message	Explanation	Error No.
Time Out ! No Trigger detected.	Trigger is not detected.	700
System Error. Cannot allocate memory.	Cannot allocate memory space.	701
Input level is out of range. Please check Reference level.	Input level is out of allowable range.	702
Burst signal is not detected. Please check Burst length.	Burst signal cannot be detected.	703
Cannot demodulate.	Cannot demodulate.	704
Trigger timing is not proper.	Trigger timing is not proper.	707
Signal Type is set to CONTINUOUS. Please set BURST in STD menu.	Continuous wave was detected.	709
TSC is not detected. please check STD menu.	Training sequence code cannot be detected.	720
TSC detection failure.	Failed in Training sequence code detection.	721
Auto Level completed !	Auto level completed.	801
Auto Level failed !	Auto level failed.	802

**TSC : Training Sequence Code**

**NOTE**

*It is possible to read error numbers by using the GPIB query, "ERRNO?", but impossible to read codes marked by (\*).*



## **IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE**

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

### **SOFTWARE License**

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

### **Restrictions**

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

### **Liability**

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

## LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
  - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
  - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
  - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
  - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
  - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
  - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
  - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
  - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

## **CUSTOMER SERVICE DESCRIPTION**

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

## SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,  
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea  
Phone: +82-2-532-7071  
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:  
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.  
Phone: +86-21-6485-2725  
Fax: +86-21-6485-2726

Shanghai Branch Office:  
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,  
Hai Dian District, Beijing,  
China 100083  
Phone: +86-10-8235-3377  
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06  
Alexandra Technopark Singapore 119967  
Phone: +65-6274-3100  
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A  
Phone: +1-408-988-7700  
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany  
(P.O.B. 80 14 60 D-81614 München, Germany)  
Phone: +49-89-4129-13711  
Fax: +49-89-4129-13723

**ADVANTEST®**

<http://www.advantest.co.jp>