

---

---

**ADVANTEST<sup>®</sup>**

**ADVANTEST CORPORATION**

---

***R3681 Series OPT52  
cdma2000  
Modulation Analysis Software  
User's Guide***

**MANUAL NUMBER FOE-8440168D00**

---

***Applicable Models***

***R3681***

***R3671***



## TABLE OF CONTENTS

1.	INTRODUCTION .....	1-1
1.1	Outline of This Manual .....	1-1
1.2	Product Overview .....	1-3
1.3	Other Manuals Relating to This Instrument .....	1-3
1.4	Conventions of Notation Used in This Document .....	1-4
1.5	Trademarks and Registered Trademarks .....	1-5
2.	BEFORE OPERATING .....	2-1
2.1	If a Fault Should Occur .....	2-1
2.2	Removing the Case .....	2-1
2.3	Overcurrent Protection .....	2-1
2.4	Hard Disk Drive .....	2-1
2.5	Handling the Touch Screen .....	2-2
2.6	Getting the Software Running with Stability .....	2-2
2.7	Transporting .....	2-2
2.8	Electromagnetic Interference .....	2-3
2.9	Before Turning On .....	2-3
2.10	Removing and Attaching the Front Panel .....	2-3
2.11	Limitations Imposed when Using Windows XP .....	2-5
3.	SETUP .....	3-1
3.1	Unpacking Inspection .....	3-1
3.2	Locating This Instrument .....	3-2
3.2.1	Operating Environment .....	3-2
3.2.2	Prevention of Electrostatic Buildup .....	3-3
3.3	Connecting Accessories .....	3-4
3.3.1	Connecting the Keyboard and Mouse .....	3-4
3.4	Supply Description .....	3-5
3.4.1	Check the Supply Power .....	3-5
3.4.2	Connecting the Power Cable .....	3-5
3.5	Operation Check .....	3-7
4.	MEASUREMENT EXAMPLES (Downlink) .....	4-1
4.1	Code Domain Power Measurement of the Base Station Signal .....	4-1
5.	MENU MAP, FUNCTIONAL EXPLANATION (Downlink) .....	5-1
5.1	Menu Index .....	5-1
5.2	Switching Communication Systems .....	5-3
5.3	Function Bar .....	5-3
5.4	Soft Menu Bar .....	5-3
5.5	Description of the Function of Each Key .....	5-4

Table of Contents

5.5.1	{MEAS SETUP} .....	5-4
5.5.2	{MEAS VIEW} .....	5-7
5.5.3	{SCALE} .....	5-9
5.5.4	{MKR} .....	5-10
5.5.5	{INPUT} .....	5-11
5.5.6	{TRIGGER} .....	5-12
5.5.7	{LEVEL} .....	5-13
5.5.8	{FREQ} .....	5-14
5.5.9	Measurement Tool Bar .....	5-15
6.	SCPI COMMAND REFERENCE (Downlink) .....	6-1
6.1	Command Reference Format .....	6-1
6.2	Common Commands .....	6-3
6.3	List of Commands .....	6-4
6.3.1	Subsystem-SYSTEM .....	6-4
6.3.2	Subsystem-INPut .....	6-4
6.3.3	Subsystem-SENSe .....	6-5
6.3.4	Subsystem-TRIGger .....	6-6
6.3.5	Subsystem-INITiate .....	6-6
6.3.6	Subsystem-CALCulate .....	6-7
6.3.7	Subsystem-DISPlay .....	6-7
6.3.8	Subsystem-MMEMory .....	6-8
6.3.9	Subsystem-MEASure .....	6-9
6.3.10	Subsystem-READ .....	6-10
6.3.11	Subsystem-FETCh .....	6-11
6.4	Status Register .....	6-12
7.	PERFORMANCE VERIFICATION (Downlink) .....	7-1
7.1	Test Signal Specifications .....	7-1
7.2	Test Procedures .....	7-2
7.2.1	RF Input Base Station Signal Measurement .....	7-2
7.2.2	IQ Input Base Station Signal Measurement .....	7-3
7.3	Test Data Record Sheet .....	7-4
8.	SPECIFICATIONS (Downlink) .....	8-1
8.1	cdma2000 Modulation Analysis Compliance System .....	8-1
8.2	cdma2000 Modulation Analysis Performance .....	8-1
9.	MEASUREMENT EXAMPLES (Uplink) .....	9-1
9.1	Analysis of the Mobile Station Offset QPSK Signal in the cdmaOne MODE .	9-1
9.2	Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE .....	9-5
10.	MENU MAP, FUNCTIONAL EXPLANATION (Uplink) .....	10-1
10.1	Menu Index .....	10-1

10.2	Switching Communication Systems .....	10-3
10.3	Function Bar .....	10-3
10.4	Soft Menu Bar .....	10-3
10.5	Description of the Function of Each Key .....	10-4
10.5.1	{MEAS MODE} .....	10-4
10.5.2	{MEAS SETUP} .....	10-5
10.5.3	{DISPLAY} .....	10-11
10.5.4	{MKR} .....	10-14
10.5.5	{INPUT} .....	10-15
10.5.6	{TRIGGER} .....	10-16
10.5.7	{LEVEL} .....	10-17
10.5.8	{FREQ} .....	10-18
10.5.9	Measurement Tool Bar .....	10-19
11.	SCPI COMMAND REFERENCE (Uplink) .....	11-1
11.1	Command Reference Format .....	11-1
11.2	Common Commands .....	11-3
11.3	List of Commands .....	11-4
11.3.1	Subsystem-SYSTEM .....	11-4
11.3.2	Subsystem-INPUT .....	11-4
11.3.3	Subsystem-CONFigure .....	11-5
11.3.4	Subsystem-SENSe .....	11-5
11.3.5	Subsystem-TRIGger .....	11-7
11.3.6	Subsystem-INITiate .....	11-7
11.3.7	Subsystem-CALCulate .....	11-8
11.3.8	Subsystem-DISPlay .....	11-10
11.3.9	Subsystem-MMEMory .....	11-11
11.3.10	Subsystem-MEASure .....	11-11
11.3.11	Subsystem-READ .....	11-12
11.3.12	Subsystem-FETCh .....	11-13
11.3.13	Subsystem-STATus .....	11-14
11.3.14	Subsystem-HCOPy .....	11-14
11.4	Status Register .....	11-15
12.	PERFORMANCE VERIFICATION (Uplink) .....	12-1
12.1	Test Signal Specifications .....	12-1
12.2	Test Procedures .....	12-2
12.2.1	Offset QPSK Signal Measurement in RF Input .....	12-2
12.2.2	Code Multiplex Signal Measurement in RF Input .....	12-3
12.2.3	Code Multiplex Signal Measurement in IQ Input .....	12-5
12.3	Test Data Record Sheet .....	12-7
13.	SPECIFICATIONS (Uplink) .....	13-1
13.1	cdma2000 Modulation Analysis Compliance System .....	13-1
13.2	cdma2000 Modulation Analysis Performance .....	13-1
13.2.1	cdmaOne Mode .....	13-1
13.2.2	cdma2000 Mode .....	13-2

Table of Contents

APPENDIX .....	A-1
A.1 Technical Data .....	A-1
A.2 Error Message List .....	A-13
ALPHABETICAL INDEX .....	I-1

## LIST OF ILLUSTRATIONS

No.	Title	Page
3-1	Operating Environment .....	3-2
3-2	Countermeasures against Static Electricity from the Human Body .....	3-3
3-3	Countermeasures against Static Electricity from the Work Floor .....	3-3
3-4	Countermeasures against Static Electricity from the Workbench .....	3-4
3-5	Connecting the Keyboard and Mouse .....	3-4
3-6	Connecting the Power Cable .....	3-6
3-7	<b>POWER</b> Switch .....	3-7
3-8	Initial Setup Screen .....	3-8
3-9	Autocalibration .....	3-9
4-1	Connection Diagram of Base-Station Code-Domain-Power Measurement .....	4-2
4-2	<b>[Input Setup]</b> Dialog Box .....	4-3
4-3	<b>[Measurement Parameter Setup]</b> Dialog Box .....	4-4
4-4	Measurement Results of the cdma2000 Base Station Signal .....	4-4
6-1	Status Registers .....	6-12
7-1	Connecting the Test Signal (RF Input) .....	7-2
7-2	Connecting the Test Signal (IQ Input) .....	7-3
9-1	Connection Diagram for the Mobile Station Offset QPSK Measurement .....	9-1
9-2	<b>[Input Setup]</b> Dialog Box .....	9-2
9-3	<b>[Measurement Parameters Setup]</b> Dialog Box of cdmaOne Mode .....	9-3
9-4	Results from the Mobile Station Offset QPSK Signal Measured in the cdmaOne MODE .....	9-3
9-5	Connection Diagram for the Mobile Station Code Domain Power Measurement .....	9-5
9-6	<b>[Input Setup]</b> Dialog Box .....	9-6
9-7	<b>[Measurement Parameters Setup]</b> Dialog Box of cdma2000 MODE .....	9-8
9-8	Results from the Mobile Station Code Multiplex Signal Measured in the cdma2000 MODE .....	9-8
11-1	Status Registers .....	11-15
12-1	Connecting the Test Signal (RF Input) .....	12-2
12-2	Connecting the Test Signal (RF Input) .....	12-3
12-3	Connecting the Test Signal (IQ Input) .....	12-5
A-1	<b>[Window Format]</b> Dialog Box .....	A-7
A-2	Marker→Specified PCG On Usage Example .....	A-8
A-3	Marker→Specified Code On Usage Example .....	A-9
A-4	Constellation .....	A-10
A-5	Null Offset Constellation .....	A-10
A-6	Setting Example of the <b>[User Table]</b> Dialog Box .....	A-11
A-7	<b>[Measurement Parameters Setup]</b> Dialog Box when Using <b>[User Table]</b> .....	A-12





---

## LIST OF TABLES

No.	Title	Page
3-1	Standard Accessories .....	3-1
3-2	ESD Countermeasures .....	3-3
3-3	Power Supply Specifications .....	3-5
4-1	Signal Specifications .....	4-1
7-1	List of Test Signal Specifications .....	7-1
12-1	List of Test Signal Specifications .....	12-1
A-1	Error Message List .....	A-13



## 1. INTRODUCTION

This chapter describes the outline of this manual and the product overview of the R3681 series signal analyzer option 52 cdma2000 Modulation Analysis.

### 1.1 Outline of This Manual

The outline of each chapter is shown below:

For basic operating methods, functions and the remote programming method of the signal analyzer, refer to "1.3 Other Manuals Relating to This Instrument."

Chapter 1. INTRODUCTION	Describes the outline of this manual and the product overview.
Chapter 2. BEFORE OPERATING	Provides preliminary tips on using this instrument. Read this chapter before using this instrument.
Chapter 3. SETUP	Describes how to set up this instrument. After installing this instrument in position, switch it on to make sure that it starts successfully.
Chapter 4. MEASUREMENT EXAMPLES (Downlink)	Describes example measurements (Downlink).
Chapter 5. MENU MAP, FUNCTIONAL EXPLANATION (Downlink)	Describes the menu configuration and functions of the soft keys (Downlink).
Chapter 6. SCPI COMMAND REFERENCE (Downlink)	SCPI command reference (Downlink). The command reference describes the commands in order of function. The following items are described: <ul style="list-style-type: none"> <li>• Command format</li> <li>• Function description</li> <li>• Parameters</li> <li>• Query response</li> </ul>
Chapter 7. PERFORMANCE VERIFICATION (Downlink)	Describes the performance verification test procedures for option 52 (Downlink).
Chapter 8. SPECIFICATIONS (Downlink)	Shows the specifications of option 52 (Downlink).
Chapter 9. MEASUREMENT EXAMPLES (Uplink)	Describes example measurements (Uplink).
Chapter 10. MENU MAP, FUNCTIONAL EXPLANATION (Uplink)	Describes the menu configuration and functions of the soft keys (Uplink).
Chapter 11. SCPI COMMAND REFERENCE (Uplink)	SCPI command reference (Uplink). The command reference describes the commands in order of function. The following items are described: <ul style="list-style-type: none"> <li>• Command format</li> <li>• Function description</li> <li>• Parameters</li> <li>• Query response</li> </ul>

1.1 Outline of This Manual

Chapter 12. PERFORMANCE VERIFICATION (Uplink)	Describes the performance verification test procedures for option 52 (Uplink).
Chapter 13. SPECIFICATIONS (Uplink)	Shows the specifications of option 52 (Uplink).
APPENDIX	Describes operation principles and the error code table.

## 1.2 Product Overview

The cdma2000 modulation analysis option is software that performs the modulation analysis of the cdma2000 base station signal and mobile station signal.

This option has the following features.

- Displays the numerical results such as Error Vector Magnitude and the frequency error as well as graphs such as the Code Domain Power graph. The results of multiple measurements can be evaluated at the same time because up to four result windows can be displayed.

## 1.3 Other Manuals Relating to This Instrument

Manuals which relate to this instrument include:

- User's Guide (Part Code: {ER3681SERIES/U}, English)  
Describes how to setup the R3681 Series Signal Analyzer, how to perform procedures such as, basic operations, applied measurements, and maintenance, and describes the functions, specifications of the R3681 Series Signal Analyzer.
- Programming Guide (Part Code: {ER3681SERIES/P}, English)  
Describes how to program the R3681 Series Signal Analyzer to automate measurement sequences and includes a remote control overview, SCPI command references, and sample application programs.
- Performance Test Guide (Part Code: {ER3681SERIES/T}, English)  
Describes how to check the performance of the R3681 Series Signal Analyzer and includes performance test procedures and specifications of the R3681 Series Signal Analyzer.

## 1.4 Conventions of Notation Used in This Document

### 1.4 Conventions of Notation Used in This Document

In this document, hard keys, touch-screen buttons and menus are represented by the following symbols:

#### Hard keys

“Hard keys” are hardware keys which are on the panel.

**Sample** Indicates a hard key labeled “Sample.”  
Example: **START**, **STOP**

#### Touch-screen system menus

**[Sample]** Indicates a touch-screen menu, tab, button or dialog box that is labeled “Sample” and that is selected or executed when touched.  
Example: **[File]** menu, **[Normal]** tab, **[Option]** button

#### Touch-screen function buttons

**{Sample}** Indicates a touch-screen button labeled “Sample.”  
Example: **{FREQ}** button, **{SWEEP}** button

#### Touch-screen side menu

**Sample** Indicates a touch-screen side menu labeled “Sample.”  
Example: **Center** key, **Span** key

#### Touch-screen system menu key operation

**[File]→[Save As...]** Indicates that you need to touch the **[File]** menu and then select **[Save As...]**.

#### Sequential key operation

**{FREQ}, Center** Indicates that you need to touch the **{FREQ}** button and then touch the **Center** key.

#### Toggle key operation

**ΔMarker On/Off** (On) Indicates that you need to touch the **ΔMarker On/Off** key to turn on the ΔMarker.

---

**NOTE:** *Screen displays and diagrams such as external view of the main unit in this manual are those of the R3681 in the R3681 series.*

---

## **1.5 Trademarks and Registered Trademarks**

- Microsoft® and Windows® are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.
- Other product and company names referenced herein are trademarks or registered trademarks of their respective owners.





## 2. BEFORE OPERATING

This chapter describes important information on using this instrument. Read this chapter before using this instrument.

### 2.1 If a Fault Should Occur

If smoke, strange smells, or strange noises are detected, switch off the power, disconnect the power cable and contact either your dealer or Advantest immediately.

### 2.2 Removing the Case

The case should not be opened except by qualified Advantest service personnel.

---

**WARNING:** *This instrument contains high-voltage and high-temperature parts. Electrical shocks or burns may result if handled incorrectly.*

---

### 2.3 Overcurrent Protection

This instrument is protected from overcurrent flow by a power breaker. Located on the rear panel, the power breaker automatically interrupts the power supply when an overcurrent flows through this instrument. When the power breaker has turned off, turn off the power supply and disconnect the power cable from the AC power. Then, call upon your dealer or us for repair services to fix a possible fault that has occurred in this instrument.

### 2.4 Hard Disk Drive

This instrument has a built-in hard disk drive. When handling the hard disk drive, take notice of these instructions.

- Do not cause impact or vibration damage to the hard disk drive.  
Damaging the disk increasing the chances of the disk malfunctioning or failing during operation.
- Do not switch off this instrument while the HDD access lamp is lit.  
The data being accessed may become corrupt.

---

**CAUTION:** *We do not assume any responsibility for the loss or corruption of data stored on the hard disk drive that might result from the disk becoming damaged.*

---

## 2.5 Handling the Touch Screen

### 2.5 Handling the Touch Screen

This instrument has a touch screen. When handling the touch screen, take notice of these instructions.

- Do not give apply excessive force to the screen. The screen is made from glass and may crack.
- Use the stylus pen included with this instrument to operate the screen. Using a tool with a hard-point (such as a mechanical pencil or ballpoint) may scratch the screen surface.

### 2.6 Getting the Software Running with Stability

The R3681 Series Signal Analyzer has Microsoft Windows XP pre-installed.

The measuring function of this instrument is dependent on the Windows environment. Do not alter the Windows operating environment in any way other than as described in this manual.

This instrument is not a data processor. Operate it only as described in this manual.

#### 1. Prohibited actions

- Installing other application programs.
- Changing or deleting items in the control panel (except as described in “A.2 Installing the Printer Driver” and “A.3 Setting up the Network” of R3681 Series User's Guide).
- Creating new files or editing existing files on the C drive.
- Operating other application programs during the measurement.
- Upgrading the Windows operating system.
- If this instrument functions incorrectly because of any of the above, re-install the system using the system recovery disk.  
For more information on the system recovery procedure, refer to section 8.7, “System Recovery Procedure” in the R3681 Series User's Guide.

#### 2. Computer viruses

Depending on the operating environment, the system may become infected by a computer virus. To protect the system, we recommended taking the following countermeasures:

- Perform a virus check before loading any file or inserting any media from an outside source.
- Make sure that any network used has safety measures against computer viruses before connecting this instrument.

[If infected with a computer virus:]

- Delete all files on the D drive. Re-install the system using the recovery disk.  
For more information on the system recovery procedure, refer to section 8.7, “System Recovery Procedure” of R3681 Series User's Guide.

### 2.7 Transporting

Extreme care as described below must be taken when carrying this instrument.

- This instrument is heavy and must be carried by two or more persons, or on a transportation cart.
- If using a cart to move this instrument, ensure the instrument is secure.

## 2.8 Electromagnetic Interference

This instrument may cause electromagnetic interference and affect television and radio reception.

If the electromagnetic interference is reduced when this instrument's is turned off, then this instrument is the cause of the problem.

Electromagnetic interference may be prevented by doing the following:

- Changing the direction of the antenna of the television or radio.
- Placing this instrument on the other side of the television or radio.
- Placing this instrument away from the television or radio.
- Using different lines power outlets for this instrument and the television or radio.

## 2.9 Before Turning On

Do not connect a DUT to this instrument when turning on.

## 2.10 Removing and Attaching the Front Panel

This instrument can be used separately after removing the panel.

When removing the panel, take notice of these instructions.


---

**MEMO:** *To use this instrument after removing the panel, a connecting cable is required (sold separately).*

---

- If this instrument's power is turned on, make sure that this instrument has stopped operating, turn off the power, and remove the power cable.
- When removing or attaching the panel, take care not to catch your fingers.
- Place this instrument on a flat and steady table when removing or attaching the panel.
- Remove the four screws that are exposed on the side of the front panel of this instrument.
- When removing the screws, steady the panel so that it will not fall.
- After all four screws have been removed, pull the panel forward.
- Remove the cable connecting the panel to the instrument.
- Replace the cable with an appropriate cable.
- If any screws become lost, use the following types of screw.
  - For the 2 screws on the key side: flat-head Phillips screws M4X35 (steel or stainless steel)
  - For the 2 screws on the liquid-crystal display: flat-head Phillips screws M4X14 (steel or stainless steel)

## 2.10 Removing and Attaching the Front Panel



## 2.11 Limitations Imposed when Using Windows XP

### END-USER LICENSE AGREEMENT

- You have acquired a device ("INSTRUMENT") that includes software licensed by [ADVANTEST] from Microsoft Licensing Inc. or its affiliates ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.
- IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE INSTRUMENT OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT [ADVANTEST] FOR INSTRUCTIONS ON RETURN OF THE UNUSED INSTRUMENT(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE INSTRUMENT, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).
- **GRANT OF SOFTWARE LICENSE.** This EULA grants you the following license:
  - You may use the SOFTWARE only on the INSTRUMENT.
  - **NOT FAULT TOLERANT.** THE SOFTWARE IS NOT FAULT TOLERANT. [ADVANTEST] HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE INSTRUMENT, AND MS HAS RELIED UPON [ADVANTEST] TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.
  - **NO WARRANTIES FOR THE SOFTWARE. THE SOFTWARE is provided "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE INSTRUMENT OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.**
  - **No Liability for Certain Damages. EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).**
  - **Limitations on Reverse Engineering, Decompilation, and Disassembly.** You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.
  - **SOFTWARE TRANSFER ALLOWED BUT WITH RESTRICTIONS.** You may permanently transfer rights under this EULA only as part of a permanent sale or transfer of the INSTRUMENT, and only if the recipient agrees to this EULA. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE.
  - **EXPORT RESTRICTIONS.** You acknowledge that SOFTWARE is of US-origin. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and country destination restrictions issued by U.S. and other governments. For additional information on exporting the SOFTWARE, see <http://www.microsoft.com/exporting/>.
- 7 **Installation and Use.** The SOFTWARE may not be used by more than two (2) processors at any one time on the INSTRUMENT. You may permit a maximum of ten (10) computers or other electronic devices (each a "Client") to connect to the INSTRUMENT to utilize the services of the SOFTWARE solely for file and print services, internet information services, and remote access (including connection sharing and telephony services). The ten (10) connection maximum includes any indirect connections made through "multiplexing" or other software or hardware which pools or aggregates connections. Except as otherwise permitted in the NetMeeting/Remote Assistance/Remote Desktop Features terms below, you may not use a Client to use, access, display or run the SOFTWARE, the SOFTWARE's user interface or other executable software residing on the INSTRUMENT.
- J If you use the INSTRUMENT to access or utilize the services or functionality of Microsoft Windows Server products (such as Microsoft Windows NT Server 4.0 (all editions) or Microsoft Windows 2000 Server (all editions)), or use the INSTRUMENT to permit workstation or computing devices to access or utilize the services or functionality of Microsoft Windows Server products, you may be required to obtain a Client Access License for the INSTRUMENT and/or each such workstation or computing device. Please refer to the end user license agreement for your Microsoft Windows Server product for additional information.
- 7 **Restricted Uses.** The SOFTWARE is not designed or intended for use or resale in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or other devices or systems in which a malfunction of the SOFTWARE would result in foreseeable risk of injury or death to the operator of the device or system, or to others.
- U **Restricted Functionality.** You are licensed to use the SOFTWARE to provide only the limited functionality (specific tasks or processes) for which the INSTRUMENT has been designed and marketed by

## 2.11 Limitations Imposed when Using Windows XP

[*ADVANTEST*]. This license specifically prohibits any other use of the software programs or functions, or inclusion of additional software programs or functions, on the INSTRUMENT.

- **Security Updates.** Content providers are using the digital rights management technology ("Microsoft DRM") contained in this SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request MS, Microsoft Corporation or their subsidiaries to provide security related updates to the Microsoft DRM components of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through Microsoft software or third party applications that utilize Microsoft DRM. You therefore agree that, if you elect to download a license from the Internet which enables your use of Secure Content, MS, Microsoft Corporation or their subsidiaries may, in conjunction with such license, also download onto your INSTRUMENT such Security Updates that a Secure Content Owner has requested that MS, Microsoft Corporation or their subsidiaries distribute. MS, Microsoft Corporation or their subsidiaries will not retrieve any personally identifiable information, or any other information, from your INSTRUMENT by downloading such Security Updates.
- **NetMeeting/Remote Assistance/Remote Desktop Features.** The SOFTWARE may contain NetMeeting, Remote Assistance, and Remote Desktop technologies that enable the SOFTWARE or other applications installed on the INSTRUMENT to be used remotely between two or more computing devices, even if the SOFTWARE or application is installed on only one INSTRUMENT. You may use NetMeeting, Remote Assistance, and Remote Desktop with all Microsoft products; provided however, use of these technologies with certain Microsoft products may require an additional license. For both Microsoft products and non-Microsoft products, you should consult the license agreement accompanying the applicable product or contact the applicable licensor to determine whether use of NetMeeting, Remote Assistance, or Remote Desktop is permitted without an additional license.
- **Consent to Use of Data.** You agree that MS, Microsoft Corporation and their affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. MS, Microsoft Corporation and their affiliates may use this information solely to improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation and their affiliates may disclose this information to others, but not in a form that personally identifies you.
- **Internet Gaming/Update Features.** If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally identifies you.
- **Internet-Based Services Components.** The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation or their affiliates may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your INSTRUMENT.
- **Links to Third Party Sites.** The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of MS, Microsoft Corporation or their affiliates. Neither MS nor Microsoft Corporation nor their affiliates are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by MS, Microsoft Corporation or their affiliates.
- **Additional Software/Services.** The SOFTWARE may permit [*ADVANTEST*], MS, Microsoft Corporation or their affiliates to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").
- If [*ADVANTEST*] provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.
- If MS, Microsoft Corporation or their affiliates make available Supplemental Components, and no other EULA terms are provided, then the terms of this EULA shall apply, except that the MS, Microsoft Corporation or affiliate entity providing the Supplemental Component(s) shall be the licensor of the Supplemental Component(s).

[*ADVANTEST*], MS, Microsoft Corporation and their affiliates reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

This EULA does not grant you any rights to use the Windows Media Format Software Development Kit ("WMFSDK") components contained in the SOFTWARE to develop a software application that uses Windows Media technology. If you wish to use the WMFSDK to develop such an application, visit <http://msdn.microsoft.com/workshop/imedia/windowsmedia/sdk/wmsdk.asp>, accept a separate license for the WMFSDK, download the appropriate WMFSDK, and install it on your system.

### 3. SETUP

This chapter describes how to set up this instrument. Topics included in this chapter are:

- 3.1 Unpacking Inspection
- 3.2 Locating This Instrument
- 3.3 Connecting Accessories
- 3.4 Supply Description
- 3.5 Operation Check

#### 3.1 Unpacking Inspection

When the product is delivered, check the condition of it and its accessories included by following these steps:

1. Check that the box and the padding in which the product was shipped has not been damaged during transit.

---

**IMPORTANT:** *If the box or the padding is damaged, leave them in their original condition until the inspection described below is complete.*

---

2. Check the product surfaces for any damage.

---

**WARNING:** *Do not supply any power to this instrument if the cover, panels (front and rear), LCD display, power switch, connector or any other key component are damaged. Electrical shocks may result from using damaged components.*

---

3. Referring to the standard accessory list of the OPT52 in Table 3-1, check that all standard accessories have been supplied and that no accessories are damaged.

Contact your dealer or Advantest in any of the following situations:

- The box or the padding in which the product was shipped was damaged during transit.
- The product surfaces are damaged.
- Any of the standard accessories are missing or damaged.
- Faults are detected in any subsequent product verification test.

Table 3-1 Standard Accessories

Name	Model	Quantity	Remarks
R3681 Series OPT52 User's Guide	ER3681OPT52	1	English version

3.2 Locating This Instrument

3.2 Locating This Instrument

This section describes the environment in which this instrument should be installed.

3.2.1 Operating Environment


This instrument should only be used in an environment that satisfies the following conditions:

- Ambient temperature: +5 °C to +40 °C (operating temperature)  
-20 °C to +60 °C (Storage temperature range)
- Relative humidity: RH80% or less (no condensation)
- An area free from corrosive gas
- An area away from direct sunlight
- A area free from dust
- An area free from vibrations
- A low noise area

Although this instrument has been designed to withstand a certain amount of noise riding on the AC power line, it should be used in an area of low noise. Use a noise filter if ambient noise is unavoidable.

- An area allowing unobstructed airflow

There is an exhaust-cooling fan on the rear panel and exhaust vents on both sides and the bottom (toward the front) of this instrument. Do not block these vents. The resulting internal temperature rise will affect measurement accuracy. Keep the rear panel 10 centimeters away from the wall. In addition, do not attempt to use this instrument when it is standing on its rear panel or lying on either side.





### 3.2.2 Prevention of Electrostatic Buildup

To prevent electrostatic discharge (ESD) from damaging components in this instrument, the precautions described below should be taken. We recommend that two or more countermeasures are combined to provide adequate protection from ESD.

(Static electricity can easily be generated when a person moves or an insulator is rubbed.)

Table 3-2 ESD Countermeasures

Operator	Use a wrist strap (see Figure 3-2).
Floor in the work area	Install a conductive mat, use conductive shoes, and connect both to ground (see Figure 3-3).
Workbench	Install a conductive mat and connect it to ground (see Figure 3-4).




Figure 3-2 Countermeasures against Static Electricity from the Human Body




Figure 3-3 Countermeasures against Static Electricity from the Work Floor

3.3 Connecting Accessories




Figure 3-4 Countermeasures against Static Electricity from the Workbench

3.3 Connecting Accessories

This section describes how to connect accessories to this instrument and run it.

3.3.1 Connecting the Keyboard and Mouse

Plug the keyboard and mouse into their respective front-panel connectors before turning on this instrument.




Figure 3-5 Connecting the Keyboard and Mouse

### 3.4 Supply Description

This section describes how to check the power supply specifications and connect the power cable.

#### 3.4.1 Check the Supply Power

Table 3-3 summarizes the power supply specifications for this instrument. Make sure that the power supply available to this instrument meets these specifications.

Table 3-3 Power Supply Specifications

	100 V AC Operation	200 V AC Operation	Remarks
Input voltage range	90 V to 132 V	198 V to 250 V	Automatically switches between input levels of 100 V AC and 200 V AC.
Frequency range	47 Hz to 63 Hz		
Power consumption	450 VA or below		

---

**WARNING:** *Be sure to provide a power supply that meets the specified power supply specifications for this instrument. Failure to meet the specifications could cause damage to this instrument.*

---

#### 3.4.2 Connecting the Power Cable

This instrument comes with a three-core power cable with a ground conductor. To prevent electrical shock hazards, ground this instrument by plugging the power cable into a three-pole power outlet.

1. Check the power cable included with this instrument for any damage.

---

**WARNING:** *Never use a damaged power cable. Electrical shock could result.*

---

2. Plug one end of the power cable included with this instrument into the AC power connector on this instrument rear panel and the other into a three-pin power outlet that has a ground pin (see Figure 3-6).

### 3.4.2 Connecting the Power Cable




Figure 3-6 Connecting the Power Cable

---

**WARNING:**

1. Use a power cable rated for the voltage being used. Be sure, however, to use a power cable that conforms to the safety standards of your country when using this instrument (Refer to "Safety Summary").
  2. Plug the power cable into a three-pin power outlet that has a ground pin to prevent electrical shocks. Using an extension cable that has no ground pin would negate having a ground.
-

### 3.5 Operation Check

This section describes how to make a simple operation check on this instrument by using its built-in autocalibration feature. To verify that this instrument runs correctly, follow these steps:

#### Starting up this instrument

1. Connect the power cable as instructed in 3.4.2 "Connecting the Power Cable."
2. Switch on the power breaker on the rear panel and wait for 3 seconds or more.
3. Press the **POWER** switch to switch on the power.




Figure 3-7 **POWER** Switch

---

**CAUTION:**

1. *If the power to this instrument is suddenly interrupted while the unit is in operation, such as is the power cable is disconnected, the hard disk drive could be damaged. Even if the hard disk drive does not fail, Scandisk launches to check for possible data corruption the next time this instrument starts up.*
2. *About Scandisk*  
*If this instrument has been switched off without being shut down, Scandisk will automatically launch to check for any corrupt data. Do not abort Scandisk while it is running. If Scandisk locates any corrupt data, take appropriate action by following the displayed messages. The software in this instrument resumes automatically when Scandisk ends.*

4. The power-on diagnostic program launches to carry out self-diagnostics. The self-diagnostic program take about 1 minute to complete.
5. The initial screen shown in Figure 3-8 is displayed unless this instrument is faulty. The initial screen may give look differently from Figure 3-8, depending on the settings in effect the last time this instrument was switched off.

---

**NOTE:** *Refer to Chapter 8, "MAINTENANCE" of R3681 Series User's Guide if any error messages are displayed as a result of the self-diagnostic program.*

---

3.5 Operation Check




Figure 3-8 Initial Setup Screen

Running autocalibration

6. <R3681>  
Install this instrument as shown in Figure 3-9 by using the SMA (f)-SMA (f) adapter, SMA (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.
- <R3671>  
Hook up this instrument as shown in Figure 3-9 by using the N (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.




Figure 3-9 Autocalibration

---

**IMPORTANT:** Allow this instrument to warm up for at least 30 minutes before running the autocalibration. For more information on how to use the autocalibration, refer to Section 4.3.1, “Autocalibration” of the R3681 Series User's Guide.

---

7. Touch the [Cal] button on this instrument's menu bar to select [SA Cal] from the dropdown menu.
8. Autocalibration runs.  
The autocalibration takes about 1 minute to complete.
9. Make sure that no error messages are displayed as a result of the autocalibration.

---

**MEMO:** Refer to Chapter 8, “MAINTENANCE” of the R3681 Series User's Guide if error messages are displayed as a result of the autocalibration.

---

#### Switching off power

10. Press **POWER** to switch off this instrument.  
The final procedure is complete and the power is automatically turned off.





## 4. MEASUREMENT EXAMPLES (Downlink)

This chapter describes how to use this option by using specific measurement examples.

### 4.1 Code Domain Power Measurement of the Base Station Signal

Specifications of signal to be measured

The target signal is the signal based on the IS-97 Base Station Test Model, Nominal, with a frequency of 870.03 MHz and an output level of -10 dBm. The specifications assume that the Even Second Clock, the 10-MHz reference signal, and the signal to be measured are output from the base station.

Table 4-1 Signal Specifications

RC1, Walsh Code Length 64, PN Offset 0

Channel	Walsh Code No.
Pilot	0
Paging	1
Traffic	6
Traffic	17
Traffic	20
Sync	32
Traffic	41
Traffic	49
Traffic	58

4.1 Code Domain Power Measurement of the Base Station Signal

Device connection





Figure 4-1 Connection Diagram of Base-Station Code-Domain-Power Measurement

[Setting the measuring conditions]

1. Touch **[Config]** on the menu bar and select **[Modulation Analyzer]**.
2. Touch **[Modulation]** on the menu bar and select **[cdma2000 DL]**.
3. Touch the **{FREQ}** button on the function bar.
4. Touch the **Center** key on the soft menu bar.
5. Touch **8**, **7**, **0**, **.**, **0**, **3**, and **M/n** in this order on the keypad.  
The center frequency is set to 870.03 MHz.
6. Touch the **{LEVEL}** button on the function bar.
7. Touch the **Auto Level Sel** key on the soft menu bar.  
The Ref Level is automatically set to the optimum value.
8. Touch the **{TRIGGER}** button on the function bar.
9. Touch the **Trigger Source** key on the soft menu bar.
10. Touch the **Ext** key on the soft menu bar.  
The trigger source is set to the external trigger.
11. Touch the **{INPUT}** button on the function bar.

## 4.1 Code Domain Power Measurement of the Base Station Signal

12. Touch the **Input Setup** key on the soft menu bar.  
The **[Input Setup]** dialog box appears.
13. Set **[Input]** in the **[Input Setup]** dialog box to **[RF]**.  
The Input mode is set to RF.
14. Touch the close button **X** in the **[Input Setup]** dialog box to close the dialog box.

Figure 4-2 **[Input Setup]** Dialog Box

15. Touch the **[MEAS SETUP]** button on the function bar.
16. Touch the **Meas Parameters** key on the soft menu bar.  
The **[Measurement Parameters Setup]** dialog box appears.
17. Set the **[Meas Mode]** option button to **[cdma2000]**.  
The measurement mode is set to cdma2000.
18. Set the **[User Table]** option button to **[NOT USE]**.  
If this is set, the user table is not used.
19. Touch the **[Meas Length]** text box and press **2** and **[ENT]** on the keypad.  
The measurement length is set to the length of two power control groups (PCG).
20. Touch the **[τ Offset]** text box and press **0** and **[ENT]** on the keypad.  
The offset value of the Time Alignment Error is set to 0.
21. Set the **[Phase Equalizing Filter]** option button to **[ON]**.  
The phase characteristics of the complimentary filter are set to the inverse characteristics of the phase equalizer.
22. Set the **[PN Offset Search]** option button to **[OFF]**.  
The PN Offset search is set to OFF.
23. Touch the **[PN Offset]** text box and press **0** and **[ENT]** on the keypad.  
The PN Offset is set to 0.
24. Touch the **[Threshold Level]** text box and press **-**, **2**, **7**, and **[ENT]** on the keypad.  
The threshold value that is used for the transmission channel (active channel) judgment is set to -27 dB.

4.1 Code Domain Power Measurement of the Base Station Signal




Figure 4-3 [Measurement Parameter Setup] Dialog Box

25. Set the [ $\Delta\tau$ ] option button to [ON].  
 $\Delta\tau$  is added to the measuring items.
26. Set the [ $\Delta\theta$ ] option button to [ON].  
 $\Delta\theta$  is added to the measuring items.
27. Touch the close button in the [Measurement Parameter Setup] dialog box to close the dialog box.
28. Press the **SINGLE** button on the front panel.  
 The Single measurement is executed, and the measurement results are displayed.




Figure 4-4 Measurement Results of the cdma2000 Base Station Signal

Upper left window

- |            |   |
|------------|---|
| $\tau$     | Delay from the trigger ( $\mu\text{s}$ )  |
| Freq Error | Carrier frequency error (Hz, ppm)   |
| $\rho$     | Waveform quality of the multiplex signal (If the measured signal is the pilot channel signal only, the value of the waveform quality factor, which is defined by the cdma2000 standard, is used.) |

## 4.1 Code Domain Power Measurement of the Base Station Signal

PN Offset		PN Offset of the base station signal
Mag Error		Magnitude error of the multiplex signal (%rms)
Phase Error		Phase error of the multiplex signal (deg.rms)
EVM		Error Vector Magnitude of the multiplex signal (%rms)
Peak EVM		Peak Error Vector Magnitude of the multiplex signal (%)
IQ Org Offset		IQ origin offset (dBc)
Tx Power		Transmission power (dBm, W)
Pilot Power		Power of the pilot channel (dBm, W)
Peak Inact Pwr	CH	The maximum logarithmic value of the Code Domain Power coefficient of the inactive channel, the Walsh code length, and the Walsh code number of the inactive channel
Peak $\Delta\tau$	CH	The maximum value of the relative Walsh code domain time offset to the pilot channel, the Walsh code length, and the Walsh code number of the peak $\Delta\tau$ channel
Peak $\Delta\theta$	CH	The maximum value of the relative Walsh code domain phase offset to the pilot channel, the Walsh code length, and the Walsh code number of the peak $\Delta\theta$ channel
No of ActCh		Number of transmission channels

## Upper right window

Horizontal axis: Code  
Vertical axis:  $\rho$  (dB)

## Lower left window

Horizontal axis: Chip  
Vertical axis: Error Vector Magnitude (%)

## Lower right window

Horizontal axis: Power control group  
Vertical axis: Transmission power (dBm)

## Marker display

29. Touch [**Window2**] and then touch the {**MKR**} button on the function bar.
30. Touch the **Active CH. Marker** key on the soft menu bar.  
The transmission channel (active channel) marker is displayed.
 

Walsh Code No.	Walsh Code number
Walsh Code Len	Walsh Code length (number of chips)


#### 4.1 Code Domain Power Measurement of the Base Station Signal

Rate	Symbol Rate (ksps)
Mod	Modulation format
$\rho$	Logarithmic value of the Code Domain Power coefficient (dB)
Power	Code Domain Power (dBm, W)
$\Delta\tau$	Relative walsh code domain time offset to the pilot channel (ns)
$\Delta\theta$	Relative walsh code domain phase offset to the pilot channel (mrad)

## 5. MENU MAP, FUNCTIONAL EXPLANATION (Downlink)

This chapter describes the configurations and functions of the soft keys displayed on the touch screen of the cdma2000 modulation analysis software.

### MEMO:

- [.....] *Used to enclose a menu name, key name, item name in the dialog box, button name, or the name of selected items in lists and menus.*
- {...} *Shows a function button on the function bar.*
-  *Shows a soft key on the soft menu bar.*
- *A dialog box is surrounded by a broken line.*
- *Operations are supposed to be made through the touch screen and "touch" means to press a button or a key.*

### 5.1 Menu Index

Operation Key	Pages	Operation Key	Pages
$\Delta\theta$ vs Code	5-7	[PN Offset Search]	5-4, 5-5
$\Delta\tau$ vs Code	5-7	[Q Eye Diagram]	5-8
$\rho$ vs Code	5-7	[Specified Code]	5-7, 5-8
[ $\Delta\theta$ vs Code]	5-8	[Specified PCG]	5-7, 5-8
[ $\Delta\theta$ ]	5-4, 5-6	[Specified PCG & Code]	5-7, 5-8
[ $\Delta\tau$ vs Code]	5-8	[Table]	5-8
[ $\Delta\tau$ ]	5-4, 5-5	[Threshold Level]	5-4, 5-5
[ $\rho$ vs Code]	5-8	[Total Result]	5-7
[ $\tau$ Offset]	5-4, 5-5	[Tx Power vs PCG]	5-7
[All PCG & Code]	5-7	[User Table]	5-4, 5-5
[Baseband Input]	5-11	[vs Code]	5-7, 5-8
[Channel]	5-4, 5-6	[Walsh Length]	5-4, 5-6
[Chip]	5-8	[Walsh Number]	5-4, 5-6
[Code Power vs Code]	5-8	{FREQ}	5-14
[Code Power vs PCG]	5-8	{INPUT}	5-11
[Constellation]	5-7, 5-8	{LEVEL}	5-13
[Display Type]	5-7, 5-8	{MEAS SETUP}	5-4
[EVM vs Chip]	5-8	{MEAS VIEW}	5-7
[Format]	5-7	{MKR}	5-10
[Graph]	5-8	{SCALE}	5-9
[I Eye Diagram]	5-8	{TRIGGER}	5-12
[Input]	5-11	Active CH. Marker	5-10
[IQ Inverse]	5-11	Analysis Restart	5-4
[Line & Chip]	5-8	ATT	5-13
[Mag Err vs Chip]	5-8	Auto Level Set	5-13
[Meas Length]	5-4, 5-5	Center	5-14
[Meas Mode]	5-4	Channel Number	5-14
[Modulation]	5-4, 5-6	Chip	5-7
[Multi Channel No.]	5-4, 5-6	Code Power vs Code	5-7
[Phase Equalizing Filter]	5-4, 5-5	Code Power vs PCG	5-7
[PN Offset]	5-4, 5-5	Constellation	5-7


5.1 Menu Index

Dual Display .....	5-9
EVM vs Chip .....	5-7
Ext1 .....	5-12
Ext2 .....	5-12
Free Run .....	5-12
Freq Offset .....	5-14
Graph .....	5-7
I Eye Diagram .....	5-7
IF Power .....	5-12
Input Setup .....	5-11
Interval On/Off .....	5-12
Line & Chip .....	5-7
Link .....	5-12
Mag Err vs Chip .....	5-7
Marker .....	5-10
Marker OFF .....	5-10
Marker→Specified Code On/Off .....	5-10
Marker→Specified PCG On/Off .....	5-10
Meas Parameters .....	5-4
Min ATT .....	5-13
Plot Number .....	5-9
Plot Start .....	5-9
Preamp On/Off .....	5-13
Q Eye Diagram .....	5-7
Quad Display .....	5-9
Ref Level .....	5-13
Ref Offset .....	5-13
Return .....	5-12
Single Display .....	5-9
Specified Code No. ....	5-7
Specified PCG No. ....	5-7
Table .....	5-7
Total Result .....	5-7
Trigger Delay .....	5-12
Trigger Slope .....	5-12
Trigger Source .....	5-12
Tx Power vs PCG .....	5-7
User Table .....	5-4, 5-5, 5-6
Window Format .....	5-7
X Scale Left .....	5-9
X Scale Right .....	5-9
Y Scale Lower .....	5-9
Y Scale Upper .....	5-9



## 5.2 Switching Communication Systems

The menu bar of this option is arranged as follows:



The menu bar consists of the same items as those of Spectrum Analyzer.

Select **[Modulation Analyzer]** from **[Config]** on the menu bar to select a modulation analysis function.

Select **[cdma2000 DL]** from **[Modulation]** on the menu bar to select the cdma2000Downlink modulation analysis function.

## 5.3 Function Bar

This section describes the functions of each function button displayed on the function bar. The configuration of the function buttons of this option is as follows:



When you click a function button on the function bar, the associated soft keys are displayed on the soft menu bar.

## 5.4 Soft Menu Bar

The area located on the right-hand side of the screen and in which soft keys are displayed is called the soft menu bar.

When you touch a button on the function bar, the associated soft keys are displayed on the soft menu bar.


5.5 Description of the Function of Each Key

5.5 Description of the Function of Each Key

This section describes the function of each key.

5.5.1 {MEAS SETUP}

When you touch the {MEAS SETUP} button, the soft keys related to the analysis parameter setting are displayed on the soft menu bar.



**Analysis Restart**

The measurement of the AD data, which has already been obtained, re-starts.

**Meas Parameters**

The dialog box used to set the measurement conditions appears.

**[Meas Mode]**

Sets the measurement method.

cdma2000:

Select this mode when measuring the cdma2000 signal. The order, in which the Walsh Code is displayed, is the Bit Reversal order.

cdmaOne:

Select this mode when measuring the cdmaOne signal. The order, in which the Walsh Code is displayed, is the Hadamard order.

**[User Table]**

Selects whether to perform analysis during the measurement by referring to the channel set by the user. Some channels are difficult to be determined as transmission channels by using the internal auto judgment function. Also, the function may determine incorrect transmission channels. By setting the channels in the user table, transmission channel determination errors can be reduced.

	USE:	Performs analysis according to the user table. The internal auto judgment function determines whether the channels, which are not defined in the user table, are used as transmission channels.
	NOT USE:	Automatically checks all channels and determines which channels are used as transmission channels.
<b>[Meas Length]</b>		Sets the measurement length in units of PCG (power control group). 1 PCG is equivalent to 1536 chips.
	<hr/>	
	<b>MEMO:</b>	
	<ol style="list-style-type: none"> <li>1. <i>If the measurement length in the x axis, which shows PCG or Chip in the graph, is shortened, the displayed area narrows. However, even if lengthened, the displayed area does not expand further than the set X scale.</i></li> <li>2. <i>If the following is set, [Meas Length] can be set to only 4, 8, 12, or 16.</i></li> </ol>	
	[User Table]:	USE
	[User Table] [Channel]:	ACKCH
	<hr/>	
<b>[<math>\tau</math> Offset]</b>		Sets the offset value of the $\tau$ (Time Alignment Error).
<b>[Phase Equalizing Filter]</b>		Sets the phase equalizing filter to ON and OFF. If the output phase characteristics of the base station pass a phase equalizer that complies with IS-95, set this function to ON.
	ON:	Sets the phase equalizing filter to ON.
	OFF:	Sets the phase equalizing filter to OFF.
<b>[PN Offset Search]</b>		Sets the PN Offset search to ON and OFF. If the signal has 64 of the maximum value of the Walsh length of the transmission channel and the PN Offset value of the base station is unknown, set this function to ON.
	ON:	Sets the PN Offset search to ON.
	OFF:	Sets the PN Offset search to OFF. The PN Offset of the measured signal must be set.
<b>[PN Offset]</b>		Sets the PN Offset value of the base station. A value from 0 to 511 can be set.
<b>[Threshold Level]</b>		Sets the threshold level to determine the transmission channel (active channel).
	<hr/>	
	<b>MEMO:</b>	
	<ol style="list-style-type: none"> <li>1. <i>If the set threshold level is too high, an active channel is incorrectly determined as a non-active channel. Accordingly, the <math>\rho</math> and modulation accuracy values are less accurate than the actual values, and the measurement cannot be performed correctly.</i></li> <li>2. <i>The transmission channel, which cannot be automatically determined as the transmission channel, is determined as an inactive channel even if its level is larger than Threshold Level. In this case, use the User Table function.</i></li> </ol>	
	<hr/>	
<b>[<math>\Delta\tau</math>]</b>		Measures the delay time of each channel. The delay time for each channel is displayed as positive if the channel is delayed in rela-

5.5.1 {MEAS SETUP}

tion to the pilot channel.  
 ON: Sets the  $\Delta\tau$  measurement to ON.  
 OFF: Sets the  $\Delta\tau$  measurement to OFF.  
 [Δθ] Measures the phase difference between each channel and the pilot channel.  
 ON: Sets the  $\Delta\theta$  measurement to ON.  
 OFF: Sets the  $\Delta\theta$  measurement to OFF.

**User Table**

The User Table dialog box appears. The channels defined here are valid if [User Table] is set to USE.  
 [Multi Channel No.] Sets the number of channels to be defined.  
 [Channel] Sets a transmission channel name  
 The channels that can be set are CPCCH, QPCH, PDCCH, PDCH, GCH, RCCH, and ACKCH.  
 CPCCH: Common Power Control Channel  
 QPCH: Quick Paging Channel  
 PDCCH: Packet Data Control Channel  
 PDCH: Packet Data Channel  
 GCH: Grant Channel  
 RCCH: Rate Control Channel  
 ACKCH: Acknowledgement Channel

---

**MEMO:** *Because the CPCCH, QPCH, GCH, RCCH, and ACKCH channels are not automatically determined as transmission channels, use the User Table function when measuring the signals which includes the channels mentioned above.*

---

[Walsh Length] Displays the Walsh Code length that corresponds to the transmission channel.  
 [Walsh Number] Sets the Walsh Code number.  
 [Modulation] Sets the modulation format. Valid only when [Channel] is set to PDCH.


---

**MEMO:** *If the Walsh Code number is set to not satisfy the orthogonality between the different channels, a measurement error occurs.*

---

## 5.5.2 {MEAS VIEW}

When you touch the {MEAS VIEW} button, the soft keys related to the display screen setup are displayed on the soft menu bar.



**Specified PCG No.**

Sets the PCG (power control group) number to display a graph.

**Specified Code No.**

Sets the code number to display a graph.

**Window Format**

Displays the dialog box to set the measurement result window.

**[Format]**

Selects the measurement result window to be displayed.

**[All PCG & Code]**

Performs the measurement on all PCG and all codes.

**[Total Result]**

Displays the numerical results of the analyzed multiplex signal.

**[Tx Power vs PCG]**


Displays the power for each PCG (power control group).

5.5.2 {MEAS VIEW}

	<b>[Code Power vs Code]</b>	Displays the Code Domain Power of each code on a graph.
	<b>[ρ vs Code]</b>	Displays the ρ of each code on a graph.
	<b>[Δτ vs Code]</b>	Displays the amount of the delay of each code on a graph. Based on the pilot channel, the direction of the delay of each channel is displayed as the positive direction.
	<b>[Δθ vs Code]</b>	Displays the phase difference between each channel on a graph, based on the phase of the pilot channel.
	<b>[EVM vs Chip]</b>	Displays the EVM of each chip on a graph.
	<b>[Mag Err vs Chip]</b>	Displays the magnitude error of each chip on a graph.
	<b>[Specified PCG]</b>	Performs measurement on the specified PCG only.
	<b>[Code Power vs Code]</b>	Displays the Code Domain Power of each code on a graph.
	<b>[ρ vs Code]</b>	Displays the ρ of each code on a graph.
	<b>[Constellation]</b>	Displays the constellation.
	<b>[I Eye Diagram]</b>	Displays the EYE pattern of the I signal.
	<b>[Q Eye Diagram]</b>	Displays the EYE pattern of the Q signal.
	<b>[Specified Code]</b>	Performs measurement on the specified code only.
	<b>[Code Power vs PCG]</b>	Displays the power for each PCG (power control group).
	<b>[Specified PCG &amp; Code]</b>	Performs the measurement on the specified PCG and code.
	<b>[Constellation]</b>	Displays the constellation.
<b>[Display Type]</b>		Sets the display method of the graph, which is selected in <b>[Format]</b> .
	<b>[vs Code]</b>	Select whether to display each vs Code result of Code Power ρ, Δτ, and Δθ on graphs or in lists.
	<b>[Graph]</b>	Displays the results on graphs.
	<b>[Table]</b>	Displays the results in lists.
	<b>[Constellation]</b>	Selects whether to display the chip positions or to display both the chip positions and the transition from one chip position to another, when the <b>[Specified PCG]</b> Constellation on a graph is displayed.
	<b>[Line &amp; Chip]</b>	Displays both the chip positions and the transition positions.
	<b>[Chip]</b>	Displays the chip positions only.

### 5.5.3 {SCALE}

When you touch the {SCALE} button, the soft keys related to the setup of the X-axis and Y-axis scales in the active display window are displayed on the soft menu bar.



#### Single Display

Displays a single window. When the 4-window display mode is set, the upper left window is zoomed.

#### Dual Display

Displays two windows. When the 4-window display mode is set, the upper two windows are zoomed.

#### Quad Display

Displays four windows.

#### X Scale Left

Sets the minimum value on the X axis.

#### X Scale Right

Sets the maximum value on the X axis.

#### Y Scale Upper

Sets the maximum value on the Y axis.

#### Y Scale Lower

Sets the minimum value on the Y axis.

#### Plot Start

Sets the position to start drawing when the Constellation and Eye Diagram are displayed.


#### Plot Number

Sets the drawing range when the Constellation and Eye Diagram are displayed.

5.5.4 {MKR}

5.5.4 {MKR}

When you touch the {MKR} button, the soft keys related to the marker setup are displayed on the soft menu bar.



**Marker**

Sets the X-axis position of the normal marker.

**Active CH. Marker**

Sets the code number of the transmission channel. Valid only when the graph, in which the X-axis is set to the code, is displayed.

**Marker->Specified PCG On/Off**

When the graph, which is selected by [**Specified PCG**] or [**Specified PCG & Code**], is displayed, this function sets whether to couple the marker-indicated PCG, which is located on the Tx Power vs PCG graph or the Code Power vs PCG graph, and the PCG number, which is specified in the Specified PCG, together.

On: Turns on the coupling function.

Off: Turns off the coupling function.

**Marker->Specified Code On/Off**

When the graph, which is selected by [**Specified Code**] or [**Specified PCG & Code**], is displayed, this function sets whether to couple the Active CH. Marker-indicated code number, which is located on the graph of Code Power vs Code,  $\rho$  vs Code,  $\Delta\tau$  vs Code, and  $\Delta\theta$  vs Code, and the code number, which is specified in the Specified Code, together.

On: Turns on the coupling function.

Off: Turns off the coupling function.

---

**MEMO:** For more information on how to use **Marker->Specified PCG On/Off** and **Marker->Specified Code On/Off**, refer to How to specify the PCG and Code by using the marker on the graph in A.1, "Technical Data."

---


**Marker OFF**

Hides the marker.



### 5.5.5 {INPUT}

When you touch the {INPUT} key, the soft keys related to the setting up of the input format for the measuring instrument are displayed on the soft menu bar.



#### **Input Setup**

When you touch the **Input Setup** button, the dialog box for setting up the input format for the measuring instrument is displayed. Set up in accordance with the measurement signal.

#### **[Input]**

Sets the input channel for the signal.

RF: Sets the RF signal input.

Baseband (I&Q):  
Sets the IQ signal (baseband) input.

#### **[Baseband Input]**

Sets the coupling for the IQ signal input.

AC: Selects the AC coupling.

DC: Selects the DC coupling.

#### **[IQ Inverse]**

Selects whether or not to invert the phase of the signal to be measured.


ON: Inverts the signal.

OFF: Does not invert the signal.

5.5.6 {TRIGGER}

5.5.6 {TRIGGER}

When you touch the {TRIGGER} button, the soft keys related to the trigger setup are displayed on the soft menu bar.



**Trigger Source**

When you touch the **Trigger Source** button, the soft keys related to the trigger setup are displayed on the soft menu bar.

**Free Run**

Obtains and analyzes data according to the internal timing of the measuring instrument.

**IF Power**

Obtains and analyzes data synchronized with the IF signal.

**Ext1**

Synchronizes the data reading with the external signal and analyzes the data entered into the EXT TRIG IN 1 connector. The threshold level for Ext1 is fixed to the TTL level.

**Ext2**

Synchronizes the data reading with the external signal and analyzes the data entered into the EXT TRIG IN 2 connector. The threshold level for Ext2 can be set.

**Link**

Obtains and analyzes data synchronizing with the trigger of an optional function.

---

**MEMO:** For information on how to use the link trigger, refer to the manual of the option in which the link trigger is used.

---

**Return**

Returns to the previous soft key array on the soft menu bar.

**Trigger Slope**

Switches the polarity of the trigger slope.  
Available only for IF Power, Ext1, and Ext2.

+: Starts sweeping at the rise of a trigger.

-: Starts sweeping at the fall of a trigger.

**Trigger Delay**

Sets the delay time from the trigger point. Is available only for IF Power, Ext1, and Ext2. When analyzing, the start position of AD data acquisition is shifted to the delay time.

**Interval On/Off**


Sets whether to synchronize the trigger and the built-in counter, whose period is set to 80 ms.

On: Synchronizes them.

Off: Does not synchronize them.

## 5.5.7 {LEVEL}

When you touch the {LEVEL} button, the soft keys related to the setup of the attenuator and reference level are displayed on the soft menu bar.



### Auto Level Set

Sets the reference level to the optimum value in accordance with the signal to be measured. When the key is pressed, Auto Level Set is executed.

---

**CAUTION:** While Auto Level Set is being executed, the level of the signal measured must remain constant.

---

### Ref Level

Sets the reference level.

### ATT

Sets the attenuator.

Auto: Automatically sets the attenuator value based on the reference level.

Man: Sets the attenuator value.

### Min ATT

Sets the Min ATT function ON and OFF.

On: Sets the minimum attenuator value and implements control regardless of whether ATT is Auto or Manual.

Off: Cancels the Min ATT limitation.

### Preamp On/Off

Sets the preamplifier function ON and OFF.

### Ref Offset

Switches the reference level offset function ON and OFF.


On: Sets the offset value and changes only the displayed reference level by the offset value.  
(Displayed reference level = Set value + Offset value)

Off: Cancels the offset function.

5.5.8 {FREQ}

5.5.8 {FREQ}

When you touch the {FREQ} button, the soft keys related to the measurement frequency setup are displayed on the soft menu bar.



**Center**

Sets the center frequency of the measurement signal.

---

**CAUTION:** *Set the center frequency correctly. If it is set incorrectly, an error may occur in the center frequency error measurement and the measurement may be incorrect.*

---

**Channel Number**

When the channel number is set, the center frequency is automatically set by using the following formula.

$$(\text{Center frequency}) = (\text{Channel interval}) \times (\text{Channel number} + \text{Channel offset}) + (\text{Start frequency})$$

The parameters such as the channel interval and the channel number setting range depend on the Standard selected by [Special] → [STD...]. For more information, refer to the R3681 Series User's Guide.

**Freq Offset**


Switches the center frequency offset function ON and OFF.

- On: Sets the offset value and changes only the displayed center frequency by the offset value.  
(Displayed center frequency = Set value + Offset value)
- Off: Cancels the offset function.

## 5.5.9 Measurement Tool Bar

The functions of waveform range selection, active window selection, and so on are displayed as icons.

The following functions can be used by touching the icons:



: Zoom in icon:

Used to zoom in on the waveform displayed in the window. The range specified by the range specification icon is zoomed in on by touching on the range.




: Zoom out icon:

Used to zoom out from the waveform displayed in the window.



: Range specification icon (X-axis mode):

Used to specify a range in the window in which the waveform is displayed. After touching the icon, specify the range by touching two points on the graph.



: Range specification icon (range mode):

Used to specify a range in the window in which the waveform is displayed. Specify the upper-left and lower-right corners of the range by touching the display.



: Active window switching icon:

Used to make one of the split windows active.



: Range shift icon:

Used to shift the display position without changing the display range. After touching the icon, touch the inside of the graph frame in the direction to be shifted.



## 6. SCPI COMMAND REFERENCE (Downlink)

This chapter describes the SCPI command reference for this instrument.

### 6.1 Command Reference Format

This section describes the format and layout used to describe commands in this chapter.

Each description includes the following items:

Function description

SCPI command

Parameter

Query reply

- [Function description]  
The usage of commands and operations in this instrument.
- [SCPI command]  
The SCPI command displays the syntax of a command sent from the external controller to this instrument. The syntax consists of a command and a number of parameters. The command and the parameters are separated by a space.  
If a command has multiple parameters, they are separated by commas (.). The three points (...) displayed between commas represent the parameter(s) omitted at that position.  
For example, the description <numeric value 1>, ..., <numeric value 4> shows that four parameters, <numeric value 1>, <numeric value 2>, <numeric value 3>, and <numeric value 4>, are required.  
If the parameter is a character string type such as <character string>, <character string 1>, the parameter must be enclosed in double quotation marks (" "). If the parameter is <block>, it shows the block format data.  
Text written in lowercase alphabetic characters in the syntax can be omitted.  
For example, ":CALibration:CABLe" can be abbreviated to ":CAL:CABL."  
The marks used in the syntax are defined as follows:
 

< >:	Shows a parameter required for sending a command
[ ]:	Shows that the command is optional It can be omitted
{ }:	Shows that only one item is required to be selected from multiple items
:	Used as a delimiter for multiple items written in curly brackets { .. }
<ch>:	Written in the command header and shows the target input channel number of the command The channel number can be omitted. However, when it is written, channel number 1 is selected
<screen>:	Written in the command header and shows the target screen number of the command The screen number can be omitted. However, when it is written, a value from 1 to 4 can be selected {{1 2 3 4}}

---

## 6.1 Command Reference Format

For example: If the syntax below is specified, `:CALC:CORR:EDEL:TIME 0.1` and `CALCULATE1:SELECTED:CORR:EDEL:TIME 25E-3` are valid.

Syntax: `CALCulate{[1][2][3][4]}[:SELEcted]:CORRection:EDELay:TIME <numeric value>`

- [Parameter]

Describes a parameter required for sending a command.

If the parameter is numeric type or alphabetic, it is enclosed in angle brackets (<>).

If the parameter is optional, it is enclosed in curly brackets ({}).

In this manual, parameter types are described in the following formats:

< int >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to an integer in this instrument

< real >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to a valid-digit real number in this instrument

< bool >: Either OFF or ON can be entered.

< str >: A character string enclosed in quotation (‘ ’) or double quotation (“ ”) marks.

< block >: Block data type  
The data content is an 8-bit binary data array

< type >: Character data selected from multiple types

- [Query reply]

When there is a query reply to the command, the data format used for reading the query is described.

Each parameter to be read is enclosed in curly brackets ({}). If multiple items, which are delimited by a vertical bar (|), exist in curly brackets ({}), only one of those items is read out. If parameters are delimited by commas (,) multiple parameters can be read out. The three points (...) displayed between commas represent data omitted from that position. For example, the description {numeric value 1},..., {numeric value 4} shows that four parameters {numeric value 1}, {numeric value 2}, {numeric value 3}, and {numeric value 4} are read.

If the parameter to be read is enclosed in square brackets ([ ]), the parameter may be omitted, depending on the measurement result, etc.

If the parameter to be read is a value in a unit, a description such as “Unit: dBm” is added to display the unit of the parameter value. However, only when the parameter is described in a level unit “dBm”, the level unit selected at that time will be applied to the parameter.



## 6.2 Common Commands

This section describes common IEEE commands.

Function description	SCPI Command	Parameter	Query reply	Remarks
Clears the status byte and related data	*CLS	-	-	
Macro definition for GET	*DDT	<block>	<block>	*1
Sets the standard event status enable register	*ESE	<int>	<int>	
Reads the standard event status register	*ESR?	-	<int>	
Device inquiry	*IDN?	-	<str>	*2
Notifies when all running operations are complete	*OPC	-	1	
Loads the device settings	*RCL	<int>   POFF	-	*3
Resets the device	*RST	-	-	
Saves the device settings	*SAV	<int>	<int>	
Sets the service request enable register	*SRE	<int>	<int>	
Reads the status byte register	*STB?	-	<int>	
Triggers the device	*TRG	-	-	
Waits until all running operations are complete	*WAI	-	-	

\*1: If the \*DDT? command is executed when the macro is undefined, a zero-length block data (#10) is returned.

\*2: <str> is output in the following format: maker name, model name, serial number and version number.

\*3: POFF indicates the parameter settings when the power was last switched off.

6.3 List of Commands

6.3 List of Commands

6.3.1 Subsystem-SYSTEM

Function description	SCPI command	Parameter	Query reply	Remarks
Config				
Measurement system selection	:SYSTEM:SELEct	SANalyzer MANalyzer	SAN MAN	
Modulation				
Modulation analysis system selection	:SYSTEM:SELEct:MODulation	CDMA2KDL	CDMA2KDL	
Preset				
Each measurement system parameter initialization	:SYSTEM:PRESet	-	-	
All measurement systems initialization	:SYSTEM:PRESet:ALL	-	-	
Log				
Inquiry about the error that occurred last	:SYSTEM:ERRor?	-	<int>,<str>	
Inquiry about the details of the error log	:SYSTEM:ERRor:ALL?	-	<int>,<str>	

6.3.2 Subsystem-INPut

Function description	SCPI command	Parameter	Query reply	Remarks
ATT/Preamp				
ATT setting (Manual)	:INPut:ATTenuation	<real>	<real>	
ATT (Auto/Manual)	:INPut:ATTenuation:AUTO	OFF ON	OFF ON	
Min ATT setting	:INPut:ATTenuation:MINimum	<real>	<real>	
Min ATT ON/OFF	:INPut:ATTenuation:MINimum:STATe	OFF ON	OFF ON	
Preamp ON/OFF	:INPut:GAIN:STATe	OFF ON	OFF ON	
Input Setup				
Input Signal RF/Baseband	:INPut:SIGNal	RF BASeband	RF BAS	
Baseband Input AC/DC	:INPut:BASEband	AC DC	AC DC	
IQ Inverse ON/OFF	:INPut:IQ:INVerse	OFF ON	OFF ON	

### 6.3.3 Subsystem-SENSE

Function description	SCPI command	Parameter	Query reply	Remarks
<b>FREQUENCY</b>				
Center Freq setting	[:SENSE]:FREQUENCY:CENTer	<real>	<real>	
Freq Offset setting	[:SENSE]:FREQUENCY:OFFSet	<real>	<real>	
Freq Offset ON/OFF	[:SENSE]:FREQUENCY:OFFSet:STATe	OFF ON	OFF ON	
Channel Number setting	[:SENSE]:FREQUENCY:CHANnel:NUMBER	<int>	<int>	
<b>Auto Level Set</b>				
Auto Level Set execution	[:SENSE]:POWER:LEVel:AUTO	-	-	
<b>Meas Parameters</b>				
Measurement mode setting	[:SENSE]:CONDition:MMODE	CDMA2K  CDMAONE	CDMA2K  CDMAONE	
User Table NOT USE/USE	[:SENSE]:CONDition:UTABle	NOT USE	NOT USE	
Meas Length setting	[:SENSE]:CONDition:MLENgtH	<int>	<int>	
$\tau$ (Time Alignment Error) offset setting	[:SENSE]:CONDition:TOFFset	<real>	<real>	
Phase Equalizing Filter ON/OFF	[:SENSE]:CONDition:PFILter	OFF ON	OFF ON	
PN Offset Search ON/OFF	[:SENSE]:CONDition:PNSearch	OFF ON	OFF ON	
PN Offset value setting	[:SENSE]:CONDition:PNOffset	<int>	<int>	
Threshold Level setting	[:SENSE]:CONDition:THReshold	<real>	<real>	
$\Delta\tau$ ON/OFF	[:SENSE]:CONDition:DTAU	OFF ON	OFF ON	
$\Delta\theta$ ON/OFF	[:SENSE]:CONDition:DTHeta	OFF ON	OFF ON	
<b>User Table</b>				
Multi Channel Number setting	[:SENSE]:CONDition:UTABle:MCNumber	<int>	<int>	
Channel setting	[:SENSE]:CONDition:UTABle:CHANnel <utbl=1 to 48>	CPCCH QPCH  PDCCH PDCH  GCH RCCH  ACKCH	CPCCH QPCH  PDCCH PDCH  GCH RCCH  ACKCH	
Walsh Number setting	[:SENSE]:CONDition:UTABle:WCNumber <utbl=1 to 48>	<int>	<int>	
Modulation setting	[:SENSE]:CONDition:UTABle:MODulation <utbl=1 to 48>	QPSK PSK8  QAM16  QPSKPSK8  QPSKQAM16  PSK8QAM16  QPSKPSK8QAM16	QPSK PSK8  QAM16  QPSKPSK8  QPSKQAM16  PSK8QAM16  QPSKPSK8QAM16	

6.3.4 Subsystem-TRIGger

**6.3.4 Subsystem-TRIGger**

Function description	SCPI command	Parameter	Query reply	Remarks
SH:Quence				
Trigger Source	:TRIGger[:SEQuence]:SOURce	IMMediate IF EXTErnal1 EXTErnal2 LINK	IMM IF EXT1 EXT2 LINK	
Trigger Slope	:TRIGger[:SEQuence]:SLOPe	POSitive NEGative	POS NEG	
IF Power setting	:TRIGger[:SEQuence]:LEVel:IF	<real>	<real>	
Ext2 Trigger Level setting	:TRIGger[:SEQuence]:LEVel:EXTErnal	<real>	<real>	
Trigger Delay setting	:TRIGger[:SEQuence]:DELay	<real>	<real>	
Interval Trigger setting	:TRIGger[:SEQuence]:INTerval:STATe	OFF ON	OFF ON	

**6.3.5 Subsystem-INITiate**

Function description	SCPI command	Parameter	Query reply	Remarks
INITiate				
Single measurement execution	:INITiate:MEASure:SINGLE	-	-	
Repeat measurement execution	:INITiate:MEASure:REPeat	-	-	
Analysis Restart execution	:INITiate:REStart	-	-	
Stop execution (measurement stop)	:INITiate:ABORt	-	-	

### 6.3.6 Subsystem-CALCulate

Function description	SCPI command	Parameter	Query reply	Remarks
MARKer				
Marker ON/OFF	:CALCulate:MARKer<scrn=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Marker X setting	:CALCulate:MARKer<scrn=1 2 3 4>:X	<real>	<real>	
Marker Y reading	:CALCulate:MARKer<scrn=1 2 3 4>:Y	–	<real>	
Constellation Marker Plot setting	:CALCulate:MARKer<scrn=1 2 3 4>:CHIP :CALCulate:MARKer<scrn=1 2 3 4>:SYMBOL	<int>	<int>	
Constellation I reading	:CALCulate:MARKer<scrn=1 2 3 4>:I	–	<real>	
Constellation Q reading	:CALCulate:MARKer<scrn=1 2 3 4>:Q	–	<real>	
Specified PCG coupling ON/OFF	:CALCulate:MARKer:SET:PCG[:STATe]	OFF ON	OFF ON	
Specified Code coupling ON/OFF	:CALCulate:MARKer:SET:CODE[:STATe]	OFF ON	OFF ON	
Active CH Marker ON/OFF	:CALCulate:ACMarker<scrn=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Active CH Marker X setting	:CALCulate:ACMarker<scrn=1 2 3 4>:X	<real>	<real>	
Active CH Marker Y reading	:CALCulate:ACMarker<scrn=1 2 3 4>:Y	–	<real>	

### 6.3.7 Subsystem-DISPlay

Function description	SCPI command	Parameter	Query reply	Remarks
WINDOW				
Ref Level setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel	<real>	<real>	
Level Offset setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFFSet	<real>	<real>	
Level Offset ON/OFF	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFF-Set:STATe	OFF ON	OFF ON	
MEAS VIEW				
Analysis format selection	:DISPlay:WINDow<scrn=1 2 3 4>:FORMat	TRE SuIt POWer  CPOWer RHO  DTAU DTHeta  EVM MERRor  SPCPOWer  SPRHO  CONStellation  IEYE QEYE  SCCPOWer  SPCCONStellation	TRE S POW  CPOW RHO  DTAU DTH  EVM MERR  SPCPOW  SPRHO CONS  IEYE QEYE  SCCPOW  SPCCONS	
Display format setting: Graph/Table List	:DISPlay:WINDow<scrn=1 2 3 4>:VSCode:TYPE	GRAPh TABLe	GRAP TABL	
Display setting for the constellation: Line&Chip/Chip	:DISPlay:WINDow<scrn=1 2 3 4> :CONStellation:TYPE	LCHip CHIP	LCH CHIP	
Specified PCG Number setting	:DISPlay:PCG	<int>	<int>	

6.3.8 Subsystem-MMEMory

Function description	SCPI command	Parameter	Query reply	Remarks
Specified Code Number setting	:DISPlay:CODE	<int>	<int>	
<b>SCALc</b>				
Multi Screen setting	:DISPlay	SINGle DUAL QUAD	SING DUAL QUAD	
X Scale Left setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :X[:SCALc]:LEFT	<real>	<real>	
X Scale Right setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :X[:SCALc]:RIGHT	<real>	<real>	
Y Scale Upper setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :Y[:SCALc]:UPPer	<real>	<real>	
Y Scale Lower setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :Y[:SCALc]:LOWer	<real>	<real>	
Constellation Plot Start setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :CONStellation:CHIP:STARt :DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :CONStellation:SYMBol:STARt	<int>	<int>	
Constellation Plot Number setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :CONStellation:CHIP:NUMBer :DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe :CONStellation:SYMBol:NUMBer	<int>	<int>	
I Eye Diagram Plot Start setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe:IEYE :CHIP:STARt	<int>	<int>	
I Eye Diagram Plot Number setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe:IEYE :CHIP:NUMBer	<int>	<int>	
Q Eye Diagram Plot Start setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe:QEYE :CHIP:STARt	<int>	<int>	
Q Eye Diagram Plot Number setting	:DISPlay[:WINDow<scrn=1 2 3 4>]:TRACe:QEYE :CHIP:NUMBer	<int>	<int>	

6.3.8 Subsystem-MMEMory

Function description	SCPI command	Parameter	Query reply	Remarks
<b>Save/Recall</b>				
Saving the settings of this instrument	:MMEMory:STORe:STATe	<int>	-	*1
Loading the settings of this instrument	:MMEMory:LOAD:STATe	<int>	-	*1
Measurement condition Save selection	:MMEMory:SElect:ITEM:CDMA2KDL:SETup	OFF ON	OFF ON	

\*1: A number, which is a maximum of 4-digit and is added to the file name of the data to be saved or loaded, must be specified in <int>.

### 6.3.9 Subsystem-MEASure

Function description	SCPI command	Parameter	Query reply	Remarks
MEASure				
$\tau$ (Time Alignment Offset) reading	:MEASure:TRESult:TAU	-	<real>	
Frequency Error reading	:MEASure:TRESult:FErRor	-	<real>,<real>	*2
$\rho$ reading	:MEASure:TRESult:RHO	-	<real>	
PN Offset reading	:MEASure:TRESult:PNOfset	-	<int>	
Mag Error reading	:MEASure:TRESult:MErRor	-	<real>	
Phase Error reading	:MEASure:TRESult:PErRor	-	<real>	
EVM reading	:MEASure:TRESult:EVM	-	<real>	
Peak EVM reading	:MEASure:TRESult:PEVM	-	<real>	
IQ Origin Offset reading	:MEASure:TRESult:IQOfset	-	<real>	
Tx Power reading	:MEASure:TRESult:POWer	-	<real>,<real>	*3
Pilot Power reading	:MEASure:TRESult:PILOt	-	<real>,<real>	*7
Peak Inactive CH Power reading	:MEASure:TRESult:PICPower	-	<real>,<int>,<int>	*4
Peak $\Delta\tau$ reading	:MEASure:TRESult:PDtau	-	<real>,<int>,<int>	*5
Peak $\Delta\theta$ reading	:MEASure:TRESult:PDTHeta	-	<real>,<int>,<int>	*6
Active CH Number reading	:MEASure:TRESult:ACHannel	-	<int>	

\*2: Outputs the frequency error in order of [Hz] and [ppm].

\*3: Outputs the Tx Power in order of [dBm] and [W].

\*4: Outputs the peak of the Inactive CH Power and its data point in order of Power[dBm], Walsh Code No., and Walsh Code Length.

\*5: Outputs the peak of  $\Delta\tau$  and its data point in order of  $\Delta\tau$ [sec], Walsh Code No., and Walsh Code Length.

\*6: Outputs the peak of  $\Delta\theta$  and its data point in order of  $\Delta\theta$ [rad], Walsh Code No., and Walsh Code Length.

\*7: Outputs the Pilot Power in order of [dBm] and [W].

6.3.10 Subsystem-READ

**6.3.10 Subsystem-READ**

Function description	SCPI command	Parameter	Query reply	Remarks
READ				
$\tau$ (Time Alignment Offset) reading	:READ:TRESult:TAU	-	<real>	
Frequency Error reading	:READ:TRESult:FERRor	-	<real>,<real>	*2
$\rho$ reading	:READ:TRESult:RHO	-	<real>	
PN Offset reading	:READ:TRESult:PNOFfset	-	<int>	
Mag Error reading	:READ:TRESult:MERRor	-	<real>	
Phase Error reading	:READ:TRESult:PERRor	-	<real>	
EVM reading	:READ:TRESult:EVM	-	<real>	
Peak EVM reading	:READ:TRESult:PEVM	-	<real>	
IQ Origin Offset reading	:READ:TRESult:IQOFFset	-	<real>	
Tx Power reading	:READ:TRESult:POWer	-	<real>,<real>	*3
Pilot Power reading	:READ:TRESult:PILot	-	<real>,<real>	*7
Peak Inactive CH Power reading	:READ:TRESult:PICPower	-	<real>,<int>,<int>	*4
Peak $\Delta\tau$ reading	:READ:TRESult:PDtau	-	<real>,<int>,<int>	*5
Peak $\Delta\theta$ reading	:READ:TRESult:PDTheta	-	<real>,<int>,<int>	*6
Active CH Number reading	:READ:TRESult:ACHannel	-	<int>	

\*2: Outputs the frequency error in order of [Hz] and [ppm].

\*3: Outputs the Tx Power in order of [dBm] and [W].

\*4: Outputs the peak of the Inactive CH Power and its data point in order of Power[dBm], Walsh Code No., and Walsh Code Length.

\*5: Outputs the peak of  $\Delta\tau$  and its data point in order of  $\Delta\tau$ [sec], Walsh Code No., and Walsh Code Length.

\*6: Outputs the peak of  $\Delta\theta$  and its data point in order of  $\Delta\theta$ [rad], Walsh Code No., and Walsh Code Length.

\*7: Outputs the Pilot Power in order of [dBm] and [W].



### 6.3.11 Subsystem-FETCH

Function description	SCPI command	Parameter	Query reply	Remarks
<b>FETCH</b>				
$\tau$ (Time Alignment Offset) reading	:FETCH:TRESult:TAU	–	<real>	
Frequency Error reading	:FETCH:TRESult:FERRor	–	<real>,<real>	*2
$\rho$ reading	:FETCH:TRESult:RHO	–	<real>	
PN Offset reading	:FETCH:TRESult:PNOffset	–	<int>	
Mag Error reading	:FETCH:TRESult:MFERRor	–	<real>	
Phase Error reading	:FETCH:TRESult:PERRRor	–	<real>	
EVM reading	:FETCH:TRESult:EVM	–	<real>	
Peak EVM reading	:FETCH:TRESult:PEVM	–	<real>	
IQ Origin Offset reading	:FETCH:TRESult:IQOffset	–	<real>	
Tx Power reading	:FETCH:TRESult:POWer	–	<real>,<real>	*3
Pilot Power reading	:FETCH:TRESult:PILOt	–	<real>,<real>	*7
Peak Inactive CH Power reading	:FETCH:TRESult:PICPower	–	<real>,<int>,<int>	*4
Peak $\Delta\tau$ reading	:FETCH:TRESult:PDtau	–	<real>,<int>,<int>	*5
Peak $\Delta\theta$ reading	:FETCH:TRESult:PDHeta	–	<real>,<int>,<int>	*6
Active CH Number reading	:FETCH:TRESult:ACHannel	–	<int>	

\*2: Outputs the frequency error in order of [Hz] and [ppm].

\*3: Outputs the Tx Power in order of [dBm] and [W].

\*4: Outputs the peak of the Inactive CH Power and its data point in order of Power[dBm], Walsh Code No., and Walsh Code Length.

\*5: Outputs the peak of  $\Delta\tau$  and its data point in order of  $\Delta\tau$ [sec], Walsh Code No., and Walsh Code Length.

\*6: Outputs the peak of  $\Delta\theta$  and its data point in order of  $\Delta\theta$ [rad], Walsh Code No., and Walsh Code Length.

\*7: Outputs the Pilot Power in order of [dBm] and [W].

6.4 Status Register

6.4 Status Register




Figure 6-1 Status Registers

## 7. PERFORMANCE VERIFICATION (Downlink)

This chapter describes how to check whether the performance of this instrument meets the specifications.

It is recommended that you copy the test data record sheet included at the end of this chapter and save it as a record of the performance test.

---

**IMPORTANT:** Before verifying the performance, warm-up and completely calibrate the instrument.

---

### 7.1 Test Signal Specifications

The test signals used for verifying the performance are shown below:

Table 7-1 List of Test Signal Specifications

No.	Test signal name	Signal specifications		Test item
		Channel No.	Amplitude	
1	Base station signal	0 (Pilot)	-6.99 dB	Downlink measurement (RF, IQ input)
		1 (Paging)	-7.25 dB	
		6 (Traffic)	-10.26 dB	
		17 (Traffic)	-10.26 dB	
		20 (Traffic)	-10.26 dB	
		32 (Sync)	-13.27 dB	
		41 (Traffic)	-10.26 dB	
		49 (Traffic)	-10.26 dB	
		58 (Traffic)	-10.26 dB	
		(Based on the IS-97 Base Station Test Model, Nominal)		

7.2 Test Procedures

7.2 Test Procedures

This section describes each test procedure.

7.2.1 RF Input Base Station Signal Measurement

Connect the signal source as shown below:




Figure 7-1 Connecting the Test Signal (RF Input)

1. The base station signal, which has a carrier frequency of 870.03 MHz and a level of -10 dBm, is output from the signal source.
2. Set this unit as follows:

<b>{MEAS SETUP}:</b>	<b>Meas Parameters</b>	
	[Meas Mode]:	cdma2000
	[User Table]:	NOT USE
	[Meas Length]:	2 PCG
	[τ Offset]:	0.000 μsec
	[Phase Equalizing Filter]:	ON
	[PN Offset Search]:	OFF
	[PN Offset]:	0
	[Threshold Level]:	-27 dB
	[Δτ]:	ON
	[Δθ]:	ON

<b>{INPUT}:</b>	<b>Input</b>	RF
<b>{TRIGGER}:</b>	<b>Trigger Source</b>	Ext1
<b>{FREQ}:</b>	<b>Center</b>	870.03 MHz
<b>{LEVEL}:</b>	Execute <b>Auto Level Set</b>	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

## 7.2.2 IQ Input Base Station Signal Measurement

Connect the signal source as shown below:




Figure 7-2 Connecting the Test Signal (IQ Input)

1. Output the base station signal (Baseband signal) from the signal source.
2. Set this unit as follows:

{MEAS SETUP}:	<b>Meas Parameters</b>	
	[Meas Mode]:	cdma2000
	[User Table]:	NOT USE
	[Meas Length]:	2 PCG
	[ $\tau$ Offset]:	0.000 $\mu$ sec
	[Phase Equalizing Filter]:	ON
	[PN Offset Search]:	OFF
	[PN Offset]:	0
	[Threshold Level]:	-27 dB
	[ $\Delta\tau$ ]:	ON
	[ $\Delta\theta$ ]:	ON

{INPUT}: **Input** Baseband(I&Q)

**Baseband Input** DC

{TRIGGER}: **Trigger Source** Ext1

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

7.3 Test Data Record Sheet

**7.3 Test Data Record Sheet**

Test data record sheet

Model name:

Serial number:

1. RF input measurement

Test item	Specifications			Pass / Fail	
	Minimum value	Measured value	Maximum value		
Carrier frequency error	-10 Hz		+10 Hz		
Code Domain power [dB]	Ch No.				
	0	-7.09 dB		-6.89 dB	
	1	-7.35 dB		-7.15 dB	
	6	-10.36 dB		-10.16 dB	
	17	-10.36 dB		-10.16 dB	
	20	-10.36 dB		-10.16 dB	
	32	-13.37 dB		-13.17 dB	
	41	-10.36 dB		-10.16 dB	
	49	-10.36 dB		-10.16 dB	
	58	-10.36 dB		-10.16 dB	
Transmission power	-10.8 dBm		-9.2 dBm		

2. IQ input measurement

Test item	Specifications			Pass / Fail	
	Ch No.	Minimum value	Measured value		Maximum value
Code Domain power [dB]	0	-7.09 dB		-6.89 dB	
	1	-7.35 dB		-7.15 dB	
	6	-10.36 dB		-10.16 dB	
	17	-10.36 dB		-10.16 dB	
	20	-10.36 dB		-10.16 dB	
	32	-13.37 dB		-13.17 dB	
	41	-10.36 dB		-10.16 dB	
	49	-10.36 dB		-10.16 dB	
	58	-10.36 dB		-10.16 dB	

## 8. SPECIFICATIONS (Downlink)

### 8.1 cdma2000 Modulation Analysis Compliance System

Compliance with

3rd Generation Partnership Project 2 (3GPP2)

TSG-C Specifications

C.S0002-D v1.0 (IS-2000.2)

### 8.2 cdma2000 Modulation Analysis Performance

Item	Specifications
Carrier frequency error	
Measurement range	< $\pm 2$ kHz
Measurement accuracy	< $\pm$ (Reference frequency accuracy $\times$ Carrier frequency + 10 Hz)
$\rho_i$ measurement accuracy	< $\pm 0.1$ dB
$\Delta\tau_i$ measurement accuracy	< $\pm 10$ ns
$\Delta\theta_i$ measurement accuracy	< $\pm 10$ mrad
Transmission power measurement accuracy	< $\pm$ (0.2 + Frequency response + Calibration signal level accuracy) dB
	Frequency response
	50 MHz to 2.5 GHz      < $\pm 0.4$ dB
	Calibration signal level accuracy      < $\pm 0.2$ dB

Note: For more information on the measurement condition, refer to the next page.

8.2 cdma2000 Modulation Analysis Performance

Measurement conditions

Item	Conditions																				
Temperature range	+20°C to +30°C																				
Base station signal	Walsh Length 64 <table border="1" data-bbox="746 577 1177 1032"> <thead> <tr> <th data-bbox="746 577 963 622">Channel No.</th> <th data-bbox="963 577 1177 622">Amplitude</th> </tr> </thead> <tbody> <tr> <td data-bbox="746 622 963 667">0 (Pilot)</td> <td data-bbox="963 622 1177 667">-6.99 dB</td> </tr> <tr> <td data-bbox="746 667 963 712">1 (Paging)</td> <td data-bbox="963 667 1177 712">-7.25 dB</td> </tr> <tr> <td data-bbox="746 712 963 757">6 (Traffic)</td> <td data-bbox="963 712 1177 757">-10.26 dB</td> </tr> <tr> <td data-bbox="746 757 963 801">17 (Traffic)</td> <td data-bbox="963 757 1177 801">-10.26 dB</td> </tr> <tr> <td data-bbox="746 801 963 846">20 (Traffic)</td> <td data-bbox="963 801 1177 846">-10.26 dB</td> </tr> <tr> <td data-bbox="746 846 963 891">32 (Sync)</td> <td data-bbox="963 846 1177 891">-13.27 dB</td> </tr> <tr> <td data-bbox="746 891 963 936">41 (Traffic)</td> <td data-bbox="963 891 1177 936">-10.26 dB</td> </tr> <tr> <td data-bbox="746 936 963 981">49 (Traffic)</td> <td data-bbox="963 936 1177 981">-10.26 dB</td> </tr> <tr> <td data-bbox="746 981 963 1025">58 (Traffic)</td> <td data-bbox="963 981 1177 1025">-10.26 dB</td> </tr> </tbody> </table> <p data-bbox="611 1055 1214 1088">(Based on the IS-97 Base Station Test Model, Nominal)</p> <p data-bbox="261 1111 448 1144">Center frequency 800 MHz/2 GHz</p> <p data-bbox="261 1155 379 1189">Input level -10 dBm (RF Input) 0.8 V<sub>P-P</sub> (IQ Input)</p> <p data-bbox="261 1234 277 1267"><math>\rho</math> &gt;0.9999</p> <p data-bbox="261 1279 304 1312"><math>\Delta\tau_i</math> 0 ns</p> <p data-bbox="261 1323 304 1357"><math>\Delta\theta_i</math> 0 mrad</p>	Channel No.	Amplitude	0 (Pilot)	-6.99 dB	1 (Paging)	-7.25 dB	6 (Traffic)	-10.26 dB	17 (Traffic)	-10.26 dB	20 (Traffic)	-10.26 dB	32 (Sync)	-13.27 dB	41 (Traffic)	-10.26 dB	49 (Traffic)	-10.26 dB	58 (Traffic)	-10.26 dB
Channel No.	Amplitude																				
0 (Pilot)	-6.99 dB																				
1 (Paging)	-7.25 dB																				
6 (Traffic)	-10.26 dB																				
17 (Traffic)	-10.26 dB																				
20 (Traffic)	-10.26 dB																				
32 (Sync)	-13.27 dB																				
41 (Traffic)	-10.26 dB																				
49 (Traffic)	-10.26 dB																				
58 (Traffic)	-10.26 dB																				
Meas Length	2 PCG																				



## 9. MEASUREMENT EXAMPLES (Uplink)

This chapter describes how to use this option by using specific measurement examples.


### 9.1 Analysis of the Mobile Station Offset QPSK Signal in the cdmaOne MODE

Specifications of the signal to be measured

The target mobile station signal, whose frequency is 825.03 MHz and level is -10 dBm, is compliant with IS-2000.

Signal specifications: Offset QPSK signal

Device connection



Note: The R3671 uses the N(m)-SMA(f) adapter.

Figure 9-1 Connection Diagram for the Mobile Station Offset QPSK Measurement

Setting the measuring conditions

1. Touch **[Config]** on the menu bar and select **[Modulation Analyzer]**.
2. Touch **[Modulation]** on the menu bar and select **[cdma2000 UL]**.
3. Touch the **{FREQ}** button on the function bar.
4. Touch the **Center** key on the soft menu bar.

9.1 Analysis of the Mobile Station Offset QPSK Signal in the cdmaOne MODE

5. Touch **[8]**, **[2]**, **[5]**, **[.]**, **[0]**, **[3]**, and **[M/n]** in this order on the keypad.  
The center frequency is set to 825.03 MHz.
6. Touch the **{LEVEL}** button on the function bar.
7. Touch the **Auto Level Set** key on the soft menu bar.  
The Ref Level is automatically set to the optimum value.
8. Touch the **{TRIGGER}** button on the function bar.
9. Touch the **Trigger Source** key on the soft menu bar.
10. Touch the **Ext1** key on the soft menu bar.  
The trigger source is set to the external trigger.
11. Touch the **{INPUT}** button on the function bar.
12. Touch the **Input Setup** key on the soft menu bar.  
The **[Input Setup]** dialog box appears.
13. Set **[Input]** in the **[Input Setup]** dialog box to **[RF]**.  
The Input mode is set to RF.
14. Touch the close button **[X]** in the **[Input Setup]** dialog box to close the dialog box.




Figure 9-2 **[Input Setup]** Dialog Box

15. Touch the **{MEAS MODE}** button on the function bar.
16. Touch the **cdmaOne** key on the soft menu bar.  
The measurement mode is set to cdmaOne.
17. Touch the **{MEAS SETUP}** button on the function bar.
18. Touch the **Meas Parameters** key on the soft menu bar.  
The **[Measurement Parameters Setup]** dialog box appears.
19. Touch the **[Meas Length]** text box and press **[6]**, **[1]**, **[5]**, and **[ENT]** on the keypad.  
The measurement length is set to 615 chips.
20. Set the **[Freq Meas Range]** option button to **[NORMAL]**.  
The frequency error measurement range is set to the NORMAL mode.

9.1 Analysis of the Mobile Station Offset QPSK Signal in the cdmaOne MODE

21. Set the **[IQ Origin Offset]** option button to **[INCLUDE]**.

The mode, in which the analysis is performed including the IQ origin offset, is set.




Figure 9-3 **[Measurement Parameters Setup]** Dialog Box of cdmaOne Mode

22. Touch **Return** on the soft menu bar to close the **[Measurement Parameters Setup]** dialog box.

23. Press the **SINGLE** button on the front panel.

The Single measurement is performed and the measurement results are displayed.




Figure 9-4 Results from the Mobile Station Offset QPSK Signal Measured in the cdmaOne MODE

Upper left window

$\rho$	Waveform quality
Freq Error	Carrier frequency error (Hz, ppm)
Mag Error	Magnitude error (%rms)
Phase Error	Phase error (deg.rms)
EVM	Error vector magnitude (%rms)
IQ Org Offset	IQ origin offset (dBc)
Tx Power	Transmission power (dBm, W)

9.1 Analysis of the Mobile Station Offset QPSK Signal in the cdmaOne MODE

Upper right window

Horizontal axis: Chip

Vertical axis: Error vector magnitude (%)

Lower left window

Horizontal axis: Chip

Vertical axis: Magnitude error (%)

Lower right window

Horizontal axis: Chip

Vertical axis: Phase error (deg)

## 9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE

The target mobile station signal, whose frequency is 825.03 MHz and level is -10 dBm, is compliant with IS-2000.

Signal specifications

Long Code Mask: ALL 0

Reverse Traffic Channel Operation signal (PICH, DCCH, SCH2, FCH, and SCH1 are multiplexed)

Walsh function of SCH1:  $W_1^2$  (M=1)

Walsh function of SCH2:  $W_2^4$  (M=1)

PICH: Reverse Pilot Channel

DCCH: Reverse Dedicated Control Channel


SCH2: Reverse Supplemental Channel 2

FCH: Reverse Fundamental Channel

SCH1: Reverse Supplemental Channel 1

M: Walsh Function Repetition Factor

Device connection



Note: The R3671 uses the N(m)-SMA(f) adapter.

Figure 9-5 Connection Diagram for the Mobile Station Code Domain Power Measurement

9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE

Setting the measuring conditions

1. Touch **[Config]** on the menu bar and select **[Modulation Analyzer]**.
2. Touch **[Modulation]** on the menu bar and select **[cdma2000 UL]**.
3. Touch the **{FREQ}** button on the function bar.
4. Touch the **Center** key on the soft menu bar.
5. Touch **8**, **2**, **5**, **.**, **0**, **3**, and **M/n** in this order on the keypad.  
The center frequency is set to 825.03 MHz.
6. Touch the **{LEVEL}** button on the function bar.
7. Touch the **Auto Level Set** key on the soft menu bar.  
The Ref Level is automatically set to the optimum value.
8. Touch the **{TRIGGER}** button on the function bar.
9. Touch the **Trigger Source** key on the soft menu bar.
10. Touch the **Ext1** key on the soft menu bar.  
The trigger source is set to the external trigger.
11. Touch the **{INPUT}** button on the function bar.
12. Touch the **Input Setup** key on the soft menu bar.  
The **[Input Setup]** dialog box appears.
13. Set **[Input]** in the **[Input Setup]** dialog box to **[RF]**.  
The Input mode is set to RF.
14. Touch the close button **✕** in the **[Input Setup]** dialog box to close the dialog box.




Figure 9-6 **[Input Setup]** Dialog Box

15. Touch the **{MEAS MODE}** button on the function bar.
16. Touch the **cdma2000** key on the soft menu bar.  
The measurement mode is set to cdma2000.
17. Touch the **{MEAS SETUP}** button on the function bar.
18. Touch the **Meas Parameters** key on the soft menu bar.  
The **[Measurement Parameters Setup]** dialog box appears.

## 9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE

19. Set the **[User Table]** option button to **[NOT USE]**.  
If this is set, the user table is not used.
20. Touch the **[Meas Length]** text box and press **[1]**, **[5]**, **[3]**, **[6]**, and **[ENT]** on the keypad.  
The measurement length is set to 1536 chips.
21. Set the **[PN Delay Search]** option button to **[ON]**.  
The PN Delay Search function is set to ON.
22. Set the **[Freq Meas Range]** option button to **[NORMAL]**.  
The frequency error measurement range is set to the NORMAL mode.
23. Touch the **[Threshold Level]** text box and press **[-]**, **[2]**, **[3]**, and **[ENT]** on the keypad.  
The threshold value that is used for the transmission channel (active channel) judgment is set to -23 dB.
24. Set the **[IQ Origin Offset]** option button to **[INCLUDE]**.  
The mode, in which the analysis is performed including the IQ origin offset, is set.
25. Set the **[Peak Inact CH Component]** option button to **[Both Inact]**.  
The Peak value of p is acquired in channels in which both I and Q signals are inactive.
26. Set the **[ $\Delta\tau$ ]** option button to **[ON]**.  
 $\Delta\tau$  is added to the measuring items.
27. Set the **[ $\Delta\theta$ ]** option button to **[ON]**.  
 $\Delta\theta$  is added to the measuring items.
28. Set the **[Chip Rate Error]** option button to **[ON]**.  
Chip Rate Error is added to the measurement items.
29. Set the **[Quadrature Error]** option button to **[ON]**.  
Quadrature Error is added to the measurement items.
30. Set the **[Walsh Code Length]** option button to **[64]**.  
The length of the Walsh code to be analyzed is set to 64.

9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE




Figure 9-7 [Measurement Parameters Setup] Dialog Box of cdma2000 MODE

31. Touch **Return** on the soft menu bar to close the [Measurement Parameters Setup] dialog box.
32. Press the **SINGLE** button on the front panel.  
The Single measurement is performed and the measurement results are displayed.




Figure 9-8 Results from the Mobile Station Code Multiplex Signal Measured in the cdma2000 MODE



## 9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE

---

**IMPORTANT:** *If [User Table] is not used, the transmission channel is automatically detected in this instrument. An error may occur in the detection of the transmission channel depending on the influence of data patterns and noise. In such a case, the transmission channel can be determined by using [User Table]. For more information on how to use [User Table], refer to A.1, "Technical Data."*

---

## Upper left window

$\rho$		Waveform quality of the multiplex signal
$\tau$		Delay from the trigger ( $\mu\text{s}$ )
PN Delay		Delay time from the head of Pilot PN Sequence and is a multiple of 64 chips from 0 to 511
Freq Error		Carrier frequency error (Hz, ppm)
Mag Error		Magnitude error of the multiplex signal (%rms)
Phase Error		Phase error of the multiplex signal (deg.rms)
EVM		Error Vector Magnitude of the multiplex signal (%rms)
IQ Org Offset		IQ origin offset (dBc)
Tx Power		Transmission power (dBm, W)
Pilot Power		Power of the pilot channel (dBm, W)
Peak Inact $\rho$	CH	The maximum logarithmic value of the Code Domain Power coefficient of the inactive channel, the Walsh code length, the Walsh code number, and components of the peak inactive $\rho$ channel
Peak $\Delta\tau$	CH	The maximum value of the relative Walsh code domain time offset in relation to the Pilot channel, the Walsh code length, the Walsh code number, and components of the peak $\Delta\tau$ channel
Peak $\Delta\theta$	CH	The maximum value of the relative Walsh code domain phase offset in relation to the Pilot channel, the Walsh code length, the Walsh code number, and components of the peak $\Delta\theta$ channel
Chip Rate Error		Chip rate error (ppm) in relation to 1.2288 Mcps
Quad Error		Q-axis quadrature error (deg) in relation to the I-axis
Active CH		Number of transmission channels
Active I Code		Number of active codes in the I-component
Active Q Code		Number of active codes in the Q-component

## Upper right window

Horizontal axis: Code

Vertical axis:  $\rho(I)$  (dB)

## 9.2 Code Domain Power Measurement of the Mobile Station Signal in the cdma2000 MODE

Lower left window

Horizontal axis: Code

Vertical axis:  $p(\text{dB})$

Lower right window


Horizontal axis: Code

Vertical axis:  $p(Q)$  (dB)

## 10. MENU MAP, FUNCTIONAL EXPLANATION (Uplink)

This chapter describes the configurations and functions of the soft keys displayed on the touch screen of the cdma2000 modulation analysis software.

### MEMO:

- [.....] *Used to enclose a menu name, key name, item name in the dialog box, button name, or the name of selected items in lists and menus.*
- {....} *Shows a function button on the function bar.*
-  *Shows a soft key on the soft menu bar.*
- *A dialog box is surrounded by a broken line.*
- *Operations are supposed to be made through the touch screen and "touch" means to press a button or a key.*

### 10.1 Menu Index


Operation Key	Pages	Operation Key	Pages
[ $\Delta\theta$ (I) vs Code]	10-11, 10-13	Line	10-11
[ $\Delta\theta$ (Q) vs Code]	10-11, 10-13	Link	10-16
[ $\Delta\theta$ ]	10-6, 10-8	Prcamp On/Off	10-17
[ $\Delta\tau$ (I) vs Code]	10-11, 10-13	Quad Display	10-11, 10-12
[ $\Delta\tau$ (Q) vs Code]	10-11, 10-13	Ref Level	10-17
[ $\Delta\tau$ ]	10-6, 10-8	Ref Offset	10-17
[ $\rho$ vs Code]	10-11, 10-12	Return	10-5, 10-8, 10-10, 10-13, 10-16
[ $\rho$ (I) vs Code]	10-11, 10-13	Single Display	10-11, 10-12
[ $\rho$ (Q) vs Code]	10-11, 10-13	Table	10-11
ATT	10-17	Trace & Dot	10-11
Active CH. Marker	10-14	User Table	10-6, 10-8
Analysis Restart	10-5, 10-6	Trigger Delay	10-16
Average	10-5, 10-6, 10-11	Trigger Slope	10-16
Auto Level Set	10-17	Trigger Source	10-16
Center	10-18	Window Format	10-11, 10-12
Channel Number	10-18	X Scale Left	10-11, 10-13
Dot	10-11	Y Scale Lower	10-11, 10-13
Dual Display	10-11, 10-12	X Scale Right	10-11, 10-13
Ext1	10-16	Y Scale Upper	10-11, 10-13
Ext2	10-16	[ACKCH Walsh Func]	10-6, 10-9
Graph	10-11	[CQICH Walsh Func]	10-6, 10-9
Free Run	10-16	[Baseband Input]	10-15
Freq Offset	10-18	[Chip Rate Error]	10-6, 10-8
IF Power	10-16	[Code Power vs Code]	10-11, 10-13
Input Setup	10-15	[Constellation]	10-11, 10-12, 10-13
Interval On/Off	10-16	[EACH/CCCH Walsh Func]	10-6, 10-9
Marker	10-14	[DCCH Walsh Func]	10-6, 10-9
Marker OFF	10-14	[EVM vs Chip]	10-11, 10-12,
Meas Parameters	10-5, 10-6		
Min ATT	10-17		

10.1 Menu Index

[Display Type] .....	10-11, 10-12, 10-13	{MEAS MODE} .....	10-4
[Dot] .....	10-12, 10-13	{MEAS SETUP} .....	10-5, 10-6
[FCH Walsh Func] .....	10-6, 10-10	{LEVEL} .....	10-17
[Format] .....	10-11, 10-12	{MKR} .....	10-14
[Graph] .....	10-13	{TRIGGER} .....	10-16
[Freq Meas Range] .....	10-5, 10-6, 10-7		
[I Eye Diagram] .....	10-11, 10-12, 10-13		
[IQ Inverse] .....	10-15		
[IQ Origin Offset] .....	10-5, 10-6, 10-7		
[Input] .....	10-15		
[Mag Error vs Chip] .....	10-11, 10-12, 10-13		
[Meas Length] .....	10-5, 10-6		
[Line] .....	10-12, 10-13		
[Modulation] .....	10-6, 10-9, 10-10		
[Null Offset Constellation] .....	10-11, 10-12		
[Null Offset I Eye Diagram] .....	10-11, 10-12		
[Null Offset Q Eye Diagram] .....	10-11, 10-12		
[Q Eye Diagram] .....	10-11, 10-12, 10-13		
[PDCCH Walsh Func] .....	10-6, 10-9		
[PDCH Walsh Func] .....	10-6, 10-10		
[PN Delay] .....	10-6, 10-7		
[PN Delay Search] .....	10-6		
[Peak Inact CH Component] .....	10-6, 10-7		
[Phase Error vs Chip] .....	10-11, 10-12, 10-13		
[Quadrature Error] .....	10-6, 10-8		
[SCH1 Walsh Func] .....	10-6, 10-10		
[SCH2 Walsh Func] .....	10-6, 10-10		
[REQCH Walsh Func] .....	10-6, 10-9		
[SPICH Walsh Func] .....	10-6, 10-9		
[Repetition Factor] .....	10-6, 10-10		
[Table] .....	10-13		
[Threshold Level] .....	10-6, 10-7		
[Total Result] .....	10-11, 10-12		
[Trace & Dot] .....	10-12, 10-13		
[User Table] .....	10-6		
[Walsh Code Length] .....	10-6, 10-8		
[vs Code] .....	10-11, 10-13		
cdma2000 .....	10-4		
cdmaOne .....	10-4		
{DISPLAY} .....	10-11		
{FREQ} .....	10-18		
{INPUT} .....	10-15		

## 10.2 Switching Communication Systems

The menu bar of this option is arranged as follows:



The menu bar consists of the same items as those of Spectrum Analyzer.

Select **[Modulation Analyzer]** from **[Config]** on the menu bar to select a modulation analysis function.

Select **[cdma2000 UL]** from **[Modulation]** on the menu bar to select the cdma2000Uplink modulation analysis function.

## 10.3 Function Bar

This section describes the functions of each function button displayed on the function bar. The configuration of the function buttons of this option is as follows:



When you click a function button on the function bar, the associated soft keys are displayed on the soft menu bar.

## 10.4 Soft Menu Bar

The area located on the right-hand side of the screen and in which soft keys are displayed is called the soft menu bar.

When you touch a button on the function bar, the associated soft keys are displayed on the soft menu bar.


## 10.5 Description of the Function of Each Key

### 10.5 Description of the Function of Each Key

This section describes the function of each key.

#### 10.5.1 {MEAS MODE}

When you touch the {MEAS SETUP} button, the soft keys related to the selection of the measurement mode are displayed on the soft menu bar.



**cdmaOne**

If **cdmaOne** is touched, the cdmaOne mode is selected. In the cdmaOne mode, the Offset QPSK signal, which is not a code multiplex signal and is compliant with RC1 and RC2 (Radio Configuration) standards, is analyzed.


**cdma2000**

If **cdma2000** is touched, the cdma2000 mode is selected. In the cdma2000 mode, the code domain analysis of the code multiplex signal, which is compliant with RC3, RC4, and RC7 standards, is performed.

## 10.5.2 {MEAS SETUP}

When you touch the {MEAS SETUP} button, the soft keys related to the analysis parameter setting are displayed on the soft menu bar.

When **cdmaOne** is selected from {MEAS MODE}.



### Analysis Restart

The measurement of the AD data, which has already been obtained, re-starts.

### Meas Parameters

The dialog box used to set the measurement conditions appears.

#### [Meas Length]

Used to enter the measurement range in chips.

#### [Freq Meas Range]

Sets whether to expand a frequency error measurement range when the measurement is performed.

NORMAL:

Does not expand a frequency error measurement range.

---

**MEMO:** Use this mode when signals exist in an adjacent channel or measuring a noisy signal.

---

EXPAND: Expands a frequency error measurement range.

#### [IQ Origin Offset]

Selects whether to include the IQ origin offset when the analysis is performed.

INCLUDE:

Includes the IQ origin offset when the analysis is performed.

EXCLUDE:

Excludes the IQ origin offset when the analysis is performed.

### Return

When **Return** is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

### Average


Selects the averaging process.

On: Performs the averaging process a set number of times for the measurement items in **[Total Result]**.

Off: Does not perform the averaging process.

10.5.2 {MEAS SETUP}

When **cdma2000** is selected from {MEAS MODE}.



**Analysis Restart**

The measurement of the AD data, which has already been obtained, re-starts.

**Meas Parameters**

The dialog box used to set the measurement conditions appears.

**[User Table]**

Selects whether to refer to a channel set by the user and to perform the analysis when the measurement is performed. If a transmission channel is known, the transmission channel can be determined by using the user table.

USE: Determines the transmission channel according to the user table.

NOT USE: The transmission channel is automatically determined.

**[Meas Length]**

Sets the measurement length in chips.

**[PN Delay Search]**

Sets the PN Delay search to ON or OFF.



	ON:	Searches the acquired signal for PN Delay if the relationship between the external trigger and PN Delay of the input signal is unknown.
	OFF:	Set to OFF and set PN Delay if the relationship between the external trigger and PN Delay of the input signal is known.
<b>[PN Delay]</b>		Sets the Pilot PN Sequence synchronization position to a multiple of 64 chips from 0 to 511.
<b>[Freq Meas Range]</b>		Sets whether to expand the frequency error measurement range when the measurement is performed.
	NORMAL:	Does not expand the frequency error measurement range.
	EXPAND:	Expands the frequency error measurement range.
<b>[Threshold Level]</b>		Sets the threshold level to determine the transmission channel (active channel). Set the threshold level to a value which is higher than the noise floor and lower than the signal.
	<i>MEMO:</i>	<i>If the set threshold level is too high, an active channel is incorrectly determined as an inactive channel. Accordingly, the <math>\rho</math> and modulation accuracy values are less accurate than the actual values, and the measurement cannot be performed correctly.</i>
<b>[IQ Origin Offset]</b>		Selects whether to include the IQ origin offset when the analysis is performed.
	INCLUDE:	Includes the IQ origin offset when the analysis is performed.
	EXCLUDE:	Excludes the IQ origin offset when the analysis is performed.
	<i>MEMO:</i>	<i>The IQ origin offset is always excluded when <math>\Delta\tau</math>, <math>\Delta\theta</math>, Chip Rate Error, and Quad Error are analyzed.</i>
<b>[Peak Inact CH Component]</b>		Selects the definition of an inactive channel.
	Both Inact:	A channel, in which both I and Q signals are inactive, is defined as the inactive channel and the maximum $\rho$ in the I and Q signals is defined as Peak Inact $\rho$ .
	Either Inact:	A channel, in which at least either I or Q signal is inactive, is defined as the inactive channel and the maximum $\rho$ in the I and Q signals is defined as Peak Inact $\rho$ .

10.5.2 {MEAS SETUP}

[ $\Delta\tau$ ]	<p>Selects whether to measure the delay time for each channel in relation to the pilot channel. The delay time for each channel is displayed as positive if the channel is delayed in relation to the pilot channel.</p> <p>ON: Measures the delay time.</p> <p>OFF: Does not measure the delay time.</p>
[ $\Delta\theta$ ]	<p>Selects whether to measure the phase difference for each channel in relation to the pilot channel.</p> <p>ON: Measures the phase difference.</p> <p>OFF: Does not measure the phase difference.</p>
[Chip Rate Error]	<p>Selects whether to measure the chip rate error in relation to 1.2288 Mcps.</p> <p>ON: Measures the chip rate error.</p> <p>OFF: Does not measure the chip rate error.</p>
[Quadrature Error]	<p>Selects whether to measure the difference of an angle between I-axis and Q-axis in relation to the angle of 90 degrees.</p> <p>ON: Measures the angle difference from the angle of 90 degrees.</p> <p>OFF: Does not measure the angle difference from the angle of 90 degrees.</p>
[Walsh Code Length]	<p>Sets the Walsh code length in the code domain analysis.</p> <p>16: Sets the Walsh code length to 16 and performs the code domain analysis.</p> <p>32: Sets the Walsh code length to 32 and performs the code domain analysis.</p> <p>64: Sets the Walsh code length to 64 and performs the code domain analysis.</p>
[Return]	<p>When [Return] is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.</p>
[User Table]	<p>The User Table dialog box is displayed. The channels defined here are enabled when [User Table] is set to USE.</p> <p>The abbreviation of each channel name is as follows:</p> <p>SPICH: Secondary Pilot Channel</p> <p>EACH: Enhanced Access Channel</p> <p>CCCH: Common Control Channel</p> <p>PDCCH: Packet Data Control Channel</p> <p>REQCH: Request Channel</p> <p>DCCH: Dedicated Control Channel</p> <p>ACKCH: Acknowledgment Channel</p> <p>CQICH: Channel Quality Indicator Channel</p> <p>FCH: Fundamental Channel</p>

	SCH1:	Supplemental Channel 1
	SCH2:	Supplemental Channel 2
	PDCH:	Packet Data Channel
<b>[SPICH Walsh Func]</b>		Sets SPICH.
	OFF:	Sets the condition in which no SPICH is transmitted.
	W64(32):	Sets the Walsh function of SPICH to $W_{32}^{64}$ and sets the condition in which SPICH is transmitted.
<b>[EACH/CCCH Walsh Func]</b>		Sets EACH or CCCH.
	OFF:	Sets the condition in which no EACH or CCCH is transmitted.
	W8(2):	Sets the Walsh function of EACH or CCCH to $W_2^8$ and sets the condition in which EACH or CCCH is transmitted.
<b>[PDCCH Walsh Func]</b>		Sets PDCCH.
	OFF:	Sets the condition in which no PDCCH is transmitted.
	W64(48):	Sets the Walsh function of PDCCH to $W_{48}^{64}$ and sets the condition in which PDCCH is transmitted.
<b>[REQCH Walsh Func]</b>		Sets REQCH.
	OFF:	Sets the condition in which no REQCH is transmitted.
	W16(8):	Sets the Walsh function of REQCH to $W_8^{16}$ and sets the condition in which REQCH is transmitted.
<b>[DCCH Walsh Func]</b>		Sets DCCH.
	OFF:	Sets the condition in which no DCCH is transmitted.
	W16(8):	Sets the Walsh function of DCCH to $W_8^{16}$ and sets the condition in which DCCH is transmitted.
<b>[ACKCH Walsh Func]</b>		Sets ACKCH.
	OFF:	Sets the condition in which no ACKCH is transmitted.
	W64(16):	Sets the Walsh function of ACKCH to $W_{16}^{64}$ and sets the condition in which ACKCH is transmitted.
<b>[CQICH Walsh Func]</b>		Sets CQICH.
	OFF:	Sets the condition in which no CQICH is transmitted.
	W16(12):	Sets the Walsh function of CQICH to $W_{12}^{16}$ and sets the condition in which CQICH is transmitted.
<b>[Modulation]</b>		Sets the modulation format of CQICH.
	BPSK(I):	Allocates the channel to the I-side and sets the modulation format to BPSK.
	BPSK(Q):	Allocates the channel to the Q-side and sets the modulation format to BPSK.

10.5.2 {MEAS SETUP}

<b>[FCH Walsh Func]</b>	<p>Sets FCH.</p> <p>OFF: Sets the condition in which no FCH is transmitted.</p> <p>W16(4): Sets the Walsh function of FCH to <math>W_4^{16}</math> and sets the condition in which FCH is transmitted.</p>
<b>[SCH1 Walsh Func]</b>	<p>Sets SCH1.</p> <p>OFF: Sets the condition in which no SCH1 is transmitted.</p> <p>W2(1): Sets the Walsh function of SCH1 to <math>W_1^2</math> and sets the condition in which SCH1 is transmitted.</p> <p>W4(2): Sets the Walsh function of SCH1 to <math>W_2^4</math> and sets the condition in which SCH1 is transmitted.</p>
<b>[Repetition Factor]</b>	<p>Sets the number of times the Walsh function of SCH1 is repeated.</p>
<b>[SCH2 Walsh Func]</b>	<p>Sets SCH2.</p> <p>OFF: Sets the condition in which no SCH2 is transmitted.</p> <p>W4(2): Sets the Walsh function of SCH2 to <math>W_2^4</math> and sets the condition in which SCH2 is transmitted.</p> <p>W8(6): Sets the Walsh function of SCH2 to <math>W_6^8</math> and sets the condition in which SCH2 is transmitted.</p>
<b>[Repetition Factor]</b>	<p>Sets the number of times the Walsh function of SCH2 is repeated.</p>
<b>[PDCH Walsh Func]</b>	<p>Sets PDCH.</p> <p>OFF: Sets the condition in which no PDCH is transmitted.</p> <p>W2(1): Sets the Walsh function of PDCH to <math>W_1^2</math> and sets the condition in which PDCH is transmitted.</p> <p>W4(2): Sets the Walsh function of PDCH to <math>W_2^4</math> and sets the condition in which PDCH is transmitted.</p> <p>W2(1)&amp;W4(2): Sets the Walsh function of PDCH to <math>W_1^2</math> and <math>W_2^4</math> and sets the condition in which PDCH is transmitted.</p>
<b>[Modulation]</b>	<p>Sets the modulation format of PDCH.</p> <p>BPSK(I): Allocates the channel to the I-side and sets the modulation format to BPSK.</p> <p>QPSK: Sets the modulation format to QPSK.</p> <p>8PSK: Sets the modulation format to 8PSK.</p>

---

**MEMO:** *The same Walsh function number as the number, which has been already set, cannot be set because the orthogonality of the code is not satisfied.*

---

**Return**

When **Return** is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.

**Average**

Selects the averaging process.

On: Performs the averaging process a set number of times for the measurement items in **[Total Result]**.

Off: Does not perform the averaging process.


---

**MEMO:** *The value displayed in each peak display item is either the maximum value or maximum deviation from zero in each measurement result.*

---

### 10.5.3 {DISPLAY}

When you touch the {DISPLAY} button, the soft keys related to the display screen setup are displayed on the soft menu bar.



10.5.3 {DISPLAY}

**Single Display** Displays a single window. Zooms in the upper left window when the 4-window display mode is set.

**Dual Display** Displays two windows. Zooms in the upper two windows when the 4-window display mode is set.

**Quad Display** Displays four windows.

When **cdmaOne** is selected from {MEAS MODE}.

**Window Format** If **Window Format** is touched, the dialog box that is used to set the measurement result window is displayed.

- [Format]** Selects the measurement result window to be displayed.
- [Total Result]** Displays the analyzed numerical result.
- [Constellation]** Displays the constellation.
- [I Eye Diagram]** Displays the EYE pattern of the I signal.
- [Q Eye Diagram]** Displays the EYE pattern of the Q signal.
- [Null Offset Constellation]** Displays a constellation, in which the filtering process is performed so that the I and Q offsets are canceled and chip positions converge.
- [Null Offset I Eye Diagram]** Displays an EYE pattern of the I signal, in which the filtering process is performed so that the I and Q offsets are canceled and chip positions converge.
- [Null Offset Q Eye Diagram]** Displays an EYE pattern of the Q signal, in which the filtering process is performed so that the I and Q offsets are canceled and chip positions converge.
- [EVM vs Chip]** Displays the EVM for each one-half chip on a graph.
- [Mag Error vs Chip]** Displays the magnitude error for each one-half chip on a graph.
- [Phase Error vs Chip]** Displays the phase error for each one-half chip on a graph.
- [Display Type]** Sets the display type of a graph which is selected in **[Format]**.
- [Constellation]** Selects whether to display either one-half chip positions or one-half chip positions and transition lines between one-half chip positions, when the constellation is displayed on a graph.
  - [Trace & Dot]** Displays both one-half chip positions and transition lines.
  - [Line]** Displays transition lines that connect between one-half chip positions by a straight line.
  - [Dot]** Displays one-half chip positions only.

When **cdma2000** is selected from {MEAS MODE}.

**Window Format** Displays the dialog box to set the measurement result window.


- [Format]** Selects the measurement result window to be displayed.
- [Total Result]** Displays the numerical results that are analyzed as a multiplex signal.
- [ρ vs Code]** Displays the ρ for each code on a graph.

<b>[Code Power vs Code]</b>	Displays the code domain power for each code on a graph.
<b>[<math>\rho</math>(I) vs Code]</b>	Displays the $\rho$ for each code of the I signal on a graph.
<b>[<math>\rho</math>(Q) vs Code]</b>	Displays the $\rho$ for each code of the Q signal on a graph.
<b>[<math>\Delta\tau</math>(I) vs Code]</b>	Displays the delay time for each code of the I signal on a graph. The delay time for each channel is displayed as positive if the channel is delayed in relation to the pilot channel.
<b>[<math>\Delta\tau</math>(Q) vs Code]</b>	Displays the delay time for each code of the Q signal on a graph. The delay time for each channel is displayed as positive if the channel is delayed in relation to the pilot channel.
<b>[<math>\Delta\theta</math>(I) vs Code]</b>	Displays the phase difference for each channel of the I signal to the pilot channel on a graph.
<b>[<math>\Delta\theta</math>(Q) vs Code]</b>	Displays the phase difference for each channel of the Q signal to the pilot channel on a graph.
<b>[Constellation]</b>	Displays the constellation.
<b>[I Eye Diagram]</b>	Displays the EYE pattern of the I signal.
<b>[Q Eye Diagram]</b>	Displays the EYE pattern of the Q signal.
<b>[EVM vs Chip]</b>	Displays the EVM for each chip on a graph.
<b>[Mag Error vs Chip]</b>	Displays the magnitude error for each chip on a graph.
<b>[Phase Error vs Chip]</b>	Displays the phase error for each chip on a graph.
<b>[Display Type]</b>	Sets the display type of a graph which is selected in <b>[Format]</b> .
<b>[vs Code]</b>	Selects whether to display the results for each <b>[vs Code]</b> either on graphs or in lists.
<b>[Graph]</b>	Displays the results on graphs.
<b>[Table]</b>	Displays the results in lists.
<b>[Constellation]</b>	Selects whether to display either chip positions or chip positions and the transition lines between the chip positions, when the constellation is displayed on a graph.
<b>[Trace &amp; Dot]</b>	Displays both chip positions and transition lines.
<b>[Line]</b>	Displays transition lines that connect between chip positions by a straight line.
<b>[Dot]</b>	Displays chip positions only.
<b>Return</b>	When <b>Return</b> is touched, the dialog box closes and the soft key array on the soft menu bar returns to the previous menu.
<b>X Scale Left</b>	Sets the minimum value on the X-axis.
<b>X Scale Right</b>	Sets the maximum value on the X-axis.
<b>Y Scale Upper</b>	Sets the maximum value on the Y-axis.
<b>Y Scale Lower</b>	Sets the minimum value on the Y-axis.

10.5.4 {MKR}

**10.5.4 {MKR}**

When you touch the {MKR} button, the soft keys related to the marker setup are displayed on the soft menu bar.



**Marker**

Sets the X-axis position of the normal marker.

**Active CH. Marker**

Sets the code number of the transmission channel. Valid only when the graph, in which the X-axis is set to the code, is displayed.


**Marker OFF**

Hides the marker.



## 10.5.5 {INPUT}

When you touch the {INPUT} key, the soft keys related to the setting up of the input format for the measuring instrument are displayed on the soft menu bar.



### Input Setup

When you touch the **Input Setup** button, the dialog box for setting up the input format for the measuring instrument is displayed. Set up in accordance with the measurement signal.

#### [Input]

Sets the input channel for the signal.

RF: Sets the RF signal input.

Baseband (I&Q):  
Sets the IQ signal (baseband) input.

#### [Baseband Input]

Sets the coupling for the IQ signal input.

AC: Selects the AC coupling.

DC: Selects the DC coupling.

#### [IQ Inverse]

Selects whether or not to invert the phase of the signal to be measured.


ON: Inverts the signal.

OFF: Does not invert the signal.

10.5.6 {TRIGGER}

10.5.6 {TRIGGER}

When you touch the {TRIGGER} button, the soft keys related to the trigger setup are displayed on the soft menu bar.



**Trigger Source**

When you touch the **Trigger Source** button, the soft keys related to the trigger setup are displayed on the soft menu bar.

**Free Run**

Obtains and analyzes data according to the internal timing of the measuring instrument.

**IF Power**

Obtains and analyzes data synchronized with the IF signal.

**Ext1**

Synchronizes the data reading with the external signal and analyzes the data entered into the EXT TRIG IN 1 connector. The threshold level for Ext1 is fixed to the TTL level.

**Ext2**

Synchronizes the data reading with the external signal and analyzes the data entered into the EXT TRIG IN 2 connector. The threshold level for Ext2 can be set.

**Link**

Obtains and analyzes data synchronizing with the trigger of an optional function.

---

**MEMO:** For information on how to use the link trigger, refer to the manual of the option in which the link trigger is used.

---

**Return**

Returns to the previous soft key array on the soft menu bar.

**Trigger Slope**

Switches the polarity of the trigger slope.  
Available only for IF Power, Ext1, and Ext2.

+: Starts sweeping at the rise of a trigger.

-: Starts sweeping at the fall of a trigger.

**Trigger Delay**

Sets the delay time from the trigger point. Is available only for IF Power, Ext1, and Ext2. When analyzing, the start position of AD data acquisition is shifted to the delay time.

**Interval On/Off**


Sets whether to synchronize the trigger and the built-in counter, whose period is set to 80 ms.

On: Synchronizes them.

Off: Does not synchronize them.

## 10.5.7 {LEVEL}

When you touch the {LEVEL} button, the soft keys related to the setup of the attenuator and reference level are displayed on the soft menu bar.



### Auto Level Set

Sets the reference level to the optimum value in accordance with the signal to be measured. When the key is pressed, Auto Level Set is executed.

---

**CAUTION:** While Auto Level Set is being executed, the level of the signal measured must remain constant.

---

### Ref Level

Sets the reference level.

### ATT

Sets the attenuator.

Auto: Automatically sets the attenuator value based on the reference level.

Man: Sets the attenuator value.

### Min ATT

Sets the Min ATT function ON and OFF.

On: Sets the minimum attenuator value and implements control regardless of whether ATT is Auto or Manual.

Off: Cancels the Min ATT limitation.

### Preamp On/Off

Sets the preamplifier function ON and OFF.

### Ref Offset

Switches the reference level offset function ON and OFF.


On: Sets the offset value and changes only the displayed reference level by the offset value.  
(Displayed reference level = Set value + Offset value)

Off: Cancels the offset function.

10.5.8 {FREQ}

**10.5.8 {FREQ}**

When you touch the **{FREQ}** button, the soft keys related to the measurement frequency setup are displayed on the soft menu bar.



**Center**

Sets the center frequency of the measurement signal.

---

**CAUTION:** *Set the center frequency correctly. If it is set incorrectly, an error may occur in the center frequency error measurement and the measurement may be incorrect.*

---

**Channel Number**

When the channel number is set, the center frequency is automatically set by using the following formula.

$$(\text{Center frequency}) = (\text{Channel interval}) \times (\text{Channel number} + \text{Channel offset}) + (\text{Start frequency})$$

The parameters such as the channel interval and the channel number setting range depend on the Standard selected by **[Special] → [STD...]**. For more information, refer to the R3681 Series User's Guide.

**Freq Offset**


Switches the center frequency offset function ON and OFF.

- On: Sets the offset value and changes only the displayed center frequency by the offset value.  
(Displayed center frequency = Set value + Offset value)
- Off: Cancels the offset function.

## 10.5.9 Measurement Tool Bar

The functions of waveform range selection, active window selection, and so on are displayed as icons.

The following functions can be used by touching the icons:



: Zoom in icon:

Used to zoom in on the waveform displayed in the window. The range specified by the range specification icon is zoomed in on by touching on the range.




: Zoom out icon:

Used to zoom out from the waveform displayed in the window.



: Range specification icon (X-axis mode):

Used to specify a range in the window in which the waveform is displayed. After touching the icon, specify the range by touching two points on the graph.



: Range specification icon (range mode):

Used to specify a range in the window in which the waveform is displayed. Specify the upper-left and lower-right corners of the range by touching the display.



: Active window switching icon:

Used to make one of the split windows active.



: Range shift icon:

Used to shift the display position without changing the display range. After touching the icon, touch the inside of the graph frame in the direction to be shifted.



## 11. SCPI COMMAND REFERENCE (Uplink)

This chapter describes the SCPI command reference for this instrument.

### 11.1 Command Reference Format

This section describes the format and layout used to describe commands in this chapter.

Each description includes the following items:

Function description

SCPI command

Parameter

Query reply

- [Function description]  
The usage of commands and operations in this instrument.
- [SCPI command]  
The SCPI command displays the syntax of a command sent from the external controller to this instrument. The syntax consists of a command and a number of parameters. The command and the parameters are separated by a space.  
If a command has multiple parameters, they are separated by commas (.). The three points (...) displayed between commas represent the parameter(s) omitted at that position.  
For example, the description <numeric value 1>, ..., <numeric value 4> shows that four parameters, <numeric value 1>, <numeric value 2>, <numeric value 3>, and <numeric value 4>, are required.  
If the parameter is a character string type such as <character string>, <character string 1>, the parameter must be enclosed in double quotation marks (" "). If the parameter is <block>, it shows the block format data.  
Text written in lowercase alphabetic characters in the syntax can be omitted.  
For example, ":CALibration:CABLe" can be abbreviated to ":CAL:CABL."  
The marks used in the syntax are defined as follows:
 

< >:	Shows a parameter required for sending a command
[ ]:	Shows that the command is optional It can be omitted
{ }:	Shows that only one item is required to be selected from multiple items
:	Used as a delimiter for multiple items written in curly brackets {..}
<ch>:	Written in the command header and shows the target input channel number of the command The channel number can be omitted. However, when it is written, channel number 1 is selected
<screen>:	Written in the command header and shows the target screen number of the command The screen number can be omitted. However, when it is written, a value from 1 to 4 can be selected {{1 2 3 4}}

---

## 11.1 Command Reference Format

For example: If the syntax below is specified, `:CALC:CORR:EDEL:TIME 0.1` and `CALCULATE1:SELECTED:CORR:EDEL:TIME 25E-3` are valid.

Syntax: `CALCulate{[1]|2|3|4}[[:SELEcted]:CORRection:EDELay:TIME <numeric value>`

- [Parameter]

Describes a parameter required for sending a command.

If the parameter is numeric type or alphabetic, it is enclosed in angle brackets (<>).

If the parameter is optional, it is enclosed in curly brackets ({}).

In this manual, parameter types are described in the following formats:

< int >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to an integer in this instrument

< real >: A numeric value that can be input in the format NR1, NR2, or NR3 and rounded to a valid-digit real number in this instrument

< bool >: Either OFF or ON can be entered.

< str >: A character string enclosed in quotation (‘ ’) or double quotation (“ ”) marks.

<block>: Block data type  
The data content is an 8-bit binary data array

< type >: Character data selected from multiple types

- [Query reply]

When there is a query reply to the command, the data format used for reading the query is described.

Each parameter to be read is enclosed in curly brackets ({}). If multiple items, which are delimited by a vertical bar (|), exist in curly brackets ({}), only one of those items is read out. If parameters are delimited by commas (,) multiple parameters can be read out. The three points (...) displayed between commas represent data omitted from that position. For example, the description {numeric value 1},..., {numeric value 4} shows that four parameters {numeric value 1}, {numeric value 2}, {numeric value 3}, and {numeric value 4} are read.

If the parameter to be read is enclosed in square brackets ([ ]), the parameter may be omitted, depending on the measurement result, etc.

If the parameter to be read is a value in a unit, a description such as “Unit: dBm” is added to display the unit of the parameter value. However, only when the parameter is described in a level unit “dBm”, the level unit selected at that time will be applied to the parameter.



## 11.2 Common Commands

This section describes common IEEE commands.

Function description	SCPI Command	Parameter	Query reply	Remarks
Clears the status byte and related data	*CLS	-	-	
Macro definition for GET	*DDT	<block>	<block>	*1
Sets the standard event status enable register	*ESE	<int>	<int>	
Reads the standard event status register	*ESR?	-	<int>	
Device inquiry	*IDN?	-	<str>	*2
Notifies when all running operations are complete	*OPC	-	1	
Loads the device settings	*RCL	<int> POFF	-	*3
Resets the device	*RST	-	-	
Saves the device settings	*SAV	<int>	<int>	
Sets the service request enable register	*SRE	<int>	<int>	
Reads the status byte register	*STB?	-	<int>	
Triggers the device	*TRG	-	-	
Waits until all running operations are complete	*WAI	-	-	

\*1: If the \*DDT? command is executed when the macro is undefined, a zero-length block data (#10) is returned.

\*2: <str> is output in the following format: maker name, model name, serial number and version number.

\*3: POFF indicates the parameter settings when the power was last switched off.

11.3 List of Commands

**11.3 List of Commands**

**11.3.1 Subsystem-SYSTEM**

Function description	SCPI command	Parameter	Query reply	Remarks
Config				
Measurement system selection	:SYSTEM:SELEct	SANalyzer MANalyzer	SAN MAN	
Modulation				
Modulation analysis system selection	:SYStem:SELEct:MODulation	CDMA2KUL	CDMA2KUL	
Preset				
Each measurement system parameter initialization	:SYStem:PRESet	-	-	
All measurement systems initialization	:SYStem:PRESet:ALL	-	-	
Log				
Inquiry about the error that occurred last	:SYStem:ERRor?	-	<int>,<str>	
Inquiry about the details of the error log	:SYStem:ERRor:ALL?	-	<int>,<str>	

**11.3.2 Subsystem-INPut**

Function description	SCPI command	Parameter	Query reply	Remarks
ATT/Preamplifier				
ATT setting	:INPut:ATTenuation	<real>	<real>	
ATT Auto/Manual	:INPut:ATTenuation:AUTO	OFF ON	OFF ON	
Min ATT setting	:INPut:ATTenuation:MINimum	<real>	<real>	
Min ATT ON/OFF	:INPut:ATTenuation:MINimum:STATe	OFF ON	OFF ON	
Preamplifier ON/OFF	:INPut:GAIN:STATe	OFF ON	OFF ON	
Input Setup				
Input Signal RF/Baseband	:INPut:SIGNal	RF BASEband	RF BAS	
Baseband Input AC/DC	:INPut:BASEband	AC DC	AC DC	
IQ Inverse ON/OFF	:INPut:IQ:INVerse	OFF ON	OFF ON	

### 11.3.3 Subsystem-CONFigure

Function description	SCPI command	Parameter	Query reply	Remarks
Mcas Mode				
Switching the mode to cdmaOne	:CONFigure:CDMAONE	-	-	
Switching the mode to cdma2000	:CONFigure:CDMA2K	-	-	

### 11.3.4 Subsystem-SENSe

Function description	SCPI command	Parameter	Query reply	Remarks
Frequency				
Center Freq setting	[:SENSe]:FREQuency:CENTer	<real>	<real>	
Freq Offset setting	[:SENSe]:FREQuency:OFFSet	<real>	<real>	
Freq Offset ON/OFF	[:SENSe]:FREQuency:OFFSet:STATe	OFF ON	OFF ON	
Channel Number setting	[:SENSe]:FREQuency:CHANnel:NUMBer	<int>	<int>	
Auto Level Set				
Auto Level Set execution	[:SENSe]:POWer:LEVel:AUTO	-	-	
Meas Parameters (cdmaOne mode)				
Meas Length setting	[:SENSe]:CONDition:CDMAONE:MLENght	<int>	<int>	
Freq Meas Range setting	[:SENSe]:CONDition:CDMAONE:FMRange	NORMal EXPand	NORM EXP	
IQ Origin Offset setting	[:SENSe]:CONDition:CDMAONE:IQOffset	INCLude EXCLude	INCL EXCL	
Average (cdmaOne mode)				
Average ON/OFF	[:SENSe]:CONDition:CDMAONE:AVERAge[:STATe]	OFF ON	OFF ON	
Average setting	[:SENSe]:CONDition:CDMAONE:AVERAge:COUNT	<int>	<int>	
Meas Parameters (cdma2000 mode)				
User Table setting	[:SENSe]:CONDition:UTABle	NOT USE	NOT USE	
Meas Length setting	[:SENSe]:CONDition:MLENght	<int>	<int>	
PN Delay Search ON/OFF	[:SENSe]:CONDition:PNDSearch	OFF ON	OFF ON	
PN Delay setting	[:SENSe]:CONDition:PNDelay	<int>	<int>	
Freq Meas Range setting	[:SENSe]:CONDition:FMRange	NORMal EXPand	NORM EXP	
Threshold Level setting	[:SENSe]:CONDition:THReashold	<int>	<int>	
IQ Origin Offset setting	[:SENSe]:CONDition:IQOffset	INCLude EXCLude	INCL EXCL	
Peak Inact CH Component setting	[:SENSe]:CONDition:PICComponent	BOTH EITHer	BOTH EITH	
$\Delta\tau$ ON/OFF	[:SENSe]:CONDition:DTAU	OFF ON	OFF ON	
$\Delta\theta$ ON/OFF	[:SENSe]:CONDition:DTHeta	OFF ON	OFF ON	

11.3.4 Subsystem-SENSE

Function description	SCPI command	Parameter	Query reply	Remarks
Chip Rate Error ON/OFF	[[:SENSE]:CONDition:CRError	OFF ON	OFF ON	
Quadrature Error ON/OFF	[[:SENSE]:CONDition:QERRor	OFF ON	OFF ON	
Walsh Code Length setting	[[:SENSE]:CONDition:WCLength	<int>	<int>	
User Table (cdma2000 mode)				
SPICH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:SPICH:WFUNcIion	OFF W32C64	OFF W32C64	
EACH/CCCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:EACCCH:WFUNcIion	OFF W2C8	OFF W2C8	
PDCCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:PDcCH:WFUNcIion	OFF W48C64	OFF W48C64	
REQCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:REQCH:WFUNcIion	OFF W8C16	OFF W8C16	
DCCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:DCcH:WFUNcIion	OFF W8C16	OFF W8C16	
ACKCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:ACKCH:WFUNcIion	OFF W16C64	OFF W16C64	
CQICH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:CQICH:WFUNcIion	OFF W12C16	OFF W12C16	
CQICH Modulation setting	[[:SENSE]:CONDition:UTABLE:CQICH:MODulation	BPSK  BPSKQ	BPSK  BPSKQ	
FCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:FCH:WFUNcIion	OFF W4C16	OFF W4C16	
SCH1 Walsh Function setting	[[:SENSE]:CONDition:UTABLE:Sch1:WFUNcIion	OFF W1C2  W2C4	OFF W1C2  W2C4	
SCH1 Repetition Factor setting	[[:SENSE]:CONDition:UTABLE:Sch1:RFAcTOr	<int>	<int>	
SCH2 Walsh Function setting	[[:SENSE]:CONDition:UTABLE:Sch2:WFUNcIion	OFF W2C4  W6C8	OFF W2C4  W6C8	
SCH2 Repetition Factor setting	[[:SENSE]:CONDition:UTABLE:Sch2:RFAcTOr	<int>	<int>	
PDCH Walsh Function setting	[[:SENSE]:CONDition:UTABLE:PDcH:WFUNcIion	OFF W1C2  W2C4  W1C2W2C4	OFF W1C2  W2C4  W1C2W2C4	
PDCH Modulation setting	[[:SENSE]:CONDition:UTABLE:PDcH:MODulation	BPSK QPSK  PSK8	BPSK QPSK  PSK8	
Average (cdma2000 mode)				
Average ON/OFF	[[:SENSE]:CONDition:AVERAge[:STATe]	OFF ON	OFF ON	
Average setting	[[:SENSE]:CONDition:AVERAge:COUNt	<int>	<int>	

### 11.3.5 Subsystem-TRIGger

Function description	SCPI command	Parameter	Query reply	Remarks
Trigger				
Trigger Source setting	:TRIGger[:SEQuence]:SOURce	IMMediate IF EXTErnal1 EXTErnal2 LINK	IMM IF EXT1 EXT2 LINK	
IF Power setting	:TRIGger[:SEQuence]:LEVel:IF	<real>	<real>	
Ext2 Trigger Level setting	:TRIGger[:SEQuence]:LEVel:EXTErnal	<real>	<real>	
Trigger Slope +/-	:TRIGger[:SEQuence]:SLOPe	POSitive NEGative	POS NEG	
Trigger Delay setting	:TRIGger[:SEQuence]:DELay	<real>	<real>	
Interval ON/OFF	:TRIGger[:SEQuence]:INTerval:STATe	OFF ON	OFF ON	

### 11.3.6 Subsystem-INITiate

Function description	SCPI command	Parameter	Query reply	Remarks
INITiate				
Single measurement execution	:INITiate:MEASure:SINGLE	-	-	
Repeat measurement execution	:INITiate:MEASure:REPeat	-	-	
Analysis Restart execution	:INITiate:REStart	-	-	
Stop execution	:INITiate:ABORt	-	-	

11.3.7 Subsystem-CALCulate

**11.3.7 Subsystem-CALCulate**

Function description	SCPI command	Parameter	Query reply	Remarks
Marker				
Marker ON/OFF	:CALCulate:MARKer<scm=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Active CH Marker ON/OFF	:CALCulate:ACMarker<scm=1 2 3 4>[:STATe]	OFF ON	OFF ON	
Marker position setting Constellation I Eye Diagram Q Eye Diagram Null Offset Constellation Null Offset I Eye Diagram Null Offset Q Eye Diagram	:CALCulate:MARKer<scm=1 2 3 4>:CHIP	<int>	<int>	<Chip No.>
Marker I reading Constellation I Eye Diagram Null Offset Constellation Null Offset I Eye Diagram	:CALCulate:MARKer<scm=1 2 3 4>:I	-	<real>	<I>
Marker Q reading Constellation Q Eye Diagram Null Offset Constellation Null Offset Q Eye Diagram	:CALCulate:MARKer<scm=1 2 3 4>:Q	-	<real>	<Q>
Marker X setting EVM vs Chip Mag Error vs Chip Phase Error vs Chip	:CALCulate:MARKer<scm=1 2 3 4>:X	<real>	<real>	<Chip No.>
Marker Y reading EVM vs Chip	:CALCulate:MARKer<scm=1 2 3 4>:Y	-	<real>	<EVM>
Marker Y reading Mag Error vs Chip	:CALCulate:MARKer<scm=1 2 3 4>:Y	-	<real>	<Mag Error>
Marker Y reading Phase Error vs Chip	:CALCulate:MARKer<scm=1 2 3 4>:Y	-	<real>	<Phase Error>
Marker X setting p(I) vs Code p(Q) vs Code p vs Code Code Power vs Code	:CALCulate:MARKer<scm=1 2 3 4>:X	<real>	<real>	<Marker Pos>
Marker Y reading p(I) vs Code p(Q) vs Code	:CALCulate:MARKer<scm=1 2 3 4>:Y	-	<int>, <int>, <real>, <real>	<Walsh Len>, <Walsh Code>, <Rate>, <p>
Marker Y reading p vs Code Code Power vs Code	:CALCulate:MARKer<scm=1 2 3 4>:Y	-	<int>, <int>, <real>, <real>, <real>, <real>	<Walsh Len>, <Walsh Code>, <Rate>, <p>, <Power[dB]>, <Power[W]>

Function description	SCPI command	Parameter	Query reply	Remarks
Active CH. Marker X setting $\rho(I)$ vs Code $\rho(Q)$ vs Code $\Delta\tau(I)$ vs Code $\Delta\tau(Q)$ vs Code $\Delta\theta(I)$ vs Code $\Delta\theta(Q)$ vs Code $\rho$ vs Code Code Power vs Code	:CALCulate:ACMarker<scrn=1 2 3 4>:X	<real>	<real>	<Marker Pos>
Active CH. Marker Y reading $\rho(I)$ vs Code $\rho(Q)$ vs Code $\Delta\tau(I)$ vs Code $\Delta\tau(Q)$ vs Code $\Delta\theta(I)$ vs Code $\Delta\theta(Q)$ vs Code	:CALCulate:ACMarker<scrn=1 2 3 4>:Y	–	<int>, <int>, <real>, <real>, <string>, <real>, <real>	<Walsh Len>, <Walsh Code>, <Rate>, < $\rho$ >, <"BPSK"  "QPSK"  "8PSK">, < $\Delta\tau$ >, < $\Delta\theta$ >
Active CH. Marker Y reading $\rho$ vs Code Code Power vs Code	:CALCulate:ACMarker<scrn=1 2 3 4>:Y	–	<int>, <int>, <real>, <real>, <real>, <real>, <string>	<Walsh Len>, <Walsh Code>, <Rate>, < $\rho$ >, <Power[dB]>, <Power[W]>, <"BPSK"  "QPSK"  "8PSK">

11.3.8 Subsystem-DISPlay

**11.3.8 Subsystem-DISPlay**

Function description	SCPI command	Parameter	Query reply	Remarks
<b>Level</b>				
Ref Level setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel	<real>	<real>	
Ref Offset setting	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFFSet	<real>	<real>	
Ref Offset ON/OFF	:DISPlay:TRACe:Y[:SCALe]:RLEVel:OFFSet:STATe	OFF ON	OFF ON	
<b>Display</b>				
Screen division setting	:DISPlay	SINGle  DUAL QUAD	SING DUAL  QUAD	
<b>Window Format (cdmaOne mode)</b>				
Results display format selection	:DISPlay:CDMAONE:WINDow<scrn=1 2 3 4>: :FORMat	TRESult  CONStellation  IEYE QEYE  NOConstella- tion  NOIEye  NOQEye  EVM  MERRor  PERRor	TRES CONS  IEYE QEYE  NOC NOIE  NOQE EVM  MERR PERR	
Constellation Display Type selection	:DISPlay:CDMAONE:WINDow<scrn=1 2 3 4>: :CONStellation:TYPE	TDOT LINE  DOT	TDOT LINE  DOT	
<b>Window Format (cdma2000 mode)</b>				
Constellation display type selection	:DISPlay:WINDow<scrn=1 2 3 4>: :FORMat	TRESult  RHO CPOwer  IRHO QRHO  IDTau QDTau  IDTHeta  QDTHeta  CONStellation  IEYE QEYE  EVM  MERRor  PERRor	TRES RHO  CPOW IRHO  QRHO IDT  QDT IDTH  QDTH CONS  IEYE QEYE  EVM MERR  PERR	
vs Code Display Type selection	:DISPlay:WINDow<scrn=1 2 3 4>: :VSCode:TYPE	GRAPh  TABLe	GRAP TABL	
Constellation Display Type selection	:DISPlay:WINDow<scrn=1 2 3 4>: :CONStellation :TYPE	TDOT LINE  DOT	TDOT LINE  DOT	
<b>Scale</b>				
X Scale Left setting	:DISPlay[:WINDow<scrn=1 2 3 4>]: :TRACe :X[:SCALe]:LEFT	<real>	<real>	
X Scale Right setting	:DISPlay[:WINDow<scrn=1 2 3 4>]: :TRACe :X[:SCALe]:RIGHt	<real>	<real>	
Y Scale Upper setting	:DISPlay[:WINDow<scrn=1 2 3 4>]: :TRACe :Y[:SCALe]:UPPer	<real>	<real>	
Y Scale Lower setting	:DISPlay[:WINDow<scrn=1 2 3 4>]: :TRACe :Y[:SCALe]:LOWer	<real>	<real>	



### 11.3.9 Subsystem-MMEMory

Function description	SCPI command	Parameter	Query reply	Remarks
Save/Load				
Saving the settings of this instrument	:MMEMory:STORe:STATe	<int>	–	*1
Loading the settings of this instrument	:MMEMory:LOAD:STATe	<int>	–	*1
Measurement condition Save selection	:MMEMory:SELEct:ITEM:CDMA2KUL:SETup	OFF ON	OFF ON	

\*1: A number, which is a maximum of 4-digit and is added to the file name of the data to be saved or loaded, must be specified in <int>.

### 11.3.10 Subsystem-MEASure

Function description	SCPI command	Parameter	Query reply	Remarks
Measure/Read				
$\rho$ reading	:MEASure:TRESult:RHO	–	<real>	
Frequency Error reading	:MEASure:TRESult:FERRor	–	<real>,<real>	<Hz>,<ppm>
Magnitude Error reading	:MEASure:TRESult:MERRor	–	<real>	
Phase Error reading	:MEASure:TRESult:PFERRor	–	<real>	
EVM reading	:MEASure:TRESult:EVM	–	<real>	
I/Q Origin Offset reading	:MEASure:TRESult:IQOFiset	–	<real>	
Tx Power reading	:MEASure:TRESult:POWer	–	<real>,<real>	<dBm>,<W>
Pilot Power reading	:MEASure:TRESult:PPOWer	–	<real>,<real>	<dBm>,<W>
$\tau$ reading	:MEASure:TRESult:TAU	–	<real>	
PN Delay reading	:MEASure:TRESult:PNDelay	–	<int>	
Peak Inactive $\rho$ reading	:MEASure:TRESult:PIRHO	–	<real>,<int>,<int>,<string>	< $\rho $
Peak $\Delta\tau$ reading	:MEASure:TRESult:PDtau	–	<real>,<int>,<int>,<string>	< $\Delta\tau $
Peak $\Delta\theta$ reading	:MEASure:TRESult:PDTHeta	–	<real>,<int>,<int>,<string>	< $\Delta\theta $
Chip Rate Error reading	:MEASure:TRESult:CRERror	–	<real>	
Quadrature Error reading	:MEASure:TRESult:QERRor	–	<real>	

11.3.11 Subsystem-READ

Function description	SCPI command	Parameter	Query reply	Remarks
Active Channel reading	:MEASure:TRESult:ACHannel	-	<int>	
Active I Code reading	:MEASure:TRESult:ACI	-	<int>	
Active Q Code reading	:MEASure:TRESult:ACQ	-	<int>	

11.3.11 Subsystem-READ

Function description	SCPI command	Parameter	Query reply	Remarks
Measure/Rcad				
$\rho$ reading	:READ:TRESult:RHO	-	<real>	
Frequency Error reading	:READ:TRESult:FERRor	-	<real>,<real>	<Hz>,<ppm>
Magnitude Error reading	:READ:TRESult:MERRor	-	<real>	
Phase Error reading	:READ:TRESult:PERRor	-	<real>	
EVM reading	:READ:TRESult:EVM	-	<real>	
I/Q Origin Offsct reading	:READ:TRESult:IQOFfset	-	<real>	
Tx Power reading	:READ:TRESult:POWER	-	<real>,<real>	<dBm>,<W>
Pilot Power reading	:READ:TRESult:PPOWER	-	<real>,<real>	<dBm>,<W>
$\tau$ reading	:READ:TRESult:TAU	-	<real>	
PN Delay reading	:READ:TRESult:PNDelay	-	<int>	
Peak Inactive $\rho$ reading	:READ:TRESult:PIRHO	-	<real>,<int>,<int>,<string>	<p>,<Walsh Code>,<Walsh Len>,<"I","Q"or"I&Q">
Peak $\Delta\tau$ reading	:READ:TRESult:PDtau	-	<real>,<int>,<int>,<string>	< $\Delta\tau$ >,<Walsh Code>,<Walsh Len>,<"I","Q"or"I&Q">
Peak $\Delta\theta$ reading	:READ:TRESult:PDHeta	-	<real>,<int>,<int>,<string>	< $\Delta\theta$ >,<Walsh Code>,<Walsh Len>,<"I","Q"or"I&Q">
Chip Rate Error reading	:READ:TRESult:CRError	-	<real>	
Quadrature Error reading	:READ:TRESult:QERRor	-	<real>	
Active Channel reading	:READ:TRESult:ACHannel	-	<int>	
Active I Code reading	:READ:TRESult:ACI	-	<int>	
Active Q Code reading	:READ:TRESult:ACQ	-	<int>	

### 11.3.12 Subsystem-FETCh

Function description	SCPI command	Parameter	Query reply	Remarks
Read				
$\rho$ reading	:FETCh:TRESt:RHO	-	<real>	
Frequency Error reading	:FETCh:TRESt:FERRor	-	<real>,<real>	<Hz>,<ppm>
Magnitude Error reading	:FETCh:TRESt:MERRor	-	<real>	
Phase Error reading	:FETCh:TRESt:PERRor	-	<real>	
EVM reading	:FETCh:TRESt:EVM	-	<real>	
I/Q Origin Offset reading	:FETCh:TRESt:IQOFset	-	<real>	
Tx Power reading	:FETCh:TRESt:POWer	-	<real>,<real>	<dBm>,<W>
Pilot Power reading	:FETCh:TRESt:PPOWer	-	<real>,<real>	<dBm>,<W>
$\tau$ reading	:FETCh:TRESt:TAU	-	<real>	
PN Delay reading	:FETCh:TRESt:PNDelay	-	<int>	
Peak Inactive $\rho$ reading	:FETCh:TRESt:PIRHO	-	<real>, <int>, <int>, <string>	< $\rho$ >, <Walsh Code>, <Walsh Len>, <"I","Q"or"I& Q">
Peak $\Delta\tau$ reading	:FETCh:TRESt:PDtau	-	<real>, <int>, <int>, <string>	< $\Delta\tau$ >, <Walsh Code>, <Walsh Len>, <"I","Q"or"I& Q">
Peak $\Delta\theta$ reading	:FETCh:TRESt:PDtheta	-	<real>, <int>, <int>, <string>	< $\Delta\theta$ >, <Walsh Code>, <Walsh Len>, <"I","Q"or"I& Q">
Chip Rate Error reading	:FETCh:TRESt:CRERror	-	<real>	
Quadrature Error reading	:FETCh:TRESt:QERRor	-	<real>	
Active Channel reading	:FETCh:TRESt:ACHannel	-	<int>	
Active I Code reading	:FETCh:TRESt:ACI	-	<int>	
Active Q Code reading	:FETCh:TRESt:ACQ	-	<int>	

11.3.13 Subsystem-STATUS

**11.3.13 Subsystem-STATUS**

Function description	SCPI command	Parameter	Query reply	Remarks
STATUS				
Standard Operation Enable Register setting	:STATUS:OPERation:ENABle	<int>	<int>	
Standard Operation Event Register reading	:STATUS:OPERation:EVENt	-	<int>	
Questionable Enable Register setting	:STATUS:QUEStionable:ENABle	<int>	<int>	
Questionable Event Register reading	:STATUS:QUEStionable:EVENt	-	<int>	
Measuring Enable Register setting	:STATUS:OPERation:MEASure:ENABle	<int>	<int>	
Measuring Event Register reading	:STATUS:OPERation:MEASure:EVENt	-	<int>	

**11.3.14 Subsystem-HCOpy**

Function description	SCPI command	Parameter	Query reply	Remarks
HCOpy				
Copy output to the file or printer	:HCOpy[:IMMediate]	-	-	
Specification of the output destination (file or printer)	:HCOpy:DEStination	MMEMory PRINt	MMEM PRIN	
Specification of the output file number	:HCOpy:MMEMory:FILE:NUMBer	<int>	<int>	
Specification of the output file type	:HCOpy:MMEMory:FILE:TYPE	BITMap PNGraphic	BITM PNG	

### 11.4 Status Register




Figure 11-1 Status Registers



## 12. PERFORMANCE VERIFICATION (Uplink)

This chapter describes how to check whether the performance of this instrument meets the specifications.

It is recommended that you copy the test data record sheet included at the end of this chapter and save it as a record of the performance test.

---

**IMPORTANT:** Before verifying the performance, warm-up and completely calibrate the instrument.

---

### 12.1 Test Signal Specifications

The test signals used for verifying the performance are shown below:

Table 12-1 List of Test Signal Specifications

No.	Test signal name	Signal specifications	Test item																		
1	Offset QPSK signal	Compliant with IS-98. Modulation format: Offset QPSK	Uplink measurement cdmaOne mode																		
2	Code multiplex signal	Compliant with IS-98. Long Code Mask: ALL 0 Reverse Traffic Channel  <table border="1" data-bbox="635 1205 1161 1576"> <thead> <tr> <th>Channel</th> <th>Walsh function</th> <th>Amplitude</th> </tr> </thead> <tbody> <tr> <td>PICH</td> <td><math>W_0^{64}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>DCCH</td> <td><math>W_8^{16}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>SCH2</td> <td><math>W_6^8(M=2)</math></td> <td>-6.99 dB</td> </tr> <tr> <td>FCH</td> <td><math>W_4^{16}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>SCH1</td> <td><math>W_2^4(M=4)</math></td> <td>-6.99 dB</td> </tr> </tbody> </table> M: Walsh Function Repetition Factor	Channel	Walsh function	Amplitude	PICH	$W_0^{64}$	-6.99 dB	DCCH	$W_8^{16}$	-6.99 dB	SCH2	$W_6^8(M=2)$	-6.99 dB	FCH	$W_4^{16}$	-6.99 dB	SCH1	$W_2^4(M=4)$	-6.99 dB	Uplink measurement cdma2000 mode
Channel	Walsh function	Amplitude																			
PICH	$W_0^{64}$	-6.99 dB																			
DCCH	$W_8^{16}$	-6.99 dB																			
SCH2	$W_6^8(M=2)$	-6.99 dB																			
FCH	$W_4^{16}$	-6.99 dB																			
SCH1	$W_2^4(M=4)$	-6.99 dB																			

12.2 Test Procedures

12.2 Test Procedures

This section describes each test procedure.

12.2.1 Offset QPSK Signal Measurement in RF Input

Connect the signal source as shown below:




Figure 12-1 Connecting the Test Signal (RF Input)

1. Output the Offset QPSK signal, which has a carrier frequency of 825.03 MHz and a level of -10 dBm, from the signal source.
2. Set this unit as follows:

```
{MEAS MODE}:  cdmaOne
{MEAS SETUP}:  Meas Parameters
                 [Meas Length]:          800 chip
                 [Freq Meas Range]:      EXPAND
                 [IQ Origin Offset]:     INCLUDE
{INPUT}:       Input          RF
{TRIGGER}:     Trigger Source  Ext1
{FREQ}:        Center         825.03 MHz
{LEVEL}:       Exccute Auto Level Set
```

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.



## 12.2.2 Code Multiplex Signal Measurement in RF Input

Connect the signal source as shown below:




Figure 12-2 Connecting the Test Signal (RF Input)

1. Output the code multiplex signal, which has a carrier frequency of 825.03 MHz and a level of -10 dBm, from the signal source.
2. Set this unit as follows:

{MEAS MODE}: **cdma2000**

{MEAS SETUP}: **Meas Parameters**

[User Table]:	USE
[Meas Length]:	1536 chip
[PN Delay Search]:	ON
[Freq Meas Range]:	EXPAND
[Threshold Level]:	-23 dB
[IQ Origin Offset]:	INCLUDE
[Peak Inact CH Component]:	Both Inact
[ $\Delta\tau$ ]:	ON
[ $\Delta\theta$ ]:	ON
[Chip Rate Error]:	ON
[Quadrature Error]:	ON
[Walsh Code Length]:	64

### User Table

[SPICH Walsh Func]:	OFF
[EACH/CCCH Walsh Func]:	OFF
[PDCCH Walsh Func]:	OFF
[REQCH Walsh Func]:	OFF
[DCCH Walsh Func]:	W16(8)
[ACKCH Walsh Func]:	OFF
[CQICH Walsh Func]:	OFF

12.2.2 Code Multiplex Signal Measurement in RF Input

	[FCH Walsh Func]:	W16(4)
	[SCH1 Walsh Func]:	W4(2)
	[Repetition Factor]:	4
	[SCH2 Walsh Func]:	W8(6)
	[Repetition Factor]:	2
	[PDCH Walsh Func]:	OFF
{INPUT}:	<b>Input</b>	RF
{TRIGGER}:	<b>Trigger Source</b>	Ext1
{FREQ}:	<b>Center</b>	825.03 MHz
{LEVEL}:	Execute <b>Auto Level Set</b>	

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

### 12.2.3 Code Multiplex Signal Measurement in IQ Input

Connect the signal source as shown below:




Figure 12-3 Connecting the Test Signal (IQ Input)

1. Output the code multiplex signal (Baseband signal) from the signal source.
2. Set this unit as follows:

{MEAS MODE}: **cdma2000**

{MEAS SETUP}: **Meas Parameters**

[User Table]:	USE
[Meas Length]:	1536 chip
[PN Delay Search]:	ON
[Freq Meas Range]:	EXPAND
[Threshold Level]:	-23 dB
[IQ Origin Offset]:	INCLUDE
[Peak Inact CH Component]:	Both Inact
[ $\Delta\tau$ ]:	ON
[ $\Delta\theta$ ]:	ON
[Chip Rate Error]:	ON
[Quadrature Error]:	ON
[Walsh Code Length]:	64

#### User Table

[SPICH Walsh Func]:	OFF
[EACH/CCCH Walsh Func]:	OFF
[PDCCH Walsh Func]:	OFF
[REQCH Walsh Func]:	OFF
[DCCH Walsh Func]:	W16(8)
[ACKCH Walsh Func]:	OFF
[CQICH Walsh Func]:	OFF

12.2.3 Code Multiplex Signal Measurement in IQ Input

	<b>[FCH Walsh Func]:</b>	W16(4)
	<b>[SCH1 Walsh Func]:</b>	W4(2)
	<b>[Repetition Factor]:</b>	4
	<b>[SCH2 Walsh Func]:</b>	W8(6)
	<b>[Repetition Factor]:</b>	2
	<b>[PDCH Walsh Func]:</b>	OFF
<b>{INPUT}:</b>	<b>Input</b>	Baseband(I&Q)
	<b>Baseband Input</b>	DC
<b>{TRIGGER}:</b>	<b>Trigger Source</b>	Ext1

3. Press the **SINGLE** button on this unit to perform measurements.
4. Write the measurement results in the test data record sheet.

## 12.3 Test Data Record Sheet

Test data record sheet

Model name:

Serial number:

### 1. Offset QPSK Signal Measurement in RF Input

Test item	Specifications			Pass / Fail
	Minimum value	Measured value	Maximum value	
Carrier frequency error	-10 Hz		+10 Hz	
Transmission power	-10.9 dBm		-9.1 dBm	

### 2. Code Multiplex Signal Measurement in RF Input

Test item		Specifications			Pass / Fail
		Minimum value	Measured value	Maximum value	
Carrier frequency error		-10 Hz		+10 Hz	
$\rho_i$	Channel				
	PICH: $W_0^{64}$	-7.09 dB		-6.89 dB	
	DCCH: $W_8^{16}$	-7.09 dB		-6.89 dB	
	FCH: $W_4^{16}$	-7.09 dB		-6.89 dB	
	SCH1: $W_2^{16}$	-7.09 dB		-6.89 dB	
	SCH2: $W_6^{16}$	-7.09 dB		-6.89 dB	
$\Delta\tau_i$	Channel				
	DCCH: $W_8^{16}$	-10 ns		+10 ns	
	SCH2: $W_6^{16}$	-10 ns		+10 ns	
	FCH: $W_4^{16}$	-10 ns		+10 ns	
	SCH1: $W_2^{16}$	-10 ns		+10 ns	
$\Delta\theta_i$	Channel				
	DCCH: $W_8^{16}$	-10 mrad		+10 mrad	
	SCH2: $W_6^{16}$	-10 mrad		+10 mrad	
	FCH: $W_4^{16}$	-10 mrad		+10 mrad	
	SCH1: $W_2^{16}$	-10 mrad		+10 mrad	
Transmission power		-10.9 dBm		-9.1 dBm	

12.3 Test Data Record Sheet

or

Test item		Specifications			Pass / Fail
		Minimum value	Measured value	Maximum value	
Carrier frequency error		-10 Hz		+10 Hz	
P <sub>i</sub>	Channel				
	PICH: W <sub>0</sub> <sup>64</sup>	-7.09 dB		-6.89 dB	
	DCCH: W <sub>8</sub> <sup>16</sup>	-7.09 dB		-6.89 dB	
	FCH: W <sub>4</sub> <sup>16</sup>	-7.09 dB		-6.89 dB	
	SCH1: W <sub>2</sub> <sup>16</sup>	-7.09 dB		-6.89 dB	
	SCH2: W <sub>6</sub> <sup>16</sup>	-7.09 dB		-6.89 dB	
Peak Δτ		-10 ns		+10 ns	
Peak Δθ		-10 mrad		+10 mrad	
Transmission power		-10.9 dBm		-9.1 dBm	

## 3. Code Multiplex Signal Measurement in IQ Input

Test item		Specifications			Pass / Fail
		Minimum value	Measured value	Maximum value	
$\rho_i$	Channel				
	PICH: $W_0^{64}$	-7.09 dB		-6.89 dB	
	DCCH: $W_8^{16}$	-7.09 dB		-6.89 dB	
	FCH: $W_4^{16}$	-7.09 dB		-6.89 dB	
	SCH1: $W_2^{16}$	-7.09 dB		-6.89 dB	
	SCH2: $W_6^{16}$	-7.09 dB		-6.89 dB	
$\Delta\tau_i$	Channel				
	DCCH: $W_8^{16}$	-10 ns		+10 ns	
	SCH2: $W_6^{16}$	-10 ns		+10 ns	
	FCH: $W_4^{16}$	-10 ns		+10 ns	
	SCH1: $W_2^{16}$	-10 ns		+10 ns	
$\Delta\theta_i$	Channel				
	DCCH: $W_8^{16}$	-10 mrad		+10 mrad	
	SCH2: $W_6^{16}$	-10 mrad		+10 mrad	
	FCH: $W_4^{16}$	-10 mrad		+10 mrad	
	SCH1: $W_2^{16}$	-10 mrad		+10 mrad	

or

Test item		Specifications			Pass / Fail
		Minimum value	Measured value	Maximum value	
$\rho_i$	Channel				
	PICH: $W_0^{64}$	-7.09 dB		-6.89 dB	
	DCCH: $W_8^{16}$	-7.09 dB		-6.89 dB	
	FCH: $W_4^{16}$	-7.09 dB		-6.89 dB	
	SCH1: $W_2^{16}$	-7.09 dB		-6.89 dB	
	SCH2: $W_6^{16}$	-7.09 dB		-6.89 dB	
Peak $\Delta\tau$		-10 ns		+10 ns	
Peak $\Delta\theta$		-10 mrad		+10 mrad	





## 13. SPECIFICATIONS (Uplink)

### 13.1 cdma2000 Modulation Analysis Compliance System

Compliance with  
 3rd Generation Partnership Project 2 (3GPP2)  
 TSG-C Specifications  
 C.S0002-D v1.0(IS-2000.2)

### 13.2 cdma2000 Modulation Analysis Performance

#### 13.2.1 cdmaOne Mode

Item	Specifications
Carrier frequency error	
Measurement range	$<\pm 10$ kHz
Measurement accuracy	$<\pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 10 \text{ Hz})$
Transmission power measurement accuracy	$\pm(0.3 + \text{Frequency response} + \text{Calibration signal level accuracy})$ dB
	Frequency response
	50 MHz to 2.5 GHz $<\pm 0.4$ dB
	Calibration signal level accuracy $<\pm 0.2$ dB

Measurement conditions

Item	Conditions
Temperature range	+20°C to +30°C
Signal	Compliant with IS-98.
Modulation format	Offset QPSK
Center frequency	800 MHz/2 GHz
Input level	-10 dBm (RF Input) 0.8 V <sub>P-P</sub> (IQ Input)
$\rho$	$>0.9999$
Meas Length	800 chip
Freq Meas Range	EXPAND

13.2.2 cdma2000 Mode

**13.2.2 cdma2000 Mode**

Item	Specifications
Carrier frequency error	
Measurement range	<±4 kHz
Measurement accuracy	<±(Reference frequency accuracy × Carrier frequency + 10 Hz)
$\rho_i$ measurement accuracy ( $\rho$ vs Code)	<±0.1 dB
$\Delta\tau_i$ measurement accuracy	<±10 ns
$\Delta\theta_i$ measurement accuracy	<±10 mrad
Transmission power measurement accuracy	±(0.3 + Frequency response + Calibration signal level accuracy) dB Frequency response 50 MHz to 2.5 GHz      <±0.4 dB Calibration signal level accuracy      <±0.2 dB

Measurement conditions

Item	Conditions																		
Temperature range	+20°C to +30°C																		
Signal	Compliant with IS-98. Long Code Mask: ALL 0 Reverse Traffic Channel <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Channel</th> <th>Walsh function</th> <th>Amplitude</th> </tr> </thead> <tbody> <tr> <td>PICH</td> <td><math>W_0^{64}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>DCCH</td> <td><math>W_8^{16}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>SCH2</td> <td><math>W_6^8(M=2)</math></td> <td>-6.99 dB</td> </tr> <tr> <td>FCH</td> <td><math>W_4^{16}</math></td> <td>-6.99 dB</td> </tr> <tr> <td>SCH1</td> <td><math>W_2^4(M=4)</math></td> <td>-6.99 dB</td> </tr> </tbody> </table> <p style="text-align: center;">M: Walsh Function Repetition Factor</p>	Channel	Walsh function	Amplitude	PICH	$W_0^{64}$	-6.99 dB	DCCH	$W_8^{16}$	-6.99 dB	SCH2	$W_6^8(M=2)$	-6.99 dB	FCH	$W_4^{16}$	-6.99 dB	SCH1	$W_2^4(M=4)$	-6.99 dB
Channel	Walsh function	Amplitude																	
PICH	$W_0^{64}$	-6.99 dB																	
DCCH	$W_8^{16}$	-6.99 dB																	
SCH2	$W_6^8(M=2)$	-6.99 dB																	
FCH	$W_4^{16}$	-6.99 dB																	
SCH1	$W_2^4(M=4)$	-6.99 dB																	
Center frequency	800 MHz/2 GHz																		
Input level	-10 dBm (RF Input) 0.8 V <sub>P-P</sub> (IQ Input)																		
$\rho$	>0.9999																		
$\Delta\tau_i$	0 ns																		
$\Delta\theta_i$	0 mrad																		
Meas Length	1536 chip																		
Freq Meas Range	EXPAND																		

## APPENDIX

This section describes the following supplemental information:

A.1 Technical Data

A.2 Error Message List

### A.1 Technical Data

#### Bit Reversal (Paley) Order

The order of the Walsh Code numbers, which is used in the cdma2000, is called the Hadamard order.

There is also an order called the Bit Reversal (Paley) order, which is different from the Hadamard order.

If the Walsh Codes are placed in the order of the Bit Reversal order, the tree-layered Walsh Code structure can be displayed according to the Walsh Code length.

The following example shows the comparison between the Hadamard order and the Bit Reversal order when the Walsh Code length is 8:

	8 × 8 matrix	Walsh Code number
The Walsh Code Hadamard order of the cdma2000	00000000	0
	01010101	1
	00110011	2
	01100110	3
	00001111	4
	01011010	5
	00111100	6
	01101001	7
Bit Reversal (Paley) Order	00000000	0
	00001111	4
	00110011	2
	00111100	6
	01010101	1
	01011010	5
	01100110	3
	01101001	7

The following lists show the Walsh Code Numbers which are placed in the order of the Bit Reversal (Paley) order when the Walsh Code Lengths are 4, 8, 16, 32, 64, and 128:

A.1 Technical Data

W4	W8	W16	W32	W64	W128
0	0	0	0	0	0
					64
				32	32
			96		
			16	16	16
					80
		48		48	
		112			
		8	8	8	8
					72
				40	40
			104		
	24		24	24	
				88	
		56	56		
	120				
	4	4	4	4	4
					68
				36	36
			100		
			20	20	20
					84
		52		52	
		116			
12		12	12	12	
				76	
			44	44	
		108			
	28	28	28		
			92		
60		60			
124					

W4	W8	W16	W32	W64	W128		
2	2	2	2	2	2		
					66		
				34	34		
			98				
			18		18		
			18	18			
		82					
		50		50			
		10	50				
			114				
			10	10			
		6	6	10	10	10	10
	74						
	42				42		
				106			
				26	26		
	26			26			
			90				
			58	58			
	6		6	6	6	6	6
							70
					38	38	
	102						
	22	22					
14	14	14	14	14	22		
					86		
		54	54				
	118						
	14		14				
	30	14	14	14	14	14	
78							
46			46				
		110					
		30	30				
62		30	30	30	30	30	
	94						
	62	62					
126							

A.1 Technical Data

W4	W8	W16	W32	W64	W128
1	1	1	1	1	1
					65
				33	33
			97		
			17		
			17	17	17
		81			
		49		49	
		113			
		9	9	9	9
					73
				41	41
	105				
	25		25		
	25		25	25	
		89			
		57	57		
	121				
	5	5	5	5	5
					69
				37	37
			101		
			21		21
			21	21	21
85					
53		53			
117					
13		13	13	13	
				77	
			45	45	
	109				
	29	29			
	29	29	29		
93					
61		61			
125					

W4	W8	W16	W32	W64	W128
3	3	3	3	3	3
					67
				35	35
			99	99	
			19	19	19
			83	83	
		51	51		
		115	115		
		11	11	11	
		75	75		
		43	43		
		107	107		
	27	27	27		
	91	91			
	59	59			
	123	123			
	7	7	7		
	71	71			
	39	39			
	103	103			
	23	23	23		
	87	87			
	55	55			
	119	119			
15	15	15			
79	79				
47	47				
111	111				
31	31	31			
95	95				
63	63				
127	127				

## Bibliography

Endo, Yasushi. Walsh kaiseki [Walsh analysis]. Tokyo Denki University Press


A.1 Technical Data

Kiyasu, Zenichi. Hadamard gyouretsu to sono ouyou [The Hadamard matrix and its application]. The Institute of Electronics, Information and Communication Engineers.

**Complementary Filter**

The Complementary Filter is defined by the IS-97 and IS-98 (Waveform Quality Measurement Equipment) and is used to measure the waveform quality and code domain.

The Complementary Filter generates a signal that is equivalent to a signal that passed through the Nyquist filter. The IS-97 and IS-98 contain no regulations concerning the roll-off factor ( $\alpha$ ) of the Nyquist filter. In this instrument,  $\alpha$  is defined as 0.05 in Downlink and 0.21 in Uplink.



**Phase Equalizing Filter (Downlink)**

The base station equalizes the phase of the signal, which travels down the transmission signal path, according to the IS-95 standard phase characteristics. The equalization filter is defined by the following formula:

$$H(\omega) = k \frac{\omega^2 + j\alpha\omega\omega_0 - \omega_0^2}{\omega^2 - j\alpha\omega\omega_0 - \omega_0^2}$$

$k$ : Arbitrary gain

$j$ :  $\sqrt{-1}$

$\alpha$ : 1.36

$\omega_0$ :  $2\pi \cdot 3.15 \cdot 10^5$

$\omega$ : Angular frequency

If the phase equalizing filter is used in the base station, this instrument analyzes waveforms through a filter that has the inverse characteristics of the equalizing filter.

To analyze the waveforms, set [Phase Equalizing Filter] of Meas Parameters to ON.

Also, to analyze signals which have not been through the phase equalizing filter, set [Phase Equalizing Filter] of Meas Parameters to OFF.



## How to specify the PCG and Code by using the marker on the graph (Downlink)

Four formats are included in the Format tab in the Window Format dialog box as follows:

1. **[All PCG & Code]** This format is used to measure all PCGs and codes.
2. **[Specified PCG]** This format is used to measure a PCG selected from all the PCGs in **[All PCG & Code]**.
3. **[Specified Code]** This format is used to measure a code selected from all the codes in **[All PCG & Code]**.
4. **[Specified PCG & Code]** This format is used to measure a specified PCG and code.

A PCG or code, which is specified by **[Specified PCG]**, **[Specified Code]**, or **[Specified PCG & Code]** can also be specified by using the marker on the **[All PCG & Code]**, **[Specified PCG]**, and **[Specified Code]** graphs that are set in the **[Window Format]** dialog box in Figure A-1.




Figure A-1 **[Window Format]** Dialog Box

A.1 Technical Data

- How to specify the PCG by using the marker

The PCG (power control group) graph can be switched by moving the marker in the [Tx Power vs PCG] graph, which was selected from [All PCG & Code], and in the [Code Power vs PCG] graph, which was selected from [Specified Code]. (See Figure A-1).

Figure A-2 shows that the [Tx Power vs PCG] graph is displayed in the upper window [Window1] and [p vs Code] selected from [Specified PCG] is displayed in the lower window [Window2].

If [Marker→Specified PCG] is set to "On" after [Window1] is activated and [Marker] on the side bar is displayed, the [p vs Code] graph of the PCG that is specified by using [Marker] is displayed on [Window2], coupling with the marker position that changes in [Window1].




Figure A-2 Marker→Specified PCG On Usage Example

- How to specify the Code by using the marker

If [Code Power vs Code], [ $\rho$  vs Code], [ $\Delta\tau$  vs Code], or [ $\Delta\theta$  vs Code] is selected, the [Code Power vs PCG (power control group)] graph and the [Constellation] graph, in which the PCG and the code are specified, can be switched by coupling the marker (See Figure A-1).

Figure A-3 shows that the [ $\rho$  vs Code] graph selected from [All PCG & Code] is displayed in [Window1] and [Code Power vs PCG] selected from [Specified Code] is displayed in [Window2].

If [Marker→Specified Code] is set to "On" after [Window1] is activated and [Active CH. Marker] on the side bar is displayed, the [Code Power vs PCG] graph of the code that is specified by using [Active CH. Marker] is displayed on [Window2], coupling with the active channel marker that changes in [Window1].




Figure A-3 Marker→Specified Code On Usage Example

### Null Offset Graph (Uplink)

The display functions of Null Offset Constellation, Null Offset I Eye Diagram, and Null Offset Q Eye Diagram can be used when MEAS MODE is set to cdmaOne and graphs are displayed.

The constellation does not converge because the Offset QPSK modulation is used in cdmaOne.




Figure A-4 Constellation

The QPSK constellation, in which symbol points converge on a point as shown in Figure A-5, is acquired by canceling the I and Q offsets of Offset QPSK and using the inverse characteristic filter against the baseband filter that is compliant with IS-2000. This graph is called a Null Offset Constellation graph.




Figure A-5 Null Offset Constellation

---

**NOTE:** Even if the I and Q offsets of Offset QPSK are canceled, a graph, in which symbol points converge on a point, cannot be acquired because of the interference between symbols in the baseband filter that is compliant with IS-2000.

---

### Example of how User Table is used (Uplink)

How to set this instrument when measuring a signal, which is shown in 9.2, by using User Table is described below.

Signal specifications

Channel	Walsh function
PICH	$W_0^{64}$
DCCH	$W_8^{16}$
SCH2	$W_2^4(M=1)$
FCH	$W_4^{16}$
SCH1	$W_1^2(M=1)$

M: Walsh Function Repetition Factor

1. Set the [User Table] dialog box as Figure A-6. (The PICH settings are not required because PICH is always set in this instrument.)




Figure A-6 Setting Example of the [User Table] Dialog Box

2. Set [USE] of the [User Table] option button in the [Measurement Parameters Setup] dialog box. This instrument is set so that User Table set in previous step 1 is used. (See Figure A-7)

A.1 Technical Data




Figure A-7 [Measurement Parameters Setup] Dialog Box when Using [User Table]

## A.2 Error Message List

This section describes the error messages displayed on this instrument.

The following information is included.

- Error number
- Displayed message
- Cause of generation and cancellation method

Table A-1 Error Message List (1 of 2)

Error number	Displayed message	Description
-1250	No such file or directory.	The file or directory does not exist. Check the file name or directory name.
-1251	Permission denied.	The file operation is prohibited. Check the drive name, file, or directory name.
-1252	Not enough space on the disk.	Not enough free space. Delete all unnecessary files.
-1253	File read/write error.	An error occurred during file I/O. Check if there is sufficient disk space or the disk is write-protected.
-1300	Device is not ready.	No disk is inserted.
-1400	There is no data in the effective state.	The requested data is not defined.
-1500	Option required.	The specified option function is required.
-3210	Input Level is out of range. Check the Ref. Level.	The input signal level is outside the permitted range. Check the reference level or input signal level.
-3211	Auto Level Set cannot be succeed. Signal level is not stable.	Auto Level Set is not complete. Check to see if the input signal level is not constant or if the attenuator is set to manual.
-3238	Incorrect User Table setting. Check the User Table.	The combination of data in the user table is incorrect and measurements cannot be performed. Check the user table setting.
-3239	Cannot execute measurement. Because $\rho$ is too low.	$\rho$ is too low to analyze. Check the input signal.
-3240	Frequency Error is out of Meas. Range.	The frequency error exceeds the measurement range. Check the frequency deviance of the input signal.
-3241	Parameter Estimation Error. Check the input signal.	The parameter cannot be estimated. Check the input signal.
-3245	Meas Length was changed in order to measure ACKCH.	The setting value of Meas Length has been changed to measure ACKCH.
-3247	Cannot synchronize to PICH. Adjust Threshold Level.	The Pilot channel cannot be synchronized. Re-set Threshold Level.

A.2 Error Message List

Table A-1 Error Message List (2 of 2)

Error number	Displayed message	Description
-3248	[Peak Inact Pwr] is larger than Threshold Level. Adjust Threshold Level or check User Table.	The value of [Peak Inact Pwr] is larger than Threshold Level. If the channel of [Peak Inact Pwr] is noise, set Threshold Level to the higher value. If the channel of [Peak Inact Pwr] is a transmission channel, set Threshold Level to the lower value or check the User Table setting.
-3254	Cannot synchronize to PICH. Adjust PN Delay.	The Pilot channel cannot be synchronized. Re-set PN Delay.



## ALPHABETICAL INDEX

[Symbol]	
$\Delta\theta$ vs Code	5-7
$\Delta\tau$ vs Code	5-7
$\rho$ vs Code	5-7
[ $\Delta\theta$ vs Code]	5-8
[ $\Delta\theta(I)$ vs Code]	10-11, 10-13
[ $\Delta\theta(Q)$ vs Code]	10-11, 10-13
[ $\Delta\theta$ ]	5-4, 5-6, 10-6, 10-8
[ $\Delta\tau$ vs Code]	5-8
[ $\Delta\tau(I)$ vs Code]	10-11, 10-13
[ $\Delta\tau(Q)$ vs Code]	10-11, 10-13
[ $\Delta\tau$ ]	5-4, 5-5, 10-6, 10-8
[ $\rho$ vs Code]	5-8, 10-11, 10-12
[ $\rho(I)$ vs Code]	10-11, 10-13
[ $\rho(Q)$ vs Code]	10-11, 10-13
[ $\tau$ Offset]	5-4, 5-5
[ACKCH Walsh Func]	10-6, 10-9
[All PCG & Code]	5-7
[Baseband Input]	5-11, 10-15
[Channel]	5-4, 5-6
[Chip]	5-8
[Chip Rate Error]	10-6, 10-8
[Code Power vs Code]	5-8, 10-11, 10-13
[Code Power vs PCG]	5-8
[Constellation]	5-7, 5-8, 10-11, 10-12, 10-13
[CQICH Walsh Func]	10-6, 10-9
[DCCH Walsh Func]	10-6, 10-9
[Display Type]	5-7, 5-8, 10-11, 10-12, 10-13
[Dot]	10-12, 10-13
[EACH/CCCH Walsh Func]	10-6, 10-9
[EVM vs Chip]	5-8, 10-11, 10-12, 10-13
[FCH Walsh Func]	10-6, 10-10
[Format]	5-7, 10-11, 10-12
[Freq Meas Range]	10-5, 10-6, 10-7
[Graph]	5-8, 10-13
[I Eye Diagram]	5-8, 10-11, 10-12, 10-13
[Input]	5-11, 10-15
[IQ Inverse]	5-11, 10-15
[IQ Origin Offset]	10-5, 10-6, 10-7
[Line]	10-12, 10-13
[Line & Chip]	5-8
[Mag Err vs Chip]	5-8
[Mag Error vs Chip]	10-11, 10-12, 10-13
[Meas Length]	5-4, 5-5, 10-5, 10-6
[Meas Mode]	5-4
[Modulation]	5-4, 5-6, 10-6, 10-9, 10-10
[Multi Channel No.]	5-4, 5-6
[Null Offset Constellation]	10-11, 10-12
[Null Offset I Eye Diagram]	10-11, 10-12
[Null Offset Q Eye Diagram]	10-11, 10-12
[PDCCH Walsh Func]	10-6, 10-9
[PDCH Walsh Func]	10-6, 10-10
[Peak Inact CH Component]	10-6, 10-7
[Phase Equalizing Filter]	5-4, 5-5
[Phase Error vs Chip]	10-11, 10-12, 10-13
[PN Delay]	10-6, 10-7
[PN Delay Search]	10-6
[PN Offset]	5-4, 5-5
[PN Offset Search]	5-4, 5-5
[Q Eye Diagram]	5-8, 10-11, 10-12, 10-13
[Quadrature Error]	10-6, 10-8
[Repetition Factor]	10-6, 10-10
[REQCH Walsh Func]	10-6, 10-9
[SCH1 Walsh Func]	10-6, 10-10
[SCH2 Walsh Func]	10-6, 10-10
[Specified Code]	5-7, 5-8
[Specified PCG]	5-7, 5-8
[Specified PCG & Code]	5-7, 5-8
[SPICH Walsh Func]	10-6, 10-9
[Table]	5-8, 10-13
[Threshold Level]	5-4, 5-5, 10-6, 10-7
[Total Result]	5-7, 10-11, 10-12
[Trace & Dot]	10-12, 10-13
[Tx Power vs PCG]	5-7
[User Table]	5-4, 5-5, 10-6
[vs Code]	5-7, 5-8, 10-11, 10-13
[Walsh Code Length]	10-6, 10-8
[Walsh Length]	5-4, 5-6
[Walsh Number]	5-4, 5-6

Alphabetical Index

{DISPLAY} ..... 10-11  
 {FREQ} ..... 5-14, 10-18  
 {INPUT} ..... 5-11, 10-15  
 {LEVEL} ..... 5-13, 10-17  
 {MEAS MODE} ..... 10-4  
 {MEAS SETUP} ..... 5-4, 10-5,  
 10-6  
 {MEAS VIEW} ..... 5-7  
 {MKR} ..... 5-10, 10-14  
 {SCALE} ..... 5-9  
 {TRIGGER} ..... 5-12, 10-16

**[A]**

Active CH. Marker ..... 5-10, 10-14  
 Analysis of the Mobile Station Offset  
 QPSK Signal in the cdmaOne MODE .. 9-1  
 Analysis Restart ..... 5-4, 10-5,  
 10-6  
 ATT ..... 5-13, 10-17  
 Auto Level Set ..... 5-13, 10-17  
 Average ..... 10-5, 10-6,  
 10-11

**[B]**

BEFORE OPERATING ..... 2-1  
 Before Turning On ..... 2-3

**[C]**

cdma2000 ..... 10-4  
 cdma2000 Mode ..... 13-2  
 cdma2000 Modulation Analysis  
 Compliance System ..... 8-1, 13-1  
 cdma2000 Modulation Analysis  
 Performance ..... 8-1, 13-1  
 cdmaOne ..... 10-4  
 cdmaOne Mode ..... 13-1  
 Center ..... 5-14, 10-18  
 Channel Number ..... 5-14, 10-18  
 Check the Supply Power ..... 3-5  
 Chip ..... 5-7  
 Code Domain Power Measurement  
 of the Base Station Signal ..... 4-1  
 Code Domain Power Measurement  
 of the Mobile Station Signal  
 in the cdma2000 MODE ..... 9-5  
 Code Multiplex Signal Measurement  
 in IQ Input ..... 12-5  
 Code Multiplex Signal Measurement  
 in RF Input ..... 12-3  
 Code Power vs Code ..... 5-7  
 Code Power vs PCG ..... 5-7  
 Command Reference Format ..... 6-1, 11-1

Common Commands ..... 6-3, 11-3  
 Connecting Accessories ..... 3-4  
 Connecting the Keyboard and Mouse ... 3-4  
 Connecting the Power Cable ..... 3-5  
 Constellation ..... 5-7  
 Conventions of Notation Used  
 in This Document ..... 1-4

**[D]**

Description of the Function of Each Key 5-4, 10-4  
 Dot ..... 10-11  
 Dual Display ..... 5-9, 10-11,  
 10-12

**[E]**

Electromagnetic Interference ..... 2-3  
 Error Message List ..... A-13  
 EVM vs Chip ..... 5-7  
 Ext1 ..... 5-12, 10-16  
 Ext2 ..... 5-12, 10-16

**[F]**

Free Run ..... 5-12, 10-16  
 Freq Offset ..... 5-14, 10-18  
 Function Bar ..... 5-3, 10-3  
 FUNCTIONAL EXPLANATION  
 (Downlink) ..... 5-1  
 FUNCTIONAL EXPLANATION  
 (Uplink) ..... 10-1

**[G]**

Getting the Software Running  
 with Stability ..... 2-2  
 Graph ..... 5-7, 10-11

**[H]**

Handling the Touch Screen ..... 2-2  
 Hard Disk Drive ..... 2-1

**[I]**

I Eye Diagram ..... 5-7  
 If a Fault Should Occur ..... 2-1  
 IF Power ..... 5-12, 10-16  
 Input Setup ..... 5-11, 10-15  
 Interval On/Off ..... 5-12, 10-16  
 INTRODUCTION ..... 1-1  
 IQ Input Base Station Signal  
 Measurement ..... 7-3

			10-12
	<b>[L]</b>		
Limitations Imposed when Using			
Windows XP .....	2-5		
Line .....	10-11		
Line & Chip .....	5-7		
Link .....	5-12, 10-16		
List of Commands .....	6-4, 11-4		
Locating This Instrument .....	3-2		
	<b>[M]</b>		
Mag Err vs Chip .....	5-7		
Marker .....	5-10, 10-14		
Marker OFF .....	5-10, 10-14		
Marker→Specified Code On/Off .....	5-10		
Marker→Specified PCG On/Off .....	5-10		
Meas Parameters .....	5-4, 10-5, 10-6		
MEASUREMENT EXAMPLES			
(Downlink) .....	4-1		
MEASUREMENT EXAMPLES			
(Uplink) .....	9-1		
Measurement Tool Bar .....	5-15, 10-19		
Menu Index .....	5-1, 10-1		
MENU MAP (Downlink) .....	5-1		
MENU MAP (Uplink) .....	10-1		
Min ATT .....	5-13, 10-17		
	<b>[O]</b>		
Offset QPSK Signal Measurement			
in RF Input .....	12-2		
Operating Environment .....	3-2		
Operation Check .....	3-7		
Other Manuals Relating to			
This Instrument .....	1-3		
Outline of This Manual .....	1-1		
Overcurrent Protection .....	2-1		
	<b>[P]</b>		
PERFORMANCE VERIFICATION			
(Downlink) .....	7-1		
PERFORMANCE VERIFICATION			
(Uplink) .....	12-1		
Plot Number .....	5-9		
Plot Start .....	5-9		
Preamp On/Off .....	5-13, 10-17		
Prevention of Electrostatic Buildup .....	3-3		
Product Overview .....	1-3		
	<b>[Q]</b>		
Q Eye Diagram .....	5-7		
Quad Display .....	5-9, 10-11,		
	<b>[R]</b>		
Ref Level .....	5-13, 10-17		
Ref Offset .....	5-13, 10-17		
Registered Trademarks .....	1-5		
Removing and Attaching the Front Panel	2-3		
Removing the Case .....	2-1		
Return .....	5-12, 10-5, 10-8, 10-10, 10-13, 10-16		
RF Input Base Station Signal Measurement	7-2		
	<b>[S]</b>		
SCPI COMMAND REFERENCE			
(Downlink) .....	6-1		
SCPI COMMAND REFERENCE			
(Uplink) .....	11-1		
SETUP .....	3-1		
Single Display .....	5-9, 10-11, 10-12		
Soft Menu Bar .....	5-3, 10-3		
SPECIFICATIONS (Downlink) .....	8-1		
SPECIFICATIONS (Uplink) .....	13-1		
Specified Code No. ....	5-7		
Specified PCG No. ....	5-7		
Status Register .....	6-12, 11-15		
Subsystem-CALCulate .....	6-7, 11-8		
Subsystem-CONFigure .....	11-5		
Subsystem-DISPlay .....	6-7, 11-10		
Subsystem-FETCH .....	6-11, 11-13		
Subsystem-HCOPy .....	11-14		
Subsystem-INITiate .....	6-6, 11-7		
Subsystem-INPut .....	6-4, 11-4		
Subsystem-MEASure .....	6-9, 11-11		
Subsystem-MMEMory .....	6-8, 11-11		
Subsystem-READ .....	6-10, 11-12		
Subsystem-SENSE .....	6-5, 11-5		
Subsystem-STATus .....	11-14		
Subsystem-SYStem .....	6-4, 11-4		
Subsystem-TRIGger .....	6-6, 11-7		
Supply Description .....	3-5		
Switching Communication Systems .....	5-3, 10-3		
	<b>[T]</b>		
Table .....	5-7, 10-11		
Technical Data .....	A-1		
Test Data Record Sheet .....	7-4, 12-7		
Test Procedures .....	7-2, 12-2		
Test Signal Specifications .....	7-1, 12-1		
Total Result .....	5-7		
Trace & Dot .....	10-11		

Alphabetical Index

Trademarks ..... 1-5  
Transporting ..... 2-2  
Trigger Delay ..... 5-12, 10-16  
Trigger Slope ..... 5-12, 10-16  
Trigger Source ..... 5-12, 10-16  
Tx Power vs PCG ..... 5-7

**[U]**

Unpacking Inspection ..... 3-1  
User Table ..... 5-4, 5-5,  
5-6, 10-6,  
10-8

**[W]**

Window Format ..... 5-7, 10-11,  
10-12

**[X]**

X Scale Left ..... 5-9, 10-11,  
10-13  
X Scale Right ..... 5-9, 10-11,  
10-13

**[Y]**

Y Scale Lower ..... 5-9, 10-11,  
10-13  
Y Scale Upper ..... 5-9, 10-11,  
10-13

## **IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE**

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

### **SOFTWARE License**

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

### **Restrictions**

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

### **Liability**

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

## LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
  - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
  - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
  - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
  - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
  - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
  - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
  - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
  - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

## **CUSTOMER SERVICE DESCRIPTION**

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

## SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,  
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea  
Phone: +82-2-532-7071  
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:  
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.  
Phone: +86-21-6485-2725  
Fax: +86-21-6485-2726

Shanghai Branch Office:  
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,  
Hai Dian District, Beijing,  
China 100083  
Phone: +86-10-8235-3377  
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06  
Alexandra Technopark Singapore 119967  
Phone: +65-6274-3100  
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A  
Phone: +1-408-988-7700  
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany  
(P.O.B. 80 14 60 D-81614 München, Germany)  
Phone: +49-89-4129-13711  
Fax: +49-89-4129-13723

**ADVANTEST**<sup>®</sup>

<http://www.advantest.co.jp>