

---

---

# **ADVANTEST<sup>®</sup>**

**ADVANTEST CORPORATION**

---

***R3962/63/64 Series***  
***S Parameter Test Set***  
***Operation Manual***

**MANUAL NUMBER FOE-8335013B02**

---

***Applicable models***

***-R3962A/B***  
***-R3963A/B***  
***-R3964A/B***



# MANUAL CHANGES

**ADVANTEST**<sup>®</sup>  
ADVANTEST Corporation

Date	September 2, 1999	Manual No.	B02
Manual Name	R3962/63/64 Series Operation Manual	Manual Change No.	EMC-02

To: R3963 and R3964 users

**1. The following labels on the front panel have been changed.**

Before	After
ANT PORT →	TEST PORT1
TEST PORT1 →	TEST PORT2
TEST PORT2 →	TEST PORT3

**2. CAUTION**

The procedure shown below for testing S parameters S11 to S33 dose not operate correctly when used for the R3963 or R3964 Test Set.

[SYSTEM] → {SERVICE MENU} → {OPTIONS} → {DUPLEXER TEST\_SET ON}

If the above procedure is used when connected to the R3963 or R3964, you must restart the network analyzer.



---

## Safety Summary

To ensure thorough understanding of all functions and to ensure efficient use of this instrument, please read the manual carefully before using. Note that Advantest bears absolutely no responsibility for the result of operations caused due to incorrect or inappropriate use of this instrument.

If the equipment is used in a manner not specified by Advantest, the protection provided by the equipment may be impaired.

- **Warning Labels**

Warning labels are applied to Advantest products in locations where specific dangers exist. Pay careful attention to these labels during handling. Do not remove or tear these labels. If you have any questions regarding warning labels, please ask your nearest Advantest dealer. Our address and phone number are listed at the end of this manual.

Symbols of those warning labels are shown below together with their meaning.

**DANGER:** Indicates an imminently hazardous situation which will result in death or serious personal injury.

**WARNING:** Indicates a potentially hazardous situation which will result in death or serious personal injury.

**CAUTION:** Indicates a potentially hazardous situation which will result in personal injury or a damage to property including the product.

- **Basic Precautions**

Please observe the following precautions to prevent fire, burn, electric shock, and personal injury.

- Use a power cable rated for the voltage in question. Be sure however to use a power cable conforming to safety standards of your nation when using a product overseas.
- When inserting the plug into the electrical outlet, first turn the power switch OFF and then insert the plug as far as it will go.
- When removing the plug from the electrical outlet, first turn the power switch OFF and then pull it out by gripping the plug. Do not pull on the power cable itself. Make sure your hands are dry at this time.
- Before turning on the power, be sure to check that the supply voltage matches the voltage requirements of the instrument.
- Connect the power cable to a power outlet that is connected to a protected ground terminal. Grounding will be defeated if you use an extension cord which does not include a protected ground terminal.
- Be sure to use fuses rated for the voltage in question.
- Do not use this instrument with the case open.
- Do not place anything on the product and do not apply excessive pressure to the product. Also, do not place flower pots or other containers containing liquid such as chemicals near this

---

## Safety Summary

product.

- When the product has ventilation outlets, do not stick or drop metal or easily flammable objects into the ventilation outlets.
- When using the product on a cart, fix it with belts to avoid its drop.
- When connecting the product to peripheral equipment, turn the power off.

- **Caution Symbols Used Within this Manual**

Symbols indicating items requiring caution which are used in this manual are shown below together with their meaning.

**DANGER:** Indicates an item where there is a danger of serious personal injury (death or serious injury).

**WARNING:** Indicates an item relating to personal safety or health.

**CAUTION:** Indicates an item relating to possible damage to the product or instrument or relating to a restriction on operation.

- **Safety Marks on the Product**

The following safety marks can be found on Advantest products.



: ATTENTION - Refer to manual.



: Protective ground (earth) terminal.



: DANGER - High voltage.



: CAUTION - Risk of electric shock.

- **Replacing Parts with Limited Life**

The following parts used in the instrument are main parts with limited life.

Replace the parts listed below before their expected lifespan has expired to maintain the performance and function of the instrument.

Note that the estimated lifespan for the parts listed below may be shortened by factors such as the environment where the instrument is stored or used, and how often the instrument is used.

The parts inside are not user-replaceable. For a part replacement, please contact the Advantest sales office for servicing.

Each product may use parts with limited life.

For more information, refer to the section in this document where the parts with limited life are described.

## Main Parts with Limited Life

Part name	Life
Unit power supply	5 years
Fan motor	5 years
Electrolytic capacitor	5 years
LCD display	6 years
LCD backlight	2.5 years
Floppy disk drive	5 years
Memory backup battery	5 years

- **Hard Disk Mounted Products**

The operational warnings are listed below.

- Do not move, shock and vibrate the product while the power is turned on.  
Reading or writing data in the hard disk unit is performed with the memory disk turning at a high speed. It is a very delicate process.
- Store and operate the products under the following environmental conditions.  
An area with no sudden temperature changes.  
An area away from shock or vibrations.  
An area free from moisture, dirt, or dust.  
An area away from magnets or an instrument which generates a magnetic field.
- Make back-ups of important data.  
The data stored in the disk may become damaged if the product is mishandled. The hard disc has a limited life span which depends on the operational conditions. Note that there is no guarantee for any loss of data.

- **Precautions when Disposing of this Instrument**

When disposing of harmful substances, be sure dispose of them properly with abiding by the state-provided law.


Harmful substances: (1) PCB (polycarbon biphenyl)  
(2) Mercury  
(3) Ni-Cd (nickel cadmium)  
(4) Other  
Items possessing cyan, organic phosphorous and hexadic chromium and items which may leak cadmium or arsenic (excluding lead in solder).

Example: fluorescent tubes, batteries

# Environmental Conditions


This instrument should be only be used in an area which satisfies the following conditions:

- An area free from corrosive gas
- An area away from direct sunlight
- A dust-free area
- An area free from vibrations
- Altitude of up to 2000 m




**Figure-1 Environmental Conditions**

- Operating position



**Figure-2 Operating Position**

- Storage position



**Figure-3 Storage Position**

- The classification of the transient over-voltage, which exists typically in the main power supply, and the pollution degree is defined by IEC61010-1 and described below.








Impulse withstand voltage (over-voltage) category II defined by IEC60364-4-443

Pollution Degree 2



## Types of Power Cable

Replace any references to the power cable type, according to the following table, with the appropriate power cable type for your country.







Plug configuration	Standards	Rating, color and length	Model number (Option number)
	PSE: Japan  Electrical Appliance and Material Safety Law	125 V at 7 A Black 2 m (6 ft)	Straight: A01402  Angled: A01412
	UL: United States of America  CSA: Canada	125 V at 7 A Black 2 m (6 ft)	Straight: A01403 (Option 95)  Angled: A01413
	CEE: Europe DEMKO: Denmark NEMKO: Norway VDE: Germany KEMA: The Netherlands CEBEC: Belgium OVE: Austria FIMKO: Finland SEMKO: Sweden	250 V at 6 A Gray 2 m (6 ft)	Straight: A01404 (Option 96)  Angled: A01414
	SEV: Switzerland	250 V at 6 A Gray 2 m (6 ft)	Straight: A01405 (Option 97)  Angled: A01415
	SAA: Australia, New Zealand	250 V at 6 A Gray 2 m (6 ft)	Straight: A01406 (Option 98)  Angled: -----
	BS: United Kingdom	250 V at 6 A Black 2 m (6 ft)	Straight: A01407 (Option 99)  Angled: A01417
	CCC: China	250 V at 10 A Black 2 m (6 ft)	Straight: A114009 (Option 94)  Angled: A114109



## Table of Power Cable Options

There are six power cable options (refer to following table).

Order power cable options by Model number.

	Plug configuration	Standards	Rating, color and length	Model number (Option number)
1		JIS: Japan  Law on Electrical Appliances	125 V at 7 A Black 2 m (6 ft)	Straight: A01402  Angled: A01412
2		UL: United States of America  CSA: Canada	125 V at 7 A Black 2 m (6 ft)	Straight: A01403 (Option 95)  Angled: A01413
3		CEE: Europe DEMKO: Denmark NEMKO: Norway VDE: Germany KEMA: The Netherlands CEBEC: Belgium OVE: Austria FIMKO: Finland SEMKO: Sweden	250 V at 6 A Gray 2 m (6 ft)	Straight: A01404 (Option 96)  Angled: A01414
4		SEV: Switzerland	250 V at 6 A Gray 2 m (6 ft)	Straight: A01405 (Option 97)  Angled: A01415
5		SAA: Australia, New Zealand	250 V at 6 A Gray 2 m (6 ft)	Straight: A01406 (Option 98)  Angled: -----
6		BS: United Kingdom	250 V at 6 A Black 2 m (6 ft)	Straight: A01407 (Option 99)  Angled: A01417



## PREFACE

- The manual describes about products outline, detailed procedure of the operation and specifications for the following test set and test adapter.
  - S parameter test set : R3962A/B.
  - Duplexer test set : R3963A/B.
  - Duplexer test adapter : R3964A/B.
- R3962A/B and R3963A/B are available following R3765A and R3767A Network Analyzer.
- R3964A/B is available following R3765C and R3767C Network Analyzer.



## TABLE OF CONTENTS

1. Outline .....	1-1
1.1 Products outline .....	1-1
1.2 Accessories .....	1-2
1.3 Option accessories .....	1-3
2. Description of the front and rear panel .....	2-1
2.1 Description of the front panel .....	2-1
2.2 Description of the rear panel .....	2-4
3. Connection with the Network Analyzer .....	3-1
3.1 Connection on the front panel side .....	3-1
3.2 Connection on the rear panel side .....	3-4
4. Measurement .....	4-1
4.1 Outline of the measurement .....	4-1
4.2 Sample measurement .....	4-2
5. Principle operation .....	5-1
5.1 R3962A/B .....	5-1
5.2 R3963A/B .....	5-4
5.3 R3964A/B .....	5-7
6. Performance test .....	6-1
6.1 Preparation for the performance test .....	6-1
6.2 Directivity .....	6-2
6.3 Test port load match. ....	6-5
6.4 Frequency characteristic .....	6-12
6.4.1 Transmission amplitude characteristic .....	6-12
6.4.2 Reflection amplitude characteristic .....	6-15
6.5 Insertion loss .....	6-20
6.6 Isolation .....	6-28
7. Specifications .....	7-1
7.1 R3962A/B .....	7-1
7.2 R3963A/B .....	7-2
7.3 R3964A/B .....	7-3
ALPHABETICAL INDEX.....	I-1





## LIST OF ILLUSTRATIONS

No.	Title	Page
2-1	Front panel of R3962A .....	2-1
2-2	Front panel of R3962B .....	2-1
2-3	Front panel of R3963A .....	2-2
2-4	Front panel of R3963B .....	2-2
2-5	Front panel of R3964A .....	2-3
2-6	Front panel of R3964B .....	2-3
2-7	Rear panel of R3962A, R3963A and R3964A .....	2-4
2-8	Rear panel of R3962B .....	2-4
2-9	Rear panel of R3963B .....	2-5
2-10	Rear panel of R3964B .....	2-5
3-1	Connection for the front panel of R3962A .....	3-1
3-2	Connection for the front panel of R3962B .....	3-1
3-3	Connection for the front panel of R3963A .....	3-2
3-4	Connection for the front panel of R3963B .....	3-2
3-5	Connection for the front panel of R3964A .....	3-3
3-6	Connection for the front panel of R3964B .....	3-3
3-7	Connection for the rear panel side of A type .....	3-4
3-8	Connection 1 for the rear panel side of B type .....	3-4
3-9	Connection 2 for the rear panel side of R3962B/R3963B .....	3-5
3-10	Connection 2 for the rear panel side of R3964B .....	3-5
5-1	Principle operation of R3962A/B .....	5-2
5-2	Block diagram of R3962A/B .....	5-3
5-3	Principle operation of R3963A/B .....	5-5
5-4	Block diagram of R3963A/B .....	5-6
5-5	Principle operation of R3964A/B .....	5-8
5-6	Block diagram of R3964A/B .....	5-9



---

## LIST OF TABLES

No.	Title	Page
1-1	Standard accessories list (R3962A/B and R3963A/B).....	1-2
1-2	Standard accessories list (R3964A/B).....	1-2
1-3	Option accessories .....	1-3



# 1 OUTLINE

## 1.1 Products Outline

R3962A/B are S parameter test set which can be connected with R3765A/R3767A Network Analyzer and available to measure the transmission and reflection characteristics for the two ports device.

The transmission and reflection characteristics of foreword direction and reverse direction can be measured simultaneously without disconnecting DUT (device under test) from the test port.

R3963A/B are duplexer test set which can be connected with R3765A/R3767A Network Analyzer and available to measure the transmission and reflection characteristic of the two ports device.

The transmission and reflection characteristic of foreword direction and reverse direction can be measured simultaneously without disconnecting DUT (device under test) from the test port.

R3964A/B are duplexer test set which can be connected with R3765C/R3767C Network Analyzer and available to measure the transmission and reflection characteristic of the two ports device.

The transmission and reflection characteristic of foreword direction and reverse direction can be measured simultaneously without disconnecting DUT (device under test) from the test port.

<NOTE. For proper use of R3963A/B and R3964A/B, following procedure is required>

- ① Set up COUPLED CH OFF before use.  
Set up DUAL CH ON for the display of CH1 and CH2 simultaneously.
- ② The characteristic between ANT PORT and TEST PORT 1 can be measured by CH1.  
The characteristic between ANT PORT and TEST PORT 2 can be measured by CH2.
- ③ Carry out the calibration between ANT PORT and TEST PORT 1 for CH1.  
Carry out the calibration between ANT PORT and TEST PORT 2 for CH2.  
The calibration data of the channels is switched in the switching of CH1 and CH2.

1.2 Accessories

**1.2 Accessories**

Table 1-1 and table 1-2 list the standard accessories shipped with the S parameter test set, Duplexer test set and Duplexer test adapter. If any of the accessories are damaged or missing, contact Advantest Customer Engineering Office, nearest Sales branch or representative. Address and telephone number are mentioned at the end of the manual.

Order accessories by stock number.

**Table 1-1 Standard accessories list (R3962A/B and R3963A/B)**

Name of accessory	Stock number	Quantity
N-N cable	A01247	3
Control cable (for A type)	A01241	1
Control cable (for B type)	A01281	1

**Table 1-2 Standard accessories list (R3964A/B)**

Name of accessory	Stock number	Quantity
N-N cable	A01247	2
Control cable (for A type)	A01241	1
Control cable (for B type)	A01281	1

### 1.3 Option Accessories

**Table 1-3 Option accessories**

Name of accessory	Type name	Remarks
N type 50 ohms Calibration Kit	Model 9617A3	DC to 18GHz female & male
3.5 mm Calibration kit	Model 9617F3	DC to 18GHz female & male
Conversion adapter 50 ohms	HRM-555S	N (male) to SMA (male)
Conversion adapter 50 ohms	HRM-554S	N (male) to SMA (female)





## 2 DESCRIPTION OF THE FRONT AND REAR PANEL

### 2.1 Description of the Front Panel

(1) R3962A/B




Figure 2-1 Front panel of R3962A




Figure 2-2 Front panel of R3962B

2.1 Description of the Front Panel

(2) R3963A/B




Figure 2-3 Front panel of R3963A




Figure 2-4 Front panel of R3963B

(3) R3964A/B




Figure 2-5 Front panel of R3964A




Figure 2-6 Front panel of R3964B

2.2 Description of the Rear Panel

2.2 Description of the Rear Panel




Figure 2-7 Rear panel of R3962A, R3963A and R3964A




Figure 2-8 Rear panel of R3962B

2.2 Description of the Rear Panel




Figure 2-9 Rear panel of R3963B




Figure 2-10 Rear panel of R3964B



### 3 CONNECTION WITH THE NETWORK ANALYZER

R3962A/B and R3963A/B can be connected with R3765A/R3767A.  
 R3964A/B can be connected with R3765C/R3767C.

#### 3.1 Connection on the Front Panel Side

- (1) R3962A/B, R3963A/B

N-N cables of accessories are connected as follows.

R3962A/B, R3963A/B	R3765A/R3767A	Cable for use
INPUT	SOURCE	A01247
A PORT	A PORT	A01247
B PORT	B PORT	A01247




Figure 3-1 Connection for the front panel of R3962A




Figure 3-2 Connection for the front panel of R3962B

3.1 Connection on the Front Panel Side




Figure 3-3 Connection for the front panel of R3963A




Figure 3-4 Connection for the front panel of R3963B



3.1 Connection on the Front Panel Side

(2) R3964A/B

R3964A/B	R3765C/R3767C	Cable for use
PORT1	TEST PORT1	A01247
PORT2	TEST PORT2	A01247




Figure 3-5 Connection for the front panel of R3964A




Figure 3-6 Connection for the front panel of R3964B

3.2 Connection on the Rear Panel Side

3.2 Connection on the Rear Panel Side

- (1) R3962A/63A/64A

A control cable (A01241) of accessories are connected as follows.





Figure 3-7 Connection for the rear panel side of A type

- (2) R3962B/63B/64B

① Control cable (A01281) of accessories are connected as follows.




Figure 3-8 Connection 1 for the rear panel side of B type

3.2 Connection on the Rear Panel Side

② N-N cables (A01247) of accessories are connected as follows.

②-1 For R3962B/63B





Figure 3-9 Connection 2 for the rear panel side of R3962B/R3963B

②-2 For R3964B





Figure 3-10 Connection 2 for the rear panel side of R3964B



## 4 MEASUREMENT

### 4.1 Outline of the Measurement

*Note. Use 50 ohms calibration kit and the cables for the measurement. When the calibration is executed, set up the type of the calibration kit and FEMAL/MAL (polarity) before measurement.*

(1) R3962A/B

Select S parameter for the measurement by **MEAS** key.

<b>MEAS</b>	Measurement
<b>S11</b>	Reflection characteristic of TEST PORT 1
<b>S21</b>	Transmission characteristic from TEST PORT 1 to TEST PORT 2
<b>S12</b>	Transmission characteristic from TEST PORT 2 to TEST PORT 1
<b>S22</b>	Reflection characteristic of TEST PORT 2

(2) R3963A/B, R3964A/B

Select S parameter for the measurement by **CH1**, **CH2** key and **MEAS** key.

	<b>MEAS</b>	Measurement
<b>CH1</b>	<b>S11</b>	Reflection characteristic of ANT PORT
	<b>S21</b>	Transmission characteristic from ANT PORT to TEST PORT 1
	<b>S12</b>	Transmission characteristic from TEST PORT 1 to ANT PORT
	<b>S22</b>	Reflection characteristic of TEST PORT 1
<b>CH2</b>	<b>S11</b>	Reflection characteristic of ANT PORT
	<b>S21</b>	Transmission characteristic from ANT PORT to TEST PORT 2
	<b>S12</b>	Transmission characteristic from TEST PORT 2 to ANT PORT
	<b>S22</b>	Reflection characteristic of TEST PORT 2

The calibration of each between ANT PORT and TEST PORT 1 by **CH1** and between ANT PORT and TEST PORT 2 by **CH2** is available.

First, set up COUPLED CH OFF then perform the calibration between ANT PORT and TEST PORT by CH1.


Next, perform the calibration between ANT PORT and TEST PORT 2 by CH2.

4.2 Sample Measurement


4.2 Sample Measurement

Using by duplexer test set R3963A/B, procedure performing two port full calibration between ANT PORT and TEST PORT 1 and measurement for the DUT is explained.

Measurement




① Press **CAL** .




② Press **CAL MENUS** .

Continue


4.2 Sample Measurement



③ Press **2PORT FULLCAL**



④ Press **REFLECT'N**




⑤ Connect the open standard to the ANT PORT and press **S11: OPEN**

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.

Continue


4.2 Sample Measurement



- ⑥ Connect the short standard to the ANT PORT and press

S11:  
SHORT


Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.



- ⑦ Connect the load standard to the ANT PORT and press

S11:  
LOAD

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.



- ⑧ Connect the open standard to the TEST PORT 1 and press


S22:  
OPEN

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.

Continue




4.2 Sample Measurement




- ⑨ Connect the short standard to the TEST PORT 1 and press S22:  
SHORT.

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.



- ⑩ Connect the load standard to the TEST PORT 1 and press S22:  
LOAD.

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.




- ⑪ Press DONE  
REFLECTION.


Gathering the reflection data is completed.

Continue

4.2 Sample Measurement




⑫ Press **TRNS-  
MISSION**



⑬ Set through condition between ANT PORT and TEST PORT 1 and press **GROUP THRU**

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.




⑭ Press **DONE  
TRNS**


Gathering the transmission data is completed.

Continue

4.2 Sample Measurement



15 Press **ISOLATION**.



16 Isolation menu has two functions which are non gathering and gathering the isolation data.


17-1 When the isolation data is not gathered,

a) Press **OMIT ISOLATION**.

(Set up infinity for the isolation data.)


b) Press **DONE ISOLATION**.

(Gathering the isolation data is completed.)



Continue


4.2 Sample Measurement



⑰-2 In case the isolation data is gathered.


- a) Connect load standard to the ANT PORT and TEST PORT 1 and press **FWD.ISON**.

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.



- b) Press **REV.ISON**.

Message of "wait for sweep" is displayed and data is gathered. This message is disappeared then the data gathering is completed.




- ⑱ Press **DONE ISOLATION**.

(Gathering the isolation data is completed.)

Continue

4.2 Sample Measurement




⑱ Press **DONE** 2-PORT

(Two port full calibration is completed.)

When set up data is stored,

Press **SAVE**.

Refer to the explanation of (SAVE) item in the operation manual of R3765A/C and R3767A/C for the operation of after save.



⑳ Connect DUT then it can be measured.

Completion

**Note)** S11, S21, S12 and S22 are available after 2 port full calibration but the calibration is not available for A/R, B/R, A/B, R, A and B.



## 5 PRINCIPLE OPERATION

### 5.1 R3962A/B

(1) Reflection characteristic.

When S11 is set, the input signal from the <INPUT> is pass through the measurement circuit 1 and is output to the <TEST PORT1>. When S22 is set, the input signal is pass through the measurement circuit 2 and is output to the <TEST PORT 2>.

Reflection component from the < TEST PORT 1> is pass through the measurement circuit 3 and is output to the <A PORT>.

Reflection component from the < TEST PORT 2> is pass through the measurement circuit 4 and is output to the <B PORT>.

Network Analyzer measures the ratio of the signal from <A PORT> or <B PORT> to the incident signal and displays the reflection characteristic.

(2) Transmission characteristic.

When S21 is set, the input signal from the <INPUT> is pass through the measurement circuit 5 and is output to the <B PORT>. When S12 is set, the input signal is pass through the measurement circuit 5 and is output to the <A PORT>.

Network Analyzer measures the signal from <A PORT> or <B PORT> and displays the transmission characteristic.

5.1 R3962A/B

Measurement circuit	1	③ → ⑪ → ⑫ → ⑨ → ⑦
	2	③ → ⑪ → ⑩ → ④ → ⑥
	3	⑦ → ⑧ → ②
	4	⑥ → ⑤ → ①
	5	③ → ⑪ → ⑫ → ⑨ → ⑦ → (DUT) → ⑥ → ⑤ → ①
	6	③ → ⑪ → ⑩ → ④ → ⑥ → (DUT) → ⑦ → ⑧ → ②




Figure 5-1 Principle operation of R3962A/B






Figure 5-2 Block diagram of R3962A/B

## 5.2 R3963A/B

(1) Reflection characteristic.

When S11 of CH1 and CH2 are set, the input signal from the <INPUT> is pass through the measurement circuit 1 and is output to the <ANT PORT>.

When S22 of CH1 is set, the input signal is pass through the measurement circuit 2 and is output to the <TEST PORT 1>. When S22 of CH2 is set, the input signal is pass through the measurement circuit 3 and is output to the <TEST PORT 2>.

Reflection component from the < ANT PORT> is pass through the measurement circuit 4 and is output to the <A PORT>.

Reflection component from the < TEST PORT 1> is pass through the measurement circuit 5 and is output to the <B PORT>.

Reflection component from the < TEST PORT 2> is pass through the measurement circuit 6 and is output to the <B PORT>.

Network Analyzer measures the signal from <A PORT> or <B PORT> and displays the reflection characteristic.

(2) Transmission characteristic.

When S21 of CH1 is set, the input signal from the <INPUT> is pass through the measurement circuit 7 and is output to the <B PORT>.

When S12 of CH1 is set, the input signal is pass through the measurement circuit 8 and is output to the <A PORT>.

When S21 of CH2 is set, the input signal is pass through the measurement circuit 9 and is output to the <B PORT>.

When S12 of CH2 is set, the input signal is pass through the measurement circuit 10 and is output to the <A PORT>.

Network Analyzer measures the signal from <A PORT> or <B PORT> and displays the transmission characteristic.

Measurement circuit	1	③ → ⑭ → ⑮ → ⑩ → ⑪ → ⑤
	2	③ → ⑭ → ⑬ → ⑦ → ⑧ → ⑰ → ⑱ → ⑥
	3	③ → ⑭ → ⑬ → ⑦ → ⑧ → ⑰ → ⑯ → ④
	4	⑤ → ⑪ → ⑫ → ②
	5	⑥ → ⑱ → ⑰ → ⑧ → ⑨ → ①
	6	④ → ⑯ → ⑰ → ⑧ → ⑨ → ①
	7	③ → ⑭ → ⑮ → ⑩ → ⑪ → ⑤ → (DUT) → ⑥ → ⑱ → ⑰ → ⑧ → ⑨ → ①
	8	③ → ⑭ → ⑬ → ⑦ → ⑧ → ⑰ → ⑱ → ⑥ → (DUT) → ⑤ → ⑪ → ⑫ → ②
	9	③ → ⑭ → ⑮ → ⑩ → ⑪ → ⑤ → (DUT) → ④ → ⑯ → ⑰ → ⑧ → ⑨ → ①
	10	③ → ⑭ → ⑬ → ⑦ → ⑧ → ⑰ → ⑯ → ④ → (DUT) → ⑤ → ⑪ → ⑫ → ②




Figure 5-3 Principle operation of R3963A/B

5.2 R3963A/B




Figure 5-4 Block diagram of R3963A/B

### 5.3 R3964A/B

(1) Reflection characteristic.

When S11 of CH1 and CH2 are set, the input signal from the <PORT 1> is pass through the measurement circuit 1 and is output to the <ANT PORT>.

When S22 of CH1 is set, the input signal from <PORT 2> is pass through the measurement circuit 2 and is output to the <TEST PORT 1>.

When S22 of CH2 is set, the input signal is pass through the measurement circuit 3 and is output to the <TEST PORT 2>.

Reflection component from the < ANT PORT> is pass through the measurement circuit 4 and is output to the <PORT 1>.

Reflection component from the < TEST PORT 1> is pass through the measurement circuit 5 and is output to the <PORT 2>.

Reflection component from the < TEST PORT 2> is pass through the measurement circuit 6 and is output to the <PORT 2>.

Network Analyzer measures the signal from <PORT 1> or <PORT 2> and displays the reflection characteristic.

(2) Transmission characteristic.

When S21 of CH1 is set, the input signal from the <PORT 1> is pass through the measurement circuit 7 and is output to the <PORT 2>. When S12 of CH2 is set, the input signal is pass through the measurement circuit 8 and is output to the <PORT 2>.

When S12 of CH1 is set, the input signal is pass through the measurement circuit 9 and is output to the <PORT 1>.

When S12 of CH2 is set, the input signal is pass through the measurement circuit 10 and is output to the <PORT 1>.

Network Analyzer measures the signal from <PORT 1> or <PORT 2> and displays the transmission characteristic.

5.3 R3964A/B

Measurement circuit	1	② → ④
	2	① → ⑦ → ⑧ → ⑤
	3	① → ⑦ → ⑥ → ③
	4	④ → ②
	5	⑤ → ⑧ → ⑦ → ①
	6	③ → ⑥ → ⑦ → ①
	7	② → ④ → (DUT) → ⑤ → ⑧ → ⑦ → ①
	8	② → ④ → (DUT) → ③ → ⑥ → ⑦ → ①
	9	① → ⑦ → ⑧ → ⑤ → (DUT) → ④ → ②
	10	① → ⑦ → ⑥ → ③ → (DUT) → ④ → ②




Figure 5-5 Principle operation of R3964A/B




Figure 5-6 Block diagram of R3964A/B





## 6 PERFORMANCE TEST

### 6.1 Preparation for the Performance Test

(1) Warming up.

It is necessary to wait over 60 minutes for preheat after power on then execute the performance test.

First, press **PRESET** key for initialize then start the each performance test.

(2) Preparation of the measurement devices.

Following table lists the measurement devices for the each performance test.

Test item	Measurement devices	Remark
Directivity	Calibration kit	Subchapter 6.2: only for R3962A/B and R3963A/B
Test port load match	Calibration kit RF cable (TEST CABLE)	Subchapter 6.3: only for R3962A/B and R3963A/B
Frequency characteristic	Calibration kit RF cable (TEST CABLE)	Subchapter 6.4: only for R3962A/B and R3963A/B
Insertion loss	RF cable (TEST CABLE) Conversion adapter	Subchapter 6.5: for R3962A/B, R3963A/B and R3964A/B
Isolation	Calibration kit RF cable (TEST CABLE) Conversion adapter	Subchapter 6.6: for R3962A/B, R3963A/B and R3964A/B

- Calibration kit : R3962A/63A/64A → Model 9617A3 (18GHz, N connector)  
R3962B/63B/64B → Model 9617F3 (18GHz, 3.5mm connector)
- RF cable : Use the proper cable for frequency characteristic (about 0.25 dB/GHz).  
: Use N connector cable for R3962A, R3963A and R3964A.  
: Use SMA connector for R3962B, R3963B and R3964B.
- Conversion adapter : HRM-554S  
Prepare the adapter which converts SMA from the port of Network Analyzer in the measurement of R3962B, R3963B and R3964B.

(3) General information.


- AC power voltage 90V to 250V.  
Power frequency 48 to 66 Hz.
- Turn OFF POWER switch for connection of power cable.
- Test condition of environment temperature, humidity and other.  
Temperature range: +25 degree C ±5 degree C.  
Relative humidity: Less than RH 80%.  
Do not operate the place in the dust, vibration, noise, wet or damp conditions.

6.2 Directivity


6.2 Directivity

(1) R3962A/B.


① Connect with the Network Analyzer for set up the performance test.



② Execute normalize (SHORT) of TEST PORT 1.



②-2 Connect short standard to TEST PORT 1.



③ Connect load standard to TEST PORT 1 and read out the measurement value of the directivity by marker from the wave form data.

Check out	Directivity of TEST PORT 1	40MHz to 2.6GHz	Less than 30 dB.
		2.6GHz to 3.8GHz	Less than 26 dB.
		3.8GHz to 8.0GHz	Less than 22 dB.

④ Execute normalize (SHORT) of TEST PORT 2.



④-2 Connect short standard to TEST PORT 2.

④-3 CAL NORMALIZE  
(SHORT)


⑤ Connect load standard to TEST PORT 2 and read out the measurement value of the directivity by marker from the wave form data.

Check out Directivity of TEST PORT 2

40MHz to 2.6GHz	Less than 30 dB
2.6GHz to 3.8GHz	Less than 26 dB
3.8GHz to 8.0GHz	Less than 22 dB

(2) R3963A/B

① Connect with the Network Analyzer for set up the performance test.



② Execute normalize (SHORT) of ANT PORT.

②-1 CH1 MEAS S11 (A/R)  
REFL FWD

②-2 Connect short standard to ANT PORT.

②-3 CAL NORMALIZE  
(SHORT)

③ Connect load standard to ANT PORT and read out the measurement value of the directivity by marker from the wave form data.

Check out Directivity of ANT PORT


40MHz to 2.6GHz	Typical 30 dB
2.6GHz to 3.8GHz	Typical 29 dB
3.8GHz to 8.0GHz	Typical 25 dB

6.2 Directivity

- ④ Execute normalize (SHORT) of TEST PORT 1.




- ④-2 Connect short standard to TEST PORT 1.




- ⑤ Connect load standard to TEST PORT 1 and read out the measurement value of the directivity by marker from the wave form data.

Check out	Directivity of TEST PORT 1	40MHz to 2.6GHz	Typical 15 dB
		2.6GHz to 3.8GHz	Typical 20 dB
		3.8GHz to 8.0GHz	Typical 8 dB

- ⑥ Execute normalize (SHORT) of TEST PORT 2.



- ⑥-2 Connect short standard to TEST PORT 2.




- ⑦ Connect load standard to TEST PORT 2 and read out the measurement value of the by marker from the wave form data.

Check out	Directivity of TEST PORT 2	40MHz to 2.6GHz	Typical 15 dB
		2.6GHz to 3.8GHz	Typical 20 dB
		3.8GHz to 8.0GHz	Typical 8 dB

### 6.3 Test Port Load Match

(1) R3962A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable to TEST PORT 2 and execute 1 PORT FULL CAL.



②-1 

CH1
-----

MEAS
------

S22 (B/R)
REFL REV

②-2 

CAL
-----

CAL MENUS
-----------

1 PORT
FULL CAL

②-3 Connect open standard to test cable and press 

OPEN
------

 key.

②-4 Connect short standard to test cable and press 

SHORT
-------

 key.

②-5 Connect load standard to test cable and press 

LOAD
------


 key.

②-6 Press 

DONE
1-PORT


6.3 Test Port Load Match

- ③ Connect test cable to TEST PORT 1 and read out the measurement value of the test port load match by marker from the wave form data.



**Check out** Load match of TEST PORT 1 40MHz to 2.6GHz Less than 18 dB  
 2.6GHz to 3.8GHz Less than 16 dB  
 3.8GHz to 8.0GHz Less than 14 dB

- ④ Connect test cable to TEST PORT 1 and execute 1 PORT FULL CAL.



④-1 

CH1
-----

MEAS
------

S11 (A/R)
REFL FWD

④-2 CAL CAL MENUS 1 PORT FULL CAL


④-3 Connect open standard to test cable and press OPEN key.

④-4 Connect short standard to test cable and press SHORT key.

④-5 Connect load standard to test cable and press LOAD key.

④-6 Press DONE 1-PORT

⑤ Connect test cable to TEST PORT 2 and read out the measurement value of the test port load match by marker from the wave form data.




Check out

Load match of TEST PORT 2	40MHz to 2.6GHz	Less than 18 dB
	2.6GHz to 3.8GHz	Less than 16 dB
	3.8GHz to 8.0GHz	Less than 14 dB

6.3 Test Port Load Match

(2) R3963A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable to TEST PORT 1 and execute 1 PORT FULL CAL.



②-1 CH1 MEAS S22 (B/R)  
REFL REV

②-2 CAL CAL MENUS 1 PORT  
FULL CAL

②-3 Connect open standard to test cable and press OPEN key.

②-4 Connect short standard to test cable and press SHORT key.


②-5 Connect load standard to test cable and press LOAD key.

②-6 Press DONE  
1-PORT




6.3 Test Port Load Match

- ③ Connect test cable to ANT PORT and read out the measurement value of the test port load match by marker from the wave form data.



Check out	Load match of ANT PORT	40MHz to 2.6GHz	Typical 25 dB
		2.6GHz to 3.8GHz	Typical 20 dB
		3.8GHz to 8.0GHz	Typical 14 dB

- ④ Connect test cable to ANT PORT and execute 1 PORT FULL CAL.



④-1	CH1	MEAS	S11 (A/R) REFL FWD
-----	-----	------	-----------------------

6.3 Test Port Load Match




④-3 Connect open standard to test cable and press OPEN key.

④-4 Connect short standard to test cable and press SHORT key.

④-5 Connect load standard to test cable and press LOAD key.


④-6 Press DONE 1-PORT

⑤ Connect test cable to TEST PORT 1 and read out the measurement value of the test port load match by marker from the wave form data.




Check out	Load match TEST PORT 1	40MHz to 2.6GHz	Typical 18 dB
		2.6GHz to 3.8GHz	Typical 20 dB
		3.8GHz to 8.0GHz	Typical 14 dB

- ⑥ Connect test cable to TEST PORT 2.



⑥-1 CH2 MEAS S11 (A/R)  
REFL FWD

- ⑦ Read out the value of the test port load match by marker from the wave form data.



Check out	Load match TEST PORT 2	40MHz to 2.6GHz	Typical 18 dB
		2.6GHz to 3.8GHz	Typical 20 dB
		3.8GHz to 8.0GHz	Typical 14 dB


6.4 Frequency characteristic

6.4 Frequency characteristic

6.4.1 Transmission amplitude characteristic

(1) R3962A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable between TEST PORT 1 and TEST PORT 2.



②-1 CH1 MEAS S21 (B/R) TRNS FWD

②-2 SCALE AUTO SCALE

③ Read out the frequency characteristic by marker from the wave form data.

③-1 MKR → MKR SEARCH [ ] RIPPLE MAX-MIN

③-2 Transmission amplitude characteristic between TEST PORT 1 and TEST PORT 2 is displayed in the marker value.

**Check out** Transmission amplitude characteristic between TEST PORT 1 and TEST PORT 2 Typical 3 dBp-p

④ Change set up for the measurement of the frequency characteristic between TEST PORT 2 and TEST PORT 1.


④-1 MEAS S12 (A/R) TRNS REV

④-2 SCALE AUTO SCALE

⑤ Read out the frequency characteristic by marker from the wave form data.





⑤-2 Transmission amplitude characteristic between TEST PORT 2 and TEST PORT 1 is displayed in the marker value.




(2) R3963A/B

① Connect with the Network Analyzer for set up the performance test.


② Connect test cable between ANT PORT and TEST PORT 1.



③ Read out the frequency characteristic by marker from the wave form data.



③-2 Transmission amplitude characteristic between ANT PORT and TEST PORT 1 is displayed in the marker value.



6.4 Frequency characteristic

- ④ Change set up for the measurement of the frequency characteristic between TEST PORT 1 and ANT PORT.

④-1

MEAS	S12 (A/R) TRNS REV
------	-----------------------

④-2

SCALE	AUTO SCALE
-------	------------

- ⑤ Read out the frequency characteristic by marker from the wave form data.


⑤-1

MKR →	MKR SEARCH [            ]	RIPPLE	MAX-MIN
-------	------------------------------	--------	---------

- ⑤-2 Transmission amplitude characteristic between TEST PORT 1 and ANT PORT is displayed in the marker value is displayed.

Check out	Transmission amplitude characteristic between TEST PORT 1 and ANT PORT	Typical 3 dBp-p
-----------	--	-----------------

- ⑥ Connect test cable between TEST PORT 2 and ANT PORT.



⑥-1

CH2	MEAS	S21 (B/R) TRNS FWD
-----	------	-----------------------

⑥-2

SCALE	AUTO SCALE
-------	------------

- ⑦ Read out the frequency characteristic by marker from the wave form data.

⑦-1

MKR →	MKR SEARCH [            ]	RIPPLE	MAX-MIN
-------	------------------------------	--------	---------

- ⑦-2 Transmission amplitude characteristic between ANT PORT and TEST PORT 2 is displayed in the marker value.

**Check out** Transmission amplitude characteristic between ANT PORT and TEST PORT 2 Typical 3 dBp-p

- ⑧ Change set up for the measurement of the frequency characteristic between TEST PORT 2 and ANT PORT.

⑧-1 **MEAS** S12 (A/R)  
TRNS REV

⑧-2 **SCALE** AUTO SCALE

- ⑨ Read out the frequency characteristic by marker from the wave form data.

⑨-1 **MKR →** MKR SEARCH [ ] RIPPLE MAX-MIN


- ⑨-2 Transmission amplitude characteristic between TEST PORT 2 and ANT PORT is displayed in the marker value.

**Check out** Transmission amplitude characteristic between TEST PORT 2 and ANT PORT Typical 3 dBp-p

### 6.4.2 Reflection amplitude characteristic

- (1) R3962A/B

- ① Connect with the Network Analyzer for set up the performance test.  
② Connect short standard to TEST PORT 1.



6.4 Frequency characteristic

②-1 CH1 MEAS S11 (A/R)  
REFL FWD

②-2 SCALE AUTO SCALE


③ Read out the frequency characteristic by marker from the wave form data.

③-1 MKR → MKR SEARCH [ ] RIPPLE MAX-MIN

③-2 Frequency characteristic of TEST PORT 1 is displayed in the marker value.

**Check out** Reflection amplitude characteristic of TEST PORT 1 Typical 4 dBp-p

④ Connect short standard to TEST PORT 2.



④-1 CH1 MEAS S22 (B/R)  
REFL REV

④-2 SCALE AUTO SCALE

⑤ Read out the frequency characteristic by marker from the wave form data.

⑤-1 MKR → MKR SEARCH [ ] RIPPLE MAX-MIN


⑤-2 Frequency characteristic of TEST PORT 2 is displayed in the marker value.

**Check out** Reflection amplitude characteristic of TEST PORT 2 Typical 4 dBp-p



(2) R3963A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect short standard to ANT PORT.



②-1 CH1 MEAS S11 (A/R)  
REFL RWD

②-2 SCALE AUTO SCALE

- ③ Read out the frequency characteristic by marker from the wave form data.


③-1 MKR → MKR SEARCH RIPPLE MAX-MIN  
[ ]

- ③-2 Frequency characteristic of ANT PORT is displayed in the marker value.

**Check out** Reflection amplitude characteristic of ANT PORT      Typical 4 dBp-p

6.4 Frequency characteristic

- ④ Connect short standard to TEST PORT 1.



- ④-1 CH1 MEAS S22 (B/R)  
REFL REV

- ④-2 SCALE AUTO SCALE


- ⑤ Read out the frequency characteristic by marker from the wave form data.

- ⑤-1 MKR → MKR SEARCH RIPPLE MAX-MIN  
[ ]

- ⑤-2 Frequency characteristic of TEST PORT 1 is displayed in the marker value.

**Check out** Reflection amplitude characteristic of TEST PORT 1 Typical 6 dBp-p

- ⑥ Connect short standard to TEST PORT 2.



- ⑥-1 CH2 MEAS S22 (B/R)  
REFL REV

- ⑥-2 SCALE AUTO SCALE

- ⑦ Read out the frequency characteristic by marker from the wave form data.

- ⑦-1 MKR → MKR SEARCH RIPPLE MAX-MIN  
[ ]

- ⑦-2 Frequency characteristic of TEST PORT 2 is displayed in the marker value.


**Check out** Reflection amplitude characteristic of TEST PORT 2 Typical 6 dBp-p

6.5 Insertion loss

6.5 Insertion loss

(1) R3962A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Change the connection using by the test cable as shown figure below.




②-1 CH1 MEAS S21 (B/R)  
TRNS FWD

②-2 SCALE AUTO SCALE

- ③ Read out the insertion loss between INPUT and TEST PORT 1 by marker from the wave form data.

Check out Insertion loss between INPUT and TEST PORT 1 Typical 9 dB

- ④ Change the cable connection as shown figure below.



④-1 MEAS S12 (A/R)  
TRNS REV


④-2 

SCALE	AUTO SCALE
-------	------------

⑤ Read out the insertion loss between INPUT and TEST PORT 2 by marker from the wave form data.

**Check out** Insertion loss between INPUT and TEST PORT 2      Typical 9 dB

⑥ Change the cable connection as shown figure below.



⑥-1 

MEAS	S11 (A/R) REFL FWD
------	-----------------------


⑥-2 

SCALE	AUTO SCALE
-------	------------

⑦ Read out the insertion loss between TEST PORT 1 and A PORT by marker from the wave form data.

**Check out** Insertion loss between TEST PORT 1 and A PORT      Typical 15 dB

⑧ Change the cable connection as shown figure below.



6.5 Insertion loss

⑧-1 MEAS S22 (B/R)  
REFL REV

⑧-2 SCALE AUTO SCALE


⑨ Read out the insertion loss between TEST PORT 2 and B PORT by marker from the wave form data.

**Check out** Insertion loss between TEST PORT 2 and B PORT Typical 15 dB

(2) R3963A/B

① Connect with the Network Analyzer for set up the performance test.

② Change the cable connection as shown figure below.




②-1 CH1 MEAS S21 (B/R)  
TRNS FWD

②-2 SCALE AUTO SCALE

③ Read out the insertion loss between INPUT and ANT PORT by marker from the wave form data.

**Check out** Insertion loss between INPUT and ANT PORT Typical 9 dB

- ④ Change the cable connection as shown figure below.




④-1 CH1 MEAS S12 (A/R)  
TRNS REV

④-2 SCALE AUTO SCALE

- ⑤ Read out the insertion loss between INPUT and TEST PORT 1 by marker from the wave form data.

Check out Insertion loss between INPUT and TEST PORT 1 Typical 12 dB

- ⑥ Change the cable connection as shown figure below.



⑥-1 CH2 MEAS S12 (A/R)  
TRNS REV


⑥-2 SCALE AUTO SCALE

6.5 Insertion loss

- ⑦ Read out the insertion loss between INPUT and TEST PORT 2 by marker from the wave form data.

**Check out** Insertion loss between INPUT and TEST PORT 2      Typical 12 dB

- ⑧ Change the cable connection as shown figure below.




⑧-1 CH1 MEAS S11 (A/R)  
REFL FWD

⑧-2 SCALE AUTO SCALE

- ⑨ Read out the insertion loss between ANT PORT and A PORT by marker from the wave form data.

**Check out** Insertion loss between ANT PORT and A PORT      Typical 15 dB

- ⑩ Change the cable connection as shown figure below.






⑩-1 CH1 MEAS S22 (B/R)  
REFL REV

⑩-2 SCALE AUTO SCALE

- ⑪ Read out the insertion loss between TEST PORT 1 and B PORT by marker from the wave form data.

**Check out** Insertion loss between TEST PORT 1 and B PORT Typical 18 dB

- ⑫ Change the cable connection as shown figure below.



⑫-1 CH2 MEAS S22 (B/R)  
REFL REV

⑫-2 SCALE AUTO SCALE



- ⑬ Read out the insertion loss between TEST PORT 2 and B PORT by marker from the wave form data.

**Check out** Insertion loss between TEST PORT 2 and B PORT Typical 18 dB

6.5 Insertion loss

(3) R3964A/B


- ① Connect with the Network Analyzer for set up the performance test.
- ② Change the cable connection as shown figure below.



- ③ Read out the insertion loss between PORT 1 and ANT PORT by marker from the wave form data.

**Check out** Insertion loss between PORT 1 and ANT PORT      Typical 2 dB

- ④ Change the cable connection as shown figure below.




④-1 CH1 MEAS S12 (A/R)  
TRNS REV

④-2 SCALE AUTO SCALE

- ⑤ Read out the insertion loss between PORT 2 and TEST PORT 1 by marker from the wave form data.

**Check out** Insertion loss between PORT 2 and TEST PORT 1 Typical 4 dB

- ⑥ Change the cable connection as shown figure below.



⑥-1 CH2 MEAS S12 (A/R)  
TRNS REV

⑥-2 SCALE AUTO SCALE

- ⑦ Read out the insertion loss between PORT 2 and TEST PORT 2 by marker from the wave form data.


**Check out** Insertion loss between PORT 2 and TEST PORT 2 Typical 4 dB

6.6 Isolation

6.6 Isolation

(1) R3962A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable between TEST PORT 1 and TEST PORT 2.



②-1 CH1 MEAS S21 (B/R)  
TRNS FWD



②-2 SCALE /DIV 1 0 X1

REF POS 5 0 X1

REF VALUE - 9 0 X1

②-3 CAL NORMLIZE  
(THRU)

- ③ Disconnect connected cable to B PORT of Network Analyzer and connect load standard.




- ④ Average count is displayed at upper left on the screen  
When average count became 64 then execute following set up.



- ⑤ Connect cable between B PORT of Network Analyzer and B PORT of S Parameter test set.

Disconnect test cable between TEST PORT 1 and TEST PORT 2 and connect load standard to TEST PORT 2.



6.6 Isolation

⑤-1 

AVG	AVG RESTART
-----	----------------

⑥ When average count became 64 then read out isolation value by marker.

<b>Check out</b>	Isolation of TEST PORT 1 and	40MHz to 2.6GHz	-90dB
	TEST PORT 2	2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB

Check out is completed then execute following set up.


⑥-1 

AVG	AVG STATE OFF
-----	------------------

⑥-2 

DISPLAY	DEFINE TRACE [DATA-MEN]	OFF
---------	-------------------------------	-----

⑦ Connect test cable between TEST PORT 1 and TEST PORT 2.



⑦-1 


CH1	MEAS	S12 (A/R) TRNS REV
-----	------	-----------------------

⑦-2 



SCALE	/DIV	1	0	X1
-------	------	---	---	----

REF POS	5	0	X1
---------	---	---	----


REF VALUE	-	9	0	X1
-----------	---	---	---	----




- ⑧ Disconnect connected cable to A PORT of Network Analyzer and connect load stand-ard.



- ⑨ Average count is displayed at upper left on the screen.  
When average count became 64 then execute following set up.



- ⑩ Connect cable between A PORT of Network Analyzer and A PORT of S parameter test set.  
Disconnect test cable between TEST PORT 1 and TEST PORT 2 and connect load standard to TEST PORT 1.



6.6 Isolation

⑩-1 

AVG
-----


AVG RESTART
----------------

⑪ When average count became 64 then read out isolation value by marker.

<b>Check out</b>	Isolation of TEST PORT 1 and TEST PORT 2	40MHz to 2.6GHz	-90dB
		2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB

(2) R3963A/B

- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable between ANT PORT and TEST PORT 1.



②-1 

CH1
-----

MEAS
------

S21 (B/R) TRNS FWD
-----------------------

②-2 

SCALE
-------

/DIV
------

1
---

0
---

X1
----

REF POS
---------

5
---

0
---

X1
----

REF VALUE
-----------

-
---

9
---

0
---

X1
----



②-3 

CAL
-----

NORMLIZE (THRU)
--------------------




- ③ Disconnect connected cable to B PORT of Network Analyzer and connect load standard.



- ④ Average count is displayed at upper left on the screen.  
When average count became 64 then execute following set up.



- ⑤ Connect cable between B PORT of Network Analyzer and B PORT of S Parameter test set.  
Disconnect test cable between ANT PORT and TEST PORT 1 and connect load standard to TEST PORT 1.




6.6 Isolation







⑥ When average count became 64 then read out isolation value by marker.

Check out	Isolation of ANT PORT and TEST PORT 1	40MHz to 2.6GHz	-90dB
		2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB

Check out is completed then execute following set up.




⑦ Connect test cable between ANT PORT and TEST PORT 1.



⑦-3 CAL NORMLIZE  
(THRU)

- ⑧ Disconnect connected cable to A PORT of Network Analyzer and connect load stand-ard.



⑧-1 AVG AVG STATE  
ON


- ⑨ Average count is displayed at upper left on the screen.  
When average count became 64 then execute following set up.

⑨-1 DISPLAY DATA → MEMORY DEFINE TRACE [ ] DATA — MEMORY

6.6 Isolation

- ⑩ Connect cable between A PORT of Network Analyzer and A PORT of S parameter test set.

Disconnect test cable between ANT PORT and TEST PORT 1 and connect load standard to ANT PORT.



- ⑩-1

- ⑪ When average count became 64 then read out isolation value by marker.


<input type="button" value="Check out"/>	Isolation of TEST PORT 1 and	40MHz to 2.6GHz	-90dB
	ANT PORT	2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB

Check out is completed then execute following set up.

- ⑪-1

- ⑪-2

- ⑫ Connect test cable between ANT PORT and TEST PORT 2.



⑫-1 CH2 MEAS S21 (B/R)  
TRNS FWD


⑫-2 SCALE /DIV 1 0 X1

REF POS 5 0 X1

REF VALUE - 9 0 X1

⑫-3 CAL NORMLIZE  
(THRU)

- ⑬ Disconnect connected cable to B PORT of Network Analyzer and connect load standard.



⑬-1 AVG AVG COUNT 6 4 X1 AVG STATE  
ON

6.6 Isolation



- ⑭ Average count is displayed at upper left on the screen.

When average count became 64 then execute following set up.



- ⑮ Connect cable between B PORT of Network Analyzer and B PORT of S parameter test set.


Disconnect test cable between ANT PORT and TEST PORT 2 and connect load standard to TEST PORT 2.




- ⑯ When average count became 64 then read out isolation value by marker.

Check out	Isolation of ANT PORT and TEST PORT 2	40MHz to 2.6GHz	-90dB
		2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB

Check out is completed then execute following set up.



- ⑰ Connect test cable between ANT PORT and TEST PORT 2.



- ⑰-1 CH2 MEAS S12 (A/R)  
TRNS FWD


- ⑰-2 SCALE /DIV 1 0 X1

- REF POS 5 0 X1

- REF VALUE - 9 0 X1

- ⑰-3 CAL NORMLIZE  
(THRU)

- ⑱ Disconnect connected cable to A PORT of Network Analyzer and connect load stand-ard.



- ⑱-1 AVG AVG STATE  
ON

6.6 Isolation



⑲ Average count is displayed at upper left on the screen.

When average count became 64 then execute following set up.



⑳ Connect cable between A PORT of Network Analyzer and A PORT of S parameter test set

Disconnect test cable between ANT PORT and TEST PORT 2 and connect load standard to ANT PORT.








㉒ When average count became 64 then read out isolation value by marker.

Check out	Isolation of TEST PORT 2 and ANT PORT	40MHz to 2.6GHz	-90dB
		2.6GHz to 3.8GHz	-85dB
		3.8GHz to 5GHz	-70dB
		5GHz to 8GHz	-60dB




(3) R3964A/B


- ① Connect with the Network Analyzer for set up the performance test.
- ② Connect test cable between ANT PORT and TEST PORT 1.




- ③ Disconnect connected cable to TEST PORT 2 of Network Analyzer and connect load standard.



6.6 Isolation





- ④ Average count is displayed at upper left on the screen.  
When average count became 64 then execute following set up.



- ⑤ Connect cable between TEST PORT 2 of Network Analyzer and PORT 2 of S Parameter test set.


Disconnect test cable between ANT PORT and TEST PORT 1 and connect load standard to TEST PORT 1.



- ⑥ When average count became 64 then read out isolation value by marker.





Check out	Isolation of ANT PORT and TEST PORT 1	40MHz to 2.6GHz	-87dB
		2.6GHz to 3.8GHz	-82dB
		3.8GHz to 5GHz	-67dB
		5GHz to 8GHz	-57dB

Check out is completed then execute following set up.







⑦ Connect test cable between ANT PORT and TEST PORT 1.



6.6 Isolation

- ⑧ Disconnect connected cable TEST PORT 1 of Network Analyzer and connect load standard.




- ⑨ Average count is displayed at upper left on the screen.

When average count became 64 then execute following set up.



- ⑩ Connect cable between TEST PORT 1 of Network Analyzer and PORT 1 of S parameter test set. Disconnect test cable between ANT PORT and TEST PORT 1, and connect load standard to TEST PORT 1.



⑩-1 

AVG	AVG RESTART
-----	----------------

⑪ When average count became 64 then read out isolation value by marker.

Check out	Isolation of TEST PORT 1 and	40MHz to 2.6GHz	-87dB
	ANT PORT	2.6GHz to 3.8GHz	-82dB
		3.8GHz to 5GHz	-67dB
		5GHz to 8GHz	-57dB

Check out is completed then execute following set up.


⑪-1 

AVG	AVG STATE OFF
-----	------------------

⑪-2 

DISPLAY	DEFINE TRACE [DATA-MEN]	OFF
---------	-------------------------------	-----

⑫ Connect test cable between ANT PORT and TEST PORT 2.



⑫-1 

CH2	MEAS	S21 (B/R) TRNS FWD
-----	------	-----------------------

⑫-2 

SCALE	/DIV	1	0	X1
-------	------	---	---	----

REF POS	5	0	X1
---------	---	---	----



REF VALUE	-	9	0	X1
-----------	---	---	---	----

⑫-3 

CAL	NORMLIZE (THRU)
-----	--------------------

6.6 Isolation

- ⑬ Disconnect connected cable TEST PORT 2 of Network Analyzer and connect load standard.




- ⑭ Average count is displayed at upper left on the screen.  
When average count became 64 then execute following set up.



- ⑮ Connect cable between TEST PORT 2 of Network Analyzer and PORT 2 of S parameter test set.

Disconnect test cable between ANT PORT and TEST PORT 2, and connect load standard to TEST PORT 2.



⑮-1 [AVG] [AVG RESTART]

⑯ When average count became 64 then read out isolation value by marker.


Check out	Isolation of ANT PORT and TEST PORT 2	40MHz to 2.6GHz	-87dB
		2.6GHz to 3.8GHz	-82dB
		3.8GHz to 5GHz	-67dB
		5GHz to 8GHz	-57dB

Check out is completed then execute following set up.

⑯-1 [AVG] [AVG STATE OFF]

⑯-2 [DISPLAY] [DEFINE TRACE [DATA-MEN]] [OFF]

⑰ Connect test cable between ANT PORT and TEST PORT 2.



⑰-1 [CH2] [MEAS] [S12 (A/R) TRNS FWD]

⑰-2 [SCALE] [/DIV] [1] [0] [X1]


[REF POS] [5] [0] [X1]

[REF VALUE] [-] [9] [0] [X1]

6.6 Isolation

- ⑰-3 CAL    NORMLIZE (THRU)

- ⑱ Disconnect connected cable to TEST PORT 1 of Network Analyzer and connect load standard.



- ⑱-1 AVG    AVG STATE ON

- ⑲ Average count is displayed at upper left on the screen.


When average count became 64 then execute following set up.

- ⑲-1 DISPLAY    DATA → MEMORY    DEFINE TRACE [    ]    DATA ← MEMORY



- ⑩ Connect cable between TEST PORT 1 of Network Analyzer and PORT 1 of S parameter test set.

Disconnect test cable between ANT PORT and TEST PORT 2, and connect load standard to ANT PORT.



- ⑩-1 

AVG	AVG RESTART
-----	----------------

- ⑪ When average count became 64 then read out isolation value by marker.

<b>Check out</b>	Isolation of TEST PORT 2 and ANT PORT	40MHz to 2.6GHz	-87dB
		2.6GHz to 3.8GHz	-82dB
		3.8GHz to 5GHz	-67dB
		5GHz to 8GHz	-57dB



## 7 Specifications

### 7.1 R3962A/B

Items	R3962A/B
Frequency range	40MHz to 8.0GHz
Directivity (25°C±5°C)	30dB (40MHz to 2.6GHz) 26dB (2.6GHz to 3.8GHz) 22dB (3.8GHz to 8.0GHz)
Test port load match (25°C±5°C)	18dB (40MHz to 2.6GHz) 16dB (2.6GHz to 3.8GHz) 14dB (3.8GHz to 8.0GHz)
Frequency characteristic Transmission amplitude TEST PORT1 to TEST PORT2 Reflection amplitude TEST PORT1 TEST PORT2	Typical 3dBp-p  Typical 4dBp-p Typical 4dBp-p
Insertion loss INPUT to TEST PORT1, 2 TEST PORT1 to A PORT TEST PORT2 to B PORT	Typical 9dB Typical 15dB Typical 15dB
RF damage level	+21dBm max
Maximum port bias	±30VDC, 0.5A (except the R3962B)
Isolation ANT PORT to TEST PORT1 ANT PORT to TEST PORT2	90dB (40MHz to 2.6GHz) 85dB (2.6GHz to 3.8GHz) 70dB (3.8GHz to 5.0GHz) 60dB (5.0GHz to 8.0GHz)
Operating condition	Temperature 0°C to +50°C Relative humidity 80% or less (Non-condensing)
Storage temperature	-20°C to +60°C
Programming and remote control	All of the functions can be controlled by R3765A or R3767A. GPIB interface of R3765A and R3767A for remote control is in common.
Power	Power is supplied from R 3765A or R3767A
Mass	Less than 5 kg
Dimensions	R3962A: Approximately 424(Width) × 88(Height) × 400(Length) mm R3962B: Approximately 250(Width) × 80(Height) × 165(Length) mm

## 7.2 R3963A/B

## 7.2 R3963A/B

\* for 2 port full calibration

Items	R3963A/B
Frequency range	40MHz to 8.0GHz
Directivity (25°C±5°C) ANT PORT  TEST PORT1, 2	Typical 30dB * Typical 40dB (40MHz to 2.6GHz) Typical 29dB * Typical 32dB (2.6GHz to 3.8GHz) Typical 25dB * Typical 26dB (3.8GHz to 8.0GHz) Typical 15dB * Typical 40dB (40MHz to 2.6GHz) Typical 20dB * Typical 32dB (2.6GHz to 3.8GHz) Typical 8dB * Typical 26dB (3.8GHz to 8.0GHz)
Test port load match (25°C±5°C) ANT PORT  TEST PORT1, 2	Typical 25dB * Typical 40dB (40MHz to 2.6GHz) Typical 20dB * Typical 32dB (2.6GHz to 3.8GHz) Typical 14dB * Typical 26dB (3.8GHz to 8.0GHz) Typical 18dB * Typical 40dB (40MHz to 2.6GHz) Typical 20dB * Typical 32dB (2.6GHz to 3.8GHz) Typical 14dB * Typical 26dB (3.8GHz to 8.0GHz)
Frequency characteristic Transmission amplitude ANT PORT → TEST PORT1 ANT PORT → TEST PORT2 Reflection amplitude ANT PORT TEST PORT1 TEST PORT2	Typical 3dBp-p Typical 3dBp-p  Typical 4dBp-p Typical 6dBp-p Typical 6dBp-p
Insertion loss INPUT to ANT PORT INPUT to TEST PORT1, 2 ANT PORT to A PORT TEST PORT1, 2 to B PORT	Typical 9dB Typical 12dB Typical 15dB Typical 18dB
RF damage level	+20dBm max
Isolation ANT PORT to TEST PORT1 ANT PORT to TEST PORT2	90dB (40MHz to 2.6GHz) 85dB (2.6GHz to 3.8GHz) 70dB (3.8GHz to 5.0GHz) 60dB (5.0GHz to 8.0GHz)
Operating condition	Temperature 0°C to +50°C Relative humidity 80% or less (Non-condensing)
Storage temperature	-20°C to +60°C
Programming and remit control	All of the functions can be controlled by R3765A or R3767A. GPIB interface of R3765A and R3767A for remote control is in common.
Power	Power is supplied from R 3765A or R3767A
Mass	Less than 5 kg
Dimensions	R3963A: Approximately 424(Width)×88(Height)×400(Length)mm R3963B: Approximately 250(Width)×80(Height)×165(Length)mm

## 7.3 R3964A/B

Items	R3964A/B
Frequency range	40MHz to 8.0GHz
Insertion loss PORT1 to ANT PORT PORT2 to TEST PORT1 PORT2 to TEST PORT2	Typical 2dB Typical 4dB Typical 4dB
RF damage level	+20dBm max
Isolation ANT PORT to TEST PORT	87dB (40MHz to 2.6GHz) 82dB (2.6GHz to 3.8GHz) 67dB (3.8GHz to 5.0GHz) 57dB (5.0GHz to 8.0GHz)
Operating condition	Temperature 0°C to +50°C Relative humidity 80% or less (Non-condensing)
Storage temperature	-20°C to +60°C
Programming and remote control	All of the functions can be controlled by R3765C or R3767C. GPIB interface of R3765C and R3767C for remote control is in common.
Power	Power is supplied from R 3765C or R3767C
Mass	Less than 5 kg
Dimensions	R3964A: Approximately 424(Width) × 88(Height) × 400(Length) mm R3964B: Approximately 250(Width) × 80(Height) × 165(Length) mm



## ALPHABETICAL INDEX

	<b>[A]</b>				
Accessories .....		1-2		Outline of the measurement .....	4-1
	<b>[B]</b>			<b>[P]</b>	
Block diagram of R3962A/B .....		5-3		Principle operation .....	5-1
Block diagram of R3963A/B .....		5-6		Principle operation of R3962A/B .....	5-2
Block diagram of R3964A/B .....		5-9		Principle operation of R3963A/B .....	5-5
	<b>[C]</b>			Principle operation of R3964A/B .....	5-8
Connection for the front panel of R3962A		3-1		Products outline .....	1-1
Connection for the front panel of R3962B		3-1		<b>[R]</b>	
Connection for the front panel of R3963A		3-2		Rear panel of R3962A, R3963A and R3964A	2-4
Connection for the front panel of R3963B		3-2		Rear panel of R3962B .....	2-4
Connection for the front panel of R3964A		3-3		Rear panel of R3963B .....	2-5
Connection for the front panel of R3964B		3-3		Rear panel of R3964B .....	2-5
Connection for the rear panel side of A type		3-4		<b>[S]</b>	
Connection on the front panel side .....		3-1		Sample measurement .....	4-2
Connection on the rear panel side .....		3-4		Specifications .....	7-1
Connection with the Network Analyzer ...		3-1		standard accessories .....	1-2
Connection 1 for the rear panel side of B type .....		3-4			
Connection 2 for the rear panel side of R3962B/R3963B .....		3-5			
Connection 2 for the rear panel side of R3964B .....		3-5			
	<b>[D]</b>				
Description of the front and rear panel ....		2-1			
Description of the front panel .....		2-1			
Description of the rear panel .....		2-4			
	<b>[F]</b>				
Front panel of R3962A .....		2-1			
Front panel of R3962B .....		2-1			
Front panel of R3963A .....		2-2			
Front panel of R3963B .....		2-2			
Front panel of R3964A .....		2-3			
Front panel of R3964B .....		2-3			
	<b>[M]</b>				
Measurement .....		4-1			
	<b>[O]</b>				
Option accessories .....		1-3			
Outline .....		1-1			





## **IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE**

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

### **SOFTWARE License**

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

### **Restrictions**

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

### **Liability**

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

## LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
  - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
  - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
  - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
  - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
  - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
  - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
  - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
  - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

## **CUSTOMER SERVICE DESCRIPTION**

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

## SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,  
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea  
Phone: +82-2-532-7071  
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:  
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.  
Phone: +86-21-6485-2725  
Fax: +86-21-6485-2726

Shanghai Branch Office:  
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,  
Hai Dian District, Beijing,  
China 100083  
Phone: +86-10-8235-3377  
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06  
Alexandra Technopark Singapore 119967  
Phone: +65-6274-3100  
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A  
Phone: +1-408-988-7700  
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany  
(P.O.B. 80 14 60 D-81614 München, Germany)  
Phone: +49-89-4129-13711  
Fax: +49-89-4129-13723

**ADVANTEST**<sup>®</sup>

<http://www.advantest.co.jp>