

Centering a Pulse Waveform

Hideo Okawara
Verigy Japan

1. Introduction

In a settling time measurement, rise/fall time calculation, and tests known as template fitting test, samplers are used to record waveforms.

The test signal waveform in such applications is usually a clock signal with 50% duty ratio. A single pulse waveform is captured in a unit test period as shown in the following example.




Figure 1. Example Captured Waveform

You may want to shift this waveform in the unit test period window to a position so you can analyze and parameterize it.

As used in this technical note, the meaning of “centering” is that you can shift your waveform to any desired phase.




Figure 2. Phase Shifting

2. Methodology of Phase Shifting

This shifting method uses Fourier's Fast Transform (FFT). The phase information of the fundamental component corresponds to the position of the pulse.

The procedure is quite simple, as follows:

1. Apply FFT to the raw data
2. Calculate the phase of the fundamental component
3. Calculate the phase distance between the desired position and the current location
4. Translate the phase distance into the data array step size (N)
5. Shift the array data N points

3. Example Program

The model code is listed below. The variable "dTargetPhase" is the desired phase to which you want to move your waveform.

```
void Shift_Pulse(ARRAY_D& dVsmp, ARRAY_D& dWave, double dTargetPhase) {
/*****
* ARRAY_D & dVsmp : Input Parameter : Measured pulse data
* ARRAY_D & dWave : Output Parameter : Shifted pulse data
* double          : Input Parameter : Target phase in RADIAN
*****/
    int i, j, N;
    double dAx, dPx;
```

```

double dQx, dX;
ARRAY_COMPLEX CSp;
int Nsamp;

void RectPolar(COMPLEX *, double *, double *);

Nsamp = dVsmp.size();

CSp.resize(Nsamp/2);
DSP_FFT(dVsmp, CSp, RECT);
RectPolar(&CSp[1], &dAx, &dPx);

dQx = dTargetPhase - dPx;
dX = 2.0 * M_PI / Nsamp;

/* How many steps to be shifted */
if (dQx >= 0.0) N = (int)(dQx/dX + 0.5);
else          N = (int)(dQx/dX - 0.5) + Nsamp;

/* Shift data N points */
i = N;
j = 0;
while (i < Nsamp) {
    dWave[j] = dVsmp[i];
    i++, j++;
}
i = 0;
while (i < N) {
    dWave[j] = dVsmp[i];
    i++, j++;
}
}

void RectPolar(COMPLEX * CAx, double * dLength, double * dArgument) {
    double dR, dArg;

    dR = sqrt(CAx->real() * CAx->real() + CAx->imag() * CAx->imag());

    if (dR == 0.0) {
        dArg = 0.0;
    }
    else {
        if (CAx->real() == 0.0) {
            if (CAx->imag() >= 0.0) dArg = 0.5 * M_PI;
            else dArg = -0.5 * M_PI;
        }
        else {
            dArg = atan2(CAx->imag(), CAx->real());
        }
    }
}

*dLength = dR;

```

```

    *dArgument = dArg;
}

```

4. Example Waveforms of Phase Shifting




Figure 3. Raw Waveform




Figure 4. Phase Shifting – 0 drg.

Centering (90 deg)




Figure 5. Phase Shifting – 90 deg.

Centering (180 deg)




Figure 6. Phase Shifting – 180 deg.

Centering (270 deg)




Figure 7. Phase Shifting – 270 deg.