

ADVANTEST CORPORATION

R3681 Series User's Guide

MANUAL NUMBER FOE-8440090H00

Applicable Models R3681 R3671

TABLE OF CONTENTS

1.	INTRODUCTION
1.1	Organization of This Document
1.2	Product Overview
1.3	Other Manuals Pertaining to This Instrument
1.4	Conventions of Notation Used in This Document
1.5	Trademarks and Registered Trademarks
2.	PRE-OPERATION TIPS
2.1	If Faults Should Occur
2.2	Removing of Case
2.3	Overcurrent Protection
2.4	Hard Disk Drive
2.5	Handling the Touch Screen
2.6	Getting the Software Running with Stability
2.7	Tip on Transportation
2.8	Electromagnetic Interference
2.9	Note for Power-on
2.10	Notes for Removing and Attaching the Panel
2.11	Limitations Imposed when Using Windows XP
2	CDM ID
3.	SETUP
3.1	Unpacking Inspection
3.2	Locating This Instrument
3.2.1	Operating Environment
3.2.2	Prevention of Electrostatic Buildup
3.3	Connecting Accessories
3.3.1	Connecting the Keyboard and Mouse
3.3.2 3.4	Caution when Connecting Peripherals
3.4.1	Check the supply power
3.4.2	Connecting the Power Cable
3.5	Operation Check
4.	QUICK START
4.1	Description of the Panels and the Screen
4.1.1	The Name and Functions of Each Component on the Front Panel
4.1.2	The Name and Function of Each Component on the Screen
4.1.3	The Name and Function of Each Component on the Rear Panel
4.2	Basic Operation
4.2.1	Menu Operation and Data Entry
4.3	Basic Measurement
4.3.1	Autocalibration

Table of Contents

4.3.2 4.3.3 4.3.4	Display of Spectrum and Operation of Markers
5.	MENU MAP, FUNCTIONAL EXPLANATION
5.1	Menu Index
5.2	Menu Bar
5.2.1	[File]
5.2.2	[System]
5.2.3	[Config]
5.2.4	[Modulation]
5.2.5	[Cal]
5.2.6	[Special]
5.3	Function Bar
5.3.1	{FREQ}
5.3.2	{SPAN}
5.3.3	{LEVEL}
5.3.4	{BW}
5.3.5	{SWEEP}
5.3.6	{MKR→}
5.3.7	{SEARCH}
5.3.8	{MKR}
5.3.9	{TRACE}
5.3.10	{MENU2>>}
5.3.11	{POWER}
5.3.12	{MEAS}
5.3.13	{PASS/FAIL}
5.3.14	{DISPLAY}
5.3.15	{MENU1>>´}
5.4	Tool Menu
6.	SPECIFICATIONS
6.1	R3681 Performance Specifications
6.1.1	Frequency
6.1.2	
6.1.3	Sweep
	Amplitude
6.1.4	Amplitude Accuracy
6.1.5	Dynamic Range
6.1.6	Input and Output
6.1.7	General Specifications
6.2	R3671 Performance Specifications
6.2.1	Frequency
6.2.2	Sweep
6.2.3	Amplitude
6.2.4	Amplitude Accuracy
6.2.5	Dynamic Range
6.2.6	Input and Output
6.2.7	General Specifications
	<u>.</u>

6.3 6.4	Option External Dimension Diagram	6 6
7.	OPTIONS AND ACCESSORIES	
7.1	Options	
7.2	Accessories	
8.	MAINTENANCE	
8.1	Cleaning	
8.1.1	Cabinet Cleaning	
8.1.2	Cleaning the Touch Screen	
8.1.3	Cleaning of Other Parts	
8.2	About Calibration	
8.3	About Replacement of Limited-Life Parts	
8.4	Method of Storing the Instrument	
8.5	How to Move and Transport the Instrument	
8.5.1	Moving	
8.5.2	Transportation	
8.6	Notes for Requesting Repair, Replacement of Parts, and Periodic Calibration	
8.6.1	Work Request	
8.6.2	Destination and Phone Number for Contact	
8.7	System Recovery Procedure	
8.8	List of Error Messages	
8.9	Product Disposal and Recycle	8
APPE	NDIX	
A.1	Setting Time and Time Zone	1
A.2	Installing the Printer Driver	
A.3	Setting up the Network	_
A.4	Setting the Guest Account	
A.5	Setting up File Sharing	
A.6	Initial Setting List	A
		A
A.7	Operation Principle	
A.7.1 A.7.2	Input Saturation	A
A.7.2 A.8	Root Nyquist Filter	A A
A.9	GlossarydB Conversion Formula	A
	Standard Information File Format	
A.10		A
A.10.1 A.10.2	Function of Standard Measurement and String	A A
A I DL	IARETICAL INDEX	

LIST OF ILLUSTRATIONS

No.	Tìtle	Page
3-1	Operating Environment	3-3
3-2	Countermeasures for Static Electricity of Human Body	3-4
3-3	Countermeasures for Static Electricity on Work Floor	3-4
3-4	Countermeasures for Static Electricity on Work Bench	3-5
3-5	Connecting the Keyboard and Mouse	3-6
3-6	Ferrite Core	3-7
3-7	Connecting the Power Cable	3-9
3-8	POWER Switch	3-10
3-9	Initial Setup Screen	3-11
3-10	Autocalibration	3-12
4-1	Front Panel	4-1
4-2	Entry Key Block	4-2
4-3	I/F Connector Block	4-3
4-4	I/O Connector Block	4-3
4-5	Screen Display	4-5
4-6	Rear Panel	4-7
4-7	Description of On-Screen Menus	4-9
4-8	Initialization Screen	4-13
4-9	Connection of CAL Signal	4-14
4-10	Initialization Screen	4-16
4-11	Connection of CAL Signal	4-17
4-12 4-13	Output of CAL Signal	4-17
4-13 4-14	Frequency Setting Change Screen	4-18 4-19
4-14 4 - 15	Completion of Setting of Measurement Conditions	4-19 4 - 19
4-15 4-16	Frequency Difference between Peak and a Point 3 dB below Peak	4-19
4-10 4-17	Frequency Difference between Peak and a Point 5 dB below Peak	4-20
4-17	Setting Measurement Conditions	4 - 21
4-19	Measurement by Frequency Counter	4-23
4-20	Connection for Signal Measurement	4-25
4 - 20	Display of UNCAL Message	4-26
5-1	Function Active Area	5-70
8-1	Reboot Dialog Box	8-6
A-1	Block Diagram of the Input Section	A-16
A-2	Relation Between Input and Output of the Mixer	A-16
A-3	Characteristics of the Root Nyquist Filter	A-18
A-4	Bandwidth Selectivity	A-19
A-5	Bandwidth Switching Uncertainty	A-20
A-6	IF Gain Uncertainty	A-20
A-7	Noise Sidebands	A-21
A-8	Occupied Bandwidth	A-22
A-9	Resolution Bandwidth	A-23

R3681 Series User's Guide

List of Illustrations

No.	Title	Page
A-10	Spurious Response	A-24
A-11	VSWR	A-24
A-12	Standard Information file	A-27

LIST OF TABLES

No.	Title	Page
3-1	Standard Accessories	3-2
3-2	ESD Countermeasures	3-4
3-3	Power Supply Specifications	3-8
7-1	Options	7 -1
7-2	Accessories	7-1
8-1	Limited-Life Parts	8-3

1. INTRODUCTION

1. INTRODUCTION

This chapter introduces you to the organization of this document and a product overview of the R3681 Series Signal Analyzer (hereafter called "this instrument") to help you get the most out of this document.

1.1 Organization of This Document

This document addresses a broad spectrum of audiences, from first-time users of this instrument to experienced users. You may read through the document in sequence, beginning with Chapter 1, to gain an all-round knowledge of this instrument or you may refer to the table of contents found at the beginning of each chapter first and jump to sections of interest to you.

This document is organized into the following chapters:

Chapter 1. INTRODUCTION	Introduces you to the organization of this document and a product overview to help you get the most out of this document.
Chapter 2. PRE-OPERATION TIPS	Provides preliminary tips on using this instrument. Read this chapter before using this instrument.
Chapter 3. SETUP	Explains how to set up this instrument on delivery. After installing this instrument in position, switch it on to make sure that it starts up successfully.
Chapter 4. QUICK START	Focuses on the functions of this instrument's panel and the individual screen components, and guides the reader through the basic operating sequence and a simple measurement example to develop a basic working knowledge of this instrument.
Chapter 5. MENU MAP, FUNCTIONAL EXPLANATION	Explains the menu configuration and function of the soft keys.
Chapter 6. SPECIFICATIONS	Summarizes the specifications of this instrument.
Chapter 7. OPTIONS AND ACCESSORIES	Introduces the separately sold options and measurement accessories that can be used with this instrument.
Chapter 8. MAINTENANCE	Explains what daily customer care procedures (such as cleaning, calibration, and storage) are needed to sustain the performance and functionality of this instrument. Also covers instructions on how to troubleshoot this instrument and recover the system.
APPENDIX	Provides the following information: Principles of measurement Glossary Network configuration How to install the printer driver Setting up file sharing

1.2 Product Overview

1.2 Product Overview

The R3681 Series Signal Analyzer is a signal analysis platform solution to the tasks of the upcoming era of digital wireless communication. In addition to offering key performance that addresses the needs for a broader signal range, a wider dynamic range, and a multi-carrier architecture, this instrument comes with a signal analysis software option to address a broad range of wireless communication systems.

Key features of this instrument are summarized below:

- Wide frequency measurement range: 20 Hz 32 GHz (R3681) / 20 Hz 13 GHz (R3671)
- Superb noise level: -158 dBm (typical @10 MHz to 1 GHz)
- Low distortion: TOI +26 dBm (typical @2 to 3.5 GHz)
- Excellent signal purity: -120 dBc/Hz (@800 MHz, 10 kHz offset)
- Broad modulation analysis bandwidth: >20 MHz
- Built-in attenuator 5 dB step
- By adding the optional wideband demodulator, the resolution bandwidth in the CCDF measurement function can be expanded to 50 MHz.

1.3 Other Manuals Pertaining to This Instrument

Available manuals pertaining to this instrument include:

- User's Guide (Part Code: {ER3681SERIES/U}, English, this manual)
 Contains information prerequisite to using the R3681 Series Signal Analyzer, ranging from setup to basic operation, applied measurement, functionality, specifications, and maintenance.
- Programming Guide (Part Code: {ER3681SERIES/P}, English)
 Covers programming information to use the R3681 Series Signal Analyzer to automate measurement sequences, including a remote control overview, SCPI command references, and sample application programs.
- Performance Test Guide (Part Code: {ER3681SERIES/T}, English)
 Covers information necessary to verify the performance of the R3681 Series Signal Analyzer, including performance test procedures and specifications.

1.4 Conventions of Notation Used in This Document

1.4 Conventions of Notation Used in This Document

In this document, panel keys, on-screen buttons and menus are represented by the following symbols:

On-panel hard keys

Sample Represents an on-panel hard key labeled "Sample."

Example: START , STOP

On-screen system menus

[Sample] Represents an on-screen menu, tab, button or dialog box that is labeled "Sample"

and that is selected or executed when touched.

Example: [File] menu, [Normal] tab, [Option] button

On-screen function buttons

Sample Represents an on-screen function button labeled "Sample."

Example: {FREQ} button, {SWEEP} button

On-screen side menu

Sample Represents an on-screen side menu key labeled "Sample."

Example: Center key, Span key

On-screen system menu key operation

[File]→[Save As...] Indicates a touch on the [File] menu followed by a choice of [Save As...].

Sequential key operation

FREQ, **Center** Indicates a touch on the **FREQ** button followed by a touch on the **Center**

key.

Toggle key operation

 Δ Marker On/Off (On) Indicates a touch on the Δ Marker On/Off key to turn on the Δ Marker.

NOTE: Screen displays and diagrams such as external view of the main unit in this manual are those of the R3681 in the R3681 series.

1.5 Trademarks and Registered Trademarks

1.5 Trademarks and Registered Trademarks

- Microsoft® and Windows® are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.
- Other product and company names referenced herein are trademarks or registered trademarks of their respective owners.

2. PRE-OPERATION TIPS

This chapter provides preliminary tips on using this instrument. Read this chapter before using this instrument.

2.1 If Faults Should Occur

If this instrument is found to smoke or deliver offensive odors or abnormal noises, switch off the power breaker and remove the power cable from the AC power connector to power off this instrument. Then, contact your dealer or us immediately.

2.2 Removing of Case

The case should not be opened except by service personnel of our company.

WARNING: High-voltage and high-temperature parts inside. You may get electrical shocks or burnt if you touch them.

2.3 Overcurrent Protection

This instrument is protected from overcurrent flow by a power breaker. Located on the rear panel, the power breaker automatically forces an interruption of the power supply when an overcurrent flows through this instrument. When the power breaker has turned off, remove the power cable from the AC power connector to power off this instrument. Then, call upon your dealer or us for repair services to fix a possible fault that has occurred in this instrument.

2.4 Hard Disk Drive

This instrument has a built-in hard disk drive. When handling the hard disk drive, take notice of these instructions.

- Do not impact or vibrate the hard disk drive.
 Damage to the disk on which data is stored could result, increasing the chances of malfunctioning or failing during operations.
- Do not switch off this instrument while the HDD access lamp is lit.
 The data being accessed might be damaged.

CAUTION: We do not assume any responsibility for the loss or corruption of data stored on the hard disk drive that might result from its faults.

2.5 Handling the Touch Screen

2.5 Handling the Touch Screen

This instrument has a touch screen. When handling the touch screen, take notice of these instructions.

- Do not give strong impacts or apply undue force to the screen. The glass could be cracked.
- Use the stylus pen included with this instrument to operate the screen. Use of a hard-pointed material (such as a mechanical pencil or ballpoint) could scratch the screen surface.

2.6 Getting the Software Running with Stability

The R3681 Series Signal Analyzer has Microsoft Windows XP pre-installed.

The measuring function of this instrument is dependent on the Windows environment. Do not alter the Windows operating environment in any way other than as described in this manual.

Furthermore, this instrument is not a data processor. Operate it only as described in this manual.

- 1. Non-permitted actions:
 - Installing other application programs.
 - Changing or deleting items in the control panel (except for "A.2 Installing the Printer Driver" and "A.3 Setting up the Network").
 - Opening or operating the existing files on the C drive.
 - Operating other application programs during the measurement.
 - Upgrading the Windows operating system.
 - If this instrument does not function correctly due to any of the above, re-install the system using the system recovery disk.
 - For more information on the system recovery method, refer to section 8.7, "System Recovery Procedure."

2. Computer viruses

Depending on the operating environment and method, the system can be contaminated by a computer virus. To use the system securely, it is recommended to take the following countermeasures:

- Run a virus check before loading a file or media from an outside source.
- Make sure that any network has safety measures against computer viruses before connecting.

[If infected with a computer virus:]

Delete all files on the D drive. Re-install the system using the recovery disk.
 For more information on the system recovery method, refer to section 8.7, "System Recovery Procedure."

2.7 Tip on Transportation

Extreme care as described below must be taken when carrying this instrument.

- This instrument is heavy and must be carried by two or more workers, or on a transportation cart.
- If using a cart, ensure this instrument is secure.

2.8 Electromagnetic Interference

2.8 Electromagnetic Interference

This instrument may cause electromagnetic interference and affect television and radio reception.

If this instrument's power is turned off and the electromagnetic interference is reduced, then this instrument has caused the problem.

Electromagnetic interference may be prevented by doing the following:

- Change the direction of the antenna of the television or radio.
- Place this instrument on the other side of the television or radio.
- Place this instrument away from the television or radio.
- Use different lines for the power sources for the television or radio and this instrument.

2.9 Note for Power-on

At power-on, do not connect the DUT to this instrument.


2.10 Notes for Removing and Attaching the Panel

This instrument can be used separately after removing the panel. When removing the panel, take notice of these instructions.

MEMO: To use this instrument after removing the panel, a separately sold connecting cable is required.

- If this instrument's power is turned on, turn off the power, remove the power cable, and then make sure that the operation of this instrument is terminated.
- When removing or attaching the panel, take care not to jam your finger.
- Place this instrument on a level and steady table when removing or attaching the panel.
- Take out the four screws that are exposed on the side of the front panel of this instrument.
- When taking out the screws, put a hand on the panel so that the panel will not unexpectedly fall off.
- After all four screws have been taken out, pull the panel forward.
- Remove the cable connecting the panel and the body of this instrument.
- Replace the cable with another one that is suitable for your use condition.
- If you have lost screws, use the following screws.
- For the 2 screws on the key side: flat-head Phillips screws M4X35 (steel or stainless steel)
- For the 2 screws on the liquid-crystal display: flat-head Phillips screws M4X14 (steel or stainless steel)

2.10 Notes for Removing and Attaching the Panel



2.11 Limitations Imposed when Using Windows XP

END-USER LICENSE AGREEMENT

- You have acquired a device ("INSTRUMENT") that includes software licensed by [ADVANTEST] from Microsoft Licensing Inc.
 or its affiliates ("MS"). Those installed software products of MS origin, as well as associated media, printed materials, and "online"
 or electronic documentation ("SOITWARE") are protected by international intellectual property laws and treaties. The
 SOFTWARE is licensed, not sold. All rights reserved.
- IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE INSTRUMENT
 OR COPY THE SOFTWARE, INSTEAD, PROMPILY CONTACT [ADVANTEST] FOR INSTRUCTIONS ON RETURN OF
 THE UNUSED INSTRUMENT(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT
 LIMITED TO USE ON THE INSTRUMENT, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR
 RATIFICATION OF ANY PREVIOUS CONSENT).
- GRANT OF SOFTWARE LICENSE. This EULA grants you the following license:
 - You may use the SOFTWARE only on the INSTRUMENT.
 - > NOT FAULT TOLERANT. THE SOFTWARE IS NOT FAULT TOLERANT. [ADVANTEST] HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE INSTRUMENT, AND MS HAS RELIED UPON [ADVANTEST] TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.
 - > NO WARRANTIES FOR THE SOFTWARE. THE SOFTWARE is provided "AS IS" and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE INSTRUMENT OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.
 - > No Liability for Certain Damages. EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).
 - Limitations on Reverse Engineering, Decompilation, and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.
 - > SOFTWARE TRANSFER ALLOWED BUT WITH RESTRICTIONS. You may permanently transfer rights under this EULA only as part of a permanent sale or transfer of the INSTRUMENT, and only if the recipient agrees to this EULA. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE.
 - > EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is of US-origin. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and country destination restrictions issued by U.S. and other governments. For additional information on exporting the SOFTWARE, see http://www.microsoft.com/exporting/.
- Installation and Use. The SOFTWARE may not be used by more than two (2) processors at any one time on the INSTRUMENT. You may permit a maximum of ten (10) computers or other electronic devices (each a "Client") to connect to the INSTRUMENT to utilize the services of the SOFTWARE solely for file and print services, internet information services, and remote access (including connection sharing and telephony services). The ten (10) connection maximum includes any indirect connections made through "multiplexing" or other software or hardware which pools or aggregates connections. Except as otherwise permitted in the NetMeeting/Remote Assistance/Remote Desktop Features terms below, you may not use a Client to use, access, display or run the SOFTWARE, the SOFTWARE's user interface or other executable software residing on the INSTRUMENT.
- If you use the INSTRUMENT to access or utilize the services or functionality of Microsoft Windows Server products (such as Microsoft Windows NT Server 4.0 (all editions) or Microsoft Windows 2000 Server (all editions)), or use the INSTRUMENT to permit workstation or computing devices to access or utilize the services or functionality of Microsoft Windows Server products, you may be required to obtain a Client Access License for the INSTRUMENT and/or each such workstation or computing device. Please refer to the end user license agreement for your Microsoft Windows Server product for additional information.
- Restricted Uses. The SOFTWARE is not designed or intended for use or resale in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, or other devices or systems in which a malfunction of the SOFTWARE would result in foreseeable risk of injury or death to the operator of the device or system, or to others.
- Restricted Functionality. You are licensed to use the SOFTWARE to provide only the limited functionality (specific tasks or processes) for which the INSTRUMENT has been designed and marketed by

П

2.11 Limitations Imposed when Using Windows XP

[ADVANTEST]. This license specifically prohibits any other use of the software programs or functions, or inclusion of additional software programs or functions, on the INSTRUMENT.

- Security Updates. Content providers are using the digital rights management technology ("Microsoft DRM") contained in this SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request MS, Microsoft Corporation or their subsidiaries to provide security related updates to the Microsoft DRM components of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through Microsoft software or third party applications that utilize Microsoft DRM. You therefore agree that, if you elect to download a license from the Internet which enables your use of Secure Content, MS, Microsoft Corporation or their subsidiaries may, in conjunction with such license, also download onto your INSTRUMENT such Security Updates that a Secure Content Owner has requested that MS, Microsoft Corporation or their subsidiaries distribute. MS, Microsoft Corporation or their subsidiaries distribute. MS, Microsoft Corporation or their subsidiaries distribute information, or any other information, from your INSTRUMENT by downloading such Security Updates.
- NetMeeting/Remote Assistance/Remote Desktop Features. The SOFTWARE may contain NetMeeting, Remote Assistance, and Remote Desktop technologies that enable the SOFTWARE or other applications installed on the INSTRUMENT to be used remotely between two or more computing devices, even if the SOFTWARE or application is installed on only one INSTRUMENT. You may use NetMeeting, Remote Assistance, and Remote Desktop with all Microsoft products; provided however, use of these technologies with certain Microsoft products may require an additional license. For both Microsoft products and non-Microsoft products, you should consult the license agreement accompanying the applicable product or contact the applicable licensor to determine whether use of NetMeeting, Remote Assistance, or Remote Desktop is permitted without an additional license.
- Consent to Use of Data. You agree that MS, Microsoft Corporation and their affiliates may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. MS, Microsoft Corporation and their affiliates may use this information solely to improve their products or to provide customized services or technologies to you. MS, Microsoft Corporation and their affiliates may disclose this information to others, but not in a form that personally identifies you.
 - Internet Gaming/Update Features. If the SOFTWARE provides, and you choose to utilize, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorize MS, Microsoft Corporation and/or their designated agent to use this information solely to improve their products or to provide customized services or technologies to you. MS or Microsoft Corporation may disclose this information to others, but not in a form that personally identifies you.
 - Internet-Based Services Components. The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that MS, Microsoft Corporation or their affiliates may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your INSTRUMENT.
- Links to Third Party Sites. The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of MS, Microsoft Corporation or their affiliates. Neither MS nor Microsoft Corporation nor their affiliates are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by MS, Microsoft Corporation or their affiliates.
- Additional Software/Services. The SOFTWARE may permit [ADVANTEST], MS, Microsoft Corporation or their affiliates to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").
- If [ADVANTEST] provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.
- If MS, Microsoft Corporation or their affiliates make available Supplemental Components, and no other EULA terms are provided, then the terms of this EULA shall apply, except that the MS, Microsoft Corporation or affiliate entity providing the Supplemental Component(s) shall be the licensor of the Supplemental Component(s).
 - [ADVANTEST], MS, Microsoft Corporation and their affiliates reserve the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.
 - This EULA does not grant you any rights to use the Windows Media Format Software Development Kit ("WMFSDK") components contained in the SOFTWARE to develop a software application that uses Windows Media technology. If you wish to use the WMFSDK to develop such an application, visit http://msdn.microsoft.com/workshop/imedia/windowsmedia/sdk/wmsdk.asp, accept a separate license for the WMFSDK, download the appropriate WMFSDK, and install it on your system.

3. SETUP

3. SETUP

This chapter explains how to set up this instrument on delivery. Topics covered in this chapter are:

- 3.1 Unpacking Inspection
- 3.2 Locating This Instrument
- 3.3 Connecting Accessories
- 3.4 Supply Description
- 3.5 Operation Check

3.1 Unpacking Inspection

When the product is delivered, check it for its appearance and accessories included by following these steps:

1. Check to see if the box or the cushioning material in which the product was shipped has been damaged during transit.

IMPORTANT: If the box or the cushioning material is found damaged, leave them in their original condition until the inspection described below completes.

2. Check the product surfaces for any damage.

WARNING: Do not power on this instrument if the cover, panels (front and rear), LCD display, power switch, connector or any other key component is found damaged. Electrical shock hazards could result from using damaged components.

- 3. Check against the list in Table 3-1 that this instrument comes complete with all the standard accessories. Contact your dealer or us in any of the following situations:
- The box or the cushioning material in which the product was shipped was damaged during transit, or there is evidence of a massive force having been applied to the cushioning material.
- The product surfaces are damaged.
- One or more standard accessories are missing or damaged.
- · Defects have been detected in a subsequent product verification test.

3.1 Unpacking Inspection

Table 3-1 Standard Accessories

Name	Model	Quantity		Remarks
Name	Widel	R3681	R3671	Remarks
Power cable	Λ01402	1	1	
Input cable (50Ω)	Λ01037-0300	1	1	
K (f)-K (f) adapter	5A-SFF40(A)	1	0	
SMA (f)-SMA (f) adapter	HRM-501	1	0	
SMA (m)-BNC (m) adapter	HRM-517(09)	1	0	
N (m)-BNC (f) adapter	JUG-201A/U	0	1	
Stylus pen	ST-PEN	1	1	
Ferrite core	ESD-SR-12	2	2	
R3681 Series User's Guide	ER3681SERIES/U	1	1	
R3681 Series Programming Guide	ER3681SERIES/P	1	1	
R3681 Series Performance Test Guide	ER3681SERIES/T	1	1	

3.2 Locating This Instrument

3.2 Locating This Instrument

This section describes the installation environment in which this instrument runs successfully.

3.2.1 Operating Environment

This instrument should only be used in a place that satisfies the following conditions:

- Ambient temperature: +5 °C to +40 °C (operating temperature) -20 °C to +60 °C (storage temperature range)
- Relative humidity: RH80% or less (no condensation)
- · An area free from corrosive gas
- An area away from direct sunlight
- A dust-free area
- An area free from vibrations
- A low noise area

Although this instrument has been designed to withstand a certain amount of noise riding on the AC power line, it should be used in an area of low noise. Use a noise filter when ambient noise is unavoidable.

An area allowing unobstructed airflow
 There is an exhaust-cooling fan on the rear panel and exhaust vents on both sides and the bottom
 (toward the front) of this instrument. Never block these vents. The resulting internal temperature rise
 will affect measurement accuracy. Keep the rear panel 10 centimeters away from the wall. In addition, do not attempt to use this instrument when it is standing on its rear panel or on either side panel.




Figure 3-1 Operating Environment

3.2.2 Prevention of Electrostatic Buildup

3.2.2 Prevention of Electrostatic Buildup

To prevent damage to semiconductor parts from electrostatic discharge (ESD), the precautions shown below should be taken. We recommend that two or more countermeasures are combined to provide adequate protection from ESD.

(Static electricity can easily be built up when a person moves or an insulator is rubbed.)

Table 3-2 ESD Countermeasures

Operator	Use a wrist strap (see Figure 3-2).
Floor in the work area	Installation of a conductive mat, the use of conductive shoes, and grounding (see Figure 3-3).
Workbench	Installation of a conductive mat and grounding (see Figure 3-4).




Figure 3-2 Countermeasures for Static Electricity of Human Body




Figure 3-3 Countermeasures for Static Electricity on Work Floor

3.2.2 Prevention of Electrostatic Buildup




Figure 3-4 Countermeasures for Static Electricity on Work Bench

3.3 Connecting Accessories

3.3 Connecting Accessories

This section explains how to connect accessories to this instrument to run it.

3.3.1 Connecting the Keyboard and Mouse

Plug the keyboard and mouse into their respective front-panel connectors (KEYBOARD and MOUSE connectors). The keyboard and mouse must be plugged before turning on this instrument.





Figure 3-5 Connecting the Keyboard and Mouse

3.3.2 Caution when Connecting Peripherals

3.3.2 Caution when Connecting Peripherals

Use shielded cables to connect peripherals to this instrument.

Attach a ferrite core (ESD-SR-12 produced by the Tokin Corporation) before connecting the Ethernet cable and the Probe power cable as show in the Figure 3-6.






Figure 3-6 Ferrite Core

3.4 Supply Description

3.4 Supply Description

This section explains how to check the power supply specifications and connect the power cable.

3.4.1 Check the supply power

Table 3-3 summarizes the power supply specifications for this instrument. Make sure that the power supply available to this instrument meets these specifications.

Table 3-3 Power Supply Specifications

	100 VAC Operation	200 VAC Operation	Remarks
Input voltage range	90 V to 132 V	198 V to 250 V	Automatically switches
Frequency range	47 Hz to 63 Hz		between input levels of 100 VAC and 200 VAC.
Power consumption	450 VA or below		

WARNING: Be sure to provide a power supply that meets the specified power supply specifications for this instrument. Failure to meet the specifications could cause damage to this instrument.

3.4.2 Connecting the Power Cable

This instrument comes with a three-core power cable with a grounding conductor. To guard against electrical shock hazards, ground this instrument by plugging the power cable into a three-pole power outlet.

1. Check the power cable included with this instrument for any damage.

WARNING: Never use a damaged power cable. Electrical shock hazards could result.

2. Plug one end of the power cable included with this instrument into the AC power connector on this instrument rear panel and the other into a three-pole power outlet having a protecting grounding terminal (see Figure 3-7).

3.4.2 Connecting the Power Cable




Figure 3-7 Connecting the Power Cable

WARNING:

- 1. Use a power cable rated for the voltage being used. Be sure however to use a power cable conforming to the safety standards of your country when using this instrument overseas (Refer to "Safety Summary").
- Plug the power cable into a three-pole power outlet having a protecting grounding terminal to guard against electrical shock hazards. Use of an extension cord without a protecting grounding terminal would override the protective grounding.

3.5 Operation Check

3.5 Operation Check

This section explains how to make a simple operation check on this instrument by using its built-in autocalibration feature. To verify that this instrument runs correctly, follow these steps:

Starting up this instrument

- 1. Connect the power cable as instructed in 3.4.2 "Connecting the Power Cable."
- 2. Switch on the power breaker on the rear panel. Then wait for 3 seconds or more.
- 3. Press the **POWER** switch to switch on the power.




Figure 3-8 POWER Switch

CAUTION:

- If this instrument is abruptly powered off while in operation, such as by pulling the power cable out of position, the hard disk drive could fail. Even when the hard disk drive does not fail, Scandisk launches to check for possible corruptions in the data stored on it the next time this instrument starts up.
- About Scandisk
 If this instrument has been powered off without being shut down, Scandisk will
 launch to check for corruptions automatically. Do not abort Scandisk while it is
 running. If Scandisk locates corruptions, take appropriate remedial action as rec ommended by the display messages. The software in this instrument resumes auto matically when Scandisk ends.
- 4. The power-on diagnostic program launches to carry out self-diagnostics. The self-diagnostics take about 1 minute to complete.
- 5. The initial screen shown in Figure 3-9 is displayed unless this instrument is tested faulty. The initial screen may give a different look from Figure 3-9, depending on the settings in effect the last time this instrument was powered off.

MEMO: Refer to Chapter 8, "MAINTENANCE" if error messages are displayed as a result of the self-diagnostics.




Figure 3-9 Initial Setup Screen

Running autocalibration

6. <R3681>

Hook up this instrument as shown in Figure 3-10 by using the SMA (f)-SMA (f) adapter, SMA (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.

<R3671>

Hook up this instrument as shown in Figure 3-10 by using the N (m)-BNC (f) adapter, and input cable (A01261-30) that come with this instrument as standard.

3.5 Operation Check




Figure 3-10 Autocalibration

IMPORTANT: Allow this instrument to warm up for at least 30 minutes before running the autocalibration. For more information on how to use the autocalibration, refer to Section 4.3.1, "Autocalibration."

- 7. Touch the [Cal] button on this instrument's menu bar to select [SA Cal] from the dropdown menu.
- 8. Autocalibration runs.
 The autocalibration takes about 1 minute to complete.
- 9. Make sure that no error messages are displayed as a result of the autocalibration.

MEMO: Refer to Chapter 8, "MAINTENANCE" if error messages are displayed as a result of the autocalibration.

Switching off power

Press the **POWER** switch of this instrument.

The final processing of the system is performed and the power is automatically turned off.

4. QUICK START

This chapter describes the panels of this instrument, the function of each component on the screen, and the basic operation of the instrument, using the example of measurement.

4.1 Description of the Panels and the Screen

The following sections describe the name and function of each component on the front panel, displays on the screen, and the rear panel.

4.1.1 The Name and Functions of Each Component on the Front Panel

This subsection describes the name and function of each component on the front panel.




Figure 4-1 Front Panel

1.	Touch screen display	Displays measurement data, setting conditions, and other infor-
		mation items. The setting conditions can be changed by the func-
		tions of the touch screen.

- 2. POWER switch Turns on or off the power of this instrument. When you turn off this switch, the system terminates before power turns off.
- 3. Entry key block Used for changing settings
- 4. Floppy disk drive A 3.5" floppy disk drive
- 5. I/F connector block An I/F connector block for a keyboard and a mouse

4.1.1 The Name and Functions of Each Component on the Front Panel

6. I/O connector block An I/O connector block for measurement

7. HDD (hard disk drive) access lamp

Lights up while access is being made to the hard disk

Power lamp

Lights up while power is on




Figure 4-2 Entry Key Block

. Back light key Turns on or off the display back light

2. Application keys Select soft menu bars for display

3. Program keys Control measurement.

SINGLE: Press for a single measurement.

STOP: Press to stop continuous measurement.
START: Press to start continuous measurement.

4. Data knob and step keys A data knob and step keys

IMPORTANT: Changing of the settings for numeric entry may fail if you continuously press the data knob too quickly to allow the system to follow.

4.1.1 The Name and Functions of Each Component on the Front Panel

Ten-key pad Used to enter numeric values

> BS: Back space key

G/p: Units key of GHz for frequency and psec for time M/n: Units key of MHz for frequency and nsec for time K/μ : Units key of kHz for frequency and µsec for time

ENT: Basic units key of Hz for frequency and msec for

time

Preset keys The initialization key of this instrument

To initialize the instrument, press the left key while you are press-

ing the right key.

The toggle key that locks and unlocks key entry] Key lock key




Figure 4-3 I/F Connector Block

USB connector A USB connector for accessories 1.

2. MOUSE connector A mouse connector

KEYBOARD connector A connector for an external keyboard

IMPORTANT: Connect the mouse and keyboard before power-on.




Figure 4-4 I/O Connector Block

INPUT I connector The input connector for the base band I signal

INPUT Q connector The input connector for the base band Q signal

3. INPUT /I connector Reserved for options

INPUT /Q connector Reserved for options 4.

PROBE POWER connector Power connector for the probe ($\pm 15 \text{ V}$ output)

EXT MIXER LO/IF Reserved for options

Connects an external mixer to expand the frequency range for

measurement (supports two ports)

8. CAL OUT connector

4.1.1 The Name and Functions of Each Component on the Front Panel

7. EXT MIXER IF connector Reserved for options
Connects an external mixer to expand the frequency range for

Outputs calibration signals

measurement (supports three ports)

measurement (supports three ports

9. INPUT connector Receives measurement signals

NOTE: Do not apply an RF level or direct current that exceeds the

respective limit value to the INPUT connector.

If you do, the input attenuator or the mixer may burn out.

4.1.2 The Name and Function of Each Component on the Screen

This subsection describes the name and function of each component on the screen.




Figure 4-5 Screen Display

1,	ADVANTEST logo mark	Display of ADVANTEST logo mark
2.	Title	The display area of the description of measurement data and other information
3.	Date	The current date and time
4.	Amplitude scale in log mode or in	linear mode The setting of the amplitude scale in the log mode
5.	RF attenuator	The setting of the attenuator An asterisk (*) appears before ATT when setting is made manually.
6.	Marker area	Displays the marker frequency (time) and the level
7.	Measurement function area	Displays the noise/Hz, frequency counter readings, and %AM measurement results
8.	Pass/Fail judgment	Displays pass/fail judgment results determined by limit lines
9.	Reference level	Displays the setting of the reference level
10.	Level offset	Displays the reference offset value when reference offset is On

4.1.2 The Name and Function of Each Component on the Screen

11.	Preamplifier	Displayed when preamplifier is On
12.	Correction factor	Displayed when correction factor is On
13.	Trace and trace detector	Displays the selected trace mode and trace detector mode
14.	Averaging count	Displays the set averaging count and the current averaging count
15.	Trigger source	Displays the selected trigger source
16.	-	-
17.	Frequency offset	Displayed when frequency offset is On
18.	Center frequency or start frequence	y Displays the center frequency or start frequency
19.	Resolution bandwidth (RBW)	Displays the set resolution bandwidth An asterisk (*) appears before RBW when setting is made manually.
20.	Video bandwidth (VBW)	Displays the set video bandwidth An asterisk (*) appears before VBW when setting is made manually. If an input signal to VBW is power log, (POW_LOG) is displayed following the VBW, or (VOLT) is displayed if the signal is voltage.
21.	Sweep time	Displays the set sweep time An asterisk (*) appears before SWP when setting is made manually.
22.	Trigger delay time	Displays trigger delay time or pre-trigger time
23.	Frequency span or stop frequency	Displays the frequency span or stop frequency
24.	UNCAL message	Displayed when manual setting is inappropriate
25.	Remote	Displayed in the GPIB remote status
26.	Panel lock	Displayed while the panel key is being locked
27.	External reference signal	Displayed when an external reference signal is input If the external reference setting is set to manual mode, "*" is displayed in front of Ext Ref.
28.	Trigger position	Displays video trigger positions and Ext2 trigger positions
29.	Level scale	Displays level scales
30.	Sweep indicator	Displays sweep positions
31.	Trigger delay position	Displays "<" for the trigger delay and " ∇ " for pre-triggering
32.	Display function area	Displays cursor, display line, reference line, and measuring window values

Displays the standard's name.

33. Standard name area

4.1.3 The Name and Function of Each Component on the Rear Panel

This subsection describes the name and function of each component on the rear panel.




Figure 4-6 Rear Panel

1,	AC power connector	Connects this instrument to the AC power outlet via the accessory power cable
2.	Power breaker	The power breaker forced to turn off if over-currents flow.
3.	GP-IB connector 1	Connects this instrument to an external controller when remote control is made through the GP-1B interface
4.	GP-IB connector 2	Reserved
5.	LAN connector	LAN connector for 10BaseT
6.	Printer connector	Connects this instrument to a printer
7.	VIDEO connector	Connects this instrument to an external monitor of VGA specifications
8.	RS-232 connector	Reserved for options
9.	AUX 1 connector	Reserved for options
	AUX 2 connector	Reserved for options
	AUX 3 connector	Reserved for options

4.1.3 The Name and Function of Each Component on the Rear Panel

10.	EXT IN 1 connector	Reserved for options
	EXT IN 2 connector	Reserved for options
	EXT IN 3 connector	Reserved for options
	EXT IN 4 connector	Reserved for options
11.	EXT TRIG IN 1 (TTL) connector	Inputs external trigger signals (TTL level)
12.	EXT TRIG IN 2 connector	Inputs external trigger signals (variable levels)
13.	TRIG OUT (TTL) connector	Outputs synchronized signals with trigger signals (TTL level)
14.	MARKER OUT (TTL) connector	Reserved for options
15.	EXT REF IN connector	Inputs external reference signals
16.	10MHz REF OUT connector	Outputs 10 MHz reference signals
17.	21.4MHz IF OUT connector	Outputs 3rd IF (21.4 MHz) signals
18.	AUX 4 connector	Reserved for options
	AUX 5 connector	Reserved for options
	AUX 6 connector	Reserved for options
19.	AUX INTERFACE connector	Reserved for options
20.	I IN connector	Reserved for options
	Q IN connector	Reserved for options
21.	I OUT connector	Reserved for options
	Q OUT connector	Reserved for options

4.2 Basic Operation

This section describes menu operation, data entry, and use of the basic measurement functions.

4.2.1 Menu Operation and Data Entry

This subsection describes operations of the panel keys and touch screen.

1. On-screen Menus

The screen displays ten kinds of menu. Use the touch screen or the mouse for menu operation. The on-screen side menus can also be handled by the panel keys.




Figure 4-7 Description of On-Screen Menus

- 1. Menu bar Provides the on-screen system menus of this instrument. When you click a menu on the bar, a dropdown menu is displayed
- 2. Dropdown menu Menu items are displayed classified by functions.
 When you click an item marked by "..." a dialog box is displayed
- 3. Function bar

 This area provides a set of function buttons classified by basic functions of this instrument.

 When you click a function button, the display of the soft menu in

the soft menu bar area is switched

4.2.1 Menu Operation and Data Entry

4.	User's title bar	The user defined screen title and present time are displayed.
5.	Entry box 1	A box to enter numeric data This box is displayed only when you press an application key that involves numeric data entry or when the numeric data entered in entry box 2 is determined
6.	Soft menu bar	When you click a function button on the function bar, the associated soft menu is displayed in this area. The soft menu provides various operations associated with the basic function groups classified by function buttons
7.	Entry box 2	A box to enter numeric data This box is displayed only when you click a soft key that involves numeric data entry. When numeric data entry is determined, this box disappears and entry box 1 appears. The entered data is passed to entry box 1
8.	Status bar	Displays measurement status and operation status of this instrument
9.	Dialog box	Contains entry boxes for data for each function as well as switches and buttons for item selection
10.	Measurement tool bar	An area that displays buttons that facilitate measurements by this instrument. A button for zoomed display is an example

4.2.1 Menu Operation and Data Entry

2. Data input

When a set value is displayed in entry box 1, you can change it using the numeric keys, step keys, data knob, or entry box 2.

• Data input using the numeric keys

Enter data using the numeric keys, decimal point key, back space (BS) key, and minus sign (-) key.

If you pressed the wrong numeric keys, delete each digit by pressing the BS key, enter the correct data, and at the end press the appropriate units key.

· Data input using the step keys

The step keys allow you to enter data with a constant interval increasing or decreasing data.

• Data input using the data knob

The data knob allows you to enter data in continuous mode. It works as a handy tool for minute adjustment of input data.

Data input using entry box 2

When you press a soft menu key, entry box 2 may appear at the left of the button for changing a set value

Set values can be changed as follows:

 $[\uparrow]$ key: for one push of the step up key

 $[\downarrow]$ key: for one push of the step down key

When you click the numeric value part in entry box 2, input keys associated with the current unit system will appear. Enter data using these keys. If you made an input error, delete the wrong digits one by one by pressing the BS key and enter the correct data.

IMPORTANT: The data you keyed in will be invalid if you press any other menu key before pressing a units key to finish your data input.

3. Display of a dialog box

A dialog box is displayed in response to the pressing of some soft menu keys.

In the dialog box, you can select items, enter numeric values, and perform other operations:

· Selection of items

Use the step keys.

Selection of set data

Rotate the data knob to select data and then press the ENT key to confirm the data.

Entering numeric values

Use the numeric keys and units keys.

Terminating the dialog box

Most of the dialog boxes are terminated by touching (clicking) the close button (🔲) on the title bar. However, some of the dialog boxes that involve operation of the soft menu bar are terminated by touching (clicking) the **Return** menu on the soft menu bar.)

4.3 Basic Measurement

4.3 Basic Measurement

This section describes the following examples of basic measurement so that you will get accustomed to the operations of this instrument.

- 4.3.1 Autocalibration
- 4.3.2 Display of Spectrum and Operation of Markers
- 4.3.3 Measuring Frequencies by Frequency Counter
- 4.3.4 How to Cancel an UNCAL Message

4.3.1 Autocalibration

This subsection describes how to use the built-in autocalibration feature for measurements on the precision level guaranteed by this instrument.

Autocalibration is available in the following two types:

[SA Cal]

CAL OUT and INPUT must be connected on the front panel.

The autocalibration takes about one minute to complete.

• [SA Cal without ATT]

CAL OUT and INPUT need not be connected on the front panel because this autocalibration uses only the internal Cal signal.

The autocalibration takes about one minute to complete.

The following is a description of how to run the [SA Cal] autocalibration.

IMPORTANT: Allow this instrument to warm up for at least 30 minutes before running the autocalibration.

Equipment to be used

R3681

Conversion adapter: SMA (f)- SMA (f) Conversion adapter: SMA (m)-BNC (f) Input cable: BNC (m)-BNC (m)

R3671

Conversion adapter: N (m)- BNC (f) Input cable: BNC (m)-BNC (m)

Switching on power

- 1. Make sure that the power breaker is OFF on the rear panel.
- Connect the power cable in the accessory package to the AC power connector on the rear panel.

4.3.1 Autocalibration

CAUTION: To protect it from breakage, do not apply input voltages or frequencies over the specified range to this instrument.

- 3. Connect the power cable to the wall socket.
- 4. Turn on the power breaker on the rear panel. Then wait for 3 second or more.
- 5. Turn on the power switch on the front panel. On completion of the self-test, the start up screen is displayed.

MEMO: The display after power is turned on depends on the status of the previous use of this instrument.

Initialization

Initialize the settings of this instrument.

6. Press the left preset key while pressing the right preset key. Initialization conditions are read out.




Figure 4-8 Initialization Screen

4.3.1 Autocalibration

Connection of input signals


Connect the calibration signal used for measurement.

7. <R3681>

Install the SMA (f)-SMA (f) adapter on the INPUT connector on the front panel. Then install the SMA (m)-BNC (f) adapter on the SMA (f)-SMA (f) adapter. Connect the SMA (m)-BNC (f) adapter to the CAL OUT connector with the accessory input cable.

<R3671>

Install the N (m)-BNC (f) adapter on the INPUT connector on the front panel. Connect the N (m)-BNC (f) adapter to the CAL OUT connector with the accessory input cable.



Note: The R3671 uses the N(m)-BNC(f) adapter.

Figure 4-9 Connection of CAL Signal

- 8. Touch [Cal] on the menu bar.
 The Cal dropdown menu is displayed. Select [SA Cal].
- The SA Cal autocalibration runs.
 The calibration takes about one minute to complete.

4.3.2 Display of Spectrum and Operation of Markers

This section describes display of spectrum and operation of markers using the CAL signal of this instrument.

As for operation of markers, frequency differences are measured between the peak point of the CAL signal and a point 3 dB below the peak, and between the peak point and a point 60 dB below the peak point, using a delta marker.

Equipment to be used

R3681

Conversion adapter: SMA (f)- SMA (f) Conversion adapter: SMA (m)-BNC (f) Input cable: BNC (m)-BNC (m)

R3671

Conversion adapter: N (m)-BNC (f) Input cable: BNC (m)-BNC (m)

Switching on power

IMPORTANT: Use this instrument in the range of specified temperatures for correct measurement. Allow this instrument to warm up for at least 30 minutes before running the autocalibration.

- 1. Make sure that the power breaker is OFF on the rear panel.
- 2. Connect the power cable in the accessory package to the AC power connector on the rear panel.

CAUTION: To protect it from breakage, do not apply input voltages or frequencies over the specified range to this instrument.

- 3. Connect the power cable to the wall socket.
- 4. Turn on the power breaker on the rear panel. Then wait for 3 second or more.
- 5. Turn on the power switch on the front panel. On completion of the self-test, the start up screen is displayed.

MEMO: The display after power is turned on depends on the status of the previous use of this instrument.

Initialization

Initialize the settings of this instrument.

6. Press the left preset key while pressing the right preset key. Initialization conditions are read out.




Figure 4-10 Initialization Screen

Connection of input signals


Connect the calibration signal used for measurement.

7. <R3681>

Install the SMA (f)-SMA (f) adapter on the INPUT connector on the front panel. Then install the SMA (m)-BNC (f) adapter on the SMA (f)-SMA (f) adapter. Connect the SMA (m)-BNC (f) adapter to the CAL OUT connector with the accessory input cable.

<R3671>

Install the N (m)-BNC (f) adapter on the INPUT connector on the front panel. Connect the N (m)-BNC (f) adapter to the CAL OUT connector with the accessory input cable.



Note: The R3671 uses the N(m)-BNC(f) adapter.

Figure 4-11 Connection of CAL Signal

Setting measurement conditions

Set measurement conditions for easy observation of input signals.

8. Press {Freq}. The current center frequency is displayed in entry box 1 and you are ready to change frequency settings.




Figure 4-12 Output of CAL Signal

9. Press 5, 0, and M/n in this order. The center frequency is set to 50 MHz.




Figure 4-13 Frequency Setting Change Screen

10. Press {SPAN}.

The current frequency span is displayed in entry box 1 and you are ready to change frequency span settings.

11. Press 2, 0, and M/n in this order. The frequency span is set to 20 MHz.

12. Press {LEVEL}.

The current reference level is displayed in entry box 1 and you are ready to change reference level settings.

13. Press -, 1, 0, and ENT in this order. The reference level is set to -10 dBm.




Figure 4-14 Completion of Setting of Measurement Conditions

Display of markers

14. Press {Search}.

A normal marker is displayed at the peak, and in the marker area the marker frequency (about 50 MHz) and the level (about -10 dBm) are displayed.




Figure 4-15 Display of Peak Search

Display of the delta marker

- 15. Press {MKR} and then **Delta Marker**. The Delta Marker menu is displayed. The delta marker is displayed, and in the marker area the frequency and level differences (relative values) between the normal marker and the delta marker are displayed.
- 16. Move the marker with the data knob to a position where the level reads -3 dB, viewing the level indication in the marker area. (When setting to the exact value is difficult due to limits by the resolution, the closest possible value may do.) The frequency indicated in the marker area is the frequency difference between the peak value and that 3 dB below the peak value (relative value).




Figure 4-16 Frequency Difference between Peak and a Point 3 dB below Peak

17. Move the marker again using the data knob to a point where the level reads -60 dB. The frequency in the marker area at this time indicates the frequency difference between the peak and a point 60 dB below the peak value.




Figure 4-17 Frequency Difference between Peak and a Point 60 dB below Peak

4.3.3 Measuring Frequencies by Frequency Counter

4.3.3 Measuring Frequencies by Frequency Counter

This section describes the operating procedure of the frequency counter function using the CAL signal of this instrument.

The frequency counter is a function that measures not the marker frequency but the frequency of the signal on which the marker is positioned at high accuracy.

The amplitude value indicates that measured at the point of the marker. The highest resolution of the counter is 0.01 Hz.

Equipment to be used

R3681

Conversion adapter: SMA(f)-SMA(f) Conversion adapter: SMA (m)-BNC (f) Input cable: BNC (m)-BNC (m)

R3671

Conversion adapter: N (m)-BNC (f) Input cable: BNC (m)-BNC (m)

LIMIT: Accurate measurements are not made unless the S/N>50 dB requirement of the signal to be measured is fulfilled.

Switching on power

1. Turn on the power of this instrument.

Initialization

Initialize the settings of this instrument.

2. Press the left preset key while pressing the right preset key. Initialization conditions are read out.

Connection of input signals

3. Connect the calibration signal used for measurement.

Setting measurement conditions

Set measurement conditions for easy observation of input signals.

- 4. Press {Freq}, 5, 0, and M/n in this order. The center frequency is set to 50 MHz.
- 5. Press {SPAN}, 5, 0, and M/n in this order. The frequency span is set to 50 MHz.




Figure 4-18 Setting Measurement Conditions

Measuring frequencies by frequency counter

Measure frequencies using the frequency counter function.

- 6. Touch [MENU2]. MENU2 is displayed.
- 7. Press {MEAS} and then **Counter**. Measurement by the frequency counter begins.




Figure 4-19 Measurement by Frequency Counter

4.3.4 How to Cancel an UNCAL Message

4.3.4 How to Cancel an UNCAL Message

Settings of resolution bandwidth (RBW), video bandwidth (VBW), frequency span (Span), and sweep time are mutually influential.

An UNCAL message is displayed in the frequency area if combinations of settings of these items are inappropriate. Accuracy of the measurement level is not guaranteed when the UNCAL message is displayed. Cancel the UNCAL message by changing the settings of the following items.

- Expand the resolution bandwidth (RBW).
- Expand the video bandwidth (VBW).
- Make the sweep time slower.
- If RBW or VBW is difficult to change, make the frequency span narrower.

IMPORTANT: An accurate measurement is not made if measurement is done with an UNCAL message displayed.

The following is a description of how to cancel the UNCAL message displayed because the set sweep time was too short, by changing the setting of RBW.

Equipment to be used


R3681 Signal generator Conversion adapter: SMA(f)-SMA(f) Input cable: SMA (m)- SMA (m) R3671 Signal generator Conversion adapter: N(m)-SMA(f)

Input cable: SMA (m)- SMA (m)

Equipment hook-up

1. Connect the equipment as shown in Figure 4-20.

4.3.4 How to Cancel an UNCAL Message



Note: The R3671 uses the N(m)-SMA(f) adapter.

Figure 4-20 Connection for Signal Measurement

Switching on power

2. Turn on the power of this instrument.

Initialization

Initialize the settings of this instrument.


3. Press the left preset key while pressing the right preset key. Initialization conditions are read out.

Setting measurement conditions

Set measurement conditions for easy observation of input signals.

- 4. Press {Freq}, Center, 1, and G/p in this order. The center frequency is set to 1 GHz.
- 5. Press {SPAN}, Span 5, 0, and k/μ in this order. The frequency span is set to 50 kHz.
- 6. Press {Sweep}, Sweep Time Auto/Man (Man), and [2], [0], [msec] from entry box 2. The sweep time is set to 20 msec and an UNCAL message is displayed.

4.3.4 How to Cancel an UNCAL Message



A sweep time of 20 msec is too short for the set conditions.

Figure 4-21 Display of UNCAL Message

How to cancel the UNCAL message

7. Press {BW}, RBW Auto/Man (Man), $\boxed{1}$, $\boxed{0}$, and $\boxed{k/\mu}$. When RBW is set to 10 kHz, the UNCAL message is cancelled because a sweep time of 20 msec meets the appropriate conditions.

5. MENU MAP, FUNCTIONAL EXPLANATION

This chapter describes the configurations and functions of the soft keys displayed on the touch screen.

МЕМО:

- [....] Used to enclose a menu name, key name, item name in the dialog box, button name, or the name of selected items in lists and menus.
- {....} Shows a function button on the function bar.
- Shows a soft key on the soft menu bar.
- A dialog box is surrounded by a broken line.
- Operations are supposed to be made through a touch screen, and "touch" means to press a button or a key.

Operation Key	Pages	Operation Key	Pages
√Nyquist Filter Setup	5-45, 5-46,	[Coarse]	5-17
	5-50, 5-52,	[Config]	
	5-55	[Couple to F(T)]	
ΔMarker On/Off	5-39	[Current]	
ΔMarker→CF	5-34	[\Delta Marker]	5-40
ΔMarker→CF Step	5-34	[\Delta Marker (Other Screen)]	5-41
ΔMarker→Mkr Step	5-34	[Date]	5-18
ΔMarker→Span	5-34	[Date and Time]	5-15, 5-17
%AM Meas On/Off	5-59, 5-61	[Default]	
[Nyquist Filter]	5-50, 5-52,	[Delete]	5-10, 5-11,
	5-55		5-14
[1] to [10]	5-37	[Delete Data]	5-8, 5-10
[3rd Order Limit]	5-61	[Disp Line]	5-36, 5-41,
[5th Order Limit]	5-61		5-68
[7th Order Limit]	5-61	[Display Setup]	5-15
[9th Order Limit]	5-61	[Display]	5-15, 5-18
[All]	5-21, 5-23	[Execute]	5-8, 5-13
[Anchor]	5-41	[Explorer]	5-15, 5-19
[Apply]	5-23	[Ext. Reference]	5-17
[Band Width]	5-50	[File]	5-7, 5-8
[Browse]	5-13	[File Type]	5-14
[BS]	5-9, 5-12,	[Filename]	5-8, 5-9,
	5-14, 5-18		5-10, 5-14
[Cal]	5-7, 5-21	[Fine]	5-18
[Cancel]	5-13	[Format]	5-18
[Carrier Band Width]	5-50	[Freq Reference Setup]	5-15
[Channel Space]	5-50	[Freq Reference]	5-15, 5-17
[CL]	5-9, 5-12,	[GPIB Address]	5-15
	5-14, 5-18	[Guest Account]	5-15, 5-16
[Clear]	5-22	[Information]	5-8, 5-9,
[Close]	5-8, 5-10,		5-10
	5-11, 5-14	[Int. Reference Adjustment]	5-17

Hytocus I DW/I	5 55		[Calf Tast]	5 2 1	
[Integral BW]			[Self Test]		5 22
[Judge]			[Service]		3-22
[Limit Abs Start]			[Single]		5 10
[Limit Abs Stop]		5 41	[sp]		
[Limit Line 1]		3-41,	[Cassial]	-	5-18
[Limit Line 2]	5-63	5 41	[Special]		3-21
[Limit Line 2]	5-63	3-41,	[Spectrum Analyzer]		5 55
[Limit Posi]			[Start]		3-33
			[Status]		5 22
[Limit Rel Start]			[STD]		
[Limit Rel Stop]			[Stop]		3-33
[Limit Width]		5 11	[Store]		5 52
[Load Data]		5-11	[Symbol Rate]	5-55,	3-32,
[Load STD Data]		5 11	[System]		5 15
[Load STD Data]		5-11	[System]		
[Log]			[Title]		3-16
[Manual Mode]			[Trace 1]		
[Meas Control]		5.00	[Trace 2]		
[Meas Control]		3-22	[Trace 3]		
[Meas Window]			[Trace 4]		
[Meas. Mode]		<i>5</i> 0	[Type]		
[Memo]		5-9,	[User Define]		
[Madulation]	5-10	5.20	[X Data Mode]		
[Modulation]		5-20	[X Posi]		
[Modulation Analyzer]		F 16	[X Range]		
[Network Setup]		3-10	[X Width]		
[Next]			[XY Cursor]		
[No Reference]			[Y]		
[OFDM]			[Y Bottom]		
[Offset]			[Y Data Mode]		
[OK]			[Y Range]		
[Open]		5 12	[Y Top]		
[Page1/2]			(DISDLAY)		
[Dage Roman]	5-14,	3-18	{DISPLAY}		
[Pass Range][Preset]		5 22	{FREQ}		
[Prev]		3-23	{MEAS}		
		5 14			
[Print]			{MENU1>>}		
[Ref Line]					
-		3-00	{MKR}		
[Reference]		5 52	{MKR→}		
[Konon Factor]	5-50, 5-55	3-32,	{POWER}		
[SA Col]			· ·		
[SA Cal without ATT]			{SEARCH}		
[SA Cal without ATT]		5 14	{SPAN}		
[Save All]		5-14	{SWEEP}		
[Save ALL]		5-13	{TRACE}		5.40
[Save Data]		5-13 5-9	ACP		
[Save Item 1		5-10	ACP Off		
[Save STD Date 1		5-10 5-11	Active Marker [1]		
[Save STD Data]	J-0,	J-11	Active ivialized [1]	J-J7,	J-40

		_	
Active Window [1]		Date	
ADC Dither On/Off		dB/div	
Annotations Setup		dBc/Hz	
Artificial Analog		dBm	
Artificial Analog On/Off		dBm/Hz	
ATT Auto/Man	*	dBmV	
Auto	*	dBμV	
Auto All		dBμV/√Hz	
Auto Level Set		dBµVemf	
	5-49, 5-51,	dBpW	
	5-54	Default	
Auto Tune	*	Delete	
Average			5-45, 5-46,
Average [RMS]			5-50, 5-54,
Average Mode Cont/Rep			5-56
	5-47, 5-48,	Delete Line	
	5-49, 5-50,	Delta Marker	
	5-52, 5-56,	Detector Auto/Man	•
	5-58	Disp Mode REL/A.L/A.R	
Average Power		Display Line On/Off	
Average Power Off		DMY	
Average Times On/Off	5-45, 5-46,	Edit Correction Factor	*
	5-47, 5-48,	Edit Limit Line	
	5-49, 5-50,	Edit Table	5-46, 5-53
	5-52, 5-56,	Ext 1	5-31, 5-32
	5-58, 5-59,	Ext 2 [2.5 V]	
	5-60	Ext. Reference	5-15
Average Type [RMS]	5-42, 5-43	F/T	5-66, 5-67
Average Type Auto/Man	5-42, 5-43	Fine	5-15
Blank	5-42, 5-43	Fixed ΔMarker On/Off	5-39
Carrier Band Width	5-46, 5-54	Fixed Marker Peak	5-60
CCDF	5-45, 5-57	Fixed Mkr Peak	5-59
CCDF Gate On/Off	5-46, 5-57	Format	5-15
CCDF Off	5-57	Free Run	5-31, 5-32
CCDF RBW	5-46, 5-57	Freq Offset On/Off	5-24, 5-25
Center	5-24	Full Span	5-25
CF Step Size Auto/Man	5-24	FUND Frequency On/Off	5-59, 5-61
Channel Number	5 - 24	Gate Delay	5-31, 5-33
Channel Power	5-45, 5-48	Gate Slope +/	5-31, 5-32
Channel Power Off	5-45, 5-49	Gate Source [Free Run]	5-31, 5-32
Coarse		Gate Width Auto/Man	5-31, 5-33
Cont Down On/Off	5-59, 5-61	Gated Sweep On/Off	5-31, 5-33
Cont Peak On/Off	5-35, 5-37	Gated Sweep Setup	5-31, 5-32
Copy Table 1 to 2	5-63, 5-65	Gated Sweep Setup Quit	5-31, 5-33
Copy Table 2 to 1	5-63, 5-65	Gaussian On/Off	5-46, 5-57
Correction Factor On/Off		Harmonics	
Counter	5-59, 5-60	Harmonics Number	5-59, 5-61
Counter Off	5-59, 5-60	Harmonics Off	5-59, 5-61
Couple to Power		IF Monitor On/Off	5-31, 5-32
Couple to Power On/Off		IF Power [50%]	
CS/BS Setup		IM Meas	5-59, 5-61

IM Meas Off	5-59, 5-62	Multi Average Power	5-45.	5-57
Init	*	Multi Average Power Off		
	5-45, 5-46,	Multi Carrier ACP		
	5-50, 5-54,	Multi Carrier ACP Off		
	5-56	Multi Inner Limit Setup		
Insert		Multi Inner Peak Search		
	5-45, 5-46,	Narrow	-	
	5-50, 5-54,	Negative	,	
	5-56	Next Min Peak		
Insert Line		Next Peak		5-39.
Int. Reference Adjustment	,	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	5-40	,
Judgement On/Off		Next Peak Left		
Last Span	•	Next Peak Right		
Limit Line I On/Off		Next Result		5-54
Limit Line 2 On/Off		Noise		
Limit Line Auto Adj	*	Noise Corr On/Off		5-46.
Limit Line Setup			5-51,	
Limit Setup		Noise/Hz	,	
Line		Noise/Hz Off		
Line 1/2	*	Noise/X Hz		
Linear		Normal		
Link		Normalize		
Manual Mode	*	Normalize On/Off		
Manual Tune		Normalize with Store Corr		
Marker	•	OBW		
Marker All Off		OBW Off	-	
Marker List On/Off		Offset Setup	,	
	5-39, 5-40	Order		
Marker No. [1]	,	Parameters Def/Man	,	
Marker OFF	·			5-48,
Marker ON			,	5-51,
Marker Reset	,			5 - 54,
Marker Setup	*			5-58,
Marker Step Size Auto/Man			5-59,	
Marker Trace 1/2/3/4		Parameters Define→Default		
	5-41			5-49,
Marker→CF	5-34		,	5-53,
Marker→Ref				5-57,
Max Hold				5-59,
MDY	•		5-62	
Meas Sample		Pass/Fail Judgement On/Off	5-59.	5-62
Meas Window		Peak ΔY		
Measurement Off		Peak List Freq		
	5-58, 5-59,	Peak List Level		
	5-62	Peak Search Condition		
Medium	5-29, 5-30	Peak X dB Down		5-60
Min ATT On/Off	*	Peak→CF		
Min Hold		Peak→Ref		
Min Peak		PLL BW [Auto]		5-30
Mkr→CF Step		Positive		
Mkr→Mkr Step		Power Ratio On/Off		
·				

D O-/O'C	506 507	C'	5 45 5 52
Preamp On/Off		Spurious Emission	
Presel Tune		Spurious Emission Off	
Previous Result		Start	•
RBW Auto/Man		Stop	
Ref Level		Store	
Ref Offset On/Off		Store 1→3	•
Ref Power Chan/Peak		Store 2→4	
Ref Power Setup		Sweep Time	
Ref/Offs Setup		Sweep Time Auto/Man	
Reference Line On/Off		Table Init	*
P. Comman Madam On IOSS	5-66	Table No 1/2/3	.*
Reference Marker On/Off	*	Trace [1]	
Reference Object		Trace Detector [Normal]	
Remove Anchor		Trace Operation	
70.	5-66, 5-67	Trace Write On/Off	
Return		Trigger Delay	
	5-26, 5-27,	m: 01	5-33
	5-28, 5-29,	Trigger Slope +/-	
	5-30, 5-31,	Trigger Source [Free Run]	
	5-32, 5-33,	Units [dBm]	
	5-42, 5-43,	VBW Auto/Man	
	5-44, 5-45,	VBW/RBW Auto/Man	
	5-46, 5-48,	Video	
	5-49, 5-50,	Video [0.00dBm]	
	5-51, 5-53,	View	
	5-54, 5-55,	Voltage	
	5-56, 5-57,	Volts	•
	5-58, 5-59,	Watts	•
	5-60, 5-61,	Wide	
	5-62, 5-63,	Window No. [1]	
	5-65, 5-66,	Window OFF	,
	5-67, 5-68	Window ON	
RMS	*	Window On/Off	
Sample			5-48, 5-66,
Sampling Times [5]			5-67
Screen Reset	5-66, 5-67,	Window Position	
			5-47, 5-48,
Set Anchor			5-58, 5-66,
	5-66, 5-67		5-67
Show Result		Window Reset	
Signal Track On/Off		Window Setup	
Single		Window Sweep On/Off	
Sort	5-26, 5-28,	Window Width	
	5-45, 5-46,		5-47, 5-48,
	5-50, 5-56,		5-58, 5-66,
	5-63, 5-65		5-67
Span		Write	
Span/RBW Auto/Man	5-29	X Cursor Position	5-42, 5-44,
Spectrum Emission Mask			5-66, 5-67
Spectrum Emission Mask Off	5-46, 5-57	X dB Down	
Split	5-66, 5-68	X dB Down Level	5-59, 5-60

R3681 Series User's Guide

X dB Left	5-59, 5-60
X dB Right	•
X Scale Max	
XY Cursor	5-66
XY Cursor On/Off	5-42, 5-44,
	5-66, 5-67
Y Cursor Position	5-42, 5-44,
	5-66, 5-67
YMD	5-15
Zero Span	5-25
Zoom	5-66, 5-67
Zoom Position	5-66, 5-67,
	5-68
Zoom Width	5-66, 5-67

5.2 Menu Bar

5.2 Menu Bar

This section describes the functions displayed on the menu bar.


The following shows the details of the system menu bar: [File], [System], [Config], [Modulation], [Cal], and [Special] are displayed on the menu bar.

When you touch the menu bar, a drop down menu is displayed. Select the required item from the drop down menu

[File]	[System]	[Config]	[Modulation]	[Cal]	[Special]	
[File]			Exec	utes save	recall, print, and application software	e.
[Syste	em]				address and networks and system fun nter drivers, etc.	ctions such a
[Cont	fig]		tion r	nodes dit	tion mode of this instrument. The av- fer depending on the options configu- abbreviation of the word "Configura	ration of th
[Mod	ulation]		"Mod	lulation A	n the modulation analysis option is equanalyzer" is selected in the Config mass option is selected.	
[Cal]				rms calib "Calibra	oration of this instrument. An abbrevion".	viation of th
[Spec	ial		Exec	utes supp	lementary functions.	


5.2.1 [File]

This subsection describes the drop down menu items comprising the [File] menu bar. When you touch the [File] menu bar, the following drop down menu items are displayed:



|Load Data...|

Loads the saved setting conditions of this instrument. When you select [Load Data...], the following dialog box is displayed. The setting conditions are loaded by selecting the name of the file to be loaded and executing [Load].



Displays the contents of the standard directory in the file list.



Displays the contents of the floppy disk in the file list.

[Filename]

Enter the name of the file to be read out.

MEMO: You can select a file by touching the name of the file. You can move directories by touching twice in quick succession (double clicking).

[Memo]

The memo information on the selected file is displayed.

[Information]

The information on the selected file is displayed.

[Load]


Performs loading.

[Close]

Closes a dialog box.

[Save Data...]

Saves the setting conditions of this instrument as a file. When you select [Save Data...], the following dialog box is displayed:






Displays the contents of the standard directory in the file list.



Displays the contents of the floppy disk in the file list.



Adds a folder to the directory being displayed. The following software keyboard is displayed to create a folder. You can name the folder any name.



[CL]

Clears the input contents.

|BS|

Deletes the character before the cursor.

[sp]

Inserts a space.

[Page1/2]

Switches the type of characters to be entered. Single-byte lower-case alphabetical characters are entered by [Page1] and single-byte uppercase alphabetical characters are entered by [Page2].

[Filename]

Enter the name of the file to be saved.

[Memo]

Enter the memo information on the file.

[Information]

The information on the selected file is displayed.

|Save ALL|

Saves all items regardless of the setting of |Save Item...|.

[Save]

Selects and saves the items to be saved according to the setting of

|Save Item...|.

MEMO: The items corresponding to the current operation mode specified in the [Config] or [Modulation] menu are to be saved. Therefore, even if data is selected to be saved in [Save Item...], only the data corresponding to the operation mode will be saved.

[Delete]

[Close]

[Save Item...]

Deletes the selected file.

Closes a dialog box.

Selects the setting conditions and the type of data to be saved. When you select [Save Item...], the following dialog box is displayed:



|Delete Data...]

Deletes the file in which the setting conditions are saved. When you select | **Delete Data...**|, the following dialog box is displayed:



7

[Filename]

Displays the contents of the standard directory in the file list.

Displays the contents of the floppy disk in the file list.

The name of the selected file is displayed.

MEMO: You can select a file by touching the name of the file. You can move directories by touching twice in quick succession (double clicking).

[Memo]

[Information]

The memo information on the selected file is displayed.

The information on the selected file is displayed.

[Delete]

[Close]

[Load STD Data...]

Deletes a file.


Closes a dialog box.

Loads the setting condition file of the standard, which is saved by using the [Save STD Data...], and creates or renews the user file. This user file is automatically selected as the default value of the standard.

When [Load STD Data...] is selected, the following dialog box appears. The setting conditions are loaded by selecting the file name to be loaded and executing [Load].

MEMO: The [Load STD Data...] menu is displayed only if the Standard information file exists in a folder whose name is D:\Advantest\R3681\STD_Param\Standard name.

(The standard name, such as cdma2000, must be entered.)



Displays the details of the standard directory in the file list.

Displays the details of the floppy disk in the file list.

Loads the setting condition file of the Standard.

Closes the dialog box.

Writes the selected Standard setting in a file.

When [Save STD Data...] is selected, the following dialog box appears.

MEMO: The [Save STD Data...] menu is displayed only if the Standard information file exists in a folder whose name is D:\Advantest\R3681\STD_Param\Standard name.

(The standard name, such as cdma2000, must be entered.)






[Load]

[Close]

[Save STD Data...]






Displays the details of the standard directory in the file list.



Displays the details of the floppy disk in the file list.



Adds a folder to the current directory. The following virtual keyboard appears and a new folder can be created.



[CL]

Clears all characters in the input window.

[BS]

Deletes one character to the left of the cursor.

|sp|

Enters a space.

[Page1/2]

Switches between the character types used. Single-byte lowercase alphabetic characters can be entered when [Page1] is selected, and single-byte uppercase alphabetic characters can be entered when [Page2] is selected.

[Filename]

The selected file name is displayed.

MEMO: The file can be selected by touching the file name. The directories can be moved by touching twice in quick succession (double clicking).

[Memo]

The selected file memo information is displayed.

[Information]

The selected file information is displayed.

[Save]

Writes the setting conditions of the Standard in a file.

[Delete]

Deletes a file.


[Close]

Closes the dialog box.

[Execute...]

Selects an execution file and executes it.

When you select [Execute...], the following dialog box is displayed:



[Open]

Enter the name of the execution file to be executed.

[OK]

Executes the execution file entered.

[Cancel]

Closes a dialog box.


[Browse...]

Displays a dialog in the Windows Explorer format. When the execution file name or the folder name in which it is stored is unknown, browse and specify it.

[Save Bitmap Data...]

Saves the screen data of this instrument in a file.

When you select [Save Bitmap Data...], the following dialog box is displayed:





Displays the contents of the standard directory in the file list.




Displays the contents of the floppy disk in the file list.



Displays the contents of the external disk F in the file list.



Adds a folder to the directory being displayed. The following software keyboard is displayed to create a folder. You can name the folder any name.



[CL] Clears the input contents.

[BS] Deletes the character before the cursor.

[sp] Inserts a space.

[Page1/2] Switches the type of characters to be entered. Single-byte lower-case alphabetical characters are entered by [Page1] and single-

byte uppercase alphabetical characters are entered by [Page1] and single byte uppercase alphabetical characters are entered by [Page2].

[Filename] Enter the name of the file to be saved.

MEMO: You can select a file by touching the name of the file. You can move directories by touching twice in quick succession (double clicking).

[File Type]

Specifies the file type to be saved. There are two file types available: the bit map file (bmp) format and the portable network graphics (png) format.

[Save]

Executes save.

[Delete]


Deletes the selected file.

[Close]

Closes a dialog box.


[Print...]

Outputs the screen data of this instrument to the printer.
When you select [Print], the following dialog box is displayed.
The following example shows the condition in which the printer driver is already installed:



5.2.2 [System]

This subsection describes the drop down menu items comprising the [System] menu bar. When you touch the [System] menu bar, the following drop down menu items are displayed:




[GPIB Address...]

Sets the GPIB Address of this instrument. When you select [GPIB Address...], the following dialog box is displayed:



[Network Setup...]

Sets the LAN network information of this instrument. When you select [Network Setup...], the following dialog box is displayed. For more information on each setting item, refer to "APPENDIX A.3 Setting up the Network."



[Guest Account...]

Sets the Guest Account.


When you select [Guest Account...], the following dialog box is displayed. To refer to a file on this instrument from an external PC, it is necessary to set the Guest Account. For more information on the Guest Account settings, refer to "APPENDIX A.4 Setting the Guest Account."



[Printers Setup...]


Installs the printer driver.

When you select [Printers Setup...], the following dialog box is displayed. The following example shows the condition in which the printer driver is already installed:



[Date and Time...]

Sets the date, time and time zone of this instrument. When you select [Date and Time...], the following dialog box is displayed:



|Freq Reference...|

Selects whether to use the internal or external frequency source as the reference, and performs fine frequency adjustment of the 10 MHz internal frequency reference source.

When you select [Freq Reference...], the following dialog box is displayed:



|Manual Mode|

When the check box is not checked, the frequency synchronization reference source mode is set to the internal/external reference signal auto-switching mode. When the auto-switching mode is set, the reference frequency source is fixed to 10 MHz. Therefore, input into [Ext Reference] is prohibited. When the check box is checked, connection to the external reference source at the frequency specified in [Ext Reference] is required. When the check box is checked and the external reference source is not connected, an error message indicating that phase lock is off is displayed.

[Ext. Reference]

When the frequency synchronization reference mode is not set to the auto-switching mode, it is fixed to the external reference source. In this case, the frequency of the external reference source can be set between 5 MHz and 20 MHz.

[Int. Reference Adjustment]

Performs frequency adjustment of the internal reference frequency source.

|Coarse|

Performs rough adjustment of the internal reference frequency source.

The setting range is between 0 and 4095.

[Fine]

Performs fine adjustment of the internal reference frequency

The setting range is between 0 and 4095. This setting becomes valid when the high-precision frequency reference source option is equipped.

[Store]

Stores the above value of [Int. Reference Adjustment] set for adjustment of the internal frequency reference source to make the adjustment value valid even when the power is off.

[Default]

Discards the adjustment value stored by [Store] above, and restores the default setting.

[Display...]

Sets the date display on the screen on/off and the display format. When you select [Display...], the following dialog box is displayed:



[Date]


When the check box is checked, the date data is displayed on the screen. When displaying the date, select a format from the following three formats: year/month/day, month/day/year, or day/month/year.

[Format]

A format can be selected from YMD (year/month/day), MDY (month/day/year), or DMY (day/month/year).

[Title...]

Enter title characters on the screen of this instrument. When you select [Title...], the following software keyboard is displayed:



[CL]

Clears the input contents.

[BS]

Deletes the character before the cursor.

[sp]


Inserts a space.

[Page1/2]

Switches the type of characters to be entered. Single-byte lower-case alphabetical characters are entered by [Page1] and single-byte uppercase alphabetical characters are entered by [Page2].

[Explorer...]


Displays the following dialog box for file operation:



5.2.3 [Config]

5.2.3 [Config]

This subsection describes the drop down menu items comprising the [Config] menu bar. When you touch the [Config] menu bar, the following drop down menu items are displayed:



|Spectrum Analyzer|

Sets the operation mode of this instrument to the Spectrum Analyzer mode. When you select this mode, the screen of this instrument is switched to the Spectrum Analyzer screen.


[Modulation Analyzer]

Sets the operation mode of this instrument to the Modulation Analyzer mode. This mode is available when the various modulation analysis options are equipped. The modulation analysis option has multiple options. An analyzable modulation format, etc. are displayed depending on the option equipped in the [Modulation] menu bar. Select a modulation format to be analyzed, etc. using the [Modulation] menu bar before switching to the Modulation Analyzer mode by this menu.

5.2.4 [Modulation]

This subsection describes the drop down menu items comprising the [Modulation] menu bar.

When you touch the [Modulation] menu bar, drop down menu items are displayed depending on the modulation analysis options equipped at that time. Following is an example of the menu displayed when the OFDM modulation analysis option is equipped:




Sets the modulation analysis operation mode of this instrument to the OFDM mode (displayed only when the option is equipped).

When you select the [Modulation Analyzer] menu on the [Config] menu bar in this mode, the screen of this instrument is switched to the Modulation Analyzer screen for OFDM.

5.2.5 [Cal]

5.2.5 [Cal]

This subsection describes the drop down menu items comprising the [Cal] menu bar. When you touch the [Cal] menu bar, the following drop down menu items are displayed:



[SA Cal]


Performs self-calibration of this instrument in the Spectrum Analyzer mode. When performing self-calibration, connection to the external Cal signal is required.

[SA Cal without ATT]

Performs self-calibration of this instrument in the Spectrum Analyzer mode. Because this calibration uses only the internal Cal signal, connection to the external Cal signal is not required.

5.2.6 [Special]

This subsection describes the drop down menu items comprising the [Special] menu bar. When you touch the [Special] menu bar, the following drop down menu items are displayed:



[Self Test...]

Displays self-diagnostic dialog of this instrument.

MEMO: Self-diagnostics can be executed in the Spectrum Analyzer mode.


[Status...]

Displays the model name, serial number, software revision information, and option configuration of this instrument.

[Log...]

Displays the log of conditions of this instrument. When you select [Log...], the following dialog is displayed:

5.2.6 [Special]



[Clear]

Deletes the log.

[Prev]

Displays the log of the previous page.


[Next]

Displays the log of the next page.

[Service...]

Displays the maintenance menu that only our service engineers are allowed to use.

When you select [Service...], the following dialog is displayed:



[Meas Control...]

Controls measurement. When you select [Meas Control...], the following dialog box is displayed:



[Single]

Starts measurement in the single measurement mode.

[Stop]

Stops sweep.

[Start]

Starts measurement in the continuous sweep mode.

|STD...|

Selects a Standard. When **|STD...|** is selected, the following dialog box appears.



|Type|

Selects a Standard. When [Type] is set to OFF, the Standard data is not used.

5.2.6 [Special]

Selects the measurement mode (such as Up Link, Down Link, Band Class) from the Standard selected by [Type]. [Meas. Mode]

Applies the current [Type] and [Meas. Mode] settings. The channel setting and the default value of the measurement function are [Apply]

set in accordance with the selected Standard.

Presets this instrument. When you touch the [Preset] menu bar, the following drop down menu items are displayed: [Preset]

[Current] Presets the currently active operation mode.

[All] Presets all operation modes. 5.3 Function Bar

5.3 **Function Bar**

This section describes the functions of each function button displayed on the function bar. The configuration of the function buttons of this instrument is as follows:



When you touch a function button on the function bar, the associated soft key is displayed on the side menu


The explanation starts from the function button on the right of MENU1 and moves toward the left.

5.3.1 {FREQ}

When you touch the {FREQ} button, the Freq. menu that enables setting of the center frequency is displayed.

The following shows the menu map:

CF Step Size Auto/Man



Center Activates the center frequency setting.

The frequency range is displayed by the center frequency and frequency span.

Start Activates the start frequency setting.

Stop Activates the stop frequency setting. The frequency range is displayed by the start frequency and stop frequency.

> Switches auto setting and manual setting of the step size for changing the center frequency by the step key.

Automatically sets the step size to 1/10 of the span Auto:

width.

Man: Sets the step size manually.

5.3.2 {SPAN}

Freq Offset On/Off Switches On and Off the frequency offset function.

> On: Sets the offset value and changes only the display of

frequency by the offset value. (Displayed value of

frequency = Set value + Offset value)

Off: Cancels the offset function.

Presel Tune Displays the Presel Tune menu.

> Auto Tune Automatically tunes the preselector according to the peak fre-

> > quency.

Manual Tune Tunes the preselector manually.

Return Returns to the above layer menu.

Channel Number When the channel number is set, the center frequency is automat-

ically set by using the following formula.

(Center frequency) = (Channel interval) × (Channel number +

Channel offset) + (Start frequency)
The parameters such as the channel interval and the channel number setting range depend on the Standard selected by [Special]→[STD...]. If the Standard selection is set to OFF, the

channel number cannot be set.

5.3.2 **SPAN**

When you touch the **SPAN**} button, the Span menu that enables setting of the frequency span is displayed. The center frequency and frequency span are displayed in the annotation field below the scale. The following shows the menu map:



Span Activates the frequency span setting.

The frequency range is displayed by the center frequency and fre-

quency span.

Full Span Makes the frequency span full.


Zero Span Sets zero span mode for the center frequency.

Last Span Returns the frequency span to the previous value. 5.3.3 {LEVEL}

5.3.3 {LEVEL}

When you touch the {LEVEL} button, the Level menu that enables setting of the amplitude display is displayed.

The following shows the menu map:



Ref Level Activates the reference level setting. dB/div Activates dB/div setting and displays waveform data in log scale. Linear Displays waveform data in linear scale. Units [dBm] Displays the Units menu. dBm Sets the display unit to dBm. dBmV Sets the display unit to dBmV. dΒμV Sets the display unit to dBµV. dBµVemf Sets the display unit to dBµ Vemf. dBpW Sets the display unit to dBpW.

5.3.3 {LEVEL}

Watts Sets the display unit to Watts.

Volts Sets the display unit to Volts.

Return Returns to the above layer menu.

ATT Auto/Man Switches auto setting and manual setting of the attenuator func-

tion.

Auto: Automatically sets the attenuator value based on the

reference level.

Man: Sets the attenuator value manually.

Min ATT On/Off Switches On and Off the Min ATT function.

On: Sets the minimum attenuator value and implements

control regardless of ATT Auto/Man.

Off: Cancels the Min ATT mode.

Preamp On/Off Switches On and Off the high-sensitivity input function.

On: Turns On the built-in preamp with gain of 20 dB or

more. Here, the preamp gain is corrected at each frequency and therefore it does not need to be

considered in level measurement.

Off: Turns Off the built-in preamp.

Ref Offset On/Off Switches On and Off the reference level offset function.

On: The range of the offset level can be set to $0 - \pm 100.0$

dB. The relation among the displayed reference level,

set reference level, and offset is as follows:

Reference level (displayed) = Reference level (set) +


Offset

Off: Cancels offset.

More 2/2 Displays Level menu (2/2).

Correction Factor On/Off Switches On and Off the level correction function.

Edit Correction Factor Displays the Edit menu and the following |Correction Factor| dialog box:



Inserts the same value as that at the cursor position in the dialog

Delete Deletes the line where the cursor is positioned in the dialog box.

5.3.3 {LEVEL}

Sorts Sorts the data input into the dialog box in the order of frequency.

Deletes all data in the set dialog box.


Return Closes the dialog box and returns to the above layer menu.

More 1/2 Displays Level menu (1/2).

5.3.4 {BW}

When you touch the {BW} button, the BW menu used to change the resolution bandwidth (RBW) and video bandwidth (VBW) is displayed. When the resolution bandwidth is manually set, setting of the resolution bandwidth is enabled.

The following shows the menu map:



RBW Auto/Man Switches auto setting and manual setting of the RBW.

Auto: Automatically sets the optimum RBW based on the

frequency span.

Man: Sets the RBW manually.

VBW Auto/Man Switches auto setting and manual setting of the VBW.

Auto: Automatically sets the optimum VBW based on the

RBW.

Man: Sets the VBW manually.

Auto All Automatically sets the RBW, VBW and sweep time based on the

frequency span.

Span/RBW Auto/Man Switches auto setting and manual setting of the RBW vs. fre-

quency span function. Available only when auto setting is applied

to the RBW.

Auto: The RBW/frequency span value is fixed to 100.

Man: The RBW vs. frequency span ratio can be changed.

VBW/RBW Auto/Man Switches auto setting and manual setting of the VBW vs. RBW

function. Available only when auto setting is applied to the VBW.

Auto: The VBW/RBW value is fixed to 1.

Man: The VBW vs. RBW ratio can be changed.

ADC Dither On/Off Switches On and Off the ADC Dither function.

On: Enables ADC Dither.
Off: Cancels ADC Dither.

5.3.4 {BW}

MEMO: When the ADC Dither is set to On, the ADC linearity for low level signal is improved and the internally-occurred intermodulation distortion is effectively restrained. When measuring the intermodulation distortion, set ADC Dither to On. On the other hand, the ADC Dither adversely affects the displayed average noise level. For the lower noise level measurement, set the ADC Dither to Off.

PLL BW [Auto]

Displays the PLL BW menu used to select the loop filter bandwidth in a PLL circuit.

Auto

Automatically sets the filter to get the optimum phase noise characteristic corresponding to the frequency span.

Narrow

Sets a narrow bandwidth filter.

Medium

Sets a medium bandwidth filter.

Wide

Sets a wide bandwidth filter.

MEMO: When the PLL BW is set to Narrow, Medium or Wide, the phase noise may worsen according to the set frequency span. In such a case, set Auto.


Return

Returns to the above layer menu.

5.3.5 **(SWEEP)**

When you touch the **{SWEEP}** button, the Sweep menu that enables setting of sweep conditions is displayed.

The following shows the menu map:



Sweep Time Auto/Man Switches auto setting and manual setting of the sweep mode.

Auto: Automatically sets the sweep time for span.

Man: Sets the sweep time manually.

Trigger Source [Free Run] Activates the trigger condition. The initial value is [Free Run].

Free Run Repeats sweep automatically.

IF Power 50% Performs sweep synchronizing with the IF signal.

The initial value is [50%].

Video [0.00dBm] Performs sweep synchronizing with the video signal.

The initial value is [0.00dBm].

Ext 1 Performs sweep synchronizing with the external trigger signal

(EXT1 terminal).

Ext 2 [2.5 V] Performs sweep synchronizing with the external trigger signal

(EXT2 terminal).

The initial value is [2.5V].

Gated Sweep Setup

5.3.5 {SWEEP}

Line Performs sweep synchronizing with the AC power frequency.

Link Performs the sweep synchronized with the trigger of an optional function.

MEMO: For more information on how to use the link trigger, refer to the manual for the option that uses the link trigger.

IF Monitor On/Off Monitors the internal IF signal. This function is enabled to specify

trigger level when setting the trigger by using the IF signal.

Return Returns to the above layer menu.

Trigger Slope +/- Switches the polarity (+/-) of the trigger slope. Available for the video trigger, external trigger, IF trigger and link trigger.

+: Starts sweep at the rise of a trigger.

-: Starts sweep at the fall of a trigger.

Sets the delay time from a trigger point. This menu item is available when the video trigger, external trigger, IF trigger, or link trigger is the trigger condition in the zero span mode.

Displays the Gated Sweep menu and displays two screens. The gated sweep screen is displayed in the upper screen and the gate signal, gate position, and gate width are displayed in the lower screen.

MEMO: When the gate signal mode is set to Auto, the gate width is not displayed.

Gate Source [Free Run] Activates the trigger condition of the gated sweep.

The initial setting is [Free Run].

Free Run Repeats sweep automatically.

IF Power [50%] Performs sweep synchronizing with the IF signal. The initial value is **[50%]**.

Performs sweep synchronizing with the external trigger signal (EXT1 terminal).

Ext 2 [2:5 V] Performs sweep synchronizing with the external trigger signal (EXT2 terminal).

The initial value is [2.5V].

Performs the sweep synchronized with the trigger of an optional

function.

MEMO: For more information on how to use the link trigger, refer to the manual for the option that uses the link trigger.

Return Returns to the above layer menu.

Cate Slope +/- Switches the trigger slope polarity between + and -. This menu

item is available when the external trigger or IF trigger is used.

5.3.5 {SWEEP}

+: Starts sweep at the rise of a trigger.

-: Starts sweep at the fall of a trigger.

Gate Delay Sets the delay time from a trigger point. The delay time is used as

the gate position at the gated sweep.

Gate Width Auto/Man Switches the gate signal mode between the auto setting and man-

ual setting when the gated sweep is performed.

Auto: Adjusts the gate width automatically to correspond with

the width of the rectangular part of the gate signal source. A signal, whose ON period is variable, is

automatically adjusted.

Man: Sets the gate width (time) manually when the gated

sweep is performed.

Gated Sweep On/Off Switches the gated sweep on and off.

On: Performs the gated sweep according to the set gate

conditions (gate position and width).

Off: Cancels the gated sweep.

Sweep Time Sets the sweep time.

Trigger Delay Sets the delay time from a trigger point.

Gated Sweep Setup Quit Clear the trigger condition setting screen and displays the Sweep

menu.

Return Returns to the above layer menu.

Gated Sweep On/Off Switches the gated sweep on and off.

On: Performs the gated sweep according to the set gate

conditions (gate position and width).


Off: Cancels the gated sweep.

5.3.6 {MKR→}

$5.3.6 \quad \{MKR \rightarrow \}$

When you touch the $\{MKR \rightarrow \}$ button, the MKR \rightarrow menu (1/2) used to use the active marker data (frequency, level, etc.) as the data for other functions is displayed.

The following shows the menu map:



Marker CF Sets the frequency of the active marker to the center frequency.

Marker Ref Sets the level of the active marker to the reference level.

Peak > CF Displays the marker at the highest peak in the targeted search range and sets the frequency of the marker to the center frequency.

Peak Ref Displays the marker at the highest peak in the targeted search

range and sets the level of the marker to the reference level.

∆Marker→CF Sets the frequency difference between the delta marker and the

normal marker to the center frequency.

AMarker > Span Sets the frequency difference between the delta marker and the

normal marker to the frequency span.

More 2/2 Displays the MKR \rightarrow menu (2/2).

Mkr→CF Step Sets the frequency of the marker to the step size of the center fre-

quency.

Mkr >Mkr Step Sets the frequency of the marker to the step size of the marker.

∆Marker→CF Step Sets the frequency difference between the delta marker and the

normal marker to the step size of the center frequency.

∆Marker→Mkr Step Sets the frequency difference between the delta marker and the

normal marker to the step size of the marker.

More 1/2 Displays the MKR \rightarrow menu (1/2).

When you touch the {SEARCH} button, the Search menu is displayed. The following shows the menu map:

(SEARCH) Peak List Level Next Peak Next Peak Left Peak List Freq Marker List On/Off Next Peak Right Min Peak Next Min Peak Multi Inner Peak Search Peak Search Condition Multi Inner Limit Setup Peak AY Cont Peak On/Off More 1/2 More 2/2

Next Peak

Moves the marker to the next highest peak from the current marker position in the targeted search range.

Next Peak Left

Moves the marker to the next lower frequency peak (on the left) of the current marker position in the targeted search range.

Next Peak Right

Moves the marker to the next higher frequency peak (on the right) of the current marker position in the targeted search range.

Min Peak


Moves the current marker to the minimum peak of the trace in the targeted search range.

Next Min Peak

Moves the marker to the next minimum peak from the current marker position in the targeted search range.

Peak Search Condition

Displays the [Peak Search Condition] dialog box. Specifies the targeted search range for execution of the peak search function using the marker. The targeted range is the full range of the waveform screen by default.



[X Range]

Specifies the search range of the horizontal axis in the waveform screen.

All: Specifies the full range as the search range.

Inner: The search range is the range specified by [Limit Posi]

and [Limit Width].

Outer: The search range is outside of the range specified by

[Limit Posi] and [Limit Width].

[Limit Posi] When Inner or Outer is specified by [X Range], specifies the cen-

ter position (when frequency span is used) or start position (when

zero span is used) of the range.

[Limit Width] When Inner or Outer is specified by [X Range], sets the search

width whose center position is specified by the value set by **|Limit Posi|** (when frequency span is used), or the search width whose start position is specified by **[Limit Posi]** (when zero span

is used).

[Couple to F(T)] Specifies the display mode of the window indicating the search

range.

ON: The window indicating the set search position and

range moves in line with the center frequency and span. The values of [Limit Posi] and [Limit Width] are not recalculated. The window position indicating the search range moves in line with the set frequency and span.

OFF: The values of [Limit Posi] and [Limit Width] are

recalculated according to the set center frequency and span, and automatically reset so that the display position and width of the window in the waveform

screen will always remain the same.

[Y Range] Specifies the search range of the vertical axis in the waveform

screen.

All: Specifies the full range as the search range.

Disp Line:

Displays a display line, and sets only the range above or below the display line as the search range according to

the condition specified by [Disp Line].

Limit Line:

Sets only the range above or below the limit line as the search range according to the condition specified by **[Limit Line 1]** and **[Limit Line 2]**. When both limit lines 1 and 2 are displayed, the search is performed

based on the AND condition.

[Disp Line] Specifies the range either above or below the display line as the

search range.

Above: Specifies the range above the display line as the search

range.

Below: Specifies the range below the display line as the search

range.

[Limit Line 1] Specifies the range either above or below limit line 1 as the search

range.

Above: Specifies the range above limit line 1 as the search

range.

Below: Specifies the range below limit line 1 as the search

range.

[Emit Em

[Limit Line 2]

Specifies the range either above or below limit line 2 as the search range.

Above: Specifies the range above limit line 2 as the search

range.

Below: Specifies the range below limit line 2 as the search

range.

Peak AY

Activates the setting of level difference of the signal to be judged as the peak point during peak search. The level difference set here is used as the threshold value for the peak point search.

This set value is used for Next Peak and as multipoint peak search by the multimarker.

Cont Peak On/Off

Switches On and Off the continuous peak search function.

On: Performs the peak search repeatedly each time a sweep

is performed.

Off: Cancels the continuous peak search function.

More 2/2

Displays the Search menu (2/2).

Peak List Level

Displays a list of levels and frequencies in the order of peak levels.

IS.

Peak List Freq

Displays a list of levels and frequencies in the order of the frequency of the peak levels

quency of the peak levels.

Marker List On/Off

Switches On and Off the display of the multimarker list.

On: Displays a list of frequencies and levels in the order of

marker numbers.

Off: Deletes the display of the multimarker list.


Multi Inner Peak Search

Executes multi inner peak search.

This function defines multiple areas and performs a batch search for the maximum value in those areas. The areas must be specified by **Multi Inner Limit Setup** before executing this function.

Multi Inner Limit Setup

Sets the search range for executing the multi inner peak search function. Displays the [Multi Inner Limit Setup] dialog box for setting.



[1] to [10]

When the check box is checked, setting of the target range is enabled, and a window is displayed in the corresponding area.

[X Posi]

Specifies the center position (when frequency span is used) or start position (when zero span is used) of the horizontal axis in the target range.

[X Width] Specifies the search range width whose center position is speci-

fied by the value set by [X Posi] (when frequency span is used) or the search range width whose start position is specified by the

value set by |X Posi| (when zero span is used).

[Y]

When the check box is checked, setting of the target range of the vertical axis specified by [Y Top] and [Y Bottom] is enabled. When the check box is not checked, the whole vertical axis in the waveform screen becomes the targeted search area.

[Y Top] Sets the upper limit of the targeted area of the vertical axis.

[Y Bottom] Sets the lower limit of the targeted area of the vertical axis.

[Couple to F(T)] Specifies the display mode of the window indicating the search

area.

ON: The window indicating the set search position and range moves in line with the center frequency and span.

The values of [Limit Posi] and [Limit Width] are not recalculated. The window position indicating the search range moves in line with the set frequency and span.

OFF: The values of [Limit Posi] and [Limit Width] are

recalculated according to the set center frequency and span, and automatically reset so that the display position and width of the window in the waveform


screen will always remain the same.

More 1/2 Displays the Search menu (1/2).

5.3.8 {MKR}

5.3.8 {MKR}

When you touch the {MKR} button, the Marker menu that enables marker setting is displayed. The following shows the menu map:



Marker Activates setting of the frequency or time position of the active

marker.

Delta Marker Displays the Delta Marker menu.

ΔMarker On/Off Switches On and Off the delta marker display function.

On: Displays the delta marker and normal marker in the same position. Displays the relative value (frequency and level) to the normal marker in the marker area.

Off: Deletes the display of the delta marker.

Fixed \(\Delta Marker \(\On \) Off Switches On and Off the fixed marker function.

On: Maintains the frequency and level of the delta marker.

Off: Cancels the fixed marker function.

5.3.8 {MKR}

1/A Marker On/Off

Switches On and Off the inverse number display function for the delta marker value.

On: Displays a frequency value on the time axis and a time

value on the frequency axis.

Off: Cancels the inverse number display function.

Marker Trace 1/2/3/4

Specifies the trace where the marker sits. Every time you touch this key, the marker moves on the trace in the order of $1\rightarrow2\rightarrow3\rightarrow4\rightarrow1$. The trace in the Blank condition when operating this key is skipped.

Next Peak Moves the marker to the next highest peak from the current

marker position in the targeted search range.

Return Returns to the above layer menu.

Marker Setup Displays the Marker Setup menu.

Marker No. 11 Specifies a marker number.

The initial value is [1].

Marker ON Displays the marker of the specified number, and displays the fre-

quency and level of the marker position in the marker area.

Marker OFF Deletes the marker of the specified number.

Active Marker [1] Activates the marker of the specified number.

The initial value is [1].

Marker Reset Deletes the multimarkers whose multimarker number is other

than 1. Marker 1 is displayed at the center of the horizontal axis.

Marker List On/Off Switches On and Off the display of the multimarker list.


On: Displays a list of frequencies and levels in the order of

marker numbers.

Off: Deletes the display of the multimarker list.

Return Returns to the above layer menu.

Reference Object Displays the [Reference Object] dialog box.



[\Delta Marker]

Displays the relative value of the frequency (or time) and level of the normal marker, using the delta marker as a reference.

5.3.8 {MKR}

[Anchor] Displays the relative value of the frequency (or time) and level of

the normal marker, using the anchor as a reference.

[Limit Line 1] Displays the relative value of each level of the normal marker,

using limit line 1 as a reference.

[Limit Line 2] Displays the relative value of each level of the normal marker,

using limit line 2 as a reference.

[Disp Line] Displays the relative value of the level of the normal marker,

using the display line as a reference.

[**Ref Line**] Displays the relative value of the level of the normal marker,

using the reference line as a reference.

[Trace 1] Displays the relative value of each level of the normal marker,

using trace 1 as a reference.

[Trace 2] Displays the relative value of each level of the normal marker,

using trace 2 as a reference.

[Trace 3] Displays the relative value of each level of the normal marker,

using trace 3 as a reference.

[Trace 4] Displays the relative value of each level of the normal marker,

using trace 4 as a reference.

[\Delta Marker (Other Screen)] Displays the relative value of the frequency (or time) and level of

the normal marker, using the delta marker on the other screen as

a reference when two screens are displayed.

[No Reference] Changes the display of the level value of the marker from the rel-

ative value to the absolute value, using no reference.

Signal Track On/Off Switches On and Off the signal truck function.

On: Performs the peak search targeting the same peak each

time a sweep is performed, and sets the frequency of the

marker to the center frequency.

Signal of the same peak means that signal exists within +/-15 dB refer to the level when this function is switched on. If no signal exists in this range, tracking operation does not function. When a signal has returned

to this range, tracking operation is restarted.

OFF: Cancels the signal truck function.

Marker Trace 1/2/3/4 Specifies the trace where the marker sits. Every time you touch

this key, the marker moves on the trace in the order of $1\rightarrow 2\rightarrow 3\rightarrow 4\rightarrow 1$. The trace in the Blank condition when operating

this key is skipped.

Marker Step Size Auto/Man Switches auto setting and manual setting of the step size for mov-

ing the marker by the step key.

Auto: Sets the marker step size to 1/10 of the frequency span.

Man: Sets the step size manually. Manual setting is

automatically applied when a value specified by Mkr→Mkr Step or ∆Marker→Mkr Step is set


to the step size.

Marker All Off Deletes all markers displayed.

5.3.9 {TRACE}

5.3.9 {TRACE}

When you touch the {TRACE} button, the Trace menu, which enables setting of the trace, is displayed. The following shows the menu map:



5,3,9 {TRACE}

Trace II Selects the trace to be the target of operation.

Write Updates the trace data each time a sweep is performed.

View Displays the trace data stored in the memory.

Blank The trace is not displayed.

Average Activates setting of the average count and displays the average

value of each trace point by trace.

Max Hold Activates setting of the max hold count and displays the maxi-

mum value of each trace point by trace.

Trace Detector [Normal] Displays the Trace Detector menu used for the target trace.

Normal Sets the normal detection mode to automatically detect whether

the peak is positive or negative at each trace point.

Positive Sets the positive peak detection mode.

Negative Sets the negative peak detection mode.

Sample Sets the sample detector mode.

Average IRMS Sets the average detector mode. There are three types of average

detection: RMS (power average), Video (Trace average), and Voltage (voltage average). The averaging method to be used can

be selected by the **Average Type |RMS**| menu.

Detector Auto/Man Switches auto setting and manual setting of the detection mode.

Auto: Automatically sets the optimum detection mode for

measurement based on the trace mode.

Man: Sets the detection mode manually.

Return Returns to the above layer menu.

Average Type [RMS] Displays the Average Type menu.

RMS Performs averaging by power (W) and draws waveforms.

Video Performs averaging by display data.

Voltage Performs averaging by voltage and draws waveforms.

Average Type Auto/Man Switches auto setting and manual setting of average type selec-

tion.

Auto: Selects an appropriate averaging method for waveform

averaging according to the type (Log/Linear) of the

vertical axis scale.

Log scale: RMS

Linear scale: Voltage

Man: Sets the averaging method manually.

Return Returns to the above layer menu.

More 2/2 Displays the Trace menu (2/2).

5.3.9 {TRACE}

Min Hold Activates setting of the minimum hold count and displays the

minimum value of each trace point by trace.

Normalize Displays the Normalize menu.

Normalize On/Off Switches On and Off the normalize function.

On: Performs level correction using the normalize data for

measurement.

Off: Cancels the normalize function.

Normalize with Store Corr Acquires the normalize data and turns on the normalize function.

When acquiring the normalize data, the waveform data displayed

on the screen at that time is used.

Reference Line On/Off Activates setting of the reference line used to specify the refer-

ence level for the normalize function.

Return Returns to the above layer menu.

Artificial Analog Displays the Artificial menu.

Artificial Analog On/Off Switches On and Off the quasi analog display function.

On: Displays the tone of the trace by using the quasi analog

display function. Because the waveform data of up to 32 traces is accumulated on the screen, the opening

condition of the waveform can be observed.

Off: Cancels the quasi analog display function.

Sampling Times [5] Activates the sampling count in the vertical axis by quasi analog

trace. The initial value is [5].

XY Cursor On/Off Switches On and Off the XY cursor function.

On: Displays the XY cursors.

Off: Deletes the XY cursors.

X Cursor Position Activates the X cursor.

Y Cursor Position Activates the Y cursor.

Set Anchor Displays an anchor at the intersection point of the XY cursors.

The display values of the XY cursors are the relative values between the anchor and the intersection point of the XY cursors.

Remove Anchor Deletes the anchor.

Return Returns to the above layer menu.

Trace Operation Displays the Trace menu.

Store 1 > 3 Copies the waveform data of the trace 1 to the waveform data area

of the trace 3, and sets the trace 3 to the View condition.

Store $2\rightarrow 4$ Copies the waveform data of the trace 2 to the waveform data area

of the trace 4, and sets the trace 4 to the View condition.

Return Returns to the above layer menu.


More 1/2 Displays the Trace menu (1/2).


5.3.10 {MENU2>>}

When you touch {MENU2>>}, {MENU 1>>} is displayed.

5.3.11 {POWER}

When you touch the **{POWER}** button, the menu concerning Power measurement is displayed. The following shows the menu map:





Average Power

Measures and displays the average power in the target range (full measurement span or measuring window). Sets the averaging count for average power measurement. In average power measurement, the resolution bandwidth (RBW) is set to be wider than the amplitude fluctuation bandwidth. (the resolution bandwidth is more than three times wider than the occupied bandwidth) The average power can be obtained by the following equation. The trace point in the horizontal axis is set to 1001.

$$P_{AVG} = 10log \left[\sum_{n=Xl} \frac{P(n)}{10^{10}} \right] \times \frac{1}{1001}$$

 P_{AVG} : Denotes the average power to be calculated

P(n): Denotes the data (dBm) for each trace point

X1: 1

1001 X2:

Window On/Off Switches On and Off the measuring window display.

> On: Displays the measuring window in the screen.

Off: Closes the measuring window.

Window Position Activates setting of the position of the measuring window.

Window Width Activates setting of the width of the measuring window.

Average Times On/Off Switches On and Off the averaging function.

> On: Sets the average number of times and measures the

average power.

Off: Cancels the averaging function.

Average Mode Cont/Rep Switches the continuous calculation setting and the repeat calculation setting of the average mode.

> Cont: Sets the continuous calculation mode. In the continuous

calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep: Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached,

the averaging count is reset to 1 and averaging is restarted from the beginning.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

> Def: Starts measurement in the auto setting mode.

The setting parameters stored by the Parameters Define Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define Default Stores the current setting parameters as the setting parameters for average power measurement.

Average Power Off Terminates average power measurement.

Return Returns to the above layer menu.

Channel Power Activates the measuring window and displays the Channel Power menu. The channel power can be obtained by using the following

equation.

 $P_{CH} = 10\log \left[\sum_{n = X1} (10^{10}) \times \frac{1}{PBW} \times \frac{Window Width}{(X2-X1)} \right]$

P_{C11}: Channel power to be obtained

 $P_{(n)}$: The power level (dBm) of each data point

SPAN: Span setting value

PBW: Noise power bandwidth

X1: Trace point at the window's startX2: Trace point at the window's end

Window On/Off Switches On and Off the measuring window display.

On: Displays the measuring window in the screen.

Off: Closes the measuring window.

Window Position Activates setting of the position of the measuring window.

Window Width Activates setting of the width of the measuring window.

Average Times On/Off Switches On and Off the averaging function.

On: Sets the average number of times in the channel power measurement and measures the average channel power.

Off: Cancels the averaging function.

Average Mode Cont/Rep Switches the continuous calculation setting and the repeat calculation setting of the average mode.

lation setting of the average mode.

Cont: Sets the continuous calculation mode. In the continuous calculation mode, the moving-average method is used

for calculation after the averaging count is reached.

Rep: Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached, the averaging count is reset to 1 and averaging is

restarted from the beginning.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

Def: Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define-Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define > Default: Stores the current setting parameters as the setting parameters for

measurement.

Channel Power Off

Closes the window and terminates channel power measurement.

Return Returns to the above layer menu.

OBW

Displays the OBW menu.

Two screens are displayed. The upper screen displays the trace and the lower screen displays the occupied bandwidth measure-

ment conditions and data.

OBW

Sets the ratio of the occupied bandwidth power to the total power

in percentage terms.

The initial value is [99%].

Average Times On/Off

Switches On and Off the averaging function.

On: Sets the averaging count and performs averaging of the

occupied bandwidth power.

Off: Cancels the averaging function.

Average Mode Cont/Rep

Switches the continuous calculation setting and the repeat calcu-

lation setting of the average mode.

Cont:

Sets the continuous calculation mode. In the continuous calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep:

Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached, the averaging count is reset to 1 and averaging is

restarted from the beginning.

Parameters Def/Man

Switches the set mode of setting parameters for measurement.

Def:

Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define → Default menu are automatically set.

Man:

Starts measurement without changing the settings

before measurement.

Parameters Define Default Stores the current setting parameters as the setting parameters for

measurement.

OBW Off

Terminates occupied bandwidth measurement.

Return

Returns to the above layer menu.

ACP

Displays the ACP menu.

Auto Level Set


Sets the reference level and ATT to the optimum value in accordance with the signal to be measured. When the key is pressed,

Auto Level Set is executed.

MEMO: The modulation signal model which is used in Auto Level Set of ACP sets the input ATT to the optimum value assuming that one carrier of W-CDMA is input.

CS/BS Setup

Displays the CS/BS menu and [CS/BS Setup] dialog box at the same time.



[Carrier Band Width] Sets the measurement bandwidth for measuring channel power as the reference power.

[Channel Space]

Sets the Offset frequency from the carrier frequency indicating the adjacent channel measuring position.

[Band Width]

Sets the measurement bandwidth for measuring adjacent channel

leakage power.

Insert

Inserts a line describing the adjacent channel measurement condition at the current cursor position. The data in the line that existed in the position before insertion is copied to each setting value as

new line data.

Delete

Deletes the measurement condition at the current cursor position.

Sort

Sorts the data input into the dialog box in the order of frequency.

Init

Initializes all data in the table currently being edited.

Return

Returns to the above layer menu.

√Nyquist Filter Setup

Displays the [$\sqrt{Nyquist Filter Setup}$] dialog box.



[√Nyquist Filter]

Switches On and Off the \(\sqrt{Nyquist filter function.} \)

Activates the √Nyquist filter. ON: OFF: Cancels the \sqrt{Ny} quist filter.

[Symbol Rate]

Sets the inverse number of the symbol rate (frequency).

|Rolloff Factor|

Sets the rolloff factor.

Average Times On/Off

Switches On and Off the averaging function.

On:

Sets the average number of times in the ACP measurement and measures the average adjacent

channel leakage power.

Off: Cancels the averaging function.

Average Mode Cont/Rep

Switches the continuous calculation setting and the repeat calculation setting of the average mode.

Cont: Sets the continuous calculation mode. In the continuous

calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep: Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached,

the averaging count is reset to 1 and averaging is

restarted from the beginning.

Noise Corr On/Off Performs a correction equivalent to the internal noise level of this instrument, and switches On and Off the measurement dynamic

range expansion function.

On: Turns on the noise correction function. Every time the measurement parameter changes, measures the internal

noise level of this instrument and reflects the noise correction value in the measured value.

Off: Turns off the noise correction function.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

> Def: Starts measurement in the auto setting mode. The

setting parameters stored by the Parameters Define Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define→Default Stores the current setting parameters as the setting parameters for

ACP measurement.

ACP Off Terminates the ACP measurement function.

Return Returns to the above layer menu.

Multi Carrier ACP Displays the Multi Carrier menu and performs multi carrier ACP

measurement.

Auto Level Set Sets the reference level and ATT to the optimum value in accor-

Auto Level Set is executed.


MEMO: The modulation signal model which is used in Auto Level

Set of Multi-Carrier ACP sets the input ATT to the optimum value assuming that three or four carriers of W-CDMA are input. When two carriers are input, the optimum value can be set by changing the ATT from -10 dB to -5 dB after exe-

cuting Auto Level Set.

Ref/Offs Setup Displays the [Ref/Offs Setup] dialog box. In this dialog box, the offset frequency and bandwidth of the reference carrier of up to 10 carriers (Abs Meas 1/2) and the frequency and bandwidth of up to 6 waves (Rel Meas) in the frequency domain to be measured by ACP measurement can be set. Set the Offset frequency from the center frequency set before measurement. The frequency to be measured by ACP measurement sets the Offset frequency from

the reference carrier frequency. The center frequency (Carrier Freq), which is a reference in Multi-Carrier ACP, can be adjusted.



√Nyquist Filter Setup

Displays the $\lceil \sqrt{\text{Nyquist Filter Setup}} \rceil$ dialog box.



|√Nyquist Filter|

Switches On and Off the \sqrt{Ny} quist filter function.

ON: Activates the \sqrt{Ny} quist filter.

OFF: Cancels the \sqrt{Ny} quist filter.

[Symbol Rate]

Sets the inverse number of the symbol rate (frequency).

[Rolloff Factor]

Sets the rolloff factor.

Average Times On/Off

Switches On and Off the averaging function.

On:

Sets the average number of times in the multi carrier ACP measurement and measures the average adjacent

channel leakage power.

Off: Cancels the averaging function.

Average Mode Cont/Rep

Switches the continuous calculation setting and the repeat calculation setting of the average mode.

Cont:

Sets the continuous calculation mode. In the continuous calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep:

Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached, the averaging count is reset to 1 and averaging is restarted from the beginning.

Noise Corr On/Off

Performs a correction equivalent to the internal noise level of this instrument, and switches On and Off the measurement dynamic range expansion function.

On:

Turns on the noise correction function. Every time the measurement parameter changes, measures the internal noise level of this instrument and reflects the noise correction value in the measured value.

Off: Turns off the noise correction function.

Parameters Def/Man

Switches the set mode of setting parameters for measurement.

Def: Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define→Default

Stores the current setting parameters as the setting parameters for

multi carrier ACP measurement.

Multi Carrier ACP Off

Terminates multi carrier ACP measurement.

Return

Returns to the above layer menu.

Spurious Emission

Displays the Spurious menu. Two screens are displayed. The upper screen displays the trace and the lower screen displays the spurious measurement result screen.

Table No 1/2/3

Switches setting sequence table number 1, 2, and 3 for spurious measurement.

1: Sets the table number 1.

2: Sets the table number 2.

3: Sets the table number 3.

Edit Table

Displays the Edit Table menu.

The [Edit Table] dialog box for editing the setting sequence table of the selected numbers at the same time are displayed. You can set the start and stop frequency for spurious measurement frequency range and, RBW, VBW, sweep time, reference level, attenuator, preamp on/off, and judgment level value for measurement by these dialog box.




Table No 1/2/3

Switches setting sequence table number 1, 2, and 3 for spurious measurement.

- 1: Sets the table number 1.
- 2: Sets the table number 2.
- 3: Sets the table number 3.

Insert Inserts a vertical row as the spurious measurement condition set-

ting area at the current cursor position. The data contained in the row that existed in the position before insertion is copied to each

setting value as new row data.

Delete Deletes a measurement condition area vertical row at the current

cursor position.

Initializes all data in the table currently being edited.

Return Returns to the above layer menu.

Show Result Displays the Show Result menu.

The measurement result is displayed on the entire screen.

Previous Result Displays the previous screen.

Next Result Displays the next screen.

Return Returns to the above layer menu.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

Def: Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define Default Stores the current setting parameters as the setting parameters for

spurious measurement.

Spurious Emission Off Returns to the single-screen display and terminates the spurious

measurement function.

Return Returns to the above layer menu.

Spectrum Emission Mask Displays the Spectrum menu.

Auto Level Set Sets the reference level and ATT to the optimum value in accor-

dance with the signal to be measured. When the key is pressed,

Auto Level Set is executed.

MEMO: The modulation signal model, which is used in Auto Level

Set of Spectrum Emission Mask, sets the input ATT to the optimum value assuming that one carrier of W-CDMA is input. The optimum value can be set by changing the ATT from 0dB to +5 dB for two carriers input and +10 dB for three or four carriers input after executing Auto Level Set.

Ref Power Setup Displays the Ref Power menu. This menu is used to set reference

power calculation parameters.

Carrier Band Width Activates setting of the power conversion bandwidth for carrier

signals.

Nyquist Filter Setup Displays the [\Nyquist Filter Setup] dialog box.



[\squist Filter] Switches On and Off the √Nyquist filter function.

> ON: Activates the √Nyquist filter. OFF: Cancels the $\sqrt{Nyquist}$ filter.

|Symbol Rate| Sets the inverse number of the symbol rate (frequency).

[Rolloff Factor] Sets the rolloff factor.

Ref Power Chan/Peak Switches calculation modes between the Channel mode and the Peak Power mode.

> Chan: Calculates the carrier power according to the setting of

Ref Power Setup and sets the calculated power value to the reference power for mask measurement.


Sets the Peak power value of the waveform to the Peak:

reference power for mask measurement.

Return Returns to the above layer menu.

Offset Setup

Displays the Offset Setup menu and |Offset Setup| dialog box for Offset data setting at the same time.



[Start] Enter the offset frequency from the center frequency for the start frequency in the emission mask judgment area.

|Stop| Enter the offset frequency from the center frequency for the stop frequency in the emission mask judgment area.

|Integral BW| Sets the power integral bandwidth at each frequency point.

[Limit Abs Start] Enter the mask value (absolute value) at the start frequency point.

[Limit Abs Stop] Enter the mask value (absolute value) at the stop frequency point. The mask value from the start frequency point to the stop frequency point is calculated by linear interpolation between the

start value and stop value.

Enter the mask value (relative value) at the start frequency point.

The mask value is used for comparison with the offset value from

the measured reference power.

|Limit Rel Start|

[Limit Rel Stop] Enter the mask value (relative value) at the stop frequency point.

The mask value from the start frequency point to the stop frequency point is calculated by linear interpolation between the

start value and stop value.

[Judge] Specifies how to make comparisons with the input mask values (absolute values and relative values) when judging the mask.

Abs: Compares the mask values set as Limit Abs Start/Stop

values with the waveform. The judgment is Pass when the waveform is equal to or under the mask values.

Rel: Compares the mask values set as Limit Rel Start/Stop values with the waveform. The judgment is Pass when the waveform is equal to or under the mask values.

A&R: Compares both the Limit Abs Start/Stop values and the Limit Rel Start/Stop values with the waveform.

When the conditions of both are met, Pass is displayed.

A|R: Compares both the Limit Abs Start/Stop values and the

Limit Rel Start/Stop values with the waveform. When either one of the conditions is met, Pass is

displayed.

Insert Inserts the same value as the cursor position in the dialog box.

Deletes Deletes the row where the cursor is positioned in the dialog box.

Sort Sorts the data input into the dialog box in the order of frequency.

Init Deletes all data in the set dialog box.

Return Closes the dialog box and returns to the above layer menu.

Average Times On/Off Switches On and Off the averaging function.

On: Sets the average number of times the spectrum emission mask measurement is performed and performs average

measurement.

Off: Cancels the averaging function.

Average Mode Cont/Rep Switches the continuous calculation setting and the repeat calculation setting of the average mode.

Cont: Sets the continuous calculation mode. In the continuous calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep: Sets the repeat calculation mode. In the repeat calculation mode, when the averaging count is reached,

the averaging count is reset to 1 and averaging is

restarted from the beginning.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

Def: Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define → Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define > Default: Stores the current setting parameters as the setting parameters for spectrum emission mask measurement.

Spectrum Emission Mask Off Terminates spectrum emission mask measurement.

Return

Returns to the above layer menu.

CCDF

Displays the CCDF menu.

The screen is switched to the CCDF measurement screen.

CCDFRBW

RBW can be set to 100 kHz to 20 MHz (1, 2, 3, and 5 sequence).

мемо:

When the wideband demodulator option is installed, the

CCDF RBW can be set to 50 MHz.

The analysis frequency range is from 200 MHz to 6 GHz and the built-in preamplifier can be used in the range from 200

MHz to 6 GHz.

Meas Sample

Sets the number of measurement samples.

Trace Write On/Off

Switches the reference waveform display on and off.

On:

Displays the currently displayed waveform as the

reference waveform.

Off: Hides the reference waveform.

Gaussian On/Off

Switches the ideal Gaussian noise waveform display on and off.

On:

Displays the ideal Gaussian noise waveform.

Off:

On:

Off:

Hides the ideal Gaussian noise waveform.

X Scale Max

Sets the horizontal axis maximum value of the waveform display.

CCDF Gate On/Off

Switches the gate function of the CCDF measurement on and off.

Sets a threshold level and perform the CCDF measurement in the period where the input signal is

higher than the specified threshold level.

Sets the gate function of the CCDF measurement to off.

Return

CCDF Off

Quits the CCDF measurement. Returns to the previous menu.

Measurement Off

Sets the measurement function to Off.

More 2/2

Displays the Power menu (2/2).

Multi Average Power

Displays the Multi-Average Power menu.

Displays the average power measured from each displayed win-

Window Setup

Displays the Window Setup menu.

Window No. [1]

Specifies a window number. The initial value is [1].

Window ON

Displays the window of the specified number.

Window OFF

Closes the window of the specified number.

Active Window [1] Activates the window of the specified number.

The initial value is [1].

Window Position Activates the settings of the position of the active window.

Window Width Activates the settings of the width of the active window.

Couple to Power Displays the window coupled to the average power (Trace).

On: Couples the window to the average power.

Off: Does not couple the window to the average power.

Window Reset Closes all windows except for window 1.

Window 1 is displayed at the far left. At this time the window

width is automatically set to one tenth of the sweep time.

Return Returns to the previous menu.

Power Ratio On/Off Switches On and Off the Power Ratio measurement.

On: Calculates the level difference between the average power in the active window and the average powers in

other displayed windows and displays the result.

Off: Cancels the Power Ratio measurement.

Average Times On/Off Switches On and Off the averaging function.

On: Sets the number of times averaging is performed and

measures the average power in the window.

Off: Cancels the averaging function.

Average Mode Cont/Rep Switches the averaging mode between the continuous calculation

mode and the repeat calculation mode.

Cont: Sets the continuous calculation mode. In the continuous

calculation mode, the moving-average method is used for calculation after the averaging count is reached.

Rep: Sets the repeat calculation mode. In the repeat

calculation mode, when the averaging count is reached, the current averaging count is reset to 1 and the averaging process is repeated from the beginning.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

Def: Starts the measurement in the mode in which setting

parameters saved in the Parameters Define > Default

menu were automatically set.

Man: Starts the measurement by using the previously-set

parameters.

Parameters Define Default Stores the currently-set parameters as measurement parameters.

Multi Average Power Off Quits the Multi-Average Power measurement.


Return Returns to the previous menu.

Measurement Off Sets the measurement function to Off.

More 1/2 Displays the Power menu (1/2).

5.3.12 {MEAS}

When you touch the {MEAS} button, the menu concerning general measurement is displayed. The following shows the menu map:



5.3.12 {MEAS}

Counter Displays the Counter menu and turns on the frequency counter

function.

Average Times On/Off Switches On and Off the averaging function.

On: Sets the average number of times the counter is

processed.

Off: Cancels the averaging function.

Counter Off Turns off the frequency counter function.

Return Returns to the above layer menu.

Noise/Hz Displays the Noise/Hz menu and starts Noise/Hz measurement.

Noise/X Hz Activates setting of the noise measurement bandwidth.

The initial value is [1Hz].

dBm/Hz Sets the vertical axis unit to dBm and the marker unit to dBm/Hz.

As the detector mode, Average is automatically selected.

dB μ **V**/V**Hz** Sets the vertical axis unit to dB μ V and the marker unit to dB μ V/

 $\sqrt{\text{Hz}}$. As the detector mode, Average is automatically selected.

dBc/Hz Sets the delta marker unit to dBc/Hz. The marker fixing function

is set to ON. As the detector mode, Average is automatically

selected.

Fixed Marker Peak Moves a delta marker to the maximum peak of the trace currently

being displayed and fixes it to that position.

Noise/Hz Off Terminates the noise measurement function.

Return Returns to the above layer menu.

X dB Down Displays the X dB Down menu.

X dB Down Level X dB Down Level: Activates the lower level setting.

X dB Down Based on the Mode setting, displays a normal marker and a delta

marker in the position lower than the current position by X dB.

X dB Left Displays a normal marker in the position lower than the current

position on the left by X dB.

X dB Right Displays a normal marker in the position lower than the current

position on the right by X dB.

Peak X dB Down Searches the maximum peak in the targeted search range, and dis-

plays a normal marker and a delta marker in the position lower

than the current position by X dB.

Disp Mode REL/A.L/A.R Sets the marker data display method.

REL: Displays a normal marker on the right and a delta

marker on the left.

A.L: Displays the marker on the left in absolute value.

A.R: Displays the marker on the right in absolute value.

5,3,12 {MEAS}

Cont Down On/Off Switches On and Off the continuous X dB down function.

On: Performs Peak X dB down repeatedly each time a

sweep is performed.

Off: Cancels the continuous X dB down function.

Reference Marker On/Off Switches On and Off the reference marker function.

On: Displays a reference marker in the reference position of

X dB Ďown.

Off: Deletes the reference marker.

Return Returns to the above layer menu.

%AM Meas On/Off Obtains the AM modulation factor using the peak search and dis-

plays the result of operation in percentage terms.

On: Performs AM modulation measurement.

Off: Terminates AM modulation measurement.

Harmonics Displays the Harmonics menu.

Two screens are displayed. The upper screen displays the trace and the lower screen displays the harmonic measurement data.

FUND Frequency On/Off Switches On and Off the frequency setting function of the funda-

mental wave.

On: Activates setting of the fundamental frequency.

Off: Sets the current center frequency to the fundamental

frequency.

Harmonics Number Activates setting of the harmonic order to be measured.

Harmonics Off Terminates the harmonic measurement function and displays the

full screen.

Return Returns to the above layer menu.


IM Meas Displays the IM Meas menu. Two screens are displayed. The

upper screen displays the trace and the lower screen displays the

intermodulation distortion measurement data.

Order Sets the measurement order. The allowed orders are 3, 5, 7, and 9.

Limit Setup Displays the [Limit Setup] dialog box.



[3rd Order Limit] Sets the limit value of the 3rd order distortion signal.

[5th Order Limit] Sets the limit value of the 5th order distortion signal.

[7th Order Limit] Sets the limit value of the 7th order distortion signal.

[9th Order Limit] Sets the limit value of the 9th order distortion signal.

5.3.12 {MEAS}

Pass/Fail Judgement On/Off Switches On and Off Pass/Fail judgment performed by compari-

son with the limit value set in the [Limit Setup] dialog box.

On: Performs Pass/Fail judgment. If the measurement result

is larger than the set limit value, a Fail judgment is

made.

Off: Pass/Fail judgment is not performed.

Parameters Def/Man Switches the set mode of setting parameters for measurement.

Def: Starts measurement in the auto setting mode. The

setting parameters stored by the

Parameters Define → Default menu are

automatically set.

Man: Starts measurement without changing the settings

before measurement.

Parameters Define Default Stores the current setting parameters as the setting parameters for

intermodulation distortion measurement.

IM Meas Off Terminates the intermodulation distortion measurement function.


Return Returns to the above layer menu.

Measurement Off Sets the measurement function to Off.

5.3.13 {PASS/FAIL}


5.3.13 {PASS/FAIL}

When you touch the {PASS/FAIL} button, the menu concerning Pass/Fail is displayed. The following shows the menu map:



Limit Line Setup

Displays the [Limit Line Setup] dialog box used for setting judgment conditions using limit lines.



[Limit Line 1]

[Pass Range] Sets the judgment condition by limit line 1

Above: Sets the range above limit line 1 as the range satisfying

the Pass condition.

Below: Sets the range below limit line 1 as the range satisfying

the Pass condition.

|Limit Line 2|

[Pass Range] Sets the judgment condition by limit line 2

Above: Sets the range above limit line 2 as the range satisfying

the Pass condition.

Below: Sets the range below limit line 2 as the range satisfying

the Pass condition.

5.3.13 {PASS/FAIL}

[X Data Mode]

Sets the attributes of the horizontal axis (frequency or time) data of the limit line.

Abs:

Sets the horizontal axis position based on the limit line set by **Limit Line Edit** as the absolute value. The position of the horizontal axis of the limit line moves according to the change in the frequency span and center frequency setting.

Rel:

Sets the horizontal axis position based on the limit line set by **Limit Line Edit** as the relative value. The position of the horizontal axis of the limit line is fixed to the position defined by Reference, and is not affected by change in the frequency span or center frequency.

[Reference]

Displays the reference position.

Center: Sets the center point of the horizontal axis as the

reference position.

Left: Sets the left-most point of the horizontal axis as the

reference position.

User Def: Sets the reference position by User Define.

|User Define|

Sets the absolute frequency to be the reference position when **[User Def]** is selected for reference position setting.

[Offset]

Sets the offset frequency from the reference position.

[Y Data Mode]

Sets the attributes of the vertical axis (level) data of the limit line.

Abs:

Sets the vertical axis position based on the limit line set by **Limit Line Edit** as the absolute value. The position of the vertical axis of the limit line moves according to the change in the level setting.

Rel:

Sets the vertical axis position based on the limit line set by **Limit Line Edit** as the relative value. The position of the vertical axis of the limit line is fixed to the position defined by Reference, and is not affected by the change in the level setting.

[Reference]

Displays the reference position.

Top: Sets the top of the horizontal axis as the reference

position.

Bottom: Sets the bottom of the horizontal axis as the reference

position.

User Def: Sets the reference position by User Define.

[User Define]

Sets the absolute level to be the reference position when **|User Def|** is selected for reference position setting.

[Offset]

Sets the offset along the vertical axis direction against the limit line.

5.3.13 {PASS/FAIL}

Judgement On/Off

Switches On and Off Pass/Fail judgment performed by comparison with limit lines 1 and 2.

On:

Off:

Performs Pass/Fail judgment. If the value does not satisfy the condition set by the Limit Line Setup dialog,

a Fail judgment is made.

Limit Line 1 On/Off

Pass/Fail judgment is not performed.

Switches On and Off limit line 1.

On: Displays limit line 1.

Off: Deletes limit line 1.

Limit Line 2 On/Off

Switches On and Off limit line 2.

On: Displays limit line 2. Off: Deletes limit line 2.


MEMO: A limit line is not displayed unless the data of at least two points for a limit line is entered with the [Limit Line] dialog

Limit Line Auto Adj

Searches the peak point of the waveform and sets the level value of the peak point to the [User Define] value in [Y Data Mode]. Moves the limit line according to the reference position. This function is available only when Y Data Mode is set to Rel.

Edit Limit Line

Displays the Edit menu and the [Limit Line] dialog box.



Line 1/2

Switches limit lines to be displayed in [Limit Line].

Insert Line Inserts the same value as the cursor position in the dialog box.

Delete Line Deletes the line where the cursor is positioned in the dialog box.

Sort Sorts the data input into the dialog box in the order of frequency.

Table Init Deletes all data in the limit line setting dialog box.

Copy Table 1 to 2 Copies the data created for limit line 1 to limit line 2.

Copy Table 2 to 1 Copies the data created for limit line 2 to limit line 1.

Return Closes the [Limit Line] dialog box, and returns to the above layer


menu.

5.3.14 {DISPLAY}

5.3.14 {**DISPLAY**}

When you touch the {DISPLAY} button, the Disp menu, which enables setting of the measuring window display, etc., is displayed.

The following shows the menu map:



Display Line On/Off

Switches On and Off the display of the display line used as the reference line for trace level comparison.

On: Activates the display line.

Off: Deletes the display line.

Reference Line On/OffSwitches On and Off the display of the reference line, which will be the reference for the relative display of the level data.

On: Displays the reference line.

The reference line position can be changed here.

Off: Deletes the reference line.

XY Cursor

Displays the XY Cursor menu.

5.3.14 {DISPLAY}

XY Cursor On/Off Switches On and Off the XY cursor function.

> On: Displays the XY cursors. Off: Deletes the XY cursors.

X Cursor Position Activates the X cursor.

Y Cursor Position Activates the Y cursor.

Displays an anchor at the intersection point of the XY cursors. Set Anchor

The display values of the XY cursors are the relative values

between the anchor and the intersection point of the XY cursors.

Remove Anchor Deletes the anchor.

Return Returns to the above layer menu.

Meas Window Displays the Meas Window menu.

Window On/Off Switches On and Off the measuring window display.

> Displays the measuring window in the screen. On:

Off: Closes the measuring window.

Window Position Activates setting of the position of the measuring window.

Window Width Activates setting of the width of the measuring window.

Window Sweep On/Off Switches the window sweep function on and off.

> On: Performs the sweep within the range specified in the

> > measuring window.

Off: Performs the sweeps in entire range of the span.

MEMO: When the window sweep is on, the minimum width of the

measuring window is frequency span/500.

If the measuring window is not completely inside the measurement screen when the window sweep is on, the sweep is

performed in the entire range of the span.

Return Returns to the above layer menu.

Zoom Displays the Zoom menu and displays two screens. The upper

screen displays a waveform before zoom. The lower screen displays a zoomed waveform. The horizontal axis represents fre-

quency (or time) both in the upper and lower screens.

Zoom Position Activates setting of the center position to be zoomed.

Zoom Width Activates setting of the zoom width.

Screen Reset Displays only the upper screen and returns to the Disp menu.

Return Returns to the above layer menu.

F/T Displays the Zoom menu and displays two screens. The upper

screen displays a waveform before zoom. The horizontal axis in the upper screen represents frequency, and the lower screen rep-

resents the time (zero span) in the zoomed position.

5.3.15 {MENU1>>}

Zoom Position Activates setting of the center position to be zoomed.

Screen Reset Displays only the upper screen and returns to the Disp menu.

Return Returns to the above layer menu.

Sets the split-screen condition to display two screens (upper and

lower). The two screens can be set individually.

Screen Reset Returns to single-screen display (only the upper screen) from


two-screen display.

More 2/2 Displays the Display menu (2/2).

Annotations Setup Displays the [Annotations Setup] dialog box used to set on or off

the annotation display that indicates the position and width of the

measuring window.



[Disp Line] By checking the check box, the level position of Display Line

when it is turned on is displayed. Deletes the display by uncheck-

ing the check box.

[Ref Line] By checking the check box, the level position of Reference Line

when it is turned on is displayed. Deletes the display by uncheck-

ing the check box.

[XY Cursor] By checking the check box, the position of XY Cursor when it is

turned on is displayed. Deletes the display by unchecking the

check box.

|Meas Window| By checking the check box, the position and width of the measur-

ing window when it is turned on is displayed. Deletes the display

by unchecking the check box.

More 1/2 Displays the Disp menu (1/2).

5.3.15 {MENU1>>}

When you touch {MENU1>>}, {MENU2>>} is displayed.

5.4 Tool Menu

This section describes the tool menu.

Functions of the tool menu are activated by touch screen operation.

The tool menu has the following functions:

Moves the active screen when multiple screens are displayed. After touching this menu, if you touch the area of the screen you want to activate, that screen is activated.

This menu is used to display a special window for touch screen operation. After touching this menu, you can display a window by simply touching the waveform screen. After touching this menu, if you specify two points (the two points specifying the window width) in the waveform screen area, the window is displayed at the specified position. Up to 10 windows can be displayed at one time.

The window for touch screen operation is displayed by simply touching the waveform screen. After touching this menu, if you specify two points on opposing corners (the two points specifying the window width and height) in the waveform screen area, the measuring window is displayed at the specified position. Up to 10 windows can be displayed at one time.

Executes the peak search function in the active screen. When the window for touch screen operation is displayed, a marker is located on the maximum value of the waveform in the window. When the window is not displayed, a marker is located on the maximum value of the whole screen. This function is executed when this menu is pressed.

Executes the multimarker peak search function in the active window (surrounded by the thickest line) in the window for touch screen operation displayed on the active screen. The screen is zoomed out automatically and the multimarker list is displayed. This function is executed when this menu is pressed.

Turns off all marker displays and marker lists. This function is executed when this menu is pressed.

Executes the Zoom In function used to set the reference level and the frequency span or time on the active screen according to the area information specified in the window for touch screen operation. When the window for touch screen operation is not displayed and this menu is touched, the current frequency span centered on the center frequency decreases by 50%. This function is executed when this menu is touched.

5.4 Tool Menu

Executes the Zoom Out function to decrease the frequency span currently set to be within the touch screen window being displayed. When the window for touch screen operation is not displayed and this menu is touched, the current frequency span centered on the center frequency expands by 50%. This function is executed when this menu is touched.

The reference level and center frequency are set by simply touching the upper, lower, left, or right part of the waveform screen area. After touching this menu, if you touch the upper or lower part of the waveform screen area, the set reference level value goes up or down according to the touched position. If you touch the left or right part, the set center frequency value goes up or down. The change in the setting varies depending on the setting condition at the time. However, it is equivalent to the change made to the value to be set at the time using the step key.

This function reacts only when the circled parts of the waveform drawing screen shown below are touched.




Figure 5-1 Function Active Area

6. SPECIFICATIONS

This chapter describes the specifications of this instrument.

The performance of this instrument is guaranteed when used under the following conditions unless noted specially.

- The instrument is calibrated at regular calibration periods.
- The instrument has been warmed up for 30 minutes or more after power is turned on under the specified environmental conditions.
- Autocalibration has been performed.

The reference data is provided not to show you the guaranteed performance but to help you use this instrument efficiently. The data contains the following notations:

Specifications (spec.): Indicate the performance guaranteed by the product. The specifications are deter-

mined in consideration of possible irregularities of quality among individual products, inaccurate measurements at the time of calibration, and performance

changes due to environmental factors.

Typical value (typ.): Indicates the average performance of the product. Possible irregularities of qual-

ity among individual products, inaccurate measurements at the time of calibration, and performance changes due to environmental factors are not considered.

Nominal value (nom.): Indicates the general or expected performance of the product.

6.1 R3681 Performance Specifications

6.1 R3681 Performance Specifications

6.1.1 Frequency

Item	Specifications		
Frequency range Spectrum analysis mode	20 Hz to 32 GHz		
	Frequency band	Frequency band	Harmonic Mixing mode (N)
	20 Hz to 3.5 GHz	0	1-
	3.4 GHz to 7.5 GHz	1	1-
	7.4 GHz to 15.4 GHz	2	2-
	15.2 GHz to 32.0 GHz	3	4-
	Bands 1 to 3 use a built-	in YIG tuning pre-	selector.
Modulation analysis mode	20 MHz to 6 GHz		
(When modulation analysis option is set)	Frequency band	Frequency band	Harmonic Mixing mode (N)
	20 MHz to 3.5 GHz	0	1-
	3.5 GHz to 6 GHz	1M	1-
	Band 1M bypasses the h	ouilt-in YIG tuning	pre-selector.
Built-in pre-amplifier (Band 0 only)	100 kHz to 3.5 GHz Gain 20 dB (typical value)		
Input coupling	DC		
Internal frequency reference stability Aging rate Temperature stability Warm-up time (nominal value) Reference frequency error	$\pm 5 \times 10^{-8}$ / day, $\pm 5 \times 10^{-7}$ / year $\pm 1 \times 10^{-7}$ (Frequency at 25°C is used as the reference in the range of 5 to 40°C) $\pm 5 \times 10^{-7}$ /minute \pm (Time elapsed from the latest factory calibration × aging rate + temperature stability)		
Marker frequency counter Accuracy Resolution	(S/N > 50 dB) ± (Marker frequency × Frequency reference error + Residual FM) 0.01 Hz		
Frequency reading accuracy	(Resolution bandwidth 1 Hz to 3 MHz) ± (Frequency reading × Frequency reference error + span × span accuracy + resolution bandwidth × 0.1 + residual FM)		
Frequency stability Residual FM	(When internal reference frequency source is used) ≤ (3 Hz × N p-p)/100 ms		
Frequency span Range Accuracy	20 Hz to 32 GHz, 0 Hz (Zero span) ± 1% (200 Hz ≤ Span) ± 1 × N% (20 Hz ≤ Span < 200 Hz)		

Item		Specifications		
Signal purity	At 800 MHz input			
(When internal reference	Offset	Offset 20°C to 30°C		
frequency source is used)	100 Hz.	< -87 dBc/Hz	< -85 dBc/Hz	
	1 kHz	<-110 dBe/Hz	<-108 dBc/Hz	
	10 kHz	< -120 dBc/Hz	< -118 dBc/Hz	
	10 kHz (Typical value)	<-122 dBc/Hz		
	100 kHz	<-120 dBc/Hz	<-120 dBc/Hz	
	100 kHz (Typical value)	< -123 dBc/Hz		
	1 MHz	<-140 dBc/Hz	<-140 dBc/Hz	
	1 MHz (Typical value)	<-143 dBc/Hz		
	10 MHz (Nominal value)	< -155 dBc/Hz	<-153 dBc/Hz	
	-125 B -130 -135 -140 -145 0 100	0 2000	10kHz off 100kHz off 1MHz off 1MHz off	
	0 100	2000	3000 [IWHZ]	
Resolution bandwidth (RBW) Range Accuracy	1 Hz to 10 MHz (1, 2, ±3%: Resolution band ±7%: Resolution band ±12%: Resolution bard ±20%: Resolution bard ±2	lwidth 1 Hz to 500 lwidth 1 MHz to 3 ndwidth 5 MHz		
Selectivity (60 dB/3 dB)	< 6:1 (5:1, typ.)			
Video bandwidth (VBW) Range	1 Hz to 10 MHz (1, 2,	3, 5 sequence)		

6.1.2 Sweep

6.1.2 Sweep

Item	Specifications
Sweep	
Sweep time setting range	
Zero span	1 μs to 6000 s
Span> 0 Hz	10 ms to 2000 s
Sweep time accuracy	±2%
Sweep mode	Continuous, Single
Trigger function	
Trigger source	Free Run, Video, IF, Line
	External 1 (TTL level), External 2 (0 to 5 V, resolution: 20 mV)
Trigger delay setting range	100 ns to 1 s
Resolution	100 ns
Gated sweep	
Gate delay	0 s to 1 s
Resolution	100 ns
Gate width	50 μs to 1 s
Resolution	100 ns
Trigger source	Free Run, IF, External 1, External 2, Link

6.1.3 Amplitude

Item	Specifications
Amplitude measurement range Preamplifier off Preamplifier on	+30 dBm to displayed average noise level +20 dBm to displayed average noise level (band 0 only)
Maximum safe input level Average continuous power Preamplifier off Preamplifier on DC voltage	+30 dBm (when input attenuator ≥ 10 dB) +13 dBm (when input attenuator ≥ 10 dB) 0 V (Do not apply DC power to signals.)
Input attenuator range	0 to 75 dB, 5 dB steps
Screen display range Log scale	10 div. fixed 0.1 dB to 1 dB/div., 0.1 dB steps 1 dB to 20 dB/div., 1 dB steps
Linear scale	10%/div. of the reference level
Scale unit	dBm, dBmV, dBμV, dBμVemf, dBpW, W, V

6.1.4 Amplitude Accuracy

Item	Specifications
Reference level set range Preamplifier off Log scale Linear scale Preamplifier on	-170 dBm to +60 dBm, 0.01 dB steps 707.1 pV to 223.6 V, approx. 1% steps
Log scale Linear scale	-170 dBm to +30 dBm, 0.01 dB steps 707.1 pV to 7.071 V, approx. 1% steps
Trace Detector mode	A maximum of 4 Normal, Positive Peak, Negative Peak, Sample, RMS, Video Average, Voltage Average

6.1.4 Amplitude Accuracy

Item	Specifications				
Calibration signal accuracy (50 MHz) Amplitude Accuracy	-10 dBm ± 0.2 dB (20°C to 30°C), ±0.3 dB (0°C to 40°C)				
Frequency response Spectrum analysis mode	(After autocalibratio ator 10 dB, after pre-			· ·	1-
Preamplifier off	Engage	Operating tem	perature range	Intraband flatness	
	Frequency	20°C to 30°C	5°C to 40°C	intraband flatness	
	50 MHz to 2.5 GHz	< ±0.4 dB	< ±0.9 dB	-	
	20 Hz to 3.5 GHz	< ±1.0 dB	< ±1.5 dB	-	
	3.5 GHz to 7.5 GHz	< ±1.5 dB	< ±3.5 dB	< ±1.5 dB	
	7.5 GHz to 15.4 GHz	< ±2.0 dB	< ±4.0 dB	< ±2.0 dB	
	15.4 GHz to 32.0 GHz	< ±2.5 dB	< ±4.5 dB	< ±2.5 dB	
Preamplifier on					
	F	Ор	erating tempera	ture range	
	Frequency	20°C to 2	30°C	5°C to 40°C	
	50 MHz to 2.5 GHz	<±1.0	dB	< ±1.5 dB	
	100 kHz to 3.5 GHz	< ±2.0	dВ	< ±2.5 dB	

6.1.4 Amplitude Accuracy

Item	Specifications		
Input attenuator switching error	(Attenuator: 10 dB reference)		
	Frequency range	Switching error	
	20 Uz to 8 GHz	<±1.0 dB (5 dB to 50 dB) <±1.4 dB (55 dB to 75 dB)	
	8 GHz to 12 GHz	< ± 1.3 dB (5 dB to 50 dB) < ±1.9 dB (55 dB to 75 dB)	
	12 GHz to 20 GHz	< ±1.4 dB (5 dB to 50 dB) < ±2.1 dB (55 dB to 75 dB)	
	20 GHz to 26.5 GHz	< ±1.8 dB (5 dB to 50 dB) < ±2.7 dB (55 dB to 75 dB)	
	26.5 GHz to 32 GHz	< ± 2.1 dB (5 dB to 50 dB) < ± 3.8 dB (55 dB to 65 dB)	
Scale display error	(Mixer level: -20 dBm reference, mixer level -10 dBm to -50 dBm, temperature range 20°C to 30°C) < ±0.13 dB		
Resolution bandwidth switching uncertainty	(Resolution bandwidth: 100 kHz reference, after autocalibration, 10 dB/div. or less) < ±0.05 dB (1 Hz to 3 MHz) < ±0.3 dB (5 MHz to 10 MHz)		
Coupling level accuracy	(After autocalibration, signal level -10 dBm to -50 dBm, preamplifier off, input attenuator 10 dB, RBW 100 kHz, temperature range 20°C to 30°C) < ± (0.2 dB + frequency response + scale display error)		

6.1.5 Dynamic Range

Item	Specifications		
Displayed average noise level Spectrum analysis mode	(Input is terminated, in Hz, detector: Sample, Video, temperature rat Add 2 dB in the temperature	average more than 20 nge 20°C to 30°C.) times, average type:
Preamplifier off	Frequency	Specification	Typical value
	100 Hz	< -96 dBm	-115 dBm
	1 kHz	<-119 dBm	-130 dBm
	10 kHz	< -129 dBm	-140 dBm
	100 kHz	< -130 dBm	-143 dBm
	1 MHz	< -140 dBm	-150 dBm
	10 MHz to 1 GHz	< -156 dBm	-158 dBm
	1 GHz to 2 GHz	<-154 dBm	-156 dBm
	2 GHz to 2.5 GHz	< -152 dBm	-154 dBm
	2.5 GHz to 3 GHz	< -150 dBm	-152 dBm
	3 GHz to 3.5 GHz	<-148 dBm	-150 dBm
	3.5 GHz to 7.5 GHz	< -146 dBm	-149 dBm
	7.5 GHz to 15.4 GHz	< -146 dBm	-149 dBm
	15.4 GHz to 26.5 GHz	<-141 dBm	-144 dBm
	26.5 GHz to 32 GHz	< -140 dBm	-143 dBm
Preamplifier on			
	Frequency	Specification	Typical value
	100 kHz	< -136 dBm	155 dBm
	1 MHz	< -146 dBm	-160 dBm
	10 MHz to 1 GHz	<-162 dBm	-168 dBm
	1 GHz to 2.5 GHz	<-160 dBm	-166 dBm
	2.5 GHz to 3 GHz	< -158 dBm	-164 dBm
	3 GHz to 3.5 GHz	<-156 dBm	-162 dBm
1 dB gain compression	(Separation: RBW × 1	5, 50 kHz min.)	
	Input frequency	Specification	Typical value
	10 MHz to 200 MHz	> +2 dBm	+5 dBm
	200 MHz to 3.5 GHz	> +7 dBm	+10 dBm
	3.5 GHz to 7.5 GHz	> -5 dBm	-2 dBm
	7.5 GHz to 32 GHz	> -3 dBm	+0 dBm

6.1.5 Dynamic Range

Item		Specifications	
2nd order harmonic distortion			
	Input frequency	Specification	Mixer level
	10 MHz to 1.75 GHz	<-60 dBc	-20 dBm
	> 1.75 GHz	<-90 dBc	-10 dBm
3rd order intermodulation distortion (TOI)	(Mixer level: -20 dBr	n, separation: 25 kHz)	
	Input frequency	Specification	Typical value
	10 MHz to 200 MHz	>+12 dBm	+16 dBm
	200 MHz to 500 MHz	>+16 dBm	+20 dBm
	500 MHz to 1 GHz	>+20 dBm	+24 dBm
	1 GHz to 2 GHz	>+21 dBm	+25 dBm
	2 GHz to 3.5 GHz	> +22 dBm	+26 dBm
	3.5 GHz to 7.5 GHz	>+5 dBm	+10 dBm
	7.5 GHz to 32 GHz	> +8 dBm	+12 dBm
lmage/multiple/out-band spurious	(Spectrum analysis mode)		
	Frequency	Specification	
	10 MHz to 15.4 GHz	<-70 dBc	
	15.4 GHz to 26.5 GHz	<-65 dBc	
	26.5 GHz to 32.0 GHz	<-60 dBc	
Residual spurious	(Spectrum analysis m ator: 0 dB)	ode, no input, input terr	minated, input attenu
		Frequency	Specification
	Preamplifier on	1 MHz to 3.5 GHz	< -95 dBm
	D 17.5 00	1 MHz to 3.5 GHz	<-90 dBm
	Preamplifier off	3.5 GHz to 32.0 GHz	< - 90 dBm

6.1.6 Input and Output

Item	Specifications
RF input Connector Impedance VSWR	K type (m), front panel 50 Ω(nominal value) Input attenuator ≥ 10 dB, at the set frequency <1.5:1 (<3.5 GHz) (nominal value) <2.0:1 (>3.5 GHz) (nominal value)
Calibration signal output Connector Impedance Frequency	BNC (f), front panel 50 Ω (nominal value) 50 MHz
Probe power source Connector Output voltage	4-pin connector, front panel ± 15 V, 150 mA (nominal value)
1st LO output Connector	When external mixer option is used SMA (f), front panel
421,4 MHz IF input Connector	When external mixer option is used SMA (f), front panel
I/Q input Connector Impedance Maximum input amplitude	BNC (f), front panel 50 Ω (nominal value), AC/DC coupled 1.0 Vp-p (DC component ±0.5V)
External trigger input 1 Connector Impedance Trigger level	BNC (f), rear panel 10 k Ω (nominal value), DC coupled TTL level
External trigger input 2 Connector Impedance Trigger level	BNC (f), rear panel 10 k Ω (nominal value), DC coupled 0 V to 5 V
Trigger output Connector Amplitude	BNC (f), rear panel TTL level
Frequency reference input Connector Impedance Frequency Amplitude	BNC (f), rear panel 50 Ω (nominal value) 5 MHz to 20 MHz 0 dBm ±5 dB
10 MHz frequency reference output Connector Impedance Frequency Amplitude	BNC (f), rear panel 50 Ω (nominal value) 10 MHz 0 dBm ±5 dB

6.1.7 General Specifications

Item	Specifications
21.4 MHz IF output	
Connector	BNC (f), rear panel
Impedance	50 Ω (nominal value)
Frequency	21.4 MHz
Amplitude	Mixer input level + 2 dB (typical value at 50 MHz)
1/O	
Keyboard	PS/2 101/106 keyboard, front panel
Mouse	PS/2 mouse, front panel
USB	Front panel
GP-IB	IEEE-488.2 compatible, rear panel
LAN port	10Base-T, protocol used: TCP/IP, rear panel
PRINTER port	Conforms to IEEE-1284-1994, rear panel
Signal for external indicator	15-pin D-SUB connector (VGA), rear panel

6.1.7 General Specifications

Item	Specifications
Operating environmental range	Ambient temperature: +5°C to +40°C Relative humidity: 80% or less (no condensation)
Storage environmental range	Ambient temperature: -20°C to +60°C Relative humidity: 80% or less (no condensation)
AC power input	AC100 V to 120 V, 50 Hz/60 Hz AC220 V to 240 V, 50 Hz/60 Hz (automatic switching between AC 100 V and AC 200 V sources)
Power consumption	500 VA or less Approx. 220 VA (except for options)
External dimensions	424 mm (W) × 266 mm (H) × 530 mm (D) (approx.)
Weight	Approx. 32 kg or less (except for options)

6.2 R3671 Performance Specifications

6.2.1 Frequency

Item	Specifications			
Frequency range Spectrum analysis mode	20 Hz to 13 GHz			
l ·	Frequency band	Frequency band	Harmonic Mixing mode (N)	
	20 Hz to 3.5 GHz	0	1-	
	3.4 GHz to 7.5 GHz	1	1-	
	7.4 GHz to 13 GHz	2	2-	
	Bands 1 to 2 use a built	in YIG tuning pre-s	selector.	
Modulation analysis mode	20 MHz to 6 GHz			
(When modulation analysis option is set)	Frequency band	Frequency band	Harmonic Mixing mode (N)	
	20 MHz to 3.5 GHz	0	1-	
	3.5 GHz to 6 GHz	1M	1-	
	Band 1M bypasses the built-in YIG tuning pre-selector.			
Built-in pre-amplifier (Band 0 only)	100 kHz to 3.5 GHz Gain 20 dB (typical value)			
Input coupling	DC			
Internal frequency reference stability Aging rate Temperature stability Warm-up time (nominal value) Reference frequency error	$\pm 5 \times 10^{-8}$ / day, $\pm 5 \times 10^{-7}$ / year $\pm 1 \times 10^{-7}$ (Frequency at 25°C is used as the reference in the range of 5 to 40°C) $\pm 5 \times 10^{-7}$ /minute \pm (Time elapsed from the latest factory calibration × aging rate + temperature stability)			
Marker frequency counter Accuracy Resolution	(S/N > 50 dB) ± (Marker frequency × Frequency reference error + Residual FM) 0.01 Hz			
Frequency reading accuracy	(Resolution bandwidth 1 Hz to 3 MHz) ± (Frequency reading × Frequency reference error + span × span accuracy + resolution bandwidth × 0.1 + residual FM)			
Frequency stability Residual FM	(When internal reference frequency source is used) ≤ (3 Hz × N p-p)/100 ms			
Frequency span Range Accuracy	20 Hz to 13 GHz, 0 Hz (Zero span) ± 1% (200 Hz ≤ Span) ± 1 × N% (20 Hz ≤ Span < 200 Hz)			

6.2.1 Frequency

Item		Specifications				
Signal purity	At 800 MHz input	At 800 MHz input				
(When internal reference frequency source is used)	Offset	20°C to 30°C	5°C to 40°C			
frequency source is used)	100 Hz	< -87 dBc/Hz	< -85 dBc/Hz			
	1 kHz	<-110 dBc/Hz	<-108 dBc/Hz			
	10 kHz	<-120 dBc/Hz	< -118 dBc/Hz			
	10 kHz (Typical value)	<-122 dBc/Hz				
	100 kHz	<-120 dBe/Hz	<-120 dBc/Hz			
	100 kHz (Typical value)	<-123 dBc/Hz				
	1 MHz	<-140 dBc/Hz	<-140 dBc/Hz			
	1 MHz (Typical value)	<-143 dBc/Hz				
	10 MHz (Nominal value)	< -155 dBe/Hz	< -153 dBe/Hz			
	-120 -125 -125 -130 -135 -140 -145 0 1000	0 2000	10kHz off = = = 100kHz off = = 100kHz off 1MHz off 3000 [MHz]			
Resolution bandwidth (RBW) Range Accuracy Selectivity (60 dB/ 3 dB)	±3%: Resolution band ±7%: Resolution band ±12%: Resolution ban ±20%: Resolution ban	1 Hz to 10 MHz (1, 2, 3, 5 sequence) ±3%: Resolution bandwidth 1 Hz to 500 kHz ±7%: Resolution bandwidth 1 MHz to 3 MHz ±12%: Resolution bandwidth 5 MHz ±20%: Resolution bandwidth 10 MHz < 6:1 (5:1, typ.)				
Video bandwidth (VBW)	< 0.1 (5.1, typ.)					
Range	1 Hz to 10 MHz (1, 2,	1 Hz to 10 MHz (1, 2, 3, 5 sequence)				

6.2.2 Sweep

Item	Specifications
Sweep	
Sweep time setting range	
Zero span	1 μs to 6000 s
Span> 0 Hz	10 ms to 2000 s
Sweep time accuracy	±2%
Sweep mode	Continuous, Single
Trigger function	
Trigger source	Free Run, Video, IF, Line
	External 1 (TTL level), External 2 (0 to 5 V, resolution: 20 mV)
Trigger delay setting range	100 ns to 1 s
Resolution	100 ns
Gated sweep	
Gate delay	0 s to 1 s
Resolution	100 ns
Gate width	50 μs to 1 s
Resolution	100 ns
Trigger source	Free Run, IF, External 1, External 2, Link

6.2.3 Amplitude

Item	Specifications		
Amplitude measurement range Preamplifier off Preamplifier on	+30 dBm to displayed average noise level +20 dBm to displayed average noise level (band 0 only)		
Maximum safe input level Average continuous power Preamplifier off Preamplifier on DC voltage	+30 dBm (when input attenuator ≥ 10 dB) +13 dBm (when input attenuator ≥ 10 dB) 0 V (Do not apply DC power to signals.)		
Input attenuator range	0 to 75 dB, 5 dB steps		
Screen display range Log scale Linear scale	10 div. fixed 0.1 dB to 1 dB/div., 0.1 dB steps 1 dB to 20 dB/div., 1 dB steps 10%/div. of the reference level		
Scale unit	dBm, dBmV, dBμV, dBμVemf, dBpW, W, V		

6.2.4 Amplitude Accuracy

Item	Specifications		
Reference level set range Preamplifier off Log scale Linear scale	-170 dBm to +60 dBm, 0.01 dB steps 707.1 pV to 223.6 V, approx. 1% steps		
Preamplifier on Log scale Linear scale	-170 dBm to +30 dBm, 0.01 dB steps 707.1 pV to 7.071 V, approx. 1% steps		
Trace	A maximum of 4		
Detector mode	Normal, Positive Peak, Negative Peak, Sample, RMS, Video Average, Voltage Average		

6.2.4 Amplitude Accuracy

Item	Specifications			
Calibration signal accuracy (50 MHz) Amplitude Accuracy	-10 dBm ± 0.2 dB (20°C to 30°C), ±0.3 dB (0°C to 40°C)			
Frequency response Spectrum analysis mode	(After autocalibration, reference frequency 50 MHz, input attenuator 10 dB, after pre-selector peak adjustment)			
Preamplifier off	Frequency	Operating tem	perature range	Intraband flatness
	requency	20°C to 30°C	5°C to 40°C	initaband framess
	50 MHz to 2.5 GHz	< ±0.4 dB	< ±0.9 dB	-
	20 Hz to 3.5 GHz	< ±1.0 dB	< ±1.5 dB	-
	3.5 GHz to 7.5 GHz	< ±1.5 dB	< ±3.5 dB	<±1.5 dB
	7.5 GHz to 13 GHz	< ±2.0 dB	< ±4.0 dB	<±2.0 dB
Preamplifier on				
Treamphrier on	Frequency	Operating temperature range		
		20°C to	30°C	5°C to 40°C
	50 MHz to 2.5 GHz	<±1.0	dB	< ±1.5 dB
	100 kHz to 3.5 GHz	< ±2.0 dB		< ±2.5 dB
Input attenuator switching error	(Attenuator: 10 dB	reference)		
	Frequency range	Switching error		rror
	20 Hz to 8 GHz	<±1.0 dB (5 dB to 50 dB) <±1.4 dB (55 dB to 75 dB)		
	8 GHz to 12 GHz	< ± 1.3 dB (5 dB to 50 dB) < ±1.9 dB (55 dB to 75 dB)		
	12 GHz to 13 GHz	<±1.4 dB (5 dB to 50 dB) <±2.1 dB (55 dB to 75 dB)		

6.2.4 Amplitude Accuracy

Item	Specifications
Scale display error	(Mixer level: -20 dBm reference, mixer level -10 dBm to -50 dBm, temperature range 20°C to 30°C) < ±0.13 dB
Resolution bandwidth switching uncertainty	(Resolution bandwidth: 100 kHz reference, after autocalibration, 10 dB/div. or less) < ±0.05 dB (1 Hz to 3 MHz) < ±0.3 dB (5 MHz to 10 MHz)
Coupling level accuracy	(After autocalibration, signal level -10 dBm to -50 dBm, preamplifier off, input attenuator 10 dB, RBW 100 kHz, temperature range 20°C to 30°C) < ± (0.2 dB + frequency response + scale display error)

6.2.5 Dynamic Range

6.2.5 Dynamic Range

Item		Specifications			
Displayed average noise level Spectrum analysis mode	Hz, detector: Sample, a Video, temperature ran	(Input is terminated, input attenuator: 0 dB, RBW1 Hz, VBW1 Hz, detector: Sample, average more than 20 times, average type: Video, temperature range 20°C to 30°C. Add 2 dB in the temperature range 5°C to 40°C.)			
Preamplifier off	Frequency	Specification	Typical value		
	100 Hz	< -96 dBm	-115 dBm		
	1 kHz	< -119 dBm	-130 dBm		
	10 kHz	<-129 dBm	-140 dBm		
	100 kHz	<-130 dBm	-143 dBm		
	1 MHz	<-140 dBm	-150 dBm		
	10 MHz to 1 GHz	<-156 dBm	-158 dBm		
	1 GHz to 2 GHz	<-154 dBm	-156 dBm		
	2 GHz to 2.5 GHz	<-152 dBm	-154 dBm		
	2.5 GHz to 3 GHz	<-150 dBm	-152 dBm		
	3 GHz to 3.5 GHz	<-148 dBm	-150 dBm		
	3.5 GHz to 7.5 GHz	<-146 dBm	-149 dBııı		
	7.5 GHz to 13 GHz	<-146 dBm	-149 dBm		
Preamplifier on		,			
	Frequency	Specification	Typical value		
	100 kHz	<-136 dBm	155 dBm		
	1 MUz	<-146 dBm	-160 dBm		
	10 MHz to 1 GHz	<-162 dBm	-168 dBm		
	1 GHz to 2.5 GHz	<-160 dBm	-166 dBm		
	2.5 GHz to 3 GHz	<-158 dBm	-164 dBm		
	3 GHz to 3.5 GHz	<-156 dBm	-162 dBm		
1 dB gain compression	(Separation: RBW × 1	(Separation: RBW × 15, 50 kHz min.)			
	Input frequency	Specification	Typical value		
	10 MHz to 200 MHz	>+2 dBm	+5 dBm		
	200 MHz to 3.5 GHz	>+7 dBm	+10 dBm		
	3.5 GHz to 7.5 GHz	> -5 dBm	-2 dBm		
	7.5 GHz to 13 GHz	> -3 dBm	+0 dBm		
2nd order harmonic distortion					
	Input frequency	Specification	Mixer level		
	10 MHz to 1.75 GHz	<-60 dBe	-20 dBm		
	> 1.75 GHz	< -90 dBc	-10 dBm		

6.2.6 Input and Output

20 dBm, separation: 25 k ncy Specification 4Hz >+12 dBm MHz >+16 dBm Hz >+20 dBm z >+22 dBm z >+5 dBm	Typical value +16 dBm +20 dBm +24 dBm +25 dBm +26 dBm +10 dBm	
MHz >+12 dBm MHz >+16 dBm Hz >+20 dBm >+21 dBm >+21 dBm >+21 dBm	+16 dBm +20 dBm +24 dBm +25 dBm +26 dBm +10 dBm	
M1 z >+16 dBm Hz >+20 dBm >+21 dBm z >+22 dBm	+20 dBm +24 dBm +25 dBm +26 dBm +10 dBm	
Hz > +20 dBm > +21 dBm z > +22 dBm	+24 dBm +25 dBm +26 dBm +10 dBm	
>+21 dBm z >+22 dBm	+25 dBm +26 dBm +10 dBm	
z >+22 dBm	+26 dBm +10 dBm	
	+10 dBm	
Hz > +5 dBm		
	1.10. ID	
Hz > +8 dBm	+12 dBm	
(Spectrum analysis mode)		
Specification		
Hz <-70 dBc		
(Spectrum analysis mode, no input, input terminated, input attenuator: 0 dB)		
Frequency	Specification	
	<-95 dBm	
1 MHz to 3.5 GHz	< -90 dBm	
1 MHz to 3.5 GHz 1 MHz to 3.5 GHz		
ıl	Frequency 1 MHz to 3.5 GHz	

6.2.6 Input and Output

Item	Specifications	
RF input Connector Impedance VSWR	N type (f), front panel 50 Ω (nominal value) Input attenuator \geq 10 dB, at the set frequency <1.5:1 (<3.5 GHz) (nominal value) <2.0:1 (>3.5 GHz) (nominal value)	
Calibration signal output Connector Impedance Frequency	BNC (f), front panel 50 Ω (nominal value) 50 MHz	
Probe power source Connector Output voltage	4-pin connector, front panel ± 15 V, 150 mA (nominal value)	
1st LO output Connector	When external mixer option is used SMA (f), front panel	

6.2.6 Input and Output

Item	Specifications
421.4 MHz IF input Connector	When external mixer option is used SMA (f), front panel
I/Q input Connector Impedance Maximum input amplitude	BNC (f), front panel 50 Ω (nominal value), AC/DC coupled 1.0 Vp-p (DC component ±0.5V)
External trigger input 1 Connector Impedance Trigger level	BNC (f), rear panel 10 k Ω (nominal value), DC coupled TTL level
External trigger input 2 Connector Impedance Trigger level	BNC (f), rear panel 10 k Ω (nominal value), DC coupled 0 V to 5 V
Trigger output Connector Amplitude	BNC (f), rear panel TTL level
Frequency reference input Connector Impedance Frequency Amplitude	BNC (f), rear panel 50 Ω (nominal value) 5 MHz to 20 MHz 0 dBm ±5 dB
10 MHz frequency reference output Connector Impedance Frequency Amplitude	BNC (f), rear panel 50 Ω (nominal value) 10 MHz 0 dBm ±5 dB
21.4 MHz IF output Connector Impedance Frequency Amplitude	BNC (f), rear panel 50 Ω (nominal value) 21.4 MHz Mixer input level + 2 dB (typical value at 50 MHz)
I/O Keyboard Mouse USB GP-IB LAN port PRINTER port Signal for external indicator	PS/2 101/106 keyboard, front panel PS/2 mouse, front panel Front panel IEEE-488.2 compatible, rear panel 10Base-T, protocol used: TCP/IP, rear panel Conforms to IEEE-1284-1994, rear panel 15-pin D-SUB connector (VGA), rear panel

6.2.7 General Specifications

6.2.7 General Specifications

Item	Specifications
Operating environmental range	Ambient temperature: +5°C to +40°C Relative humidity: 80% or less (no condensation)
Storage environmental range	Ambient temperature: -20°C to +60°C Relative humidity: 80% or less (no condensation)
AC power input	AC100 V to 120 V, 50 Hz/60 Hz AC220 V to 240 V, 50 Hz/60 Hz (automatic switching between AC 100 V and AC 200 V sources)
Power consumption	500 VA or less Approx. 220 VA (except for options)
External dimensions	424 mm (W) × 266 mm (H) × 530 mm (D) (approx.)
Weight	Approx. 32 kg or less (except for options)

6.3 Option

6.3 Option


OPTION 11 Wideband demodulator


ltem	Specifications
Analysis frequency range Analysis resolution bandwidth (CCDF RBW)	200 MHz to 6 GHz 50 MHz
Dynamic Range (CCDF RBW: 50 MHz)	(Center frequency: 1 GHz, Reference level: +5 dBm, Input attenuator: Auto, Temperature range: 20°C to 30°C, and the 1-GHz and +5-dBm CW signal is input.) > 50 dB

OPTION 22 High stability frequency reference source

Item	Specifications
Reference frequency stability Aging rate Temperature stability Warm-up time (nominal value)	$\pm 3 \times 10^{-10}$ /day, $\pm 2 \times 10^{-8}$ /year $\pm 5 \times 10^{-9}$ (5 to 40°C, frequency at 25°C used as the reference) $\pm 1 \times 10^{-8}$ / 30 min } (frequency at 25°C, 24 hours after power $\pm 5 \times 10^{-9}$ / 60 min } on used as reference)
Frequency reference error	\pm (Time elapsed after the latest factory calibration \times aging rate + temperature stability)

6.4 External Dimension Diagram





NOTE: This drawing shows external dimensions of this instrument.

The difference in products and options used can cause a change in the appearance of the instrument.

7. OPTIONS AND ACCESSORIES

7. OPTIONS AND ACCESSORIES

This chapter introduces the separately sold options and measurement accessories that can be used with this instrument.

7.1 Options

Table 7-1 Options

Option	Explanation
OPT11	Wideband demodulator
OPT22	High stability frequency reference source
OPT50	3GPP modulation analysis software
OPT52	cdma2000 modulation analysis software
OPT54	cdma2000 1xEV-DO modulation analysis software
OPT56	GSM/EDGE modulation analysis software
OPT57	Bluetooth modulation analysis software
OPT59	IEEE802.11b/g modulation analysis software
OPT60	WiBro modulation analysis software WiBro (WiBro 16e) modulation analysis software
OPT64	Single-carrier general-purpose modulation analysis software
OPT68	OFDM modulation analysis software
OPT71	200M AWG module
OPT72	Digital signal generator module
OPT73	3GPP multi-carrier generator option
OPT74	Pulse modulator
OPT80	C/N measurement software
ОРТ83	AMP measurement software

7.2 Accessories

Table 7-2 Accessories

Accessory Name	Part Code	Code Compliance
Rack-mount set B	A02724	EIA standard
	A02725	JIS standard
Panel extension cable (3 m)	A112003	-

8. MAINTENANCE

This chapter describes the following matters related to the maintenance of this instrument in order to maintain its designed performance.

- 8.1 Cleaning
- 8.2 About Calibration
- 8.3 About Replacement of Limited-Life Parts
- 8.4 Method of Storing the Instrument
- 8.5 How to Move and Transport the Instrument
- 8.6 Notes for Requesting Repair, Replacement of Parts, and Periodic Calibration
- 8.7 System Recovery Procedure
- 8.8 List of Error Messages
- 8.9 Product Disposal and Recycle

8.1 Cleaning

This section describes how to clean this instrument and some matters to note.

WARNING:

Turn off the power breaker on the rear panel and extract the power cable from the wall socket to protect yourself from electric shock accidents.

Never attempt to remove the cabinet cover to clean the inside of the instrument.

8.1.1 Cabinet Cleaning

Use the following procedure to clean the cabinet of this instrument.

Clean the cabinet surface with a soft dry cloth.

If the surface is not clean enough, try again with a cloth soaked in a weakened neutral detergent. Then wipe the surface with a soft dry cloth.

CAUTION:

Do not allow water to splash into the inside of the instrument.

Do not use an organic solvent such as benzene, toluene, xylene, or acetone and the cleanser for cleaning. They can cause the paint on the cabinet to come off, deform, or degrade.

8.1.2 Cleaning the Touch Screen

8.1.2 Cleaning the Touch Screen

Cleaning with a soft dry cloth is sufficient for ordinary use. If dirt remains on the touch screen, wipe the surface with a soft cloth soaked in ethanol.

CAUTION: The screen surface may be scratched if you rub it powerfully.

Handle the touch screen very carefully. It may be broken if it is exposed to strong physical shock because it contains glass.

8.1.3 Cleaning of Other Parts

Use appropriate caution to protect this instrument from dust.

WARNING: Remove dust periodically from wall sockets and power connector plugs.

Dust that is wet with humidity may cause tracking that could cause a fire.

The rear panel is equipped with an exhaust cooling fan and the side and the bottom panels have exhaust vents. Keep these vents clean for sufficient exhaustion. If dust piled on the vents causes exhaustion to become poor, the temperature inside will rise and the instrument will not work correctly.

8.2 About Calibration

8.2 About Calibration

Calibration should be performed periodically to prevent performance deterioration or to adjust chronological performance changes.

The recommended period of regular calibration is once a year.

Calibration is done at the factory site.

For more information, call a sales representative.

8.3 About Replacement of Limited-Life Parts

Table 8-1 lists the proper limited-life parts of this instrument.

The table also shows the number of operations for the expected life spans of each of these parts, to suggest a recommended time of replacement in terms of the number of times of operations. For replacement, call the Service Center (Advantest Customer Support (ACS)).

Note that the life span can become shorter than expected depending on the operation environment, frequency of use, and storage environment.

MEMO: The table shows the expected life spans or recommended time of replacement only for the user's reference.

It does not guarantee the life of the components.

Name Life (Reference values provided by manufacturer) Panel key switch 10⁶ operations 50,000 hours LCD back light Rotary encoder 25×10^5 operations 40,000 hours Cooling fan Lithium battery cells for data backup About 3 years Input attenuator 10⁶ operations Mechanical relay, RF block 10⁶ operations Mechanical relay, IF block 10⁵ operations

Table 8-1 Limited-Life Parts

8.4 Method of Storing the Instrument

8.4 Method of Storing the Instrument

When you store this instrument, keep it in an environment that meets the following requirements.

- · Reduced vibration
- Not dusty
- Protected from direct sunlight
- Ambient temperature range: -20 to +60°C
- Relative humidity: 30 to 85%

When you do not use the instrument for 90 days or more, store it in an appropriate moisture-proof bag with desiccant.

8.5 How to Move and Transport the Instrument

8.5.1 Moving

CAUTION:

This instrument is a weighty item. Sufficient care is needed for moving or transporting it from one place to another. Use the following procedures to protect yourself from accidents.

Use a cart with sufficient strength.

When you hand-carry the instrument, be sure to work with an assistant.

8.5.2 Transportation

For transportation, use the packing materials used for the shipping of this instrument. If you use other materials, double-pack the instrument using the following procedure.

- 1. Install the protection cover of the touch screen display on this instrument.
- 2. Cover the instrument with a protective plastic sheet. (Put desiccant inside for protection from moisture.)
- 3. Prepare an inner carton case.
 - The panels of the case must be 5 mm or more thick. The inner dimensions must be 10 cm or more larger than the physical size of this instrument because cushioning materials are placed inside. Place the instrument so that it is covered with cushioning or plastic foam material on all sides. (The cushioning material must be 4 cm or more thick.)
- 4. Seal the carton case with an industrial stapler or packing tape.
- 5. Prepare an outer carton case.
 - The panels of the case must be 5 mm or more thick. The dimensions must be 10 cm or more larger than the inner case on all sides. Place cushioning material 4 cm or more thick inside the outer case and put the inner case prepared in steps 3 and 4 therein.
- 6. Stuff the cushioning material in the space between the inner and outer cases and seal the outer case. Fasten the outer case with packing strings.

8.6 Notes for Requesting Repair, Replacement of Parts, and Periodic Calibration

8.6 Notes for Requesting Repair, Replacement of Parts, and Periodic Calibration

8.6.1 Work Request

Attach a tag indicating the following data to this instrument when you send it to a sales representative.

- · Your company name and address
- · Name of the person in charge
- Serial number (on the rear panel)
- What work to request (repair or periodic calibration)

8.6.2 Destination and Phone Number for Contact

Call Advantest Instrument Call Center: ICC.

8.7 System Recovery Procedure

8.7 System Recovery Procedure

This instrument adopts Microsoft Windows XP Embedded and Windows application programs for measurement functions.

The system files required for the operation of this instrument are stored in the built-in system drive.

If a system file is destroyed during operation of this instrument for any reason, the instrument may not operate normally.

In such a case, you can recover the built-in system drive to the factory-set state by using the System Recovery Disk attached to this instrument as an accessory.

IMPORTANT: The contents of the built-in system drive are lost by recovery operation. In other words, the settings of networks or printers made after you purchased the instrument are lost.

Recovery of this instrument is impossible in the case of damage of disk partition information or disks. Call a sales representative for repair.

Recovery procedure

- 1. Make sure that the power of this instrument is turned off.

 When the instrument is operating, press the **POWER** switch on the front panel to terminate the operation of this instrument.
- 2. Insert the floppy disk with "System Recovery Disk" on the label into the disk drive.
- Press the POWER switch on the front panel to turn on power.
 The recovery software is read from the system recovery disk and a dialog box is displayed.
- 4. Select [Continue] with the data knob for system recovery. Press the ENT button on the front panel.
- 5. System recovery begins. System recovery takes about 5 minutes to complete.
- The Reboot dialog box shown in Figure 8-1 is displayed on completion of system recovery.




Figure 8-1 Reboot Dialog Box

8.7 System Recovery Procedure

 Press the eject button on the floppy disk drive and extract the system recovery disk.

CAUTION: Do not press the eject button on the floppy disk drive while the access lamp on the drive is on. If you do, the floppy disk drive or floppy disk may be broken.

8. Select [Reboot] with the data knob and press the ENT button on the front panel.

The system restarts and the final processing is performed. It takes about 7 minutes to complete.

Although restarting occurs several times during this period, it does not mean any error has occurred.

 After completion of the final processing, the firmware of this instrument operates

8.8 List of Error Messages

This section describes the error messages displayed on this instrument. The list contains the following items of information.

- Error number
- Message text
- Cause of the error and action to take

Error number	Message text	Description
-232	Invalid data format.	The file format is illegal. Check the file storing format and file extension.
-257	Bad File name.	The file name is illegal. Change the file name.
-330	Self-test failed.	An error occurred in the self-test at power-on. A description of the error can be checked in a dialog box, opening it by touching [Special], and then [Self Test] on the menu bar. After checking the description, contact a sales representative.
-1250	No such file or directory.	The specified file or directory does not exist. Check the file name or directory name.
-1251	Permission denied.	File operation is forbidden. Check the drive, file, or directory.
-1252	Not enough space on the disk.	Not enough space is available. Delete unnecessary files.
-1253	File read/write error.	A file I/O error occurred.
-1254	No item is selected.	No item is selected.
-1255	Invalid data format.	The setting information file format of the Standard is incorrect.
-1256	Standard is not selected.	The Standard is not selected. Execute after selecting a Standard.
-1257	Standard is selected.	The Standard is selected. Execute after setting the Standard selection to OFF.
-1300	Device is not ready.	A disk is not inserted.
-1310	Unlock 200MHz PLL.	The 200 MHz PLL circuit used in the system is unlocked. Check external reference input setting.
-1311	Unlock Sweep PLL.	The Sweep PLL circuit used in the system is unlocked. Contact a sales representative for repair.
-1312	Unlock Sampler PLL.	The Sampler PLL circuit used in the system is unlocked. Contact a sales representative for repair.

Error number	Message text	Description
-1313	Unlock YTO PLL.	The YTO PLL circuit used in the circuit is unlocked. Contact a sales representative for repair.
-1400	There is no data in the effective state.	Exclusive GPIB error. The data requested to be read out is uncertain. After performing proper measurement, read out data.
-1500	Option required.	The associated option function is required.
-1510	Invalid Frequency-Correction Data1. Please contact a service engineer.	The internal frequency correction data is invalid. Contact a sales representative for repair.
-1511	Invalid Frequency-Correction Data2. Please contact a service engineer.	The internal frequency correction data is invalid. Contact a sales representative for repair.
-2200	Span is set 0 Hz. Please change span.	The frequency span is set to zero span. Change the span.
-2201	Span is not set 0 Hz. Please change to zero span.	The frequency span is not set to zero span. Set the frequency span to zero span.
-2202	Scale is Linear mode. Please select dB/div scale. [LEVEL → dB/div]	The vertical axis is set to linear scale. Select the dB/div scale.
-2204	ΔMarker is not active. Please activate ΔMarker. [MKR → Delta Marker]	The Δ marker is not turned on. Turn on the Δ marker.
-2205	Blank mode is selected. Please change to Write mode. [Trace → Write]	Cannot be executed because Blank mode is set. Change the mode to Write.
-2206	No peak is detected.	The peak is not found.
-2207	Marker Frequency is base-band.	The pre-selector tuning cannot be executed because the marker is in the base-band frequency range.
-2208	Not available. Trigger source is Free Run or Line.	Cannot be executed because the trigger source is set to Free Run or Line.
-2209	Gated sweep setup mode. Please select the same Gate source.	Gated sweep setting mode. Cannot select the trigger, which does not meet the gated sweep trigger condition.
-2210	Trace Normalize is active. Turn Trace Normalize off.	Normalize function is being executed. Turn off normalize function.
-2211	Display line is not active.	Cannot be selected because Display line is turned off.
-2212	Reference line is not active.	Cannot be selected because Reference line is turned off.
-2213	Limit Line1 is not active.	Cannot be selected because Limit Line 1 is turned off.
-2214	Limit Line2 is not active.	Cannot be selected because Limit Line 2 is turned off.
-2215	Anchor is not active.	Cannot be selected because the anchor of XY cursor is turned off.

Error number	Message text	Description
-2216	Invalid data mode. Set to Relative mode.	Y Data Mode of Limit Line is invalid.
-2217	Not available in High Speed ADC mode.	Video trigger is not available in High Speed ADC mode. Video Set a trigger other than Video trigger.
-2218	Gated sweep is active. Turn Gated sweep off.	Cannot be executed because the gated sweep is set to on.
-2221	Trigger source incorrect. Set Trigger source to IF Power or Free Run.	The trigger source is set incorrectly. Set to IF Power or Free Run.
-2222	Not available. RBW is less than 1kHz.	Cannot be executed because RBW is less than 1 kHz.
-2223	Not available. Sweep time is less than 100μs.	Cannot be executed because the sweep time is less than $100~\mu s$.
-2224	Not available. Gate source is Free Run.	Cannot be executed because the gate source is set to Free Run.
-2240	Parameter is out of range.	An invalid parameter is set for measurement.
-2241	Incorrect data. Set span to (1.0 + alpha) *Tf or more.	The root Nyquist filter is set to a value that cannot be measured. Change the setting to a value that meets the following requirement. Frequency span > (1.0+Rolloff Factor) × Symbol Rate
-2242	Frequency table contains no data.	The function cannot be executed because data is not contained in the table.
-2243	Editor is active. Please quit the editor first.	Cannot be executed in the Editor mode. Terminate the editor mode.
-2244	Incorrect data. Set span to Carrier Band Width or more.	The carrier bandwidth is set to a value that cannot be measured. Change the setting to a value that meets the following requirement: Frequency span > Carrier bandwidth
-2245	Not available. Spurious is ON.	Cannot be executed because Spurious measurement mode is on.
-2246	Not available. CCDF is ON.	Cannot be executed in the CCDF measurement mode.
-2248	Not available. IF Monitor is ON.	Cannot be executed in the IF signal monitor mode.
-2249	Not available. Center Frequency is larger than 7.5GHz.	RBW cannot be set to 50 MHz because a center frequency of more than 7.5 GHz is set.
-2281	Not available in Single-screen mode.	Cannot be executed in the single-screen mode.
-2282	Not available in Zoom(F/F) mode.	Cannot be executed in Zoom (F/F) mode.
-2283	Not available in Zoom(T/T) mode.	Cannot be executed in Zoom (T/T) mode.

Error number	Message text	Description
-2284	Not available in F/T mode.	Cannot be executed in Zoom (F/T) mode.
-2286	Not available in Gated sweep setup mode.	Cannot be executed in the gated-sweep setting mode.
-2287	Not available in Multi-screen mode.	Cannot be executed in the multi-screen mode.
-2289	Please select Zoom or F/T mode.	Cannot be executed because Zoom (F/F, T/T) or F/T mode is not on. Select Zoom or F/T mode.
-2500	Cal data is not enough. Please execute Cal All	CAL data is insufficient. Execute Cal All.
-2501	Internal CAL Level (-10[dBm]) out of range	Calibration failed.
-2502	Internal CAL Level (-30[dBm]) out of range	Calibration failed.
-2503	External CAL Level out of range	Calibration failed.
-2504	ATT 0dB out of range	Calibration failed.
-2509	ATT 5dB out of range	Calibration failed.
-2518	ATT 15dB out of range	Calibration failed.
-2523	ATT 20dB out of range	Calibration failed.
-2528	ATT 25dB out of range	Calibration failed.
-2533	ATT 30dB out of range	Calibration failed.
-2534	ATT 35dB out of range	Calibration failed.
-2535	ATT 40dB out of range	Calibration failed.
-2536	ATT 45dB out of range	Calibration failed.
-2537	ATT 50dB out of range	Calibration failed.
-2539	ATT 55dB out of range	Calibration failed.
-2540	ATT 60dB out of range	Calibration failed.
-2541	ATT 65dB out of range	Calibration failed.
-2542	ATT 70dB out of range	Calibration failed.
-2543	ATT 75dB out of range	Calibration failed.
-2544	IF Input Level out of range	Calibration failed.
-2545	IF Gain Amp out of range	Calibration failed.
-2546	2nd Wide BPF Level out of range	Calibration failed.
-2547	Preamp Level out of range	Calibration failed.
-2548	x2 Path Clock Skew out of range	Calibration failed.
-2549	x4 Path Clock Skew out of range	Calibration failed.
-2550	x6 Path Clock Skew out of range	Calibration failed.

Error number	Message text	Description
-2551	x8 Path Clock Skew out of range	Calibration failed.
-2552	x12 Path Clock Skew out of range	Calibration failed.
-2553	x16 Path Clock Skew out of range	Calibration failed.
-2555	Prefilter Wide CF1 CAL Error	Calibration failed.
-2556	Prefilter Wide CF2 CAL Error	Calibration failed.
-2557	Prefilter Wide Tank l CAL Error	Calibration failed.
-2558	Prefilter Wide Tank2 CAL Error	Calibration failed.
-2559	Prefilter RBW 1MHz Bandwidth Error	Calibration failed.
-2560	Prefilter RBW 500kHz Bandwidth Error	Calibration failed.
-2561	Prefilter RBW 300kHz Bandwidth Error	Calibration failed.
-2562	Prefilter RBW 200kHz Bandwidth Error	Calibration failed.
-2563	Prefilter Middle CF CAL Error	Calibration failed.
-2564	Prefilter Middle Tank CAL Error	Calibration failed.
-2565	Prefilter Middle Symmetry CAL Error	Calibration failed.
-2566	Prefilter RBW 100kHz Bandwidth Error	Calibration failed.
-2567	Prefilter RBW 50kHz Bandwidth Error	Calibration failed.
-2568	Prefilter Narrow CF CAL Error	Calibration failed.
-2569	Prefilter Narrow Tank CAL Error	Calibration failed.
-2570	Prefilter Narrow Symmetry CAL Error	Calibration failed.
-2571	Prefilter RBW 30Hz Bandwidth Error	Calibration failed.
-2572	Prefilter RBW 20Hz Bandwidth Error	Calibration failed.

Error number	Message text	Description
-2573	Prefilter RBW 10Hz Bandwidth Error	Calibration failed.
-2574	Prefilter RBW 5kHz Bandwidth Error	Calibration failed.
-2575	Prefilter RBW 3kHz Bandwidth Error	Calibration failed.
-2576	Prefilter RBW 2kHz Bandwidth Error	Calibration failed.
-2577	Prefilter RBW 1kHz Bandwidth Error	Calibration failed.
-2578	Prefilter RBW 500Hz Bandwidth Error	Calibration failed.
-2579	Prefilter RBW 300Hz Bandwidth Error	Calibration failed.
-2580	Prefilter RBW 200Hz Bandwidth Error	Calibration failed.
-2581	Prefilter RBW 100Hz Bandwidth Error	Calibration failed.
-2582	Prefilter RBW 50Hz Bandwidth Error	Calibration failed.
-2583	Prefilter RBW 30Hz Bandwidth Error	Calibration failed.
-2584	Prefilter RBW 20Hz Bandwidth Error	Calibration failed.
-2585	Prefilter RBW 10Hz Bandwidth Error	Calibration failed.
-2590	Wideband Demodulator Ranging Amp Off out of range	Calibration failed.
-2591	Wideband Demodulator Ranging Amp On out of range	Calibration failed.
-5300	Option 11 Cal Error	Automatic adjustment of the wideband demodulator has failed.

8.9 Product Disposal and Recycle

This product should be disposed of according to the regulations and laws that are established in your country and municipality.

Before this product is disposed of, separately collect components shown in the table below to prevent the spread of substances, which may be harmful to the global environment, humans, and ecology.

	Used/			
Substance/Component	Not used	Location	Unit	Component
Polychlorinated biphenyls (PCB) containing capacitors	Not used	-	-	-
Mercury containing components	Used	Main frame	LCD monitor	Fluorescent tube
Batteries	Used	Main frame	BLK-030857X02	Lithium-ion battery
Printed circuit boards	Used	Main frame	Panel, Controller	Printed circuit board
			Power supply	Printed circuit board
			Board, Slot	Printed circuit board
Toner cartridges	Not used	-	-	-
Plastic containing brominated flame retardants	Used	Main frame	BEB-030571 BEB-031113 BEB-031114 BEB-031235 BEB-031812 BEC-029787 BEC-029788 BEC-030550 BEC-031374 BEG-029154 BEK-029784 BGK-030548 BLB-027808 BLB-027809 BLB-027810 BLB-027811 BLB-029378 BLB-029378 BLB-030111 BLB-030151 BLB-031115 BLB-031116 BLC-027690 BLC-029789 BLC-030142 BLC-030547 BLF-027807 BLF-029156 BLF-030112	Packages used for tantalum capacitors, diodes, transistors, and ICs (memory, Logic, PMOS, and analog)

	Used/			
Substance/Component	Not	Location	Unit	Component
bull statices component	used	Docation	Cint	Сотронен
			BLG-027689	
			BLG-027089 BLG-029155	
			BLK-027921	
			BLK-029132	
			BLK-029783	
			BLK-029785	
			BLK-029783 BLK-029790	
Plastic containing brominated flame			BLK-029791	
retardants			BLK-029792	
rettration			BLK-029793	
			BLK-029794	
			BLK-030106	
			BLK-030857X02	
			BLK-031454	
			BLR-029193X02	
			Cases	
Asbestos waste and components	Not	_	-	-
which contain asbestos	used			
Cathode ray tubes	Not	_	-	_
Canada lay labes	used			
Chlorofluorocarbons (CFC),	Not			
Hydrochlorofluorocarbons (HCFC),	used	_	-	-
Hydrofluorocarbons (HFC) or	uscu			
Hydrocarbons (HC)				
Gas discharge lamps	Used	Main frame	LCD monitor	Fluorescent tube
Liquid crystal displays of a surface	Used	Main frame	Monitor	Liquid crystal displays
greater than 100 square centimeters	Osed	Wiain Haine	Withitton	Liquid Crystal displays
greater than 100 square continueters	Used	ļ	l Main frame	Power cable
Parkers of a few states and the	Oscu	Than Tune		
External electric cables				Signal cable
]	Couch panel	Signal cable
Components containing refractory	Not	-	-	-
ceramic fibers	used			
Components containing radioactive	Not	-	-	-
substances	used			
Electrolyte capacitors containing	Not		-	-
substances of concern (height > 25	used			
mm, diameter > 25 mm or propor-				
tionately similar volume)				
Cadmium and Cadmium compounds	Used	Main frame	Electronic components	Electric and electronic
				components (Connectors)
				Mechanical parts
Hexavalent Chromium compounds	Used	Main frame	Electronic components	Electric and electronic
İ			1	components (Connectors)
				Mechanical parts
Azo colorant	Used	!	Main frame	Electronic components
				<u>-</u>

Substance/Component	Used/ Not used	Location	Unit	Component
Antimony and Antimony compounds	Used	Main frame		Electronic components
Beryllium and Beryllium compounds	Used	Main frame		Electric and electronic components (Connectors) Mechanical parts
Arsenic and Arsenic compounds	Used	Main frame	Electronic components	GaAs IC
Bismuth and Bismuth compounds	Used	I	Main frame	Electronic components
Nickel and Nickel compounds	Used	I	Main frame	Electric and electronic components (Connectors) Mechanical parts
Polyvinyl chloride (PVC)	Used	I	Main frame	Electric and electronic components (Connectors) Mechanical parts
Phthalate	Used	Main frame		Electric and electronic components (Connectors) Mechanical parts
Lead and Lead compounds	Used	Main frame (Board)	BEB-030571 BEB-031113 BEB-031114 BEB-031235 BEB-031812 BEC-029787 BEC-029788 BEC-030550 BEC-031374 BEG-029154 BEK-029784 BGK-030548 BLB-027808 BLB-027809 BLB-027811 BLB-027811 BLB-029378 BLB-029657X02 BLB-030111 BLB-031115 BLB-031116 BLC-027690 BLC-029789 BLC-030142 BLC-030547 BLF-027807 BLF-029156 BLF-030112	Electronic components mounted on the printed circuit board and lead solder used for mounting.

Substance/Component	Used/ Not used	Location	Unit	Component
Lead and Lead compounds	Used	Main frame (Board)	BLG-027689 BLG-029155 BLK-029132 BLK-029783 BLK-029785 BLK-029790 BLK-029791 BLK-029792 BLK-029793 BLK-029794 BLK-030106 BLK-030857X02 BLK-031454 BLR-029193X02 BPJ-033488 BPG-033489 BPF-033527	Electronic components mounted on the printed circuit board and lead solder used for mounting.

APPENDIX

A.1 Setting Time and Time Zone

The default settings of time and time zone for this instrument are set to Japan time.


Therefore, if you use this instrument outside Japan, it is necessary to set the time and time zone.

Otherwise, the time stamp for files will be incorrect.

This section describes procedures for setting the time and time zone.

Procedures


- 1. Touch |System| on the menu bar and select |Date and Time...|. The |Date and Time Properties| dialog box will be displayed.
- 2. Touch the [Time Zone] tab on the opened [Date and Time Properties] dialog box.
- 3. Select the area in which this instrument will be used from the drop down list box for the time zone.



 Touch the [Date & Time] tab on the opened [Date and Time Properties] dialog box.

The dialog box for adjusting the date and time will be displayed. Set the date and time.

A.1 Setting Time and Time Zone



5. Touch the **[OK]** button and close the dialog box.

A.2 Installing the Printer Driver

A.2 Installing the Printer Driver

This section describes the procedures for installing the printer driver.

Obtaining a printer driver

The printer driver used in this instrument is a printer driver for Windows XP. Use a printer driver for Windows XP attached to the printer or obtain one from the website of the printer manufacturer.

IMPORTANT:

- Before starting installation of the printer driver, press the STOP button on the front panel to hold measurement.
- Use a printer driver for Windows XP.

Installing the Printer Driver

Install the printer driver in accordance with the installation procedures attached to the printer.

If the driver is provided with a CD-ROM, install it using the CD-ROM drive of an external PC through a network.

This instrument does not support Standard TCP/IP Port.

Setting the printer


Perform the setting for the printer from the [Printers and Faxes] window that is displayed by selecting [Printers Setup...] of [System] on the menu bar.

Uninstalling the Printer Driver


The printer driver is installed using the system area of this instrument. Therefore, the printer driver cannot be installed in certain cases, depending on the remaining system area for this installation. In such cases, it is necessary to perform new installation after uninstalling printer drivers that are not used, in accordance with the following procedures.

Select [Printers Setup...] of [System] and open the [Printers and Faxes] window.

A.2 Installing the Printer Driver



- From the window, select the printer drivers to be uninstalled and touch [File].
 Select [Delete] and touch the [Yes] button of the displayed dialog to delete the drivers from the driver list.
- 3. If you touch the [File] menu on the [Printers and Faxes] window and select [Server Properties], the [Printers Server Properties] dialog box shown below will be displayed.



4. Touch the [Drivers] tag in the [Printers Server Properties] dialog box to display the printer driver installed on this instrument. From the displayed printer drivers, select the ones to be uninstalled by touching them and then touch the [Remove] button. After that, touch the [Yes] button in accordance with the instruction to complete the procedures to uninstall drivers.


A.3 Setting up the Network

A.3 Setting up the Network

If you connect this instrument with a network, you can share files and folders with computers in the network. This section describes each component in the network setting dialog box.

IMPORTANT: Before starting procedures for network setting, press the STOP button on the front panel to hold measurement.

1. Touch [System] on the menu bar and select [Network Setup...]. The [Network Setting] dialog box will be displayed.



[Computer Name] The computer name of this instrument will be displayed. If you

change this item, the change becomes effective only after restart-

ing the computer.

[Workgroup] The Windows workgroup name will be displayed. If you change

this item, the change becomes effective only after restarting the

computer.

[IP Address]

Obtain an IP address automatically

Select this command for obtaining the IP address from the DHCP

server.

[Use the following IP address] Select this command for specifying the IP address manually.

[IP Address] The current setting is displayed immediately after the IP address

dialog box is displayed.

[Subnet Mask] The current setting is displayed immediately after the subnet

mask dialog box is displayed.

[Default Gateway] The current setting is displayed immediately after the Default

Gateway dialog box is displayed.

[DNS Server]

[Obtain DNS server address automatically]

Select this command for obtaining DNS server information from

the DHCP server.

A.3 Setting up the Network

[Use the following DNS server address]
Select this command for setting the DNS server manually.

[Preferred DNS Server]

The current setting is displayed immediately after the preferred DNS server address dialog box is displayed.

[Alternate DNS Server]

The current setting is displayed immediately after the alternative DNS server address dialog box is displayed.

A.4 Setting the Guest Account

A.4 Setting the Guest Account

It is necessary to set the Guest Account in order to access this instrument from a remote PC through a network and share files.

Because the Guest Account is disabled in default status, perform this setting before sharing files.

This section describes each component in the Guest Account setting dialog.

1. Touch [System] on the menu bar and select [Guest Account...]. The [Guest Account] setting dialog will be displayed.



[Enable the Guest Account]

f you check this box, the Guest Account will be enabled. You can enter [Guest Password] only when this box is checked.

[Guest Password]

This text box is used for entering the Guest Account password. The password is not displayed.

If you press the **|OK|** button with this box empty, setting will be performed without a password.

A.5 Setting up File Sharing

A.5 Setting up File Sharing


For referring to a file through the network, perform setting for file sharing from Explorer. When accessing a product through the network, enable the Guest Account.

For information on setting the Guest Account, refer to APPENDIX A.4 Setting the Guest Account.


This section describes the procedures for setting for file sharing.

Procedures

- Touch [System] on the menu bar and select [Explorer]. Explorer will be displayed.
- 2. Select from Explorer the folder for which setting for sharing will be made.
- 3. Touch [File] on the menu bar of Explorer and select [Sharing and Security...]. The [Shared Documents Properties] dialog box will be displayed.




4. Select [Share this folder] and enter the share name into [Share name].




If you want to write from an external PC, perform the following setting.

5. Touch the [Permissions] button.
The [Permissions for Documents] dialog box will be displayed.



6. Select the [Full Control] check box for setting for sharing of [Everyone].



7. Press the [OK] buttons of all displayed dialog boxes to close the dialog boxes.

A.6 Initial Setting List

A.6 Initial Setting List

This section describes the default preset parameter setting list.

Function	Dogometer	Initial set value		
Function	Parameter	R3681	R3671	
{FREQ}	Center Freq setting	16 GHz	6.5 GHz	
	Start Freq setting	0 Hz	0 Hz	
	Stop Freq setting	32 GHz	13 GHz	
	Freq Offset setting	0 Hz	0 Hz	
	Freq Offset On/Off	Off	Off	
	CF Step Size setting (Manual)	3.2 GHz	1.3 GHz	
	CF Step Size (Auto/Manual)	Auto	Auto	
	Presele Manual Tune setting	0	0	
	Channel Number setting	1	1	
{SPAN}	Span setting	32 GHz	13 GHz	
· · · · · · · · · · · · · · · · · · ·	Last Span setting	32 GHz	13 GHz	
{LEVEL}	Ref Level setting	5.0 dBm	5.0 dBm	
,	LOG/LIN selection	LOG	LOG	
	dB/div setting	10 dB/div	10 dB/div	
	Unit setting	dBm	dBm	
	ATT (Auto/Manual)	Auto	Auto	
	ATT setting (Manual)	10 dB	10 dB	
	Min ATT setting	10 dB	10 dB	
	Min ATT On/Off	On	On	
	Preamp On/Off	Off	Off	
	Ref Offset setting	0.00 dB	0.00 dB	
	Ref Offset On/Off	Off	Off	
	Correction Factor On/Off	Off	Off	
{BW}	RBW setting (Manual)	3 MHz	3 MHz	
()	RBW (Auto/Manual)	Auto	Auto	
	VBW setting (Manual)	3 MHz	3 MHz	
	VBW (Auto/Manual)	Auto	Auto	
	VBW/RBW ratio	1	1	
	VBW/RBW ratio (Auto/Manual)	Auto	Auto	
	SPAN/RBW ratio	100	100	
	SPAN/RBW ratio (Auto/Manual)	Auto	Auto	
	PLL Band Width	Auto	Auto	
	ADC Dither On/Off	Off	Off	
{SWEEP}	Sweep Time setting (Manual)	480 ms	195 ms	
– – ,	Sweep Time (Auto/Manual)	Auto	Auto	
	Trigger Source Free Run/IF Power/Video/Ext1/Ext2/Line/ Link	Free Run	Free Run	
	Trigger Slope +/-	+	+	
	Video Level setting	0 dBm	0 dBm	

E	D	Initial s	set value
Function	Parameter	R3681	R3671
	Ext2 Level setting	2.5 V	2.5 V
	IF Power Level setting	50%	50%
	Trigger Delay setting	0.0 ms	0.0 ms
	IF Monitor On/Off	Off	Off
{SWEEP} Gated Sweep	Gated Sweep On/Off	Off	Off
	Gate Source FreeRun/IF Power/Ext1/Ext2/Link	Free Run	Free Run
	Gate Slope +/-	+	+
	Ext2 Level setting	2.5 V	2.5 V
	IF Power Level setting	50%	50%
	Gate Delay	0 sec	0 sec
	Gate Width	1 ms	1 ms
	Gate Width(Auto/Manual)	Auto	Auto
{SEARCH}	Peak Search Condition		
	X Range Mode All/Inner/Outer	All	All
	X Range Limit Position setting	16 GHz (freq)	6.5 GHz
	X Range Limit Width setting	6.4 GHz (freq)	2.6 GHz
	Couple to Freq(Time) ON/OFF	OFF	OFF
	Y Range Mode All/Disp Line/Limit Line	All	All
	Y Range Display Line Above/Below	Above	Above
	Y Range Limit Line 1 Above/Below	Above	Above
	Y Range Limit Line 2 Above/Below	Above	Above
	Peak ΔY setting	10 dB	10 dB
	Continuous Peak On/Off	Off	Off
	Multi Inner Limit Setup		
	Mkr X Range Inner Limit ON/OFF	OFF	OFF
	Mkr X Range Position setting	16 GHz	6.5 GHz
	Mkr X Range Width setting	6.4 GHz	2.6 GHz
	Mkr Y Range Inner Limit ON/OFF	OFF	OFF
	Mkr Y Range Top setting	1000 dBm	1000 dBm
	Mkr Y Range Bottom setting	-1000 dBm	-1000 dBm
	Couple to Freq(Time) ON/OFF	OFF	OFF
	Marker List On/Off	Off	Off
{MKR}	Marker Function ON/OFF	OFF	OFF
	ΔMarker On/Off	Off	Off
	Fixed∆Marker On/Off	Off	Off
	1ΔMarker On/Off	Off	Off
	Marker No.	1	1
	Active Marker	1	1
	Reference Object	No Reference	No Reference
	Signal Track On/Off	Off	Off
	Marker Trace 1/2/3/4	1	1

A.6 Initial Setting List

Function	D	Initial s	et value
Function	Parameter	R3681	R3671
	Marker Step Size setting (Manual)	3.2 GHz (freq)	1.3 GHz (freq)
		1 ms (time)	1 ms (time)
	Marker Step Size (Auto/Manual)	Auto	Auto
{TRACE}	Trace setting	Write	Write
	Active Trace setting	1	1
	Trace Detector	Normal	Normal
	Normal/Positive/Negative/Sample/Average		
	Detector (Auto/Manual)	Auto	Auto
	Average Type RMS/Video/Voltage	RMS	RMS
	Average Type (Auto/Manual)	Auto	Auto
	Normalize Correction On/Off	Off	Off
	Artificial Analog On/Off	Off	Off
	Analog Sampling Times setting	5	5
{POWER} Channel Power	Channel Power Window On/Off	On	On
	Channel Power Window Position setting	Center frequency	Center frequency
	Channel Power Window Width setting	6.4 GHz	6.4 GHz
	Average Times setting	100	100
	Average Times On/Off	On	On
	Avg Mode Cont/Rep	Continuous	Continuous
	Parameters Default/Manual	Manual	Manual
{POWER} Average Power	Average Power Window On/Off	Off	Off
	Average Power Window Position setting	Center frequency	Center frequency
	Average Power Window Width setting	6.4 GHz	6.4 GHz
	Average Times setting	100	100
	Average Times On/Off	On	On
	Avg Mode Cont/Rep	Continuous	Continuous
	Parameters Default/Manual	Manual	Manual
{POWER} OBW	OBW % setting	99%	99%
	Average Times setting	5	5
	Average Times On/Off	Off	Off
	Avg Mode Cont/Rep	Repeat	Repeat
	Parameters Default/Manual	Manual	Manual
{POWER} ACP	Average Times setting	5	5
	Average Times On/Off	Off	Off
	Avg Mode Cont/Rep	Repeat	Repeat
	Carrier Band Width setting	3.84 MHz	3.84 MHz
	Channel Space & Band Width Data In	CS:5 MHz/ BS:3.84 MHz	CS:5 MHz/ BS:3.84 MHz
	√Nyquist filter ON/OFF	OFF	OFF
	Symbol Rate setting	3.84 MHz	3.84 MHz

F	D	Initial s	et value
Function	Parameter	R3681	R3671
	Rolloff factor setting	0.22	0.22
	Parameters Default/Manual	Manual	Manual
	Noise Correction On/Off	Off	Off
{POWER} Multi Carrier ACP	Symbol Rate setting	3.84 MHz	3.84 MHz
	Rolloff Factor setting	0.22	0.22
	√Nyquist fĭler ON/OFF	OFF	OFF
	Average Times setting	5	5
	Average Times On/Off	Off	Off
	Average Mode Cont/Rep	Repeat	Repeat
	Parameter Setup Default/Manual	Manual	Manual
	Noise Correction On/Off	Off	Off
	Carrier Freq Adjustment setting	0 Hz	0 Hz
	Carrier Freq Adjustment On/Off	Off	Off
{POWER} Spurious Emission	Spurious Table No.	1	1
	Parameters Default/Manual	Manual	Manual
{POWER} Spectrum Emission Mask	Carrier Band Width setting	3.84 MHz	3.84 MHz
	√Nyquist filter ON/OFF	OFF	OFF
	Symbol Rate setting	3.84 MHz	3.84 MHz
	Rolloff factor setting	0.22	0,22
	Ref Power Chan/Peak	Channel	Channel
	Average Times setting	5	5
	Average Times On/Off	Off	Off
	Average Mode Cont/Rep	Continuous	Continuous
	Parameters Default/Manual	Manual	Manual
{POWER} CCDF	CCDF RBW setting	10 MHz	10 MHz
	Meas Sample setting	1 k	1 k
	Trace Write On/Off	Off	Off
	Gaussian On/Off	Off	Off
	X Scale Max	100 dB	100 dB
	CCDF Gate On/Off	Off	Off
{POWER} Multi Average Power	Window No.	1	1
	Window On/Off	On(Window1) Off(Window2 - 10)	On(Window1) Off(Window2 - 10)
	Window Position	0 ms	0 ms
	Window Width	1 ms	1 ms
	Active Window	1	1

A.6 Initial Setting List

Function	Parameter	Initial set value		
1 unction	r at afficien	R3681	R3671	
	Couple to Power On/Off	Off	Off	
	Power Ratio On/Off	Off	Off	
	Average Times setting	100	100	
	Average Times On/Off	Off	Off	
	Average Mode Cont/Rep	Continuous	Continuous	
	Parameters Default/Manual	Manual	Manual	
{MEAS} Counter	Counter ON/OFF	OFF	OFF	
	Counter Average Times setting	2	2	
	Counter Average Times On/Off	Off	Off	
{MEAS} X dB Down	X dB setting	3 dB	3 dB	
	Disp Mode REL/A.L/A.R	REL	REL	
	Cont Down On/Off	Off	Off	
	Ref Marker On/Off	Off	Off	
{MEAS} Noise/Hz	Noise/Hz ON/OFF	OFF	OFF	
	Noise/Hz x Hz setting	1 Hz	1 Hz	
	Noise/Hz Mode dBm/dBµV/dBc	dBm/Hz	dBm/Hz	
{MEAS} %AM	%AM Measure On/Off	Off	Off	
{MEAS} Harmonics	FUND Frequency setting	100 MHz	100 MHz	
	FUND Frequency On/Off	Off	Off	
	Harmonics Number setting	2	2	
{MEAS} IM Meas	Order setting	3	3	
	Limit Setup setting	0 dB	0 dB	
	Pass/Fail Judgment On/Off	On	On	
	Parameters Default/Manual	Manual	Manual	
{PASS/FAIL}	Judgment On/Off	On	On	
	Limit Line 1 On/Off	Off	Off	
	Limit Line 2 On/Off	Off	Off	
	Limit Line 1 Pass Range Above/Below	Below	Below	
	Limit Line 2 Pass Range Above/Below	Above	Above	
	X Data Mode Abs/Rel	ABS	ABS	
	X Data Reference Center/Left/User Def	Left	Left	
	X Data User Define setting	0 Hz (freq) 0 sec (time)	0 Hz (freq) 0 sec (time)	
	X Data Offset setting	0 Hz (freq) 0 sec (time)	0 Hz (freq) 0 sec (time)	
	Y Data Mode Abs/Rel	Abs	Abs	
	Y Data Reference Top/Bottom/User Define	Тор	Тор	

A.6 Initial Setting List

Function	Doramatar	Initial se	et value
Function	Parameter	R3681	R3671
	Y Data User Define setting	0 dBm	0 dBm
	Y Data Offset setting	0 dB	0 dB
{DISPLAY}	Display Line On/Off	Off	Off
	Display Line setting	-50 dBm	-50 dBm
	Reference Line On/Off	Off	Off
	Reference Line setting	-50 dBm	-50 dBm
	XY Cursor On/Off	Off	Off
	Cursor Position X setting	16 GHz (freq)	6.5 GHz
	Cursor Position Y setting	-50 dBm	-50 dBm
	Anchor On/Off	Off	Off
	Meas Window On/Off	Off	Off
	Window Position setting	16 GHz	6.5 GHz
	Window Width setting	6.4 GHz	2.6 GHz
	Window Sweep On/Off	Off	Off
	Zoom F/F, Zoom T/T, F/T, OFF	OFF	OFF
	Zoom F/F(F/T) Position setting	16 GHz	6.5 GHz
	Zoom F/F(F/T) Width setting	32 GHz	13 GHz
	Zoom T/T Delay setting	0 s	0 s
	Zoom T/T Width setting	2 ms	2 ms
	Split ON/OFF	OFF	OFF
	Active Screen setting	1	1
	Annotations Setup		
	Disp Line ON/OFF	ON	ON
	Ref Line ON/OFF	ON	ON
	XY Cursor ON/OFF	ON	ON
	Meas Window ON/OFF	ON	ON
[GPIB Address]	GPIB address of this instrument	8	8
[Freq Reference]	Manual Mode ON/OFF	OFF	OFF
	Ext. Reference	10 MHz	10 MHz
[Display]	Date Format YMD/MDY/DMY	YMD	YMD
	Date ON/OFF	ON	ON
	Title setting	NULL	NULL
[Save Item]	Setup ON/OFF	ON	ON
	Trace ON/OFF	OFF	OFF
	Normalize Correction ON/OFF	OFF	OFF
	Limit Line ON/OFF	OFF	OFF
	Correction Factor ON/OFF	OFF	OFF
	Spectrum Emission Mask ON/OFF	OFF	OFF
	Spurious ON/OFF	OFF	OFF

A.7 Operation Principle

A.7 Operation Principle

This section describes a root Nyquist filter to be used for input saturation and ACP measurement based on the operation principle of this instrument.

A.7.1 Input Saturation

When a large level signal is applied to this instrument, measurement errors may become larger, depending on the attenuator setting. Input saturation may be suspected as a cause of this. This section describes input saturation.

Cause of Input Saturation

A block diagram of the input section of this instrument is shown in Figure A-1. The signal entering from the input connector is input into the mixer through the attenuator.




Figure A-1 Block Diagram of the Input Section

Under normal conditions, the input level and output level of the mixer are proportionate to each other. If the input level of the mixer becomes larger, however, the mixer is saturated and the output level of the mixer becomes disproportionate to the input level.

This is input saturation, which hinders correct measurement (see Figure A-2).




Figure A-2 Relation Between Input and Output of the Mixer

· Countermeasures against input saturation

If input saturation occurs, set the most suitable attenuator value to lower the mixer input level.

IMPORTANT: If the attenuator setting is too large, the necessary signal becomes smaller and analysis becomes impossible. Contrarily, if the attenuator setting is too small, it may cause damage to the internal mixer circuit.

Usually, automatic setting to an appropriate value is performed for continuous wave (CW) input signal if you set the attenuator to auto and the peak of the signal at or below the reference level. In the case of measurement of input signal with a wide modulation bandwidth in which the resolution bandwidth (RBW) is narrower than the modulation bandwidth, the indication level becomes smaller. Therefore, it must be set to the optimum value manually.

- Method to confirm the optimum value
 - Obtain a rough set value for the attenuator with the following formula.
 The maximum input level of the mixer is -5 dBm.
 Input attenuator set value (dB) ≥ Input level (dBm) + 10 dB
 - Watching the screen, decrease the setting for the attenuator by one step. If the peak value on the screen does not change, there is no input saturation. You can continue measurement.
 If there is any change, increase the setting for the attenuator to eliminate the change.

A.7.2 Root Nyquist Filter

In this instrument, a correction equivalent to the passage of input signal in the root Nyquist filter can be made in adjacent channel leak power measurement.

In calculating the power for each channel by integrating the trace data, multiply by the coefficient of the root Nyquist filter at the corresponding frequency (H(n)).

$$P"_{U} = \sum_{n=a}^{b} \frac{P(n)}{10} \times H(n)$$

$$a = f_{Uch} - \frac{(1+\alpha)}{2T}, b = f_{Uch} + \frac{(1+\alpha)}{2T}$$

$$P"_{L} = \sum_{n=a}^{b} \frac{P(n)}{10} \times H(n)$$

$$a = f_{Lch} - \frac{(1+\alpha)}{2T}, b = f_{Lch} + \frac{(1+\alpha)}{2T}$$

The coefficient of the root Nyquist filter (H(n)) is calculated from the symbol rate (T) and the rolloff factor (α) using the following formula.

$$|H(n)| = \begin{cases} 1 & 0 \le |f| \le (1-\alpha)/2T \\ \cos[(T/4\alpha) (2\pi |f| -\pi (1-\alpha)/T)] & (1-\alpha)/2T \le |f| \le (1+\alpha)/2T \\ 0 & (1+\alpha)/2T \le |f| \end{cases}$$

A.7.2 Operation Principle

Characteristics of the root Nyquist filter are shown below.




Figure A-3 Characteristics of the Root Nyquist Filter

A.8 Glossary

Average Noise Level

This sensitivity represents spectrum analyzer's capability of detecting the smallest signal and is directly related with noises generated from a spectrum analyzer itself. The sensitivity, however, varies depends on the resolution bandwidth used. In general, the maximum input sensitivity of a spectrum analyzer is expressed as average noise level when the instrument is used with its minimum resolution bandwidth.

Bandwidth Accuracy

The bandwidth accuracy of the resolution bandwidth filter is expressed by the deviation from the nominal value of the 3 dB lowered point. This deficiency has almost no effect when measuring normal signals at a continuous level, but it should be taken into consideration when measuring the level of a noise signal.

Bandwidth Selectivity

The bandpass filter normally attenuates using a Gaussian distribution instead of the so-called rectangular characteristic. Consequently, if two adjacent signals of different sizes are mixed, the smaller signal hides at the tail of the larger signal (Figure A-4).

Therefore, the bandwidth at a certain attenuation range (60 dB) should also be defined. The ratio between the 3 dB width and 60 dB width is expressed as the bandwidth selectivity (BW60 dB/BW3 dB).




Figure A-4 Bandwidth Selectivity

A.8 Glossary

Bandwidth Switching Uncertainty

Several resolution bandwidth filters are used to obtain an optimal resolution in signal spectrum analysis according to the scan width. When switching from one resolution bandwidth filter to another while measuring one signal, an error is generated for the differences in loss. This error is defined as the bandwidth switching uncertainty.




Figure A-5 Bandwidth Switching Uncertainty

Frequency Response

This term represents amplitude characteristics (frequency characteristics) for a given frequency. In the spectrum analyzer, frequency response means the frequency characteristics (flatness) of the input attenuator and mixer for the input frequency, and is given in $\pm \Delta dB$.

Gain Compression

If the input signal is greater than a certain value, the correct value is not displayed on the screen, and the input signal appears as if it were compressed. This phenomenon is called gain compression, and it reflects an error in the linearity of the input signal range. Normally, the gain compression for a spectrum analyzer is specified as the input signal level that produces a 1 dB error from a perfect linear response.

IF Gain Uncertainty

The uppermost scale on the screen is the reference used to read the absolute level of an input signal on the spectrum analyzer. The level set for this uppermost scale is referred to as the reference level.

The reference level is set using the **Ref Level** key and displayed in dBm or dB μ . The absolute accuracy of this display is determined by the IF gain uncertainty assuming the input attenuator is at a constant level.




Figure A-6 IF Gain Uncertainty

Maximum Input Level

This is the maximum level allowed for the input circuit of the spectrum analyzer. The level can be modified by the input attenuator.

Noise Sidebands

Spectrum analyzer efficiency is reduced by noise generated in the local oscillator and phase lock loop of the analyzer. This noise will appear in the vicinity of the spectrum on the screen.

To compensate for this, the sideband of the analyzer is defined so that signals out of the sideband can be analyzed in a certain range. This range is called the noise sideband.

The spectrum analyzer's noise sideband characteristics are shown in the following example.

Example Suppose the noise level measured in the resolution bandwidth of 1 kHz is -70 dB at 20 kHz apart from the carrier. The noise level is normally expressed by the energy contained in the 1 Hz bandwidth (Figure A-7 (b)). With a bandwidth of 1 Hz, the following applies: Since the value is -70 dB when the bandwidth is 1 kHz, the signals within the 1 Hz bandwidth will be lower than this by about 10 log 1 Hz/1 kHz [dB], or about 30 dB; consequently, it is expressed as -100 dB/Hz at 20 kHz apart from the carrier when the resolution bandwidth is 1 kHz.




Figure A-7 Noise Sidebands

A.8 Glossary

Occupied Bandwidth

When information is transmitted through radio waves, the extension of the frequency spectrum is caused along with the modulation. The occupied bandwidth is defined as the width of frequency spectrum that occupies 99% of all averaged electric power (see Figure A-8).




Figure A-8 Occupied Bandwidth

Residual FM

The short-term frequency stability of the local oscillators built in the spectrum analyzer is expressed as residual FM. The frequency width fluctuating per unit time is expressed as p-p. This also determines the measurement limit value when measuring the residual FM of a signal.

Residual Response

Residual response is a measure of how much (in the input level calculation) the spurious signal generated by the spectrum analyzer is suppressed. Residual response is generated by leaks of signals such as local oscillation output in the spectrum analyzer. This should be taken into consideration when analyzing a low-level input signal.

Resolution Bandwidth

The spectrum analyzer uses the bandpass filter (BPF) to analyze the frequency components contained in the input signal. The 3dB bandwidth of the BPF is called the resolution bandwidth (See Figure A-9 (a) below). BPF characteristics should be set according to the sweep width and the sweep speed used for the trace. This spectrum analyzer sets the optimal value for the sweep width. In general, smaller bandwidths improve resolution so the resolution of the spectrum analyzer should be expressed using the narrowest resolution bandwidth (See Figure A-9 (b) below).




Figure A-9 Resolution Bandwidth

Spurious Response

Spurious signals are signals that cause distortion to an ideal signal, and are classified according to their characteristics.

Second harmonic distortion:

This is the distortion caused by the non-linearity of a spectrum analyzer (especially generated in the mixer) when an ideal, undistorted signal is input to the spectrum analyzer. This performance determines spectrum analyzer's capability of measuring harmonic distortion (see Figure A-10).

Third order distortion:

This is the distortion caused by the non-linearity of a spectrum analyzer when two signals with different frequencies f1 and f2 are input, thus outputting two signals: one signal with frequency 2f1-f2; and another signal with frequency 2f2-fi. The amplitude of these signals depends on the input levels at the mixer (see Figure A-10). The maximum value is specified.

Image/Multiple/Extra-band responses:

In addition to the two types of spurious signals described above, there is a third type called "non-harmonic spurious" that is generated by the spectrum analyzer with a frequency proper to each spectrum analyzer. There are three types of responses in the non-harmonic spurious: the image, multiple and extra-band responses.

A.8 Glossary




Figure A-10 Spurious Response

VSWR (Voltage Standing Wave Ratio)

This shows the state of impedance matching when a spectrum analyzer is connected to a voltage source whose output impedance is ideal and nominal. The VSWR is expressed as the ratio of the maximum value to minimum value of a standing wave which consists of traveling and reflected waves. The VSWR is another expression of the reflection coefficient or return loss.

Referring to Figure A-11, The signal at the receiving end E1 is the same as the signal at the transmitting end $(E_0$, or the spectrum analyzer input section) if the impedance of the receiving end is matched to that of the transmitting end.

The reflection coefficient is expressed in the formula shown below when the reflected wave E_R exists due to a mismatch between the impedances.

Reflection coefficient m = Reflected wave E_R / Traveling wave E_0

The Return loss is expressed in the formula shown below.

$$\begin{aligned} \text{Return loss} &= 20 \log E_R / E_0 \text{ [dB] VSWR} \\ &= \left(E_0 + E_R\right) / \left(E_0 - E_R\right) \end{aligned}$$

The relationship of VSWR with the reflection coefficient is as follows.

$$VSWR = (1 + |m|) / (1 - |m|)$$

The range of VSWR is between 1 and ∞ the nearer to 1 this value is, the better the state of impedance matching is.




Figure A-11 VSWR

A.8 Glossary

Zero Span

The spectrum analyzer sweeps at any frequency along the horizontal axis as the time axis but will not sweep in zero span mode.

A.9 dB Conversion Formula

A.9 dB Conversion Formula

1. Definitions

$$\begin{array}{ll} 0dBV = 1\,Vrms & YdBV = 20log \; \frac{XV}{lV} \\ \\ 0dBm = 1mW & YdBm = 10log \; \frac{XmW}{lmW} \\ \\ 0dB\mu V = 1\mu Vrms & YdB\mu V = 20log \; \frac{X\mu V}{l\mu V} \\ \\ 0dBpw = 1pW & YdBpw = 10log \; \frac{XpW}{lpW} \end{array}$$

2. Conversion formulas

$$\begin{split} &\text{If } R = 50 \ \Omega; &\text{If } R = 75 \ \Omega; \\ &\text{dBV} \cong (\text{dBm - 13dB}) &\text{dBV} \cong (\text{dBm - 11dB}) \\ &\text{dB}\mu\text{V} \cong (\text{dBm + 107dB}) &\text{dB}\mu\text{V} \cong (\text{dBm + 109dB}) \\ &\text{dB}\mu\text{Vemf} \cong (\text{dBm + 113dB}) &\text{dB}\mu\text{Vemf} \cong (\text{dBm + 115dB}) \\ &\text{dBpw} \cong (\text{dBm + 90dB}) &\text{dBpw} \cong (\text{dBm + 90dB}) \end{split}$$

3. Examples

$$\label{eq:converting 1mV} \begin{array}{ll} \text{Converting 1mV into } dB\mu V: & 20log \ \frac{1mV}{l\mu V} = 20log \ 10^3 = 60dB\mu V \\ \text{Converting 0} dBm \ \text{into } dB\mu V: & \begin{cases} 0dBm + 107dB = 107dB\mu V (R = 50\Omega) \\ 0dBm + 109dB = 109dB\mu V (R = 75\Omega) \end{cases} \\ \text{Converting 60} dB\mu V \ \text{into } dBm: & \begin{cases} 60dB\mu V - 107dB = -47dBm (R = 50\Omega) \\ 60dB\mu V - 109dB = -49dBm (R = 75\Omega) \end{cases} \\ \text{Converting 10V/m into } dB\mu V/m: & 20log \ \frac{10V/m}{l\mu V/m} = 140dB\mu V/m \end{cases}$$

4. Relationship between dBm and Watt

+50dBm	+40dBm	+30dBm	+20dBm	+10dBm	+0dBm	-10dBm	-20dBm	-30dBm
100W	10W	1W	100mW	10mW	ImW	0.1mW	0.01mW	0.001mW

A.10 Standard Information File Format

When the standard's setting is saved by using the [Save STD Data...], the file shown in Figure A-12 is created.

If the file is loaded by using the [Load STD Data...] after the file data is edited, the parameters can be set as the default value of the standard. This standard Information file is created in CSV format.




Figure A-12 Standard Information file

The file consists of the previous header portion, which includes the early several rows, and the following parameter portion.

1. Header

This portion includes all the rows from the beginning of the file to the 8th row. Don't change this portion, because the standard's parameters are unrelated.

Row number	String shown in Figure A-12	Description
1	[ASCII]	Shows the strings in ASCII format.
2	[R3681]	Shows the product series name of the main unit when the file was created by using the [Save STD Data].
3	[test]	Shows the strings, which are indicated in the Memo area, when the file is selected by using the [Load STD Data].
4	[User Data]	Shows the strings which are indicated in the Information area, when the file is selected by using the [Load STD Data].
5	[1934]	The load cannot be executed if the value is deleted.
6	3GPP	Shows the standard's name. The user file, which is created or renewed when the [Load STD Data] is executed, belongs to the category of this standard and is named "Standard name_User.csv".
7	UpLink	Shows the state of the standard, when the file was created by using the [Save STD Data]. Changing the row has no effect.
8	2003/11/7	The memo. Any characters can be written.

2. Parameters

This portion includes the rows from the 9th row to the end of the file. These rows describe the relation to the default value of the standard. The parameter portion consists of the function name row and the parameter rows.

This portion is described in the following order: the function name (single row) \rightarrow the parameters (multiple rows) \rightarrow The description of the parameter rows, which are next to the function name row, shows the default values of the function.

The rows from the 10th to the 19th rows are the parameters of the Average Power function, and the rows from 22nd to 28th rows are the parameters of the ACP function in Figure A-12.

A.10.1 Function of Standard Measurement and String

The function, which can set the default values in the standard measurement, and the string of the function name are below.

Function name	String
OBW	[OBW]
ACP	[ACP]
Multi Carrier ACP	[Multi Carrier ACP]
Spurious Emission	[Spurious Emission]
Spectrum Emission Mask	[Spectrum Emission Mask]
Channel Power	[Channel Power]
Average Power	[Average Power]
Channel	[Channel]
Multi Average Power	[Multi Average Power]

A.10.2 Parameters of Standard Measurement

The table of the parameters in the Standard Information file and the setting values when the parameters are omitted is below.

The parameters which can be set in all measurement functions

Parameter name	Label	Parameter	Initial value
Span	: FREQ : SPAN	Real value	1 GHz
RBW	: BAND : RES	Real value	3 MHz
RBW Auto/Manual	: BAND : RES : AUTO	ON or OFF	Manual
VBW	: BAND : VID	Real value	3 MHz
VBW Auto/Manual	: BAND : VID : AUTO	ON or OFF	Manual
Sweep Time	: SWE : TIME	Real value	10 ms
Sweep Time Auto/Manual	: SWE : TIME : AUTO	ON or OFF	Manual
Trace Write / View / Blank / Average / MaxHold / MinHold	: DISP : TRAC : MODE<1~4>	WRIT / VIEW / BLAN / AVER / MAXH / MINH	Write(1), Blank(2~4)
Detector	: DET : TRAC : FUNC<1~4>	NORM / POS / NEG / SAMP / AVER	Auto value of each function
Detector Auto/Manual	: DET : TRAC : FUNC : AUTO<1~4>	ON or OFF	Manual
Average Type RMS / Video / Average	: AVER : TYPE	RMS or VID or AVER	RMS
Average Type Auto / Manual	: AVER : TYPE : AUTO	ON or OFF	Manual

Parameter name	Label	Parameter	Initial value
Gated Sweep On/Off	: SWE : GATE	ON or OFF	OFF
Gate Source	: SWE : GATE : SOUR	IMM / IF / EXT1 / EXT2 / LINK	IMM
Gate Width	: SWE : GATE : WIDT	Real value	50 μs
Gate Width Auto/Manual	: SWE : GATE : WIDT : AUTO	ON or OFF	Manual
Gate Delay	: SWE : GATE : DEL	Real value	0 s
Gate Trigger Level (IF Power)	: SWE : GATE : LEV : IF	Real value	50%
Gate Trigger Level (Ext2)	: SWE : GATE : LEV : EXT	Real value	2.5 V
Gate Slope +/-	: SWE : GATE : SLOP	POS/NEG	+
Trigger Source	: TRIG : SOUR	IMM / IF / VID / EXT1 / EXT2 / LINE / LINK	IMM
Trigger Level (IF Power)	: TRIG : LEV : IF	Real value	50%
Trigger Level (Video)	: TRIG : LEV : VID	Real value	0 dBm
Trigger Level (Ext2)	: TRIG : LEV : EXT	Real value	2.5 V
Trigger Slope +/-	: TRIG : SLOP	POS / NEG	+
Trigger Delay	: TRIG : DEL	Real value	0 s

OBW Parameter

Parameter name	Label	Parameter	Initial value
OBW Percent	: OBW : PERC	Real value	99.8%
Average On/Off	: OBW : AVER	ON or OFF	OFF
Average Count	: OBW : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: OBW : AVER : MODE	CONT or REP	Repeat

ACP Parameter

Parameter name	Label	Parameter	Initial value
Average On/Off	: ACP : AVER	ON or OFF	OFF
Average Count	: ACP : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: ACP : AVER : MODE	CONT or REP	Repeat
Carrier Band Width	: ACP : CBW	Real value	3.84 MHz
Channel Space & Band Width	: ACP : CSBW : DATA	Real value, Real value	All initialization
√Nyquist Filter On/Off	: ACP : RNYQ	ON or OFF	OFF
Symbol Rate	: ACP : RNYQ : SRAT	Real value	3.84 MHz
Rolloff Factor	: ACP : RNYQ : RFAC	Real value	0.22
Noise Correction On/Off	: ACP : NCOR	ON or OFF	OFF

Average Power Parameter

Parameter name	Label	Parameter	Initial value
Average On/Off	: APOW : AVER	ON or OFF	OFF
Average Count	: APOW : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: APOW : AVER : MODE	CONT or REP	Cont
Window On/Off	: APOW : WIND	ON or OFF	ON
Window Position	: APOW : WIND : POS	Real value	0 Hz
Window Width	: APOW : WIND : WIDT	Real value	1 GHz

Channel Power Parameter

Parameter name	Label	Parameter	Initial value
Average On/Off	: CPOW : AVER	ON or OFF	OFF
Average Count	: CPOW : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: CPOW : AVER : MODE	CONT or REP	Cont
Window On/Off	: CPOW : WIND	ON or OFF	ON
Window Position	: CPOW : WIND : POS	Real value	0 Hz
Window Width	: CPOW : WIND : WIDT	Real value	1 GHz

Multi Carrier ACP Parameter

Parameter name	Label	Parameter	Initial value
Average On/Off	: MCAC : AVER	ON or OFF	OFF
Average Count	: MCAC : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: MCAC : AVER : MODE	CONT or REP	Repeat
√Nyquist Filter On/Off	: MCAC : RNYQ	ON or OFF	OFF
Symbol Rate	: MCAC : RNYQ : SRAT	Real value	3.84 MHz
Rolloff Factor	: MCAC : RNYQ : RFAC	Real value	0.22
Offset Setup On/Off	: MCAC : PAR : STAT<1~16>	ON or OFF	OFF
Offset Freq	: MCAC : PAR : FREQ<1~16>	Real value	0 Hz
Band Width	: MCAC : PAR : BWID<1~16>	Real value	0 Hz
Reference No.	: MCAC : PAR : REF<11~16>	Integer	1
Limit	: MCAC : PAR : LIM<11~16>	Real value	0 dB
Noise Corr On/Off	: MCAC : NCOR	ON or OFF	OFF
Carrier Freq Adjustment On/Off	: MCAC : CARR : ADJ : STAT	ON or OFF	ON
Carrier Freq Adjustment	: MCAC : CARR : ADJ	Real value	0 Hz

Spurious Parameter

Parameter name	Label	Parameter	Initial value
Table 1/2/3	: SPUR : DATA : ACT	Real value	
Table Data In (1~3)	: SPUR : DATA<1~3>	(*1)	All initialization

Spectrum Emission Mask Parameter

Parameter name	Label	Parameter	Initial value
Carrier Band Width	: SEM : CBW	Real value	3.84 MHz
√Nyquist Filter On/Off	: SEM : RNYQ	ON or OFF	ON
Symbol Rate	: SEM : SRAT	Real value	3.84 MHz
Rolloff Factor	: SEM : RFAC	Real value	0.22
Offset Data In	: SEM : DATA	(*2)	All initialization
Average Times On/Off	: SEM : AVER	ON or OFF	OFF
Average Times	: SEM : AVER : COUN	Integer	5
Average Mode Cont/Repeat	: SEM : AVER : MODE	CONT or REP	Cont
Reference Power Chan/Peak	: SEM : RPOW : MODE	CHAN or PEAK	Channel

Channel Parameter

Parameter name	Label	Parameter	Initial value
Table Enable/Disable	: CHAN : STAT<1~9>	ON or OFF	OFF
Channel Number Min	: CHAN : MIN<1~9>	Integer	
Channel Number Max	: CHAN : MAX<1~9>	Integer	
Channel Space	: CHAN : SPAC<1~9>	Real value	
Channel Offset	: CHAN : OFFS<1~9>	Integer	
Channel Base Freq	: CHAN : BASE<1~9>	Real value	

Multi Average Power Parameter

Parameter name	Label	Parameter	Initial value
Window On/Off	: MAP : WIND<1~10>	ON or OFF	1:ON 2-10:OFF
Window Position	: MAP : WIND : POS<1~10>	Real Value	Time on the left side of the screen
Window Width	: MAP : WIND : WIDT<1~10>	Real Value	Sweep time/10
Active Window	: MAP : WIND : ACT	1-10	1
Couple to Power	: MAP : WIND : COUP	ON or OFF	OFF
Power Ratio On/Off	: MAP : PRAT	ON or OFF	OFF
Average On/Off	: MAP : AVER	ON or OFF	OFF
Average Count	: MAP : AVER : COUN	Integer	100
Average Mode Cont/Repeat	: MAP : AVER : MODE	CONT or REP	Cont

- (*1) The following 13 parameters are included in the Spurious Table Data In.

 Real value (start freq), Real value (stop freq), ON or OFF(RBW Auto), Real value (RBW), ON Or OFF(VBW Auto), Real value (VBW), ON or OFF(SWP Auto), Real value (SWP), Real value (Ref Level), ON or OFF(ATT Auto), Real value (ATT), ON or OFF(Preamp), Real value (Limit)
- (*2) The following 8 parameters are included in the Spectrum Emission Mask Offset Data In. Each parameter is written in the column from B to I.

 Real value (Start), Real value (Stop), Real value (IBW), Real value (Limit Abs Start), Real value (Limit Abs Stop), Real value (Limit Rel Start), Real value (Limit Rel Stop), ABS or REL or AAR or AOR

ALPHABETICAL INDEX

[Symbol]		[Explorer]	5-15, 5-19
√Nyquist Filter Setup	5-45, 5-46,	[Ext. Reference]	5-17
,,,,, dense , mer e eeste mannen	5-50, 5-52,	[File]	
	5 - 55	[File Type]	5-14
ΔMarker On/Off		[Filename]	
ΔMarker→CF			5-10, 5-12,
ΔMarker→CF Step			5-14
ΔMarker→Mkr Step		[Fine]	5-18
ΔMarker→Span		[Format]	5-18
%AM Meas On/Off		[Freq Reference Setup]	5-15
[\sqrt{Nyquist Filter}]		[Freq Reference]	
[> -1]	5-55	[GPIB Address]	5-15
[1] to [10]		[Guest Account]	5-15, 5-16
[3rd Order Limit]		[Information]	5-8, 5-9,
[5th Order Limit]			5-10, 5-12
[7th Order Limit]		[Int. Reference Adjustment]	5-17
[9th Order Limit]		[Integral BW]	
[All]		[Judge]	5-56
[Anchor]		[Limit Abs Start]	
[Apply]		[Limit Abs Stop]	
[Band Width]		[Limit Line 1]	
[Browse]			5-63
[BS]		[Limit Line 2]	5-37, 5-41,
[25]	5-14. 5-18		5-63
[Cal]	,	[Limit Posi]	5-36
[Cancel]		[Limit Rel Start]	
[Carrier Band Width]		[Limit Rel Stop]	
[Channel Space]		[Limit Width]	
[CL]		[Load]	
	5-14, 5-18	[Load Data]	
[Clear]	*	[Load STD Data]	
[Close]		[Log]	
[01050]	5-11, 5-12,	[Manual Mode]	
	5-14	[Meas Control]	
[Coarse]		[Meas Control]	5-21, 5-22
[Config]		[Meas Window]	
[Couple to F(T)]		[Meas. Mode]	
[Current]		[Memo]	5-8, 5-9,
$[\Delta \text{ Marker}]$			
[Δ Marker (Other Screen)]		[Modulation]	5-7, 5-20
[Date]		[Modulation Analyzer]	
[Date and Time]		[Network Setup]	5-15, 5-16
[Default]		[Next]	5-22
[Delete]		[No Reference]	5 - 41
	5-12, 5-14	[OFDM]	5-20
[Delete Data]	·	[Offset]	5-64
[Disp Line]		[OK]	
Fr mb maral management	5-68	[Open]	
[Display Setup]		[Page 1/2]	
[Display]			5-14, 5-18
[Execute]		[Pass Range]	,
[======================================	5 0, 5 15		

FT. 3		(3 m + 0)	# #O
[Preset]		{MEAS}	
[Prev]		{MENU1>>}	
[Print]		{MENU2>>}	
[Printers Setup]		{MKR}	
[Ref Line]		{MKR→}	
[Reference]		{PASS/FAIL}	
[Rolloff Factor]	5-50, 5-52,	{POWER}	
	5-55	{SEARCH}	. 5-35
[SA Cal]	5-21	{SPAN}	. 5-25
[SA Cal without ATT]	5-21	{SWEEP}	. 5-31
[Save]	5-9, 5-12,	{TRACE}	. 5-42
	5-14		
[Save ALL]	5-9	[Numerics]	
[Save Bitmap Data]		[Numerics]	
[Save Data]		1/Δ Marker On/Off	. 5-39, 5-40
[Save Item]			
[Save STD Data]		[A]	
[Self Test]		About	8-3
[Service]		About Calibration	
[Single]		About Replacement of Limited-Life	. 6-5
[sp]		Parts	Q 2
[sp]	5-14, 5-18	Accessories	
[Cmanial]	,		
[Special]		ACP	*
[Spectrum Analyzer]		ACP Off	,
[Start]		Active Marker [1]	
[Status]		Active Window [1]	
[STD]	•	ADC Dither On/Off	
[Stop]		Amplitude	
[Store]		Amplitude Accuracy	
[Symbol Rate]		Annotations Setup	
	5-55	Artificial Analog	
[System]		Artificial Analog On/Off	5-42, 5-44
[Title]	5-15, 5-18	ATT Auto/Man	5-26, 5-27
[Trace 1]	5 - 41	Auto	5-29, 5-30
[Trace 2]	5 - 41	Auto All	. 5-29
[Trace 3]	5-41	Auto Level Set	5-45, 5-46,
[Trace 4]	5-41		5-49, 5-51,
[Type]	5-22		5-54
[User Define]	5-64	Auto Tune	5-24, 5-25
[X Data Mode]	5-64	Autocalibration	
[X Posi]	5-37	Average	5-42, 5-43
[X Range]		Average [RMS]	
[X Width]		Average Mode Cont/Rep	
[XY Cursor]			5-47, 5-48,
[Y]			5-49, 5-50,
[Y Bottom]			5-52, 5-56,
[Y Data Mode]			5-58
[Y Range]		Average Power	
[Y Top]		Average Power Off	
{BW}		Average Times On/Off	
{DISPLAY}		Average Times On/OH	
			5-47, 5-48,
{FREQ}			5-49, 5-50,
{LEVEL}	3-20		5-52, 5-56,

	5-58, 5-59,	$dB\mu V/\sqrt{Hz}$	5-59,	5-60
	5-60	dBμVemf		
Average Type [RMS]	5-42, 5-43	dBpW		
Average Type Auto/Man		Default		
		Delete	5-26,	5-27,
ren			5-45,	5-46,
[B]	4.10		5-50,	5-54,
Basic Measurement			5-56	·
Basic Operation		Delete Line	5-63,	5-65
Blank	5-42, 5-43	Delta Marker		
		Description of the Panels and the Screen		
[C]		Destination and Phone Number		
Cabinet Cleaning	8-1	for Contact	8-5	
Carrier Band Width		Detector Auto/Man		5-43
CCDF		Disp Mode REL/A.L/A.R		
CCDF Gate On/Off		Display Line On/Off		
CCDF Off		Display of Spectrum		
CCDF RBW		and Operation of Markers	4-15	
Center	·	DMY		
CF Step Size Auto/Man	5-24	Dynamic Range		6-16
Channel Number		,	,	
Channel Power		re1		
Channel Power Off		[E]	5.04	5 27
Check the supply power		Edit Correction Factor		
Cleaning		Edit Limit Line		
Cleaning of Other Parts		Edit Table		5-53
Cleaning the Touch Screen		Electromagnetic Interference		
Coarse		Error Messages		5 22
Connecting Accessories		Ext 1		
Connecting the Keyboard and Mouse		Ext 2 [2.5 V]		5-32
Connecting the Power Cable		Ext. Reference		
Cont Down On/Off		External Dimension Diagram	6-21	
Cont Peak On/Off				
Conventions of Notation Used	,	[F]		
in This Document	1-3	F/T	5-66,	5-67
Copy Table 1 to 2	5-63, 5-65	Fine		
Copy Table 2 to 1		Fixed ΔMarker On/Off	5-39	
Correction Factor On/Off		Fixed Marker Peak	5-60	
Counter		Fixed Mkr Peak	5-59	
Counter Off	5-59, 5-60	Format	5-15	
Couple to Power	5-58	Free Run	5-31,	5-32
Couple to Power On/Off		Freq Offset On/Off	5-24,	5-25
CS/BS Setup	5-45, 5-50	Frequency		
-		Full Span		
נחז		Function Bar		
[D]	5 15	FUNCTIONAL EXPLANATION	5-1	
Date		FUND Frequency On/Off	5-59,	5-61
dB Conversion Formula		•		
dB/div		[G]		
dBc/Hz	*		5 21	5 22
dBm		Gate Slope +/		
dBm/Hz		Gate Slope +/-		
dBmV		Gate Source [Free Run]		
dBμV	J-4U	Gate Width Auto/Man	J-31,	دد-د

Gated Sween On/Off	5 2 1 5 2 2	Limitations Imposed		
Gated Sweep On/Off		Limitations Imposed when Using Windows XP	2.5	
Gated Sweep Setup Quit		Line		2
Gaussian On/Off		Line 1/2		
General Specifications		Linear		,
Getting the Software Running	0 .0, 0 .5	Link		2
with Stability	2-2	Locating This Instrument		
Glossary				
•		[M]		
[H]		MAINTENANCE	Q 1	
Handling the Touch Screen	2-2	Manual Mode		
Hard Disk Drive		Manual Tune		5
Harmonics		Marker		,
Harmonics Number		Marker All Off		1
Harmonics Off		Marker List On/Off		
How to Cancel an UNCAL Message			5-39, 5-40	
How to Move		Marker No. [1]		
and Transport the Instrument	8-4	Marker OFF		
·		Marker ON	5-39, 5-40	0
[1]		Marker Reset	5-39, 5-40	0
If Faults Should Occur	2-1	Marker Setup		
IF Monitor On/Off		Marker Step Size Auto/Man		
IF Power [50%]		Marker Trace 1/2/3/4		0,
IM Meas			5-41	
IM Meas Off	,	Marker→CF		
Init		Marker→Ref		_
	5-45, 5-46,	Max Hold		3
	5-50, 5-54,	MDY		7
	5-56	Meas Sample Meas Window		
Initial Setting List	A-10	Measurement Off		
Input and Output	6-9, 6-17	Weastrement Off	5-58, 5-59	,
Input Saturation			5-62	٠,
Insert		Measuring Frequencies	2 02	
	5-45, 5-46,	by Frequency Counter	4-22	
	5-50, 5-54,	Medium		0
Toward I San	5-56	Menu Bar	5-7	
Insert Line	3-03, 3-03	Menu Index	5-1	
Installing the Printer Driver		MENU MAP	5-1	
Int. Reference AdjustmentINTRODUCTION		Menu Operation and Data Entry	4-9	
THE TRODUCTION	1-1	Method of Storing the Instrument		
F 13		Min ATT On/Off		
[7]		Min Hold		4
Judgement On/Off	5-63, 5-65	Min Peak		
		Mkr→CF Step	5-34	
[L]		Mkr→Mkr Step		
Last Span	5-25	Multi Average Power		7
Limit Line I On/Off	5-63, 5-65	Multi Average Power Off		
Limit Line 2 On/Off		Multi Carrier ACP		
Limit Line Auto Adj		Multi Carrier ACP Off		
Limit Line Setup		Multi Inner Limit Setup	5-35. 5-3	7
Limit Setup	5-59, 5-61	Multi Inner Peak Search	5-35. 5-3	7
			,	

[N]				5-54,	5-57
Narrow	5-29,	5-30		5-58,	5-59
Negative	5-42,	5-43		5-62	
Next Min Peak	5-35		Pass/Fail Judgement On/Off		
Next Peak	5-35,	5-39,	Peak ΔY		
	5-40		Peak List Freq	-	
Next Peak Left	5-35		Peak List Level	-	5-37
Next Peak Right	5-35		Peak Search Condition		
Next Result	5-46,	5-54	Peak X dB Down		5-60
Noise	5-59		Peak→CF		
Noise Corr On/Off	5-45,	5-46,	Peak→Ref		
	5-51,	5-52	PLL BW [Auto]		
Noise/Hz	5-59,	5-60	Positive		
Noise/Hz Off			Power Ratio On/Off	5-46,	5-58
Noise/X Hz			Preamp On/Off		5-27
Normal			PRE-OPERATION TIPS	2-1	
Normalize			Presel Tune	5-24,	5-25
Normalize On/Off			Prevention of Electrostatic Buildup	3-4	
Normalize with Store Corr			Previous Result		5-54
Note for Power-on		J 77	Product Disposal and Recycle		
Notes for Removing	2-3		Product Overview		
and Attaching the Panel	2.3				
Notes for Requesting Repair, Replacemen			[0]		
of Parts, and Periodic Calibration			[Q]		
or raits, and remodic Canoration	0-3		QUICK START	4-1	
[0]			[R]		
OBW	5-45.	5-49		6 11	
OBW Off			R3671 Performance Specifications		
Offset Setup			R3681 Performance Specifications RBW Auto/Man		
Operating Environment					
Operation Check			Ref Level		5 07
Operation Principle			Ref Offset On/Off		
Option			Ref Power Chan/Peak		
Options			Ref Power Setup	-	
OPTIONS AND ACCESSORIE			Ref/Offs Setup		
Order		5-61	Reference Line On/Off		5-44
Organization of This Document		3-01		5-66	
Other Manuals Pertaining	1-1		Reference Marker On/Off		
to This Instrument	1.2		Reference Object		5-40
Overcurrent			Registered Trademarks		
Overcurrent Protection			Remove Anchor		
Overcurrent Protection	Z-1			5-66,	5-67
			Removing of Case		
[P]			Return		
Parameters Def/Man	5-45,	5-46,		5-26,	
	5-47,			5-28,	5-29
	5-49,			5-30,	
	5-52,			5-32,	5-33
	5-56,			5-42,	5-43
	5-59,			5-44,	5-45
Parameters Define→Default				5-46,	
- water and a second of the se	5-47,			5-49,	
	5-51,			5-51,	

	5-54, 5-55,	The Name and Function of Each	
	5-56, 5-57,	Component on the Rear Panel	4-7
	5-58, 5-59,	The Name and Function of Each	7-7
	5-60, 5-61,	Component on the Screen	4.5
		The Name and Functions of Each	4-3
	5-62, 5-63,		4.1
	5-65, 5-66,	Component on the Front Panel	
D146	5-67, 5-68	Tip on Transportation	
RMS		Tool Menu	
Root Nyquist Filter	A-17	Trace [1]	
		Trace Detector [Normal]	
[S]		Trace Operation	
Sample	5-42 5-43	Trace Write On/Off	
Sampling Times [5]		Trademarks	
Screen Reset		Transportation	
Sereen Reset	5-68	Trigger Delay	5-31, 5-32,
Set Anchor			5-33
Set Allelioi		Trigger Slope +/	5-31, 5-32
Cattle of Cart Account	5-66, 5-67	Trigger Source [Free Run]	5-31
Setting the Guest Account			
Setting Time and Time Zone		F1 17	
Setting up File Sharing		[U]	
Setting up the Network		Units [dBm]	
SETUP		Unpacking Inspection	3-1
Show Result			
Signal Track On/Off	5-39, 5-41	[V]	
Single	5-21	VBW Auto/Man	5-20
Sort	5-26, 5-28,	VBW/RBW Auto/Man	
	5-45, 5-46,	Video	
	5-50, 5-56,		
	5-63, 5-65	Video [0.00dBm]	
Span	5-25	View	
Span/RBW Auto/Man	5-29	Voltage	
SPECIFICATIONS	6-1	Volts	3-26, 3-27
Spectrum Emission Mask			
Spectrum Emission Mask Off		[W]	
Split		Watts	5-26, 5-27
Spurious Emission	,	Wide	
Spurious Emission Off		Window No. [1]	
Start		Window OFF	
Stop		Window ON	
Store		Window On/Off	,
Store 1→3		Wildow Oll/Oll	
Store 2→4			5-48, 5-66, 5-67
Supply Description		Window Docition	
		Window Position	
Sweep			5-47, 5-48,
Sweep Time			5-58, 5-66,
Sweep Time Auto/Man		Will I D	5-67
System Recovery Procedure	გ- 6	Window Reset	
		Window Setup	
m		Window Sweep On/Off	
Table Init	5-63 5-65	Window Width	
Table No 1/2/3			5-47, 5-48,
14019 110 11210	5 -10, 5-55		5-58, 5-66,
			5-67

W. 1 D	0.5
Work Request	
Write	5-42, 5-43
[X]	
X Cursor Position	5-42 5-44
7. Cursor rosition	5-66, 5-67
X dB Down	
X dB Down Level	
X dB Left	·
	/
X dB Right	
X Scale Max	**
XY Cursor	
XY Cursor On/Off	
	5-66, 5-67
[Y]	
Y Cursor Position	5-42, 5-44,
	5-66, 5-67
YMD	5-15
	3 13
[7]	
[Z]	
Zero Span	
Zoom	
Zoom Position	5-66, 5-67,
	5-68
Zoom Width	5-66, 5-67

Liability for the Spread of Computer Viruses

Customer acknowledges that Advantest Software may not operate properly on a computer system or in a computer network containing software viruses, worms, or other third-party computer code, files, or programs designed to interrupt, destroy, or limit the functionality of computer software, hardware, or networks. Customer further acknowledges that it bears sole responsibility for securing its computer systems, software, hardware, and networks from any such malicious third-party computer code. Advantest shall have no responsibility for, and hereby disclaims any liability arising from, any failures, errors, damage to data or systems, or any other losses caused by any such malicious third-party computer code.

Advantest Software has been designed and developed for use in a self-contained computer environment, in which computers and networks running Advantest Software are not accessible, directly or indirectly, via the Internet or any other source of internal or external contamination. Advantest Software should be used in such a self-contained environment. If you choose to use Advantest Software outside of a self-contained environment, you do so at your own risk, and you should take all available steps to secure your software, hardware, and networks from computer viruses, in consultation with a computer security expert and Advantest.

IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

SOFTWARE License

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

Restrictions

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

Liability

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than it's intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

LIMITED WARRANTY

- 1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
- 2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
- 3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
- 4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
 - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
 - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
 - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
 - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
 - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
 - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
 - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
 - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
- 5. EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.
- 6. THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.
- 7. ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.
- 8. OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLEGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.

CUSTOMER SERVICE DESCRIPTION

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest 's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,

1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea

Phone: +82-2-532-7071 Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:

Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.

Phone: +86-21-6485-2725 Fax: +86-21-6485-2726

Shanghai Branch Office:

406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,

Hai Dian District, Beijing,

China 100083

Phone: +86-10-8235-3377 Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06

Alexandra Technopark Singapore 119967

Phone: +65-6274-3100 Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A

Phone: +1-408-988-7700 Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany (P.O.B. 80 14 60 D-81614 München, Germany)

Phone: +49-89-4129-13711 Fax: +49-89-4129-13723



http://www.advantest.co.jp